

Magelis HMISTU655/855

User Manual

10/2014

EIO0000000614.05

www.schneider-electric.com



The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2014 Schneider Electric. All rights reserved.

Table of Contents



	Safety Information	5
	About the Book	7
Part I	HMISTU655/855 Panels	9
Chapter 1	HMISTU655/855 Panels	11
	HMISTU655/855 Series of Panels	12
	HMISTU655/855 Package Contents	15
	Accessories	16
	Parts Identification and Functions	19
	Certifications and Standards	23
	System Design	25
Chapter 2	Specifications	29
2.1	General Specifications	30
	General Specifications	30
2.2	Functional Specifications	32
	Display	33
	Memory, Clock, and Touch Panel	35
2.3	Interface Specifications	36
	Interface Specifications	37
	Specifications of Serial Interface COM1	38
2.4	Dimensions	40
	HMISTU655/855	40
Chapter 3	Installation and Wiring	45
3.1	Installation	46
	Panel Cut-out Dimensions and Installation	47
	Installation Procedures	51
3.2	Wiring Principles	56
	Connecting the Power Cord	57
	Connecting the Power Supply	60
	Grounding	62
3.3	USB Port	64
	Important Considerations When Using the USB Port	65
	USB Data Transfer Cable (BMXXCAUSBH018) - USB Driver Installation	66
	USB Standard A	68
	USB Mini-B	73

3.4	Ethernet Cable Connector	75
	Presentation	75
Part II	Settings	77
Chapter 4	Configuring the Unit	79
	Types of Settings	80
	System Settings	81
	Offline Settings	85
	Diagnostics Settings	88
Chapter 5	Troubleshooting	91
	Troubleshooting Checklists	92
	Self Test List	94
Chapter 6	Maintenance	95
	Regular Cleaning	96
	Periodic Check Points	98
Index		99

Safety Information



Important Information

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

About the Book



At a Glance

Document Scope

This manual describes how to use the Magelis HMISTU655/855 and HMISTU655W/855W units.

The HMISTU655W/855W series are same as the standard STU series, only without marking on the front overlay (no Schneider logo or Magelis printed on the front).

In rest of the document, HMISTU655/855 references apply for both series (regular and W) unless otherwise specified.

All overlay drawings in this document are of HMISTU655/855 series.

Validity Note

This documentation is valid for the HMISTU655/855 and HMISTU655W/855W when used with Vijeo Designer version 6.1 SP2 or later.

Product Related Information

WARNING

UNINTENDED EQUIPMENT OPERATION

The application of this product requires expertise in the design and programming of control systems. Only persons with such expertise should be allowed to program, install, alter, and apply this product.

Follow all local and national safety codes and standards.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Part I

HMISTU655/855 Panels

Overview

This part describes how to use HMISTU655/855 Panels.

What Is in This Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
1	HMISTU655/855 Panels	11
2	Specifications	29
3	Installation and Wiring	45

Chapter 1

HMISTU655/855 Panels

Overview

This chapter describes the HMISTU655/855 Panels and connectable devices.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
HMISTU655/855 Series of Panels	12
HMISTU655/855 Package Contents	15
Accessories	16
Parts Identification and Functions	19
Certifications and Standards	23
System Design	25

HMISTU655/855 Series of Panels

Introduction

The HMISTU655/855 is a Human Machine Interface product that has an operating voltage of 24 VDC.

The following table describes the HMISTU655/855 characteristics:

Part Number	Marking on Overlay	Screen Size	Screen (Pixel) Resolution	Mono/Color	Screen Technology	Serial Port	Ethernet Port
HMISTU655	Yes	8.9 cm (3.5 in.)	320x240 (QVGA)	65 K colors and LED's backlight	TFT	Yes	Yes
HMISTU655W	No						
HMISTU855	Yes	14.48 cm (5.7 in.)	320x240 (QVGA)	65 K colors and LED's backlight	TFT	Yes	Yes
HMISTU855W	No						
TFT: Thin-Film Transistor Technology.							

Critical systems, Detected Alarms and Handling Requirements

Critical detected alarm indicators and system functions require independent and redundant protection hardware and/or mechanical interlocks.

If the unit for any reason becomes inoperative (for example, an inoperative backlight) it may be difficult or impossible to identify a function. Functions that may present a hazard if not immediately executed, such as emergency stop, must be provided independently of the unit. The design of the control system must take into account an inoperative unit (backlight) and that the operator is unable to control the machine or respond to detected errors using the unit.

When the power is cycled, wait at least 10 seconds before restoring the power to the HMI unit. Switching the power OFF and ON quickly can damage the unit.

WARNING

LOSS OF CONTROL

- Consider the potential failure modes of control paths in the machine control system design, such as:
 - The possibility of backlight failure,
 - Unanticipated link transmission delays or failures,
 - The operator being unable to control the machine,
 - The operator making errors in the control of the machine.
- Provide a means to achieve a safe state during and after a path failure for critical control functions such as emergency stop and overtravel stop.
- Provide separate or redundant control paths for critical control functions.
- Test individually and thoroughly each implementation of the HMISTU655/855 for correct operation before service.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

WARNING

UNINTENDED EQUIPMENT OPERATION

- Do not use the unit as the only means of control for critical system functions such as motor start/stop or power control.
- Do not use the unit as the only notification device for critical alarms, such as device overheating or overcurrent.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Handling the LCD Panel

The following characteristics are specific to the LCD unit and are considered normal behavior:

- LCD screen may show unevenness in the brightness of certain images or may appear different when seen from outside the specified viewing angle. Extended shadows, or cross-talk, may also appear on the sides of screen images.
- LCD screen pixels may contain black and white colored spots and color display may seem to have changed over time.
- When the same image is displayed on the screen for a long period, an after-image may appear when the image is changed. If this happens, turn off the unit, wait 10 seconds and then restart it.

NOTE: Do not display the same image for a long time, change the screen image periodically.

CAUTION

SERIOUS EYE AND SKIN INJURY

The liquid present in the LCD panel contains an irritant:

- Avoid direct skin contact with the liquid.
- Wear gloves when you handle a broken or leaking unit.
- Do not use sharp objects or tools in the vicinity of the LCD touch panel.
- Handle the LCD panel carefully to prevent puncture, bursting, or cracking of the panel material.

If the panel is damaged and any liquid comes in contact with your skin, immediately rinse the area with running water for at least 15 min.

If the liquid gets in your eyes, immediately rinse your eyes with running water for at least 15 minutes and consult a doctor.

Failure to follow these instructions can result in injury or equipment damage.

Using Touch Panel Correctly

WARNING

UNINTENDED EQUIPMENT OPERATION

- Operate the HMISTU655/855 touch panel with only one finger.
- Do not activate two or more points of the touch panel simultaneously.

Failure to follow these instructions can result in death, serious injury, or equipment damage.


Use only one finger to select an object on the touch panel.

If the touch panel receives pressure at two or more points at the same time, an unintended object could be selected.

HMISTU655/855 Package Contents

Package Contents

Verify all items listed here are present in your package:



- 1 Display Module
- 2 Rear Module
- 3 Tightening Wrench
- 4 USB Standard Type A Cable Holder
- 5 Anti-rotation Tee
- 6 Terminal Block
- 7 Quick Reference Guide

Revision

You can identify the product version (PV), revision level (RL) and the software version (SV) from the unit product label.

Accessories

Optional Accessories

Product Number	Description
HMIZS61	Set of 5 Screen Protective Sheets
HMIZSU62	Set of 5 Screen Protective Sheets for HMISTU855
HMIZSUKIT	Accessory Kit for HMISTU655/855, contains: ● USB standard Type A cable holder ● USB mini B cable holder ● Anti-rotation tee ● 2 Panel adapters
ZB5AZ905	Tightening Wrench
ZB5AZ901	Kit of 10 display module fixing nuts
BMXXCAUSBH018	Mini-B USB <-> PC download cable
HMIZSUSBB	USB Front Cable (MiniB)
HMIZURS	USB-232C Converter Cable
XBTZGPWS1	Set of 5 Power Connectors
HMIS65	Front module 8.9 cm (3.5 in.)
HMIS85	Front module 14.48 cm (5.7 in.)
HMIS5T	Rear module
HMIS65W¹	Front module 8.9 cm (3.5 in.) without marking on overlay
HMIS85W¹	Front module 14.48 cm (5.7 in.) without marking on overlay
HMIZSURDP²	3 m (9.84 ft), separation cable
HMIZSURDP5²	5 m (16.40 ft), separation cable
HMIZSURDP10²	10 m (32.80 ft), separation cable
(1) In rest of the document, HMIS65/S85 references apply for both series (regular and W) unless otherwise specified. (2) The outer diameter of the cable is 80 mm (0.32 in.). Extra space of 20 mm (0.79 in.) is required to bend the cable at the end of the rubber to assemble this product.	

NOTE: Only HMIS5T supports both front module sizes without any new configuration.

Rear Module Label	Front Module Compatibility	
	HMIS65	HMIS85
HMISTU655	OK	–
HMISTU855	–	OK
HMIS5T	OK	OK

DANGER

RISK OF EXPLOSION IN HAZARDOUS LOCATIONS

Do not substitute a rear module labeled HMISTU655 by a rear module labeled HMIS5T when installed in hazardous locations.

Failure to follow these instructions will result in death or serious injury.

Serial Interface Items

Product Number	Description
XBTZ9780 (2.5 m/8.20 ft) XBTZ9782 (10 m/32.80 ft)	Connects COM1 to Premium, Micro or Twido PLC.
XBTZ9980 (2.5 m/8.20 ft) XBTZ9982 (10 m/32.8 ft)	Connects COM1 to Modicon M340
VW3A8306	Connects COM1 to derivation box TSXSCA62
VW3A8306R10	Connects COM1 to ATV Drives, a Hub LU9GC3 or Fieldbus Taps TWDXCAT3RJ or TWDXCAISO
XBTZG939 + XBTZ988	Connects COM1 port to Advantys STB
XBTZG939	Cable adapter COM1, RJ45
XBTZ968 XBTZ9680 XBTZ9681	Connects COM1 port with XBTZ adapter to Premium, Micro or Twido PLC
XBTZ9710	Connects COM1 port with XBTZ adapter to Quantum PLC
XBTZ9711	Connects COM1 port with XBTZ adapter to Momentum PLC
XBTZ908	Connects COM1 port with XBTZ adapter to derivation box TSXSCA62
XBTZ938	Connects COM1 port with XBTZ adapter to ATV drives, a Hub LU9GC3 or Fieldbus Taps TWDXCAT3RJ or TWDXCAISO
XBTZ918	Connects COM1 port with XBTZ adapter to Premium SCY
XBTZ988	Connects COM1 port with XBTZ adapter to Advantys STB
XBTZ9733	Connects COM1 to Rockwell DF1 Logix PLC
XBTZ9734	Connects COM1 to Rockwell DH485 Logix PLC

Product Number	Description
XBTZ9743	Connects COM1 to Omron PLC Sysmac Link series
XBTZ9730 XBTZ9731	Connects COM1 with XBTZ adapter to Rockwell DF1 PLC
XBTZ9732	Connects COM1 with XBTZ adapter to Rockwell DH485 PLC
XBTZ9740	Connects COM1 with XBTZ adapter to Omron PLC Sysmac Link series

USB Interface Items

Product Number	Description
XBTZG935	Connects the panel to a personal computer to transfer screen data and user program
XBTZGUSB	Extends a USB host interface on a waterproofing cabinet
BMXXCAUSB018	Connects the panel to a: - personal computer to transfer screen data and user program - USB terminal port of a PLC (Modicon M340)
HMIZSUSBB	Extends a USB device interface on a waterproofing cabinet
HMIZURS	Connects the panel to a serial printer


Software

Product Name	Software Name	Description
HMISTU655 PV < 4	Vijéo Designer 5.1 or later	Software installed on a PC for creating HMI unit project data
HMISTU655 PV ≥ 4	Vijéo Designer 6.1 SP1 or later	Software installed on a PC for creating HMI unit project data
HMISTU855 PV < 3	Vijéo Designer 5.1 SP2 or later	Software installed on a PC for creating HMI unit project data
HMISTU855 PV ≥ 3	Vijéo Designer 6.1 SP1 or later	Software installed on a PC for creating HMI unit project data
HMISTU655W/855W	Vijéo Designer 6.1 SP1 or later	Software installed on a PC for creating HMI unit project data
HMIS5T	Vijéo Designer 6.1 SP1 or later	Software installed on a PC for creating HMI unit project data

Parts Identification and Functions


Display Module

Front:




- A** Display: displays user created screens and remote equipment variables.
- B** Touch panel: performs screen change operations and sends data to the host (PLC).

Rear:




Rear Module

Front:




Rear:




Connectors:

Bottom:



- C** Standard A USB port connector: connects the data transfer cable or memory stick to the unit.
- D** Serial I/F (host I/F 8 pin RJ45): connects a RS-232C or RS-485 (serial) cable (from the host/PLC) to the unit (Y port).
- E** Ethernet Interface (LAN): connects an Ethernet cable (from the host/PLC) to the unit (X port).
- F** Power input Terminal block: connects the power input and ground wires to the unit.

Side:



G Mini-B USB port connector: connects the data transfer PC cable to the unit.

Certifications and Standards

Introduction

Schneider Electric submitted this product for independent testing and qualification by third-party listing agencies. These agencies have certified this product as meeting the following standards.

Agency Certifications for HMISTU655/855 Unit

HMISTU655/855 unit is certified by the Underwriters Laboratory according to:

- UL 508 and CSA C22.2 n° 142 for Industrial Control Equipment
- ANSI/ISA 12.12.01 and CSA C22.2 n° 213 for Electrical Equipment for Use in Class I, Division 2 Hazardous Locations

ATEX certification by INERIS is ongoing, please refer to product label.

HMISTU655/855 unit is designed to comply to merchant navy bridge and deck requirements (Refer to the Schneider Electric website for installation guidelines).

For detailed information, contact your local distributor or see the catalog & marking on the product.

Hazardous Substances

HMISTU655/855 unit is designed for compliance with:

- WEEE, Directive 2002/96/EC
- RoHS, Directive 2011/65/EU
- RoHS China, Standard SJ/T 11363-2006

UL Conditions of Acceptability and Handling Cautions for HMISTU655/855 Unit

The HMISTU655/855 unit is suitable for use in hazardous locations in accordance with Class 1, Division 2 standards. All relevant local, state, and regional codes must be followed.

CE Markings

This product conforms to the necessary requirements of the following Directives for applying the CE label:

- 2006/95/EC Low Voltage Directive
- 2004/108/EC EMC Directive

This conformity is based on compliance with IEC61131-2.

** WARNING****RISK OF EXPLOSION IN HAZARDOUS LOCATIONS**

- Verify that the power, input and output (I/O) wiring are in accordance with Class I, Division 2 wiring methods.
- Do not substitute components that may impair compliance to Class I, Division 2.
- Do not connect or disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
- Securely lock externally connected units and each interface before turning on the power supply.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Interfaces are: COM1, ETHERNET, USB1 and USB2.

** WARNING****RISK OF EXPLOSION IN HAZARDOUS LOCATIONS**

- Do not disconnect while circuit is live.
- Potential electrostatic charging hazard: wipe the front panel of the terminal with a damp cloth before turning ON.


Failure to follow these instructions can result in death, serious injury, or equipment damage.

System Design

Introduction


The following diagrams represent equipment that can be connected to the unit.

HMISTU655/855 Edit Mode Peripherals



- 1 HMISTU655/855 unit
- 2 Personal computer
- 3 **BMXXCAUSBH018** cable
- 4 To Ethernet network


HMISTU655/855 Run Mode Peripherals



- 1 HMISTU655/855 unit
- 2 USB DEVICE interface (TYPE-miniB)
- 3 USB Front Cable **HMIZSUSBB**
- 4 PLC
- 5 To Ethernet network

Connecting Magelis HMISTU655/855 unit to an external device

The following diagram represents a selection of equipment that can be connected to the HMISTU655/855 unit.



- 1 HMISTU655/855
- 2 USB HOST interface (TYPE-A)
- 3 USB Front Cable (A) 1 m (3.28 ft) **XBTZGUSB**
- 4 USB Memory
- 5 USB HUB (Self Power Only)
- 6 Barcode Reader
- 7 Printer
- 8 USB-232C Converter Cable 0.5 m (1.64 ft) **HMIZURS**
- 9 Printer (Commodity). NEC PC-PR201/PL Command Compatible, EPSON ESC/P24-J84© Command Compatible or HP Laser Jet PCL4 Command Compatible
- 10 USB DEVICE interface (TYPE-miniB)
- 11 Download Cable **BMXXCAUSBH018**
- 12 PC
- 13 Vijeo-Designer
- 14 USB Front Cable **HMIZSUSBB**

Chapter 2

Specifications

Overview

This chapter presents the HMISTU655/855 specifications.

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
2.1	General Specifications	30
2.2	Functional Specifications	32
2.3	Interface Specifications	36
2.4	Dimensions	40

Section 2.1

General Specifications

General Specifications

Electrical Specifications

The following table shows the electrical specifications of HMISTU655/855:

Part Number	Rated Input Voltage	Input Voltage Limits	Acceptable Voltage Drop	Power Consumption	In-Rush Current	Voltage endurance between power terminal and frame ground (FG)	Insulation Resistance between power terminal and FG
HMISTU655	24 Vdc	20.4 Vdc to 28.8 Vdc	≤ 10 ms	≤ 6.5 W	≤ 30 A	1000 Vac 20 mA for 1 minute	10 MΩ or higher at 500 Vdc
HMISTU855	24 Vdc	20.4 Vdc to 28.8 Vdc	≤ 7 ms	≤ 6.8 W	≤ 30 A	1000 Vac 20 mA for 1 minute	10 MΩ or higher at 500 Vdc

Environmental Specifications

The following table shows the environmental specifications of HMISTU655/855:

	Specification	HMISTU655	HMISTU855
Physical Environment	Ambient operating temperature (cabinet interior and panel face)	0 °C to +50 °C (32 °F to 122 °F)	0 °C to +50 °C (32 °F to 122 °F)
	Storage temperature	-20 °C to +60 °C (-4 °F to 140 °F)	-20 °C to +60 °C (-4 °F to 140 °F)
	Relative Humidity	85 % w/o condensation (Non-condensing, wet bulb temperature 39 °C (102.2 °F) or less)	85 % w/o condensation (Non-condensing, wet bulb temperature 39 °C (102.2 °F) or less)
	Air purity (dust)	≤ 0.1 mg/m ³ (10 ⁻⁷ oz/ft ³) (non-conductive levels)	≤ 0.1 mg/m ³ (10 ⁻⁷ oz/ft ³) (non-conductive levels)
	Corrosive gases	Free of corrosive gases	Free of corrosive gases
	Atmospheric pressure	800 hPa to 1,114 hPa (2000 m (6,561 ft) or lower)	800 hPa to 1,114 hPa (2000 m (6,561 ft) or lower)

	Specification	HMISTU655	HMISTU855
Mechanical Environment	Vibration immunity (operating)	IEC 61131-2 1gn 5Hz to 150Hz (maximum 3.5 mm (0.13 in.))	IEC 61131-2 1gn 5Hz to 150Hz (maximum 3.5 mm (0.13 in.))
	Protection (front panel)	IP 65 - (IEC 60529)	IP 65 - (IEC 60529)
	Protection structure	Type 4X indoor, installed on a panel	Type 4X indoor, installed on a panel
	Protection (rear panel)	IP 20 - (IEC 60529)	IP 20 - (IEC 60529)
	Shock immunity (operating)	IEC 61131-2 15gn 11 ms	IEC 61131-2 15gn 11 ms
	Cooling method	Natural air circulation	Natural air circulation
	Weight	0.25 kg (0.55 lb.) or less (main unit only)	0.25 kg (0.55 lb.) or less (main unit only)
	Color	Front bezel: dark gray	Front bezel: dark gray
	Material	PC/PBT	PC/PBT & PAA
Electrical Environment	Noise immunity	Noise voltage: 1000 Vp-p Pulse width: 1 µs Rising time: 1 ns	Noise voltage: 1000 Vp-p Pulse width: 1 µs Rising time: 1 ns
	High Energy Surges	1 kV CM, 0.5 kV DM on DC power supply 1 kV CM on shielded cables	1 kV CM, 0.5 kV DM on DC power supply 1 kV CM on shielded cables
	Electrical fast transient burst	2 kV CM, 2 kV DM on DC power supply. 1 kV on shielded cables	2 kV CM, 2 kV DM on DC power supply. 1 kV on shielded cables
	Radiated radio frequency electromagnetic field	10 V/m / 80 MHz to 2.7GHz Sinus amplitude modulated 80 % 1 kHz + Internal clock frequency	10 V/m / 80 MHz to 2.7GHz Sinus amplitude modulated 80 % 1 kHz + Internal clock frequency
	Electrostatic Discharge Immunity	6 kV direct contact 8 kV air contact	6 kV direct contact 8 kV air contact
	Grounding	D type grounding (SG-FG connected)	D type grounding (SG-FG connected)
CM Common Mode DM Differential Mode			

Section 2.2

Functional Specifications

Overview

This section presents the HMISTU655/855 functional specifications of the display, memory and interfaces.

What Is in This Section?

This section contains the following topics:

Topic	Page
Display	33
Memory, Clock, and Touch Panel	35

Display

Display Specifications

The following table shows the display specifications of the HMISTU655/855:

Items	HMISTU655	HMISTU855
Type	Color TFT LCD	Color TFT LCD
Resolution (pixels)	320 x 240 (QVGA)	320 x 240 (QVGA)
Active Display Area (W x H)	70.56 x 52.92 mm (2.78 x 2.08 in.)	115.2 x 86.4 mm (4.53 x 3.40 in.)
Colors	65536 colors	65536 colors
Backlight	LED backlight:	LED backlight:
	Lifetime: 50000 hours before dimmed to 50% brightness. Ambient temperature = 25° C (77° F)	Lifetime: 50000 hours before dimmed to 50% brightness. Ambient temperature = 25° C (77° F)
	Non exchangeable	Non exchangeable
	LED ON / OFF control, adjustable screen saver activation time	LED ON / OFF control, adjustable screen saver activation time
Brightness adjustment	16 levels of adjustment available via touch panel in the Configuration menu.	16 levels of adjustment available via touch panel in the Configuration menu.
Brightness on LCD surface	White LED: 350 cd/m ² (33 cd/ft ²) maximum	White LED: 350 cd/m ² (33 cd/ft ²) maximum
View angle	60 degrees: left, right 40 degrees: up 60 degrees: down (Test condition: contrast ratio > 2)	80 degrees: left, right 70 degrees: up 70 degrees: down (Test condition: contrast ratio > 2)
System embedded language character sets	ASCII: (Code page 850) alphanumeric (including european characters) Chinese: (GB2312-80 codes) simplified Chinese fonts Japanese: ANK 158 Kanji: 6,962 (JIS Standards 1 & 2) (including 607 non-kanji characters) Korean: (KSC5601 - 1992 codes) Hangul fonts Taiwanese: (Big 5 codes) traditional Chinese fonts	ASCII: (Code page 850) alphanumeric (including european characters) Chinese: (GB2312-80 codes) simplified Chinese fonts Japanese: ANK 158 Kanji: 6,962 (JIS Standards 1 & 2) (including 607 non-kanji characters) Korean: (KSC5601 - 1992 codes) Hangul fonts Taiwanese: (Big 5 codes) traditional Chinese fonts
Character sizes (2)	8 x 8, 8 x 16, 16 x 16 and 32 x 32 pixels fonts	8 x 8, 8 x 16, 16 x 16 and 32 x 32 pixels fonts
Font sizes	Width can be expanded 1 to 8 times. Height can be expanded 1/2 and 1 to 8 times.	Width can be expanded 1 to 8 times. Height can be expanded 1/2 and 1 to 8 times.

Items	HMISTU655	HMISTU855
8 x 8 pixels	40 characters per row x 30 rows	40 characters per row x 30 rows
8 x 16 pixels	40 character per row x 15 rows	40 character per row x 15 rows
16 x 16 pixels	20 character per row x 15 rows	20 character per row x 15 rows
32 x 32 pixels	10 character per row x 7 rows	10 character per row x 7 rows

Memory, Clock, and Touch Panel

Memory

The following table shows the memory specifications of HMISTU655/855:

Items	Specification
Application flash	32 MB
Data backup in FRAM	64 KB
Application run DRAM	64 MB

Memory Back-up Management in FRAM

Detected alarms data are saved:

- automatically every hour in the back-up memory.
- upon user request through Vijeo Designer application design.

Clock

Variations in operating conditions can cause a clock shift from -380 to +90 seconds per month.

Touch Panel

The following table shows the touch panel specifications of HMISTU655/855:

Items	Specification
Type	Analog resistance film type (Metal Tab, Golden Plated)
Lifetime	1 million touches or more

Section 2.3

Interface Specifications

Overview

This section presents the interface specifications of the HMISTU655/855 units.

What Is in This Section?

This section contains the following topics:

Topic	Page
Interface Specifications	37
Specifications of Serial Interface COM1	38

Interface Specifications

Serial Interface COM1

The following table describes the serial interface COM1 of HMISTU655/855 unit:

Interface	Description
Serial interface COM1 RJ45	
Asynchronous Transmission	RS-232C / RS-485
Data Length	7 or 8 bits
Stop Bit	1 or 2 bits
Parity	None, odd or even
Data Transmission Speed	2,400 to 115,200 bps
Maximum Transmission Distance	RS-232C 15 m (49.21 ft)/ RS-485 1200 m (3,937 ft) at 100 kbps

USB1 Interface (USB peripherals)

The following table describes the USB1 Interface of HMISTU655/855 unit:

Interface		Description
HOST Interface		
Transmission Speed	High speed	480 Mbps
	Full speed	12 Mbps
	Low speed	1.5 Mbps
Maximum Current Supplied		250 mA
Maximum Transmission Distance		5 m (16.40 ft) at 12 Mbps
Connector		USB Type-A V2.0

USB2 Interface (application download)

USB Mini B V2.0 type connector is used for application download.

Ethernet Interface

The following table describes the LED colors and status:

LED	Contents
Green 1	Link state
Green 2	Activity

Specifications of Serial Interface COM1

Introduction

This interface is used to connect the HMISTU655/855 to remote equipment via an RS-232C or RS-485 cable. The connector used is a RJ45-8 pin type connector.

When using a long PLC cable to connect the unit, a difference of electric potential can be observed between the cable and the unit, even if both are connected to ground.

The serial port is not isolated. The SG (signal ground) and the FG (frame ground) terminals are connected inside the unit.

NOTE: When setting up RS-485 communication, the cable diagram for some equipment may require polarization on the terminal side. This terminal does not require any special setting as it handles polarization automatically.

⚠ DANGER

ELECTRIC SHOCK


When using the SG terminal to connect an external device to the unit:

- Verify that a short-circuit loop is not created when you set up the system.
- Connect the #8 SG terminal to remote equipment when the host (PLC) unit is not isolated. Connect the #8 SG terminal to a known reliable ground connection to reduce the risk of damaging the RS-232C/RS-485 circuit.

Failure to follow these instructions will result in death or serious injury.

Serial Interface COM1

The following table describes the RJ45-8 pin connector on the HMISTU655/855 units:

Pin Connection	Pin	Signal Name	Direction	Meaning
	1	RXD	Input	Receive Data (RS-232C)
	2	TXD	Output	Send Data (RS-232C)
	3	Not connected	-	-
	4	D1	Output/Input	Transfer Data (RS-485)
	5	D0	Output/Input	Transfer Data (RS-485)
	6	RTS	Output	Request To Send
	7	Not connected	-	-
	8	SG	-	Signal Ground

RS-232C Type

The following table describes the 9-pin COM interface connector on the HMISTU655/855:

RS-232C			
Label	Signal Name	Direction	Meaning
CI	CI(RI)	Input	Called status display
CD	CD	Input	Carrier detect
CS	CS(CTS)	Input	Send possible
RS	RS(RTC)	Output	Request to send
SG	SG	-	Signal ground
DR	DR(DSR)	Input	Data set ready
ER	ER(DTR)	Output	Data terminal ready
RD	RD(RXD)	Input	Receive data
SD	SD(TXD)	Output	Send data

Any excessive weight or stress on communication cables may cause a disconnection and unintended equipment operation.

CAUTION

LOSS OF COMMUNICATION

When using HMISTU655/855:

- All connections to the communication ports on the bottom and sides of the unit must not put excessive stress on the ports.
- Securely attach communication cables to the panel or cabinet.
- Use only RJ45 cables with a locking tab in good condition.


Failure to follow these instructions can result in injury or equipment damage.

Section 2.4

Dimensions


HMISTU655/855

Display Module HMISTU655




- 1 Front
- 2 Left Side
- 3 Top

Display Module HMISTU855




Rear Module HMISTU655/855




- 1 Front
- 2 Right Side

Display and Rear Modules HMISTU655



Display and Rear Modules HMISTU855



- 1 Front
- 2 Right side
- 3 Top
- 4 Bottom
- 5 Left side

Chapter 3

Installation and Wiring

Overview

This chapter describes the installation procedures and the wiring principles for HMISTU655/855.

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
3.1	Installation	46
3.2	Wiring Principles	56
3.3	USB Port	64
3.4	Ethernet Cable Connector	75

Section 3.1

Installation

Overview

This section describes the installation Procedures for HMISTU655/855.

What Is in This Section?


This section contains the following topics:

Topic	Page
Panel Cut-out Dimensions and Installation	47
Installation Procedures	51

Panel Cut-out Dimensions and Installation

Inserting a HMISTU655/855 Without an Anti-rotation Tee

Create a panel cut-out and insert the display module of the unit into the panel from the front. The following illustration shows the panel cut-out for a HMISTU655/855 unit without a tee:




Dimensions

Unit	A (mm)	A (in.)	B (1)	B (2)
HMISTU655/855	+0 22.50 -0.30	+0 0.88 -0.01	1.5...6 mm (0.06...0.23 in.)	3...6 mm (0.11...0.23 in.)
(1) Steel sheet				
(2) Glass fiber reinforced plastics (minimum GF30)				

NOTE: Without the tee option, the rotating torque that can be supported by the display module is 2.5 Nm (22.12 in-lb).

Inserting a HMISTU655/855 With an Anti-rotation Tee

Create a panel cut-out and insert the display module of the unit into the panel from the front. The following illustration shows the panel cut-out for a HMISTU655/855 unit using a tee:




Dimensions

Unit	C (mm)	C (in.)	D (mm)	D (in.)
HMISTU655/855	+0 30.00 -0.20	+0 1.18 -0.007	+0 4.00 -0.20	+0 0.15 -0.007

NOTE: With the tee option, the rotating torque that can be supported by the display module is 6 Nm (53.10 in-lb).

Illustration




- 1 Display module
- 2 Support
- 3 Nut
- 4 Tee

Panel Adaptor

The Panel Adaptor, supplied in the accessory kit **HMIZSUKIT** ([see page 16](#)), allows mounting the product on a:

- Metallic support with a thickness between 1 and 1.5 mm (0.039 and 0.059 in.)
- Plastic support with a thickness between 1 and 3 mm (0.039 and 0.118 in.) for HMISTU655
- Glass fiber reinforced plastic with a thickness between 2 and 3 mm (0.078 and 0.118 in.) for HMISTU855

The following illustration shows the assembly with the panel adaptor:



- 1 Display module
- 2 Support
- 3 Panel adaptor
- 4 Nut
- 5 Tee

Installation Procedures


Panel Setup Procedure

Mount the unit in an enclosure that provides a clean, dry, robust and controlled environment (IP65 enclosure or UL50 4x, if indoors) ([see page 30](#)).


The unit can be mounted with the front and rear modules connected together directly, or separately using a separation cable.

Before installing the HMISTU655/855 verify that:


- The gasket is flat and not damaged.
- The installation panel or cabinet surface is flat (planarity tolerance: 0.5 mm (0.019 in.)), in good condition and has no jagged edges. Metal reinforcing strips may be attached to the inside of the panel, near the panel cut-out, to increase the rigidity.
- The panel must be designed to avoid any induced vibration resonance on the rear module exceeding a punctual factor of 10 and to avoid any induced permanent vibration resonance. To reduce the resonance use the panel adaptor accessory.
- The ambient operating temperature and the ambient humidity are within their specified ranges ([see page 30](#)).
- The heat from surrounding equipment does not cause the unit to exceed its specified operating temperature ([see page 30](#)).
- The panel face is not inclined more than 30° when installing the unit in a slanted panel:






- The power plug is positioned vertically when the unit is vertically installed.
- The unit is at least 100 mm (3.94 in.) away from adjacent structures and other equipment for easier maintenance, operation and improved ventilation:



Step	Action
1	Place the unit on a clean and level surface with the display panel facing downward.
2	The support thickness depends on the material: • Metallic: between 1.5 and 6 mm (0.059 and 0.236 in.) • Plastic: between 3 and 6 mm (0.118 and 0.236 in.) If the thickness is between 1 and 1.5 mm (0.039 and 0.059 in.) for metallic support or 1 and 3 mm (0.039 and 0.118 in.) for plastic, use the panel adaptor supplied in accessory kit HMIZSUKIT (see page 16).
3	Create the correct sized holes required to install the unit, using the Panel Cut-out Dimension and Installation (see page 47).

Step	Action
4	Insert the display module (with Tee, if used) into the panel hole:  Screw the nut with the tightening wrench with a torque between 1.2 and 2 Nm (10.62 and 17.70 in-lb.).

Step	Action
5	(a). If you install front and rear modules together, insert and push the rear module until it locks into place:  Insert and push Click Free Locked (b). If you install front and rear modules separately, insert and push both ends of the separation cable until they lock into place: 

Step	Action
6	To remove the rear module, push the yellow button to unlock it, then pull the rear module out:  The diagram illustrates the process of removing a rear module in three stages: Locked: The module is shown fully inserted into the chassis. A yellow button is visible on the top edge of the module. Unlocked: An arrow labeled "Push" points down to the yellow button, indicating the action to be taken. Free: The module is shown partially pulled out of the chassis. An arrow labeled "Pull" points to the right, indicating the direction to move the module out.

Section 3.2

Wiring Principles

Overview

This section presents HMISTU655/855 wiring principles.

What Is in This Section?

This section contains the following topics:

Topic	Page
Connecting the Power Cord	57
Connecting the Power Supply	60
Grounding	62

Connecting the Power Cord

Introduction

Follow these instructions when supplying power to the unit:


- When the frame ground (FG) terminal is connected, verify the wire is grounded. Not grounding the unit can result in excessive Electromagnetic Interference (EMI). Grounding is required to meet EMC level immunity.
- The shield ground (SG) and FG terminals are connected internally in the unit.
- Remove power before wiring to the power terminals of the unit.
- The unit uses only 24 Vdc power. Using any other level of power can damage both the power supply and the unit.
- Since the unit is not equipped with a power switch, connect a power switch to the unit's power supply.

Power Cord Preparation

Before using your power cord:

- Verify the ground wire is the same gauge or heavier than the power wires.
- Do not use aluminum wires for the power cord for power supply.
- If the conductor end (individual) wires are not twisted correctly, the end wires may either short loop to each other or against an electrode. To avoid this, use D25CE/AZ5CE cable ends.
- Use wires that are 0.2 to 2.5 mm² (24 - 12 AWG) for the power cord, and twist the wire ends before attaching the terminals.
- The conductor type is solid or stranded wire.
- To reduce electromagnetic noise, make the power cord as short as possible.


Power Plug Illustration



Connection	Wire
+	24 V
-	0 V
FG	Grounded terminal connected to the unit chassis

How to connect the Power Cord

The following table explains how to connect the power plug:


Step	Action
1	Remove the power cord from the power supply.
2	Remove the power plug from the unit.
3	Remove 7 mm (0.28 in.) of the vinyl cover of each of the power cord wires. 
4	If using stranded wire, twist the ends. Tinning the ends with solder reduces the risk of fraying and enhances electrical transfer.
5	Connect the wires to the power plug by using a flat-blade screwdriver (Size 0.6 x 3.5).
6	Torque the mounting screws: 0.5 to 0.6 Nm (4.4 to 5.2 lb-in).
7	Replace the power plug to the power connector.

NOTE:

- Do not solder the wire directly to the power receptable pin.
- The power supply cord must meet the specification shown above. Twist the power cords together, up to the power plug, for EMC cancellation. (See illustration as shown below).

Power Connection

The following illustration displays a connection of the power cord:



Connecting the Power Supply

Precautions

- Connect the power cord to the power connector on the side of the unit using the power plug.
- Use a regulated power supply with a Class 2 power supply between the line and the ground.
- Do not bundle the power supply cord with, or keep close to, main circuit lines (high voltage, high current), or input/output signal lines.
- Connect a lightning surge absorber to handle power surges.

Excessive stress on the power connection or attempting to install a unit with the power cables connected may disconnect or cause damage to the power connections. This can cause short circuits, fire or unintended equipment operation.

WARNING



SHORT CIRCUITS, FIRE, OR UNINTENDED EQUIPMENT OPERATION

- Securely attach power cables to the panel or cabinet.
- Use the designated torque to tighten the unit terminal block screws.
- Install and fasten unit on installation panel or cabinet prior to connecting Power Supply and Communication lines.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Power Supply Connections


For ease of maintenance, use the following optional connection diagram to set up your power supply connections.



NOTE:

- Ground the surge absorber (E1) separately from the unit (E2).
- Select a surge absorber that has a maximum circuit voltage greater than the peak voltage of the power supply.

The following diagram displays a lightning surge absorber connection:




Grounding

Introduction

Take the following precautions for grounding the unit.

Exclusive Grounding

Connect the frame ground (FG) terminal on the power plug to an exclusive ground.



Grounding Procedure

Step	Action
1	Check that the grounding resistance is less than 100 Ω
2	Create the connection point as close to the unit as possible, and make the wire as short as possible. When using a long grounding wire, replace the thin wire with a thicker wire, and place it in a duct.

Common Grounding


Precautions:

Electromagnetic Interference (EMI) can be created if the devices are improperly grounded. Electromagnetic Interference (EMI) can cause loss of communication.


Do not use common grounding, except for the authorized configuration described below.

If exclusive grounding is not possible, use a common connection point.

Correct grounding



Incorrect grounding



Section 3.3

USB Port

Overview

This section presents the USB port.

What Is in This Section?

This section contains the following topics:

Topic	Page
Important Considerations When Using the USB Port	65
USB Data Transfer Cable (BMXXCAUSBH018) - USB Driver Installation	66
USB Standard A	68
USB Mini-B	73

Important Considerations When Using the USB Port

Introduction

Data transfer cable (BMXXCAUSBH018) can be attached to the USB port to allow data transfer from the computer to the unit.

WARNING
--

RISK OF EXPLOSION IN HAZARDOUS LOCATIONS

In hazardous locations as described in ANSI/ISA - 12.12.01:

- | |
|---|
| <ul style="list-style-type: none">• confirm that the USB cable has been attached with the USB cable clamp before using the USB host interface.• remove power before attaching or detaching any connector(s) to or from the unit. |
|---|

Failure to follow these instructions can result in death, serious injury, or equipment damage.

<i>NOTICE</i>

UNINTENDED EQUIPEMENT OPERATION
--

Do not use the 4.5 m USB cable BMXXCAUSBH045.

Failure to follow these instructions can result in equipment damage.

USB Data Transfer Cable (BMXXCAUSBH018) - USB Driver Installation

Important information

Follow the procedure described below to avoid damage to the cable connector or the unit:

- Do not connect the USB data transfer cable until told to do so in the instructions.
- Insert the connector at the correct angle when connecting the USB data transfer cable to the PC or to the unit.
- Hold the connector, not the cable itself when disconnecting the cable.
- Use the port designated during installation. If the cable is unplugged from the port designated during installation and connected to a different port, the OS (Operating System) will not recognize the new port.
- Restart the PC and quit all resident applications before re-installing the software if the installation does not complete successfully.

NOTE: Vijeo Designer must be installed before installing the USB driver.

Installation Procedure

Step	Action
1	Insert the Vijeo Designer Installation CR-ROM into your CR-ROM drive. The Setup window for Vijeo Designer opens automatically. If not, at the Windows Start menu, click Run and type x:\install.exe (where x is your CR-ROM drive name).
2	In the install menu, select USB Driver .
3	Select the driver you want to install from the window that appears. For the BMXXCAUSBH018USB cable, select Install USB driver for....
4	A popup window appears stating the installation of the driver was successful.
5	Connect the USB cable to the computer. Windows automatically detects the cable and states that the device is ready to use.

Post-Installation Check

Perform the following check after installation:

Step	Action
1	On the target machine, verify the USB cable is physically connected to the USB port.
2	On the PC, verify the USB cable is physically connected to the USB port.
3	On the desktop, right-click My Computer and click Properties .
4	In System Properties dialog box, select Hardware tab, and then click Device Manager .
5	In Device Manager , the USB link cable (BMXXCAUSBH018) is displayed below the USB controller.

Troubleshooting

Detected problem/Symptom	Solution
The USB cable is not recognized.	Connect the cable correctly, or restart your PC. Also, when connecting a USB hub, connect it directly to your PC USB port.
Overcurrent occurred.	
The Plug and Play is not functioning correctly.	
You are unable to use the USB cable after connecting it to a USB hub.	The power supplied from the hub may be insufficient. Verify the hub is self-powered.
	Connect the cable directly to the PC USB port.
After installation, a ? is displayed when you try to confirm the cable's status via the Device Manager.	The driver has not been installed correctly. Uninstall the driver and re-install it.

Uninstalling the USB Driver

Step	Action
1	Click the USB device icon Stop USB link cable in the Windows task tray and then click Stop USB link cable (BMXXCAUSBH018) for Windows 2000, or Safely remove USB link cable (BMXXCAUSBH018) for Windows XP.
2	When the Safe To Remove Hardware message box appears, remove the USB download cable.
3	Click OK to close the message box.

USB Standard A

Introduction

When using a USB device, you can attach a USB holder to the USB interface on the side of the unit to prevent the USB cable from being disconnected.

WARNING
--


RISK OF EXPLOSION IN HAZARDOUS LOCATIONS

In hazardous locations as described in ANSI/ISA 12.12.01:


- | |
|---|
| <ul style="list-style-type: none">● confirm that the USB cable has been attached with the USB cable clamp before using the USB host interface.● remove power before attaching or detaching any connector(s) to or from the unit. |
|---|

Failure to follow these instructions can result in death, serious injury, or equipment damage.


Attaching the USB Holder

Step	Action
1	Attach the USB holder to the USB Host Interface on the rear module. Hook the upper pick of the USB holder to the attachment hole of the main unit, and insert the lower pick as shown below to fix the USB holder.  1 USB Holder

Step	Action
2	Insert the USB cable into the USB host interface.




1 USB Holder
2 USB Cable

Step	Action
3	Attach the USB cover to fix the USB cable in place. Insert the USB cover into the tab of the USB holder.  1 USB Holder 2 USB Cover 3 USB Cable

Removing the USB Holder

Push down the tab of the USB holder and then remove the USB cover.



- 1 USB Holder
- 2 USB Cover
- 3 USB Cable

USB Mini-B

Introduction

When using a USB device, you can attach a USB holder to the USB interface on the side of the unit to prevent the USB cable from being disconnected.

 WARNING


RISK OF EXPLOSION IN HAZARDOUS LOCATIONS

In hazardous locations as described in ANSI/ISA 12.12.01:


- confirm that the USB cable has been attached with the USB cable clamp before using the USB host interface.
- remove power before attaching or detaching any connector(s) to or from the unit.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Attaching the USB Holder

Step	Action
1	Insert the USB cable into the USB host interface.  1 USB Cable


Step	Action
2	Attach the USB holder to fix the USB cable in place.



1 USB Holder
2 USB Cable

Removing the USB Holder

Push down the tab of the USB holder and then remove the USB holder.



Section 3.4

Ethernet Cable Connector


Presentation

Introduction

The HMISTU655/855 comes equipped with an IEEE802.3 compliant Ethernet interface, that transmits and receives data at 10 Mbps or 100 Mbps.

Ethernet Cable Connector

The following illustration displays the location of the RJ45 Ethernet cable connector:



Do not confuse the RJ45 Ethernet connector with the RJ45 COM1/COM2 serial port.

NOTE: Ethernet networks must be installed by a trained and qualified person.

1:1 connections must be made with a hub or a switch. It is possible to use the 1:1 connection with a cross cable depending on the connected PCs and network cards.

Part II

Settings

Overview

This part describes the settings available on the target machine as well as how to debug the unit.

What Is in This Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
4	Configuring the Unit	79
5	Troubleshooting	91
6	Maintenance	95

Chapter 4

Configuring the Unit

Overview

This chapter presents the settings on the HMISTU655/855 units.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Types of Settings	80
System Settings	81
Offline Settings	85
Diagnostics Settings	88

Types of Settings

Introduction

You can use the **Settings** menu to configure the unit.

Depending on how you use your HMISTU655/855, you can display the **Settings** menu using three different methods:

- Use an action,
- Touch the top-left corner of the panel when powering up,
- Touch two corners of the panel successively while the application is running.

You can select which methods your application uses in the Vijeo Designer editor's **Target** properties.

Calling Up the Settings Menu

Step	Action
1	Set up any combination of the following methods for displaying the Settings menu. • Action: Create a switch and add the Configuration System Operation. See the Vijeo Designer online help for more information on creating a switch. • Top-Left Corner: In Target properties, set To Configuration to either Top Left Corner or Top Left/2 Corner. • Touch two corners successively: In Target properties, set To Configuration to either 2 Corner or Top Left/2 Corner. If you set To Configuration to None and do not create a switch to display the Settings menu, then there is no way to configure the unit at runtime.
2	Connect the power supply.
3	Depending on what you set up in Step 1, you can display the Configuration menu using one of the following methods: • Action: Touch the switch set up with the Configuration system operation. • Top-Left Corner: Touch the top-left corner of the screen within ten seconds after the unit begins starting up. • Touch two corners successively: Touch successively the top left corner then the bottom right corner within half a second. The touch area is 50 dots by 50 dots. Vijeo Designer Runtime restarts and displays the Settings menu.
4	The Settings menu contains 3 tabs: Offline , System , Diagnostics and To Run Mode . Click a tab to display its settings.

System Settings

Introduction

You can change system settings while the user application is still running.

Stylus

Use the Stylus to calibrate the screen:

Step	Action
1	In the Setting menu, press the System tab.
2	Press the Stylus button.
3	Press the center of the cross several times to complete calibration of the screen.

Changing the Date/Time

Step	Action
1	In the Setting menu, press the System tab.
2	Press the Date/Time button.
3	Press any of the Year , Month or Day fields and a data entry keypad is displayed. Use this keypad to define the selected date setting.
4	Press any of the Hour , Minutes or Seconds fields and a data entry keypad is displayed. Use this keypad to define the selected time setting.
5	In the Time Zone tab press the up/down arrows to select the desired time zone.
6	Check the Auto. adjust clock for daylight saving time box to choose adjusting clock for daylight saving time changes automatically.
7	In the DST tab press the up/down arrows to select the desired daylight saving time type: ● Date: the DST is added, or subtracted, on the exact date chosen. ● Rule: the DST is added, or subtracted, on a specific weekday in the month.
8	Press the Amount field and a data entry keypad is displayed. Use this keypad to define the desired daylight saving time amount (minutes).
9	Press the OK button to validate your configuration or configure the parameters of daylight saving time by Date (see page 82) or by Rule (see page 82).

Daylight Saving Time Setting by Date

If **Date** is selected in step 7 of Changing the Date/Time (*see page 81*), follow this procedure to set the daylight saving time parameters:

Step	Action
1	Follow the procedure of Changing the Date/Time (<i>see Magelis Small Panels, HMI STO User Manual</i>) til step 9.
2	In Add Time press the up/down arrows to select the desired month and press the right field to display the keypad to define the desired day to add time. In @ press any of the fields to display the keypad and define the hour to add time.
3	In Subtract Time press the up/down arrows to select the desired month and press the right field to display the keypad to define the desired day to subtract time. In @ press any of the fields to display the keypad and define the hour to subtract time.

Daylight Saving Time Setting by Rule

If **Rule** is selected in step 7 of Changing the Date/Time (*see page 81*), follow this procedure to set the daylight saving time parameters:

Step	Action
1	Follow the procedure of Changing the Date/Time (<i>see Magelis Small Panels, HMI STO User Manual</i>) til step 9.
2	In Add Time press the up/down arrows to select the desired day and the desired month to add time. In @ press any of the fields to display the keypad and define the hour to add time.
3	In Subtract Time press the up/down arrows to select the desired day and the desired month to subtract time. In @ press any of the fields to display the keypad and define the hour to subtract time.

Forcing a Restart

Step	Action
1	In the Setting menu, press the System tab.
2	Press the Restart button, the following message appears: Are you sure you want to restart the operating system?
3	Press the Restart button to restart the unit or the Cancel button to return to the System menu.

Selecting a Language

The following table describes how to select the language used for the Settings menu, the run-time messages and user application.

Step	Action
1	In the Setting menu, press the System tab.
2	Press the Language button.
3	Press the up/down arrows to select the desired languages for: • System, • User Application, • Keyboard Language. The languages available in the language settings are defined in the Vijeo Designer editor.
4	Press OK to validate.

Displaying Version Information

Step	Action
1	In the Setting menu, press the System tab.
2	Press the Ver. Info button, version information displays: • Vijeo-Designer Runtime Version, • Vijeo-Designer Version, • build number.

Displaying Memory Statistics

Step	Action
1	In the Setting menu, press the System tab.
2	Press the Memory button. • DRAM describes the amount of memory currently being used by the application. • Main Flash indicates the amount of internal memory (flash memory) required to store the runtime system files and the user application.

Brightness Control

Step	Action
1	In the Setting menu, press the System tab.
2	Press the Brightness button.
3	Press the up/down arrows to adjust the brightness. NOTE: Reducing the brightness could increase the life span of the backlight.

Offline Settings

Introduction

The offline settings cannot be changed while a user application is running.

Changing the Network Settings

Step	Action
1	In the Setting menu press the Offline tab.
2	Press the Network button, the following message appears: Working with Offline Settings will stop the user application and runtime. Continue?
3	Press the OK button to restart the system or the Cancel button to return to the System menu.
4	In the Static IP tab, press any of IP Address , Subnet Mask or Default Gateway fields, a numerical keypad displays, enter the desired parameters and validate by pressing Enter button.
5	In the DHCP tab, press the Enable DHCP checkbox to obtain configuration information from the network. This reduces system administration workload, allowing devices to be added to the network with little or no manual intervention.
6	In the MAC/DNS tab: ● Press Obtain DNS Setting checkbox to translate names into IP addresses. ● Press any of IP Address fields, a numerical keypad displays, entry the desired IP address and validate by Enter button.
7	In Static IP tab press the Ok button to validate.

Changing the Buzzer Settings

Step	Action
1	In the Setting menu press the Offline tab.
2	Press the Buzzer button, the following message appears: Working with Offline Settings will stop the user application and runtime. Continue?
3	Press the OK button to restart the system or the Cancel button to return to the System menu.
4	Press the desired buzzer mode. The factory setting is Pressing Touch Object . ● None: Selecting this turns the buzzer off. ● When Press Touch Object: The buzzer only sounds when a Touch Object is pressed.

Changing Backlight Control

Step	Action
1	In the Setting menu press the Offline tab.
2	Press the Backlight button, the following message appears: Working with Offline Settings will stop the user application and runtime. Continue?
3	Press the OK button to restart the system or the Cancel button to return to the System menu.
4	In the Backlight control, define the backlight operations. ● Wait: To extend the life of the backlight, you can set up the unit so that it turns off the backlight when the panel is inactive (idle) for the defined period of time, (Idle means the unit panel has not been pressed). The factory setting for this item is off. ● Enable Touch if Backlight Burned Out: This setting defines whether the press panel is enabled or disabled when a backlight burnout is detected. When this feature is cleared and the backlight burns out, press inputs are ignored to prevent operation detected errors. The factory setting for this item is off.
5	To turn the Backlight off automatically after a specified period of time, press the Wait checkbox and then set the idle time.

Self Test

Step	Action
1	In the Setting menu, press the Offline tab.
2	Press the Self Test button, the following message appears: Working with Offline Settings will stop the user application and runtime. Continue?
3	Press the OK button to restart the system or the Cancel button to return to the System menu.
4	In the Self Test control, press: ● Char. Pattern: to check the characters in each font set available on the unit. Use this test when characters (usually 2-byte characters) do not display properly. Ok appears if there is no detected error. NG appears if there is a detected error. ● Disp. Pattern: to test your LCD screen with some graphical test patterns. ● Touch Panel: to test the touch panel cells. Each cell highlights when it is pressed during the test. ● COM 1: to test the COM 1 port connector. Ok appears if there is no detected error. NG appears if an error is detected. ● Video memory: to test hardware memory.

Driver Configuration

Step	Action
1	In the Setting menu, press the Offline tab.
2	Press the IO Manager button, the following message appears: Working with Offline Settings will stop the user application and runtime. Continue?
3	Press the OK button to restart the system or the Cancel button to return to the System menu.
4	In the IO Manager control, press the Driver Config button.
5	In the Driver Config control: Select Driver: press the up/down arrow to select the desired driver.
6	Set the parameters of the selected driver.

Equipment Configuration

Step	Action
1	In the Setting menu, press the Offline tab.
2	Press the IO Manager button, the following message appears: Working with Offline Settings will stop the user application and runtime. Continue?
3	Press the OK button to restart the system, or the Cancel button to return to the Setting menu.
4	In the IO Manager control, press the Equipment Config button.
5	In the Equipment Config control: Select Equipment: press the up/down arrow to select the desired equipment.
6	Set the parameters of the selected equipment.

Diagnostics Settings

Introduction

The HMISTU655/855 units are equipped with a number of diagnostic features that can be used to check the systems and the interfaces for any problems.

Diagnostics

See the Vijeo Designer online help for information on accessing the **Diagnostics Settings** menu.

Variables

Use the **Variable** menu to check that the application is running correctly. The following table describes how to get to the **Variable** menu:

Step	Action
1	In the Settings menu, press the Diagnostics tab.
2	Press the Variable button.
3	Select Equipment: press the up/down arrow to select the equipment whose variables you want to test.
4	In the Variable menu, press the Go Offscan button, the following message appears: Warning: Entering the Variable Test screen pauses communication with all equipment. Continue?
5	Press the OK button to restart the system, or the Cancel button to return to the Variable menu.
6	If the Go Onscan is pressed, the test reads the value for each variable associated with the selected equipment. If any of the variables detects a problem, because of a detected error in the equipment or a time-out, the event log displays a message with the name of the variable.
7	After you complete testing variables from one equipment, you can continue testing variables for other equipment connected to the target machine.
8	Alternatively, you can test all equipment at once by selecting Test All in the Select Equipment drop-down list.
9	Press the Return button to return to the Diagnostics menu.

Statistics

Use the **Statistics** menu to check the connection between equipment. The following table describes how to get to **Statistics** menu:

Step	Action
1	In the Settings menu, press the Diagnostics tab.
2	Press the Statistics button. NOTE: When you write any value to this system control word, press the Rollover button to: ● Copy the values in the current statistic variables to the previous statistic variables. ● Reset current statistic variables to zero.
3	In Show Stats for: press the up/down arrow to select the equipment whose variables you want to show statistics for.
4	Press the right arrow button to view the next display.
5	Press the Go Offscan button to start the test.
6	Press the right arrow button to view the next display.
7	Total Good: the total number of received variables without detected error. Total Bad: the total number of detected errors of all types. Total Count: Total Good + Total Bad. No Reply: no reply was received in response to the request. Chksum Fail: received a request or response (1) with an incorrect checksum. Wrong Addr.: received a request or response (1) with an incorrect address. Error Resp.: received a detected error response from the equipment. (1): Master-type drivers send out requests and receive responses. Slave-type drivers receive requests and send responses.
8	Press the next arrow button to view the next display.
9	Inv. Resp.: received a response that contained a protocol detected error. Init. Fail: initializing communications with the equipment was unsuccessful. Write Fail: writing a new value to the equipment was unsuccessful. Intrn Error: internal driver detected error indicates improper driver configuration or driver problem. Xmit Fail: transmitting a request or response was unsuccessful. Unsupp. Req.: received a request for an unsupported service. Inv. Request: received a request that contained a protocol detected error.
10	Press the Return button to return to the Diagnostics menu or the previous arrow button to view the previous display.

Chapter 5

Troubleshooting

Overview

This chapter describes how to find and resolve detected problems with the HMISTU655/855 units.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Troubleshooting Checklists	92
Self Test List	94

Troubleshooting Checklists

Introduction

When there is a detected problem, go through the checklist and follow the instructions given.

Here are the main detected problems that may occur when using HMISTU655/855 unit.

- Panel display is blank,
- Connected equipment cannot be used,
- Panel does not respond or responds very slowly,
- Panel beeps when powered on,
- Cannot change the date or time.

NOTE: Contact your local Schneider Electric vendor or your local distributor.

Panel Display is Blank

If the unit display is blank, perform the following check steps:

Step	Check/Operation	Solution
1	Are all Vijeo Designer screens downloaded?	You may have to download the screens again.
2	Is the Initial Panel ID set up correctly in Vijeo Designer?	Enter the Initial Panel ID in the Vijeo Designer editor and download again.
3	Is the unit using the correct rated voltage?	Verify the power supply connections and levels.
4	Is the power supply off or disconnected?	Follow the instructions in this manual for reconnecting the power supply.
5	Is the backlight lit?	Potential detected problem with the unit. Contact your local Schneider Electric distributor.
6	Is the detected problem resolved?	If none of the previous steps fixed the blank panel display detected problem, then verify the hardware.

Connected Equipment Cannot be Used

If the unit does not communicate with connected equipment, perform the following check steps:

Step	Check/Operation	Solution
1	Is the power supply off or disconnected?	Verify the power supply connections and levels.
2	Do the Driver and Equipment settings in Vijeo Designer match the actual equipment you are trying to communicate with?	In the Vijeo Designer editor Navigator window's Project tab, expand the I/O Manager node to enter the correct configuration settings for the Driver and Equipment nodes.
3	Is the communication cable connected correctly?	Refer to the associated protocol manual for information about cable diagrams.
4	Is the detected problem resolved?	If none of the previous steps fixed the communication detected problem, then verify the hardware.

Unit does not respond when pressed

If the unit is either not responding when pressed or if its response time is very slow, perform the following check steps:

Step	Check/Operation	Solution
1	Disconnect all the cables except the power cable.	-
2	In the Settings menu, press the Offline tab and then press the Self Test icon. Run the Touch Panel test.	If the test is unsuccessful, there is a detected problem with the hardware.
3	If touch response is slow, does it happen on a specific panel?	If the panel displays the values of a large number of equipment variables, you may want to redesign the panel and separate the variables into different panels and download again.
4	If touch response is slow, the target CPU may be very busy communicating with external equipment.	To resolve this detected problem, try each of the following in the Vijeo Designer editor and download again. ● If you are using serial communication, verify the communication speed between the target and equipment is optimized. ● In the equipment or scan group properties, reduce the Scan Rate to Slow. This will reduce the frequency of variable updates to 1000 ms. ● If you use many equipment variables in application scripts, you may want to change the script to a panel script so that the variables are active only when the information is necessary. If none of the above works, then you may have to reduce the number of external variables in the project. If none of the proposed options work, contact your Schneider Electric Technical Support for optimizing your project.

Target beeps when powered ON

A continuous beep from the target means that system files are corrupted. To resolve this detected problem, go to the Vijeo Designer Start menu and run Recovery on the target machine.

Self Test List

Introduction

The HMISTU655/855 units are equipped with a number of diagnostic features that can be used to check the systems and the interfaces for any detected s.

Self Test

From the **Settings** menu, press the **Offline** button and then the **Self Test** icon. **Self Test** menu appears. See the Vijeo Designer online help for information on accessing the **Offline** tab.

Self Tests

The following tests can be accessed from the **Self Test** menu.

Test	Description
Char. Pattern	Checks the characters in each font set available on the unit. Use this test when characters (usually 2-byte characters) are not displayed properly. OK appears if there is no detected error; NG appears if there is a detected error.
Disp. Pattern	Use this test when your drawings are not displayed properly.
Touch Panel	Tests the touch panel cells. Each cell highlights when it is pressed during the test.
COM 1	Checks that the serial port (RS-232C and RS-485) is working properly. To run the check, you may need to connect a loopback cable (see below). OK appears if there is no detected error; a detected error message appears if there is an error.
Video Memory	Use this test to check the video memory (memory used for screen display). Run this test when the screen does not display properly. OK appears if there is no detected error; NG appears if there is a detected error.

Wiring for COM 1 tests

When testing the serial port, depending on which port and which communication format you are testing, you may need to attach a loopback cable with wiring as defined below:

RS-232C	RS-485
HMISTU655/855 in COM1 RXD 1 TXD 2	Not available.

Chapter 6

Maintenance

Overview

This chapter explains how to maintain your HMISTU655/855 units.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Regular Cleaning	96
Periodic Check Points	98

Regular Cleaning

Cleaning the display

NOTICE

EQUIPMENT DAMAGE

- Power off the unit before cleaning it.
- Do not use hard or pointed objects to operate the touch panel, since it can damage the panel surface.
- Do not use paint thinner, organic solvents, or a strong acid compound to clean the unit.

Failure to follow these instructions can result in equipment damage.

When the surface or the frame of the display gets dirty, soak a soft cloth in water with a neutral detergent, wring the cloth tightly and wipe the display.

Chemical Substances

The products in the following table can be used when cleaning the unit:

Kinds of fluid	Company	Product designation	Concentration	Temperature °C (°F)	pH Value
Cleaning agents in the food and beverage industry	Ecolab	Topmaxx 422	5	40 (104)	1% : pH=13
	Ecolab	P3 Topax M 95	5	40 (104)	1% : pH=12.3
	Ecolab	P3 Oxonia Active	3	40 (104)	
	Ecolab	P3 Topax 52 FR	5	40 (104)	1% : pH=2
	Ecolab	P3 Topax 36	5	40 (104)	
	Ecolab	P3 Luboklar MH	0.7	40 (104)	
	Johnson Diversey	Divosan 2000	1	25 (77)	100% : pH=7
	Johnson Diversey	Diverfoam Septiplus	5	25 (77)	3% : pH=8.3
	Johnson Diversey	Acifoam	5	25 (77)	1% : pH=2.2
	Johnson Diversey	HD Plus Foam	5	25 (77)	1% : pH=12.9
	Johnson Diversey	Oxofoam	5	25 (77)	1% : pH=12.7
	Johnson Diversey	Endoroplus VE6	5	25 (77)	1% : pH=12.1
	Johnson Diversey	Endorofoce VE2	5	25 (77)	1% : pH=12.5
	Johnson Diversey	Endorocid VE10	5	25 (77)	1% : pH=2

Kinds of fluid	Company	Product designation	Concentration	Temperature °C (°F)	pH Value
Diverse		Water	100	50 (122)	
		Milk	100	25 (77)	
		Methanol	10	25 (77)	
Oils		ASTM 1	100	25 (77)	
		IRM 902	100	25 (77)	
		IRM 903	100	25 (77)	
		Cerechlor/IRM 903	50/50	25 (77)	
		Syntopon B	3	25 (77)	
Cutting oils	Ecocut	HBN 16LE	Pure	25 (77)	
	Quakercool	7101H	Emulsion	25 (77)	
	Quakercool	2769	Soluble / Synthetic	25 (77)	
	Quakercool	3750H	Micro-emulsion	25 (77)	

Periodic Check Points

Operation Environment

Refer to the Environmental Specifications ([see page 30](#)).

Electrical Specifications

The input voltage must be within 20.4 to 28.8 Vdc.

Related Items

- Are all power cords and cables connected properly? Are there any loose cables?
- Are all mounting brackets holding the unit securely?
- Are there scratches or traces of dirt on the installation gasket?



Symbols

Peripherals
 Edit Mode, 25

A

accessories, 16

C

Certifications and Standards, 23
Connecting the Power Cord, 57
Connecting the Power Supply, 60

D

Diagnostics Settings, 88

E

Edit Mode Peripherals, 25
Ethernet
 Cable connector, 75

G

Grounding, 62

I

Installation
 Procedures, 51

M

Maintenance
 Check points, 98
 Cleaning, 96

P

Part number
 HMISTU655, 12
 HMISTU655W, 12
 HMISTU855, 12
 HMISTU855W, 12
Parts Identification and Functions, 19
Power plug, 57

S

Self Test, 94
Settings
 menu, 80
Specifications
 COM, 38
 COM1, 37, 38
 Display, 33
 General, 30
 Interfaces, 37
 Memory, 37, 37
 USB, 37, 37
System Settings, 81

T

Troubleshooting, 92

U

USB
 Data Transfer Cable, 66
 Mini-B, 73
 Port, 65
 Standard A, 68

