



EXOR International

Industrial Computing Solutions

eTOP-EPC

eTOP-EPC 1230T/1231T/1235T/1530T/1531T/17
30T/1731T/1930T/1931T

User Manual





CONTENTS

Preface

Copyright	v
Disclaimer	v
Acknowledgements	v
Regulatory Compliance Statements	v
Declaration of Conformity	v
RoHS Compliance	vi
Warranty and RMA	vii
Safety Information	ix
Installation Recommendations	ix
Safety Instructions	x
Technical Support and Assistance	xi
Components Used in this Manual	xi
Global Service Contact Information	xii
Package Contents	xiv
Ordering Information	xvi

Chapter 1: Product Introduction

eTOP-EPC 1230T/1231T/1235T	1
Specifications	2
eTOP-EPC 1530T/1531T	4
Specifications	5
eTOP-EPC 1730T/1731T	7
Specifications	8
eTOP-EPC 1930T/1931T	10

Specifications	11
Knowing Your eTOP-EPC Series	13
Rear Top	13
Rear Bottom	14
Rear (eTOP-EPC 1230T/1235T/1530T/1730T/1930T only)	15
Rear (eTOP-EPC 1231T/1531T/1731T/1931T only)	16
Mechanical Dimensions	17
eTOP-EPC 1230T/1231T/1235T	17
Mechanical Dimensions	18
eTOP-EPC 1530T/1531T	18
Mechanical Dimensions	19
eTOP-EPC 1730T/1731T	19
Mechanical Dimensions	20
eTOP-EPC 1930T/1931T	20

Chapter 2: Jumpers and Connectors

Before You Begin	21
Precautions	21
Jumper Settings	22
Locations of the Jumpers and Connectors	23
Top View	23
Bottom View	24
Jumpers and DIP Switch Settings	25
CMOS Clear Select	25
AT/ATX Selection	25
Dimming Type Select	26



Content

Dimming Signal Level Select26

Panel Resolution Select27

LCD Panel VDD Power Select28

Touch 4/5 Wire Select28

COM1 RI Pin Power Select29

COM2 RI Pin Power Select29

COM3 RI Pin Power Select30

COM4 RI Pin Power Select30

Connector Pin Definitions31

External I/O Interface31

12V-30V DC Power Input31

Video Input31

Keyboard/Mouse Port32

Port: Serial Port RS232/422/48532

Port: Serial Port RS232/422/48533

Port and Connector: Serial Port RS23234

Port and Connector: Serial Port RS23235

Ports35

2 Port36

1 Port36

Line-out Jack37

Internal Connectors38

LVDS Channel 138

LVDS Channel 238

Panel Backlight Connector39

Touch Sensor Connector39

USB Connector40

Bluetooth Connector40

SATA Connector41

SATA DOM Power Connector41

Line-in/Mic-in Connector42

Speaker-out Connector42

GPIO Connector43

DIO Connector44

Power/HDD LED Indicator Connector45

Backlight Control Input Connector45

Dimming Control Button Connector46

SIM Card Slot46

Mini-PCle Slot47

Mini-PCle Slot48

CFast Card Slot49

Power Button Connector49

Block Diagram50

eTOP-EPC 1930T/APPC 1730T/APPC 1530T/APPC 1230T/APPC 1235T50
Block Diagram51

eTOP-EPC 1931T/APPC 1731T/APPC 1531T/APPC 1231T51

Chapter 3: System Setup

Installing a SATA Hard Drive52

Installing a CFast Card56

Installing a SODIMM58

Installing a SATA DOM61

Installing a Mini PCIe Module65

Installing the Half-Size Mini PCIe Module67

Installing the Full-Size Mini PCIe Module68

Installing a Bluetooth Module72

Placing Panel Mount Hole Blocks76

Installing the Power Adapter Bracket78

Plugging the DC Power Cable82

Panel Mounting83

Chapter 4: BIOS Setup

About BIOS Setup85



Content

When to Configure the BIOS.....85

Default Configuration.....86

Entering Setup.....86

Legends.....86

BIOS Setup Utility.....88

Main88

Advanced.....90

Chipset.....99

Boot.....102

Security.....104

Save & Exit.....104

Appendix A: GPI/O Programming Guide.....106

Appendix B: Digital I/O Programming Guide.....108

Appendix C: Watchdog Programming Guide.....110

Appendix D: Power Consumption.....112

Appendix E: Troubleshooting.....114




Preface

PREFACE

Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from EXOR International S.p.A.


+86-15876525394
Sales@vicpas.com
VICPAS.com

Disclaimer

The information in this document is subject to change without prior notice and does not represent commitment from Exor International S.p.A. However, users may state their knowledge of any product in use by constantly checking its manual posted on our website: <http://www.exorint.it> EXOR shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of any product, nor for any infringements upon the rights of third parties, which may result from such use. Any implied warranties of merchantability or fitness for any particular purpose is also disclaimed.

Acknowledgements

eTOP-EPC 1230T/1231T/1235T/1530T/1531T/1730T/1731T/1930T/1931T is a trademark of EXOR International S.p.A. All other product names mentioned herein are registered trademarks of their respective owners.

Regulatory Compliance Statements

This section describes how to keep the system CE compliant.

Declaration of Conformity

CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.



Preface

RoHS Compliance

EXOR RoHS Environmental Policy and Status Update



This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from EXOR International S.p.A.

RoHS is the use of Lead (Pb) < 0.1% or 1,000ppm, Mercury (Hg) < 0.1% or 1,000ppm, Cadmium (Cd) < 0.01% or 100ppm, Hexavalent Chromium < 0.1% or 1,000ppm, Polybrominated biphenyls (PBB) < 0.1% or 1,000ppm and Polybrominated diphenyl Ethers (PBDE) < 0.1% or 1,000ppm. In order to meet the RoHS compliant directives, EXOR has established an engineering and manufacturing task force to implement the introduction of new products. The task force will ensure that we follow the standard EXOR development procedure and that all the new RoHS components and new manufacturing processes maintain the highest industry quality levels for which EXOR are renowned.

The model selection criteria will be based on market demand. Vendors and suppliers will ensure that all designed components will be RoHS compliant.

All new product models launched after January 2006 will be RoHS compliant. They will use the usual EXOR naming convention.



Warranty and RMA

EXOR Warranty Period

EXOR manufactures products that are new or equivalent to new in accordance with industry standard. EXOR warrants that products will be free from defect in material and workmanship for 2 years, beginning on the date of invoice by EXOR. HCP series products (Blade Server) which are manufactured by EXOR are covered by a three year warranty period.

EXOR Return Merchandise Authorization (RMA)

Customers shall enclose the "EXOR RMA Service Form" with the returned product. Customers must collect all the information about the problems encountered and note anything abnormal or, print out any on-screen information, and describe the problems on the "EXOR RMA Service Form" and fill in the RMA number apply process.

Customers can send back the faulty products with or without accessories (manuals, cable, etc.) and any components from the card, such as CPU and RAM. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, EXOR is not responsible for the devices/parts.

- Customers are responsible for the safe packaging of defective products, making sure it is durable enough to be resistant against further damage and deterioration during transportation. In case of damages occurred during transportation, the repair is treated as "Out of Warranty."
- Any products returned by EXOR to other locations besides the customers' site will bear an extra charge and will be billed to the customer.

Repair Service Charges for Out-of-Warranty Products

EXOR will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

Repair Service Charges for Out-of-Warranty Products

EXOR will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

System Level

- Component fee: EXOR will only charge for main components such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistor, capacitor.
- Items will be replaced with EXOR products if the original one cannot be repaired. Ex: motherboard, power supply, etc.
- Replace with 3rd party products if needed.
- If RMA goods can not be repaired, EXOR will return it to the customer without any charge.

Board Level

- Component fee: EXOR will only charge for main components, such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistors, capacitors.
- If RMA goods can not be repaired, EXOR will return it to the customer without any charge.



Preface

Warnings

Read and adhere to all warnings, cautions, and notices in this guide and the documentation supplied with the chassis, power supply, and accessory modules. If the instructions for the chassis and power supply are inconsistent with these instructions or the instructions for accessory modules, contact the supplier to find out how you can ensure that your computer meets safety and regulatory requirements.

Cautions

Electrostatic discharge (ESD) can damage system components. Do the procedures only at an ESD workstation. If no such station is available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the computer chassis.


Contact us for your HMI running
sales@vicpas.com
+86-15876525394



Safety Information

Before installing and using the device, note the following precautions:

- Read all instructions carefully.
- Do not place the unit on an unstable surface, cart, or stand.
- Follow all warnings and cautions in this manual.

When replacing parts, ensure that your service technician uses parts supplied by the manufacturer.

Avoid placing the system near water, in direct sunlight, or near a heating source. The system unit does not solely rely for support from the points located on the sides. Firm support from the bottom is highly necessary in order to provide balance stability.

The computer is provided with a battery-powered real-time clock circuit. There is a danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

Installation Recommendations

Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.

Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:

- A Phillips screwdriver
- A flat-tipped screwdriver
- A grounding strap
- An anti-static pad

Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nose pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.





Preface

Safety Precautions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep equipment away from humidity.
6. Do not drop equipment on a stable surface during installation. Dropping it or placing it on an unstable surface may cause damage.
7. Do not place equipment in an area with openings on the enclosure are for air convection to protect the equipment from overheating. DO NOT COVER THE OPENINGS.
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Place the power cord in a way so that people will not step on it. Do not place anything on top of the power cord. Use a power cord that has been approved for use with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
10. All cautions and warnings on the equipment should be noted.

11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
 - a. The power cord or plug is damaged.
 - b. Liquid has penetrated into the equipment.
 - c. The equipment has been exposed to moisture.
 - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
 - e. The equipment has been dropped and damaged.
 - f. The equipment has obvious signs of breakage.
15. Do not place heavy objects on the equipment.
16. The unit uses a three-wire ground cable which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace your obsolete outlet.
17. CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.



Preface

Technical Support and Assistance

- 1. For the most updated information of EXOR products, visit EXOR's website at www.exorint.it
- 2. For technical issues that require contacting our technical support team or sales representative, please have the following information ready before calling:
 - Product name and serial number
 - Detailed information of the peripheral devices
 - Detailed information of the installed software (operating system, application software, etc.)
 - Complete description of the problem
 - Exact wordings of the error messages
- 3. CompactFlash: Turn off the unit's power before inserting or removing a CompactFlash storage card.

Conventions Used in this Manual



Warning:

Information about certain situations, which if not observed, can cause personal injury. This will prevent injury to yourself when performing a task.



Caution:

Information to avoid damaging components or losing data.



Note:

Provides additional information to complete a task easily.



Everything for your HMI running

1. HMI running

2. Maintenance: to keep the unit clean, use only approved cleaning products or clean with a dry cloth.

3. CompactFlash: Turn off the unit's power before inserting or removing a CompactFlash storage card.

sales@vicpas.com

+86-15876525394



Preface

Package Contents

Before continuing, verify that the package you received is complete. Your package should have all the items listed in the table.

eTOP-EPC 1930T/eTOP-EPC 1931T

Item	Description	Qty
1	PS/2 Y Cable	1
2	Panel Mount Kit	14
3	Touch Pen	1
4	DC Power Cable	1
5	Flat Head for HDD Installation	4
6	Panel Mount Hole Block	14

eTOP-EPC 1730T/eTOP-EPC 1731T

Item	Description	Qty
1	PS/2 Y Cable	1
2	Panel Mount Kit	12
3	Touch Pen	1
4	DC Power Cable	1
5	Flat Head for HDD Installation	4
6	Panel Mount Hole Block	12

eTOP-EPC 1530T/eTOP-EPC 1531T

Item	Description	Qty
1	PS/2 Y Cable	1
2	Panel Mount Kit	12
3	Touch Pen	1
4	DC Power Cable	1
5	Flat Head for HDD Installation	4
6	Panel Mount Hole Block	12

eTOP-EPC 1230T/eTOP-EPC 1231T/eTOP-EPC 1235T

Item	Description	Qty
1	PS/2 Y Cable	1
2	Panel Mount Kit	12
3	Touch Pen	1
4	DC Power Cable	1
5	Flat Head for HDD Installation	4
6	Panel Mount Hole Block	12



Note: Package contents may vary depending on your country region, some items may be optional. Please contact your local distributor for more information.

Preface



Cable



Everything for your HMI running

✉ sales@vicpas.com

☎ +86-15876525394



Panel Mount Kit
(eTOP-EPC 1930T/eTOP-EPC 1931T)



Panel Mount Kit
(eTOP-EPC 1730T/eTOP-EPC 1731T/eTOP-EPC 1530T/eTOP-EPC 1531T/eTOP-EPC 1230T/eTOP-EPC 1231T/eTOP-EPC 1235T)



Panel Mount Hole Block
(eTOP-EPC 1930T/eTOP-EPC1 931T)



Touch Pen



DC Power Cable



Panel Mount Hole Block
(eTOP-EPC 1730T/eTOP-EPC 1731T/eTOP-EPC 1530T/eTOP-EPC 1531T/eTOP-EPC 1230T/eTOP-EPC 1231T/eTOP-EPC 1235T)



Flat Head Screw



Ordering Information

The following information below provides ordering information for eTOP-EPC series.

• Barebone

eTOP-EPC 1930T

- 19" SXGA LED Backlight Touch Panel PC, Intel® Atom™ D2550
- 1.86 GHz, touch screen, 1GB DDR3, 2x RS232/422/485

eTOP-EPC 1931T

- 19" SXGA LED Backlight Touch Panel PC, Intel® Atom™ D2550
- 1.86 GHz, touch screen, 1GB DDR3, 2x RS232/422/485 and 4/4 DI/O
- with isolated protection, 2x RS232, 2x2 GPIO, Brightness adjustment

eTOP-EPC 1730T

- 17" SXGA CCFL Backlight Touch Panel PC, Intel® Atom™ D2550
- 1.86 GHz, touch screen, 1GB DDR3, 2x RS232/422/485

eTOP-EPC 1731T

- 17" SXGA CCFL Backlight Touch Panel PC, Intel® Atom™ D2550
- 1.86 GHz, touch screen, 1GB DDR3, 2x RS232/422/485 and 4/4 DI/O
- with isolated protection, 2x RS232, 2x2 GPIO, Brightness adjustment
- buttons

eTOP-EPC 1530T

- 15" XGA LED Backlight Touch Panel PC, Intel® Atom™ D2550
- 1.86 GHz, touch screen, 1GB DDR3, 2x RS232/422/485

eTOP-EPC 1531T

- 15" XGA LED Backlight Touch Panel PC, Intel® Atom™ D2550
- 1.86 GHz, touch screen, 1GB DDR3, 2x RS232/422/485 and 4/4 DI/O
- with isolated protection, 2x RS232, 2x2 GPIO, Brightness adjustment
- buttons

eTOP-EPC 1230T

- 12.1" SVGA LED Backlight Touch Panel PC, Intel® Atom™ D2550
- 1.86 GHz, touch screen, 1GB DDR3, 2x RS232/422/485

eTOP-EPC 1231T

- 12.1" SVGA LED Backlight Touch Panel PC, Intel® Atom™ D2550
- 1.86 GHz, touch screen, 1GB DDR3, 2x RS232/422/485 and 4/4 DI/O
- with isolated protection, 2x RS232, 2x2 GPIO, Brightness adjustment
- buttons

eTOP-EPC 1235T

- 12.1" XGA LED Backlight Touch Panel PC, Intel® Atom™ D2550
- 1.86 GHz, touch screen, 1GB DDR3, 2x RS232/422/485

• Optional


- 12V, 60W AC/DC power adapter w/o power cord

Everything for your IMI running
VICPAS
sales@vicpas.com
+86-15876525394

CHAPTER 1: PRODUCT INTRODUCTION

eTOP-EPC 1230T/1231T/1235T

Overview



Key Features

- 4:3 12.1" SVGA Fanless LED Panel Computer (eTOP-EPC 1230T/1231T)
- 4:3 12.1" XGA Fanless LED Panel Computer (eTOP-EPC 1235T)
- Intel® Atom™ D2550, Dual Core, Low Consumption CPU
- Flush Panel by 5-wire Touch Screen
- Dual GbE/ 2nd display-VGA/ Line-in/ Line-out/ MIC-in/ PS2 KB/MS
- USB x4/ 2x mini-PCIe sockets/ 1x CFast/ 2x RS232/ 422/ 485
- Optional 3.5G/ Wi-Fi Module / 2.5" HDD/ 2x COMs / GPIO / DIO
- DDR3 1GB/ 2.5" HDD Bracket
- IP65 Compliant Front Panel
- Mounting Support: Panel/ Wall/ Stand/ VESA 100mm x 100mm
- Wide Range Power Input 12V~30V DC



Specifications

Panel

eTOP-EPC 1230T/eTOP-EPC 1231T

- LED Size: 12.1", 4:3
- Resolution: SVGA 800x600
- Luminance: 450cd/m2
- Contrast ratio: 700
- LCD color: 16.2M
- Viewing Angle: 65(U), 75(D), 80(L), 80(R)
- Backlight: LED
- Resolution: 1235T
- LED Size: 12.1", 4:3
- Resolution: XGA 1024x768
- Luminance: 500cd/m2
- Contrast ratio: 700
- LCD color: 16.2M
- Viewing Angle: 80(U), 80(D), 80(L), 80(R)
- Backlight: LED



Touch Screen

- 5-wire resistive (flush panel type)
- Light transmission: 80%
- Interface: USB

System

- CPU: On-board Intel® Atom™ Dual Core processor D2550, 1.86GHz, 1M L2 Cache
- BIOS: AMI BIOS

- System chipset: Intel® NM10 Express chipset
- System memory: 2x 204-pin DDR3 SO-DIMM socket, 1G DDR3 (Default), support up to 4GB DDR3-800/1066, Non-ECC and un-buffered
- Storage Device:
 - 1x external locked CFast socket
 - 1x hard drive bay: optional 1x 2.5" SATA HDD or 1x SATA DOM
- Watchdog timer: Watchdog timeout can be programmed by software from 1 second to 255 seconds and from 1 minute to 255 minutes (Tolerance 15% under room temperature 25°C)
- H/W status monitor: Monitoring system temperature, and voltage
- Expansion: 2x mini-PCIe sockets (support optional Wi-Fi or 3.5G module)
- Panel backlight control button: Increase brightness / decrease brightness / Backlight On/Off (For ETOP-EPC1231T only)

Rear I/O

- Ethernet: 2x RJ45
- 2nd display VGA port: 1x DB15
- Audio port: 1x Line out; 1x Line in; 1x MIC-in
- USB: 4x USB 2.0
- PS2 keyboard/ mouse
- Power switch / Reset button
- COM #1: RS232/422/485 w/RI or 5V selection
- COM #2: RS232/422/485 w/RI or 12V selection



Chapter 1: Product Introduction

For eTOP-EPC1231T only

DIO w/ 2.5kv isolated:

4x Digital Input (Source type)

– Input Voltage (Dry Contact): Logic 0: Close to GND

– Logic 1: Open

– Input Voltage: Logic 0: 3V max

– Logic 1: +5V ~ +30V

4x Digital Output (Sink type)

– Output Voltage: 3.6V ~ 5V

– Sink current: 200 mA max. per channel

GPIO: 3 digital in / 2x digital out

CC RS232/422/485 w/ 2.5kv isolated

CC RS232/422/485 w/ 2.5kv isolated

CC RS232 w/ RI or 5V selection

CC RS232 w/ RI or 12V selection



Audio codec: Realtek ALC886-GR

Audio interface: Line out/Line in/MIC-in Audio Jack

Ethernet

- LAN chip: dual Intel® 82574L Gigabit LAN
- Ethernet interface: 10/100/1000 Based-Tx Ethernet compatible

Mechanical & Environment

- Color: pantone black\RAL 15 00 front bezel w/ Pantone 400C\RAL 090 80 10 metal style membrane
- IP protection: IP65 front
- Mounting: panel/ wall/ stand/ VESA 100mm x 100mm

- Power input: 12V~ 30V DC
- Power adapter: Optional AC to DC power adaptor (+12V, 60W)
- Vibration:
 - IEC 68 2-64 (w/ HDD)
 - 1Grms @ sine, 5~500Hz, 1hr/axis (HDD Operating)
 - 2Grms @ sine, 5~500Hz, 1hr/axis (CFast Operating)
 - 2.2Grms @ random condition, 5~500Hz, 0.5hr/axis (Non-operating)
- Shock:
 - IEC 68 2-27
 - HDD: 20G@wall mount, half sine, 11ms
 - Operating temperature: -5°C to 60°C
 - Storage temperature: -20°C to 75°C
 - Operating humidity: 10%~90% relative humidity, non-condensing
Limits to be at 90% RH at max 50°C
- Dimension: 317 x 243 x 65.89mm
- Weight: 3.9 Kg

Certifications

- CE approval

eTOP-EPC 1530T/1531T



Key Features

- 4:3 15" XGA Fanless LED Panel Computer
- Intel® Atom™ D2550, Dual Core, Low Consumption CPU
- Flush Panel by 5-wire Touch Screen
- Dual GbE/ 2nd display-VGA/ Line-in/ Line-out/ MIC-in/ PS2 KB/MS
- USB x4/ 2x mini-PCIe sockets/ 1x CFast/ 2x RS232/ 422/ 485
- Optional 3.5G / Wi-Fi Module / 2.5" HDD / 2x COMs / GPIO / DIO
- DDR3 1GB / 2.5" HDD Bracket
- IP65 Compliant Front Panel
- Mounting Support: Panel/ Wall/ Stand/ VESA 100mm x 100mm
- Wide Range Power Input 12V ~ 30V DC

VICPAS®
everything for your ML run
sales@vicpas.com
+86-15876525394

- Viewing Angle: 60(U), 80(D), 80(L), 80(R)
- Backlight: LED

- On-board Intel® Atom™ Dual Core processor D2550, 1.86GHz, 1GB Cache
- BIOS: AMI BIOS
- System chipset: Intel® NM10 Express chipset
- System memory: 2x 204-pin DDR3 SO-DIMM socket, 1G DDR3 (Default), support up to 4GB DDR3-800/1066, Non-ECC and un-buffered
- Storage Device:
 - 1x external locked CFast socket
 - 1x hard drive bay: optional 1x 2.5" SATA HDD or 1x SATA DOM
- Watchdog timer: Watchdog timeout can be programmed by software from 1 second to 255 seconds and from 1 minute to 255 minutes (Tolerance 15% under room temperature 25°C)

- DIO w/ 2.5kv isolated:
 - 4x Digital Input (Source type)
 - Input Voltage (Dry Contact): Logic 0: Close to GND
 - Logic 1: Open
 - Input Voltage: Logic 0: 3V max
 - Logic 1: +5V ~ +30V
 - 4x Digital Output (Sink type)
 - Output Voltage: 3.6V ~ 5V
 - Sink current: 200 mA max. per channel



Chapter 1: Product Introduction

- GPIO: 2x digital in/ 2x digital out
- COM #1: RS232/422/485 w/ 2.5kv isolated
- COM #2: RS232/422/485 w/ 2.5kv isolated
- COM #3: RS232 w/ RI or 5V selection
- COM #4: RS232 w/ RI or 12V selection

Audio

- AC97 codec: Realtek ALC886-GR
- Audio interface: Line out/Line in/MIC-in Audio Jack


Everything for your HMI running
+86-15876525394
sales@vicpas.com

Ethernet interface: dual Intel® 82574L Gigabit LAN
Ethernet interface: 10/100/1000 Based-Tx Ethernet compatible

Medical & Environment

- CMA Pantone blackRAL 15 00 front bezel w/ Pantone 400CIRAL
- 0.010 metal style membrane
- Protection: IP65 front
- Mounting: panel/ wall/ stand/ VESA 100mm x 100mm
- Power input: 12V~ 30V DC
- Power adapter: Optional AC to DC power adaptor (+12V, 60W)
- Vibration:
 - IEC 68 2-64 (w/ HDD)
 - 1Grms @ sine, 5~500Hz, 1hr/axis (HDD Operating)
 - 2Grms @ sine, 5~500Hz, 1hr/axis (CFast Operating)
 - 2.2Grms @ random condition, 5~500Hz, 0.5hr/axis (Non-operating)
- Shock:
 - IEC 68 2-27
 - HDD: 20G@wall mount, half sine, 11ms
- Operating temperature: -5°C to 60°C

- Storage temperature: -20°C to 75°C
- Operating humidity: 10%~90% relative humidity, non-condensing
Limits to be at 90% RH at max 50°C
- Dimension: 384.37 x 309.95 x 63.2 mm
- Weight: 5 Kg

Certifications

- CE approval

eTOP-EPC 1730T/1731T

Key Features

- 4:3 17" SXGA Fanless Panel Computer
- Intel® Atom™ D2550, Dual Core, Low Consumption CPU
- Flush Panel by 5-wire Touch Screen
- Dual GbE/ 2nd display-VGA/ Line-in/ Line-out/ MIC-in/ PS2 KB/MS
- USB x4/ 2x mini-PCIe sockets/ 1x CFast/ 2x RS232/ 422/ 485
- Optional 3.5G / Wi-Fi Module / 2.5" HDD / 2x COMs / GPIO / DIO
- DDR3 1GB / 2.5" HDD Bracket
- IP65 Compliant Front Panel
- Mounting Support: Panel/ Wall/ Stand/ VESA 100mm x 100mm
- Wide Range Power Input 12V~ 30V DC





Specifications

Panel


- LED Size: 17", 4:3
- Resolution: SXGA 1280x1024
- Luminance: 380cd/m²
- Contrast ratio: 1000
- LCD color: 16.7M
- Viewing Angle: 80(U), 80(D), 85(L), 85(R)
- Backlight: CCFL

Rear I/O

- Ethernet: 2x RJ45
- 2nd display VGA port: 1x DB15
- Audio port: 1x Line out; 1x Line in; 1x MIC-in
- USB: 4x USB 2.0
- PS2 keyboard/ mouse
- Power switch
- Reset button
- COM #1: RS232/422/485 w/RI or 5V selection
- COM #2: RS232/422/485 w/RI or 12V selection

For ETOP-EPC1731T only

- DIO w/ 2.5kv isolated:
- 4x Digital Input (Source type)
 - Input Voltage (Dry Contact): Logic 0: Close to GND
 - Logic 1: Open
- Input Voltage: Logic 0: 3V max
- Logic 1: +5V ~ +30V
- 4x Digital Output (Sink type)
 - Output Voltage: 3.6V ~ 5V
 - Sink current: 200 mA max. per channel


Evening for your system running
sales@vicpas.com
+86-15876525394

On-board Intel® Atom™ Dual Core processor D2550, 1.86GHz, 1MB Cache

BIOS: AMI BIOS

System chipset: Intel® NM10 Express chipset

System memory: 2x 204-pin DDR3 SO-DIMM socket, 1G DDR3 (Default), support up to 4GB DDR3-800/1066, Non-ECC and un-buffered

Storage Device:

- 1x external locked CFast socket
- 1x hard drive bay: optional 1x 2.5" SATA HDD or 1x SATA DOM

Watchdog timer: Watchdog timeout can be programmed by software from 1 second to 255 seconds and from 1 minute to 255 minutes (Tolerance 15% under room temperature 25°C)

H/W status monitor: Monitoring system temperature, and voltage



Chapter 1: Product Introduction

- GPIO: 2x digital in/ 2x digital out
- COM #1: RS232/422/485 w/ 2.5kv isolated
- COM #2: RS232/422/485 w/ 2.5kv isolated
- COM #3: RS232 w/ RI or 5V selection
- COM #4: RS232 w/ RI or 12V selection

Audio

- AC97 codec: Realtek ALC886-GR
- Audio interface: Line out/Line in/MIC-in Audio Jack


Everything for your HMI running
+86-15876525394
sales@vicpas.com

Electrical & Environment

- CPU: dual Intel® 82574L Gigabit LAN
- Ethernet interface: 10/100/1000 Based-Tx Ethernet compatible
- Case: Pantone blackRAL 15 00 front bezel w/ Pantone 400CIRAL 100 metal style membrane
- Protection: IP65 front
- Mounting: panel/ wall/ stand/ VESA 100mm x 100mm
- Power input: 12V~ 30V DC
- Power adapter: Optional AC to DC power adaptor (+12V, 60W)
- Vibration:
 - IEC 68 2-64 (w/ HDD)
 - 1Grms @ sine, 5~500Hz, 1hr/axis (HDD Operating)
 - 2Grms @ sine, 5~500Hz, 1hr/axis (CFast Operating)
 - 2.2Grms @ random condition, 5~500Hz, 0.5hr/axis (Non-operating)
- Shock:
 - IEC 68 2-27
 - HDD: 20G@wall mount, half sine, 11ms

- Operating temperature: -5°C to 50°C
- Storage temperature: -20°C to 75°C
- Operating humidity: 10%~90% relative humidity, non-condensing
Limits to be at 90% RH at max 50°C
- Dimension: 410.4 x 340.4 x 75.79 mm
- Weight: 6.6 Kg

Certifications

- CE approval



eTOP-EPC 1930T/1931T



Key Features

- 4:3 19" SXGA Fanless LED Panel Computer
- Intel® Atom™ D2550, Dual Core, Low Consumption CPU
- Flush Panel by 5-wire Touch Screen
- Dual GbE/ 2nd display-VGA/ Line-in/ Line-out/ Mic-in/ PS2 KB/MS
- USB x4/ 2x mini-PCIe sockets/ 1x CFast/ 2x RS232/ 422/ 485
- Optional 3.5G / Wi-Fi Module / 2.5" HDD / 2x COMs / GPIO / DIO
- DDR3 1GB / 2.5" HDD Bracket
- IP65 Compliant Front Panel
- Mounting Support: Panel/ Wall/ Stand/ VESA 100mm x 100mm
- Wide Range Power Input 12V~ 30V DC



Specifications

Panel

- LED Size: 19", 4:3
- Resolution: SXGA 1280x1024
- Luminance: 350cd/m2
- Contrast ratio: 1000
- LCD color: 16.7M
- Viewing Angle: 80(U), 80(D), 85(L), 85(R)
- Backlight: LED

- Expansion: 2x mini-PCIe sockets (support optional WiFi or 3.5G module)
- Panel backlight control button: Increase brightness / decrease brightness / Backlight On/Off (For eTOP-EPC1931T only)

Rear I/O

- Ethernet: 2x RJ45
- 2nd display VGA port: 1x DB15
- Audio port: 1x Line out; 1x Line in; 1x MIC-in
- USB: 4x USB 2.0
- PS2 keyboard/ mouse
- Power switch
- Reset button
- COM #1: RS232/422/485 w/RI or 5V selection
- COM #2: RS232/422/485 w/RI or 12V selection

For eTOP-EPC1931T only

- DIO w/ 2.5kv isolated:
 - 4x Digital Input (Source type)
 - Input Voltage (Dry Contact): Logic 0: Close to GND
 - Logic 1: Open
 - Input Voltage: Logic 0: 3V max
 - Logic 1: +5V ~ +30V
- 4x Digital Output (Sink type)
 - Output Voltage: 3.6V ~ 5V
 - Sink current: 200 mA max. per channel



- On-board Intel® Atom™ Dual Core processor D2550, 1.86GHz, 1MB Cache
- BIOS: AMI BIOS
- System chipset: Intel® NM10 Express chipset
- System memory: 2x 204-pin DDR3 SO-DIMM socket, 1G DDR3 (Default), support up to 4GB DDR3-800/1066, Non-ECC and un-buffered
- Storage Device:
 - 1x external locked CFast socket
 - 1x hard drive bay: optional 1x 2.5" SATA HDD or 1x SATA DOM
- Watchdog timer: Watchdog timeout can be programmed by software from 1 second to 255 seconds and from 1 minute to 255 minutes (Tolerance 15% under room temperature 25°C)
- HW status monitor: Monitoring system temperature, and voltage



Chapter 1: Product Introduction

- GPIO: 2x digital in/ 2x digital out
- COM #1: RS232/422/485 w/ 2.5kv isolated
- COM #2: RS232/422/485 w/ 2.5kv isolated
- COM #3: RS232 w/ RI or 5V selection
- COM #4: RS232 w/ RI or 12V selection

Audio

- AC97 codec: Realtek ALC886-GR
- Audio interface: Line out/Line in/MIC-in Audio Jack


Everything for your HMI running
+86-15876525394
sales@vicpas.com

• Ethernet interface: dual Intel® 82574L Gigabit LAN
• Ethernet interface: 10/100/1000 Based-Tx Ethernet compatible

Medical & Environment

- Casing: Pantone blackRAL 15 00 front bezel w/ Pantone 400CIRAL 00 10 metal style membrane
- Protection: IP65 front
- Mounting: panel/ wall/ stand/ VESA 100mm x 100mm
- Power input: 12V ~ 30V DC
- Power adapter: Optional AC to DC power adaptor (+12V, 60W)
- Vibration:
 - IEC 68 2-64 (w/ HDD)
 - 1Grms @ sine, 5~500Hz, 1hr/axis (HDD Operating)
 - 2Grms @ sine, 5~500Hz, 1hr/axis (CFast Operating)
 - 2.2Grms @ random condition, 5~500Hz, 0.5hr/axis (Non-operating)
- Shock:
 - IEC 68 2-27
 - HDD: 20G@wall mount, half sine, 11ms

- Operating temperature: -5°C to 50°C
- Storage temperature: -20°C to 75°C
- Operating humidity: 10%~90% relative humidity, non-condensing
Limits to be at 90% RH at max 50°C
- Dimension: 457.64 x 379.24 x 61.25 mm
- Weight: 6.5 Kg


Certifications

- CE approval



Knowing Your eTOP-EPC Series

Rear Top



Antenna holes for optional 3.5G/ WiFi/ Bluetooth

The 3 external antenna holes are used to mount and connect optional 3.5G/ WiFi/ Bluetooth antennas.

CFast Card Socket

Used to insert a CFast card.

Power Switch

Press to power-on or power-off the panel PC.

Panel Backlight Control Buttons (eTOP-EPC1231T/eTOP-EPC1531T/eTOP-EPC1731T/eTOP-EPC1931T only)

Backlight On/Off

Press to turn-on or turn-off the display

Increase Brightness

Press to increase brightness of the screen.

Decrease Brightness


Press to decrease brightness of the screen.



8 brightness level available:
30%, 40%, 50%, 60%, 70%, 80%, 90% and 100%



Rear Bottom



Line-in

Used to connect an audio device as sound source.

Mic-in

Used to connect an external microphone.

Line-out

Used to connect a headphone or a speaker.

LAN 1 and LAN 2

Used to connect the system to a local area network. LAN1 supports Wake up on LAN.

USB

Used to connect USB 2.0/1.1 devices.

COM 1 and COM 2

These COM ports support RS232/422/485 compatible series device by BIOS setting.

COM1 of eTOP-EPC 1230T/1235T/1530T/1730T/1930T supports 5V or RI by Jumper setting.

COM2 of eTOP-EPC 1230T/1235T/1530T/1730T/1930T supports 12V or RI by Jumper setting.

eTOP-EPC 1231T/1531T/1731T/1931T have 2.5kV isolated protection.

PS/2 KB/MS

Used to connect a PS/2 keyboard and a PS/2 mouse

Reset Button

Press this button to restart the system.

VGA

Used to connect an analog VGA monitor.

12V-30V DC Input

Used to plug a DC power cord.



Rear (eTOP-EPC 1230T/1235T/1530T/1730T/1930T only)




VESA Mounting Holes

These are mounting holes for VESA mount (100x100mm)



Rear (eTOP-EPC 1231T/1531T/1731T/1931T only)



DIO

The digital I/O connector support 4 isolated protection digital input channels and 4 isolated protection digital output channels.
Isolation voltage: 2500 VDC

DI:

- 4x Digital Input (Source Type)
 - Input Voltage (Dry Contact)
 - Logic 0: Close to GND
 - Logic 1: Open
 - Input Voltage (Wet Contact)
 - Logic 0: 3V max.
 - Logic 1: +5V-+30VDC

4x Digital Output (Sink Type)

- Output Voltage: Typical 24VDC, 30VDC max.
 - Logic 0: 0-0.6VDC
 - Logic 1: 3.6-5VDC
- Sink Current: 200mA max. per channel

GPIO

The GPIO connector supports 2 digital input and 2 digital output.

COM3 and COM4

These COM ports support RS232 compatible serial devices.
COM3 supports 5V or RI by Jumper setting.
COM4 supports 12V or RI by Jumper setting.



VESA Mounting Holes

These are mounting holes for VESA mount (100x100mm).




Mechanical Dimensions

eTOP-EPC 1230T/1231T/1235T



VICPAS®
Everything for your HMI running
sales@vicpas.com
+86-15876525394

eTOP-EPC 1530T/1531T





Mechanical Dimensions


eTOP-EPC 1730T/1731T







Everything for your HMI running

 sales@vicpas.com

 +86-15876525394



eTOP-EPC 1930T/1931T





CHAPTER 2: JUMPERS AND CONNECTORS

This chapter describes how to set the jumpers and connectors on the motherboard. Note that information in this chapter applies to eTOP-EPC 1230T/ 1231T/1235T/1530T/1531T/1730T/1731T/1930T/1931T.

Before You Begin

You have a stable, clean working environment. Dust and dirt can damage components and cause a malfunction. Use containers to keep components separated.

Use proper lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:

- A flat-tipped screwdriver
- A set of jewelers screwdrivers
- A grounding strap
- An anti-static pad

- Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nosed pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.
- Before working on internal components, make sure that the power is off. Ground yourself before touching any internal components, by touching a metal object. Static electricity can damage many of the electronic

components. Humid environments tend to have less static electricity than dry environments. A grounding strap is warranted whenever danger of static electricity exists.

Precautions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous.

Follow the guidelines below to avoid damage to your computer or yourself:

- Always disconnect the unit from the power outlet whenever you are working inside the case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Don't flex or stress the circuit board.
- Leave all components inside the static-proof packaging that they shipped with until they are ready for installation. Use correct screws and do not over tighten screws.


 Everything for your HMI running
Sales@vicpas.com
+86-15876525394




Jumper Settings

A jumper is the simplest kind of electric switch. It consists of two metal pins and a cap. When setting the jumpers, ensure that the jumper caps are placed on the correct pins. When the jumper cap is placed on both pins, the jumper is short. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is open.

Refer to the illustrations below for examples of what the 2-pin and 3-pin jumpers look like when they are short (on) and open (off).




Two-Pin Jumpers: Open (Left) and Short (Right)





Locations of the Jumpers and Connectors

Top View






Everything for your HMI running

✉ sales@vicpas.com

☎ +86-15876525394



Bottom View



VICPAS[®].com
Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394



Jumpers and DIP Switch Settings

CMOS Clear Select

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP1




Everything for your HMI running
sales@vicpas.com
+86-15876525394


sales@vicpas.com


+86-15876525394

	Settings
1	Normal
2	Clear BIOS

	Definition
1	NC
2	RTC Power
3	GND

AT/ATX Selection

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP8



Pin	Settings
1-2 On	AT Mode
2-3 On	ATX Mode


2-3 On: default

Pin	Definition
1	AUTO (AT MODE)
2	PWRBT In
3	Manual (ATX MODE)



Dimming Type Select

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: SW2




Everything for your HMI running
sales@vicpas.com
+86-15876525394

SW2-2	Settings	Model
Off	PWM Mode	eTOP-EPC1230T
		eTOP-EPC1231T
		eTOP-EPC1235T
		eTOP-EPC1530T
		eTOP-EPC1531T
		eTOP-EPC1930T
On	Analog Mode	eTOP-EPC1931T
		eTOP-EPC1730T
Off		eTOP-EPC1731T

Default: PWM

Dimming Signal Level Select

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP6



Pin	Settings	Model
1-2 On	3.3V	eTOP-EPC1230T
		eTOP-EPC1231T
		eTOP-EPC1235T
		eTOP-EPC1930T
		eTOP-EPC1931T
2-3 On	5V	eTOP-EPC1530T
		eTOP-EPC1531T
		eTOP-EPC1730T
		eTOP-EPC1731T

Pin	Definition
1	VCC3
2	Power for Dimming
3	VCC5




Chapter 2: Jumpers and Connectors

Panel Resolution Select

Connector type: 4-pin On/Off Switch

Connector location: SW1



VICPAS
Everything for your HMI running
sales@vicpas.com
+86-15876525394

SW1-1	SW1-2	SW1-3	SW1-4	Resolution/Color/Backlight On	Model
ON	ON	ON	ON	800 x 600/6 bits/High	eTOP-EPC1230T eTOP-EPC1231T
OFF	OFF	OFF	ON	800 x 600/8 bits/High	
ON	ON	ON	ON	1024 x 768/6 bits/High	eTOP-EPC1235T eTOP-EPC1530T eTOP-EPC1531T
OFF	OFF	ON	ON	1024 x 768/8 bits/High	
OFF	OFF	ON	ON	1280 x 1024/8 bits/Low	
ON	OFF	OFF	ON	1280 x 1024/8 bits/High	eTOP-EPC1930T eTOP-EPC1931T
ON	OFF	OFF	OFF	1920 x 1080/8 bits/High	



Chapter 2: Jumpers and Connectors

LCD Panel VDD Power Select

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP5




Everything for your HMI running
sales@vicpas.com
+86-15876525394


Settings	Model
3.3V	eTOP-EPC1230T
	eTOP-EPC1231T
	eTOP-EPC1235T
	eTOP-EPC1530T
	eTOP-EPC1531T
5V	eTOP-EPC1730T
	eTOP-EPC1731T
	eTOP-EPC1930T
	eTOP-EPC1931T

1-2 On: default

Pin	Definition
1	VCC3
2	Power for VDD
3	VCC5

Touch 4/5 Wire Select

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP7



Pin	Settings
1-2 On	5 wire
2-3 On	4 wire

1-2 On: default



COM1 RI Pin Power Select
(eTOP-EPC 1230T/eTOP-EPC 1235T/eTOP-EPC 1530T/eTOP-EPC 1730T/
eTOP-EPC 1930T only)

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP12




Everything for your HMI running
sales@vicpas.com
+86-15876525394

Settings	
1	RING
2	+5V

Definition	
1	SP1_RI
2	SP1_PSRI
3	VCC5

COM2 RI Pin Power Select
(eTOP-EPC 1230T/eTOP-EPC 1235T/eTOP-EPC 1530T/eTOP-EPC 1730T/
eTOP-EPC 1930T only)

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP13



Settings	
1-2 On	RING
2-3 On	+12V

1-2 On: default

Definition	
1	SP2_RI
2	SP2_PSRI
3	+12V



COM3 RI Pin Power Select
(eTOP-EPC 1231T/eTOP-EPC 1531T/eTOP-EPC 1731T/eTOP-EPC 1931T only)

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP9




Everything for your HMI running
sales@vicpas.com
+86-15876525394

Settings	
1	RING
2	+5V

Definition	
1	SP3_RI
2	SP3_PSRI
3	VCC5

COM4 RI Pin Power Select
(eTOP-EPC 1231T/eTOP-EPC 1531T/eTOP-EPC 1731T/eTOP-EPC 1931T only)

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP10



Settings	
1-2 On	RING
2-3 On	+12V

1-2 On: default

Definition	
1	SP4_RI
2	SP4_PSRI
3	12V



Connector Pin Definitions

External I/O Interface

12V-30V DC Power Input

Connector type: DC 4-pin DIN power jack with shield
Connector location: CN13


Everything for your HMI running

1 2 3 4

Pin	Settings
1	DC+
2	DC+
3	DC-
4	DC-
5	GND

VGA Port

Connector type: DB-15 port, 15-pin D-Sub
Connector location: VGA1



Pin	Definition	Pin	Definition
1	Red	9	+5V
2	Green	10	GND
3	Blue	11	N/C
4	N/C	12	DDC Data
5	GND	13	HSYNC
6	GND	14	VSYNC
7	GND	15	DDC Clock
8	GND		





Chapter 2: Jumpers and Connectors

PS/2 Keyboard/Mouse Port

Connector type: PS/2, Mini-DIN-6, 2.0mm pitch
2x4 8-pin header, 2.54mm pitch

Connector location: JP4





Everything for your HMI running

✉ sales@vicpas.com

☎ +86-15876525394

External Connector


Settings	
KB_DATA	
MS_DATA	
GND	
VCC5	
KB_CLK	
MS_CLK	

Internal Connector

Pin	Definition	Pin	Definition
1	VCC5	2	VCC5
3	KB_DATA	4	MS_DATA
5	KB_CLK	6	MS_CLK
7	GND	8	GND

COM2 Port: Serial Port RS232/422/485
eTOP-EPC 1230T/eTOP-EPC 1235T/eTOP-EPC 1530T/eTOP-EPC 1730T/
eTOP-EPC 1930T
(Ring or +12V Power for Pin 9)
eTOP-EPC 1231T/eTOP-EPC 1531T/eTOP-EPC 1731T/eTOP-EPC 1931T
(Isolation protection with RS232/422/485)

Connector type: 9-pin D-Sub
Connector location: CN16




RS232

Pin	Definition
1	COM2_DCD
2	COM2_RXD
3	COM2_TXD
4	COM2_DTR
5	COM2_GND
6	COM2_DSR
7	COM2_RTS
8	COM2_CTS
9	COM2_RI (Could be a +12V Power Pin)



RS422


Pin	Definition
1	COM2_TXD-
2	COM2_TXD+
3	COM2_RXD+
4	COM2_RXD-
5	COM2_GND
6	COM2_RTS-
7	COM2_RTS+
8	COM2_CTS+
9	COM2_CTS- (Could be a +12V Power Pin)


Everything for your RS485 running
sales@vicpas.com
+86-15876525394

Pin	Definition
1	COM2_TXD-
2	COM2_TXD+
3	COM2_RXD+
4	Reserve
5	Reserve
6	Reserve
7	Reserve
8	Reserve
9	Reserve (Could be a +12V Power Pin)

COM1 Port: Serial Port RS232/422/485
eTOP-EPC 1230T/eTOP-EPC 1235T/eTOP-EPC 1530T/eTOP-EPC 1730T/
eTOP-EPC 1930T
(Ring or +5V Power for Pin 9)
eTOP-EPC 1231T/eTOP-EPC 1531T/eTOP-EPC 1731T/eTOP-EPC 1931T
(Isolation protection with RS232/422/485)

Connector type: 9-pin D-Sub
Connector location: CN15



RS232

Pin	Definition
1	COM1_DCD: Data Carrier Detect
2	COM1_RXD: Receive Data
3	COM1_TXD: Transmit Data
4	COM1_DTR: Data Terminal Ready
5	COM1_GND
6	COM1_DSR: Data Set Ready
7	COM1_RTS: Request To Send
8	COM1_CTS: Clear To Send
9	COM1_RI: Ring Indicator (Could be a +5V Power Pin)



RS422

Pin	Definition
1	COM1_TXD-; Transmit Data Negative
2	COM1_TXD+; Transmit Data Positive
3	COM1_RXD+; Receive Data Positive
4	COM1_RXD-; Receive Data Negative
5	COM1_GND
6	COM1_RTS-; Request To Send Negative
7	COM1_RTS+; Request To Send Positive
8	COM1_CTS+; Clear To Send Positive
9	COM1_CTS-; Clear To Send Negative (Could be a +5V Power Pin)



Everything for your HM running

sales@vicpas.com

+86-15876525394

RS422

Pin	Definition
1	COM1_TXD-; Transmit Data Negative COM1_RXD-; Receive Data Negative
2	COM1_TXD+; Transmit Data Positive COM1_RXD+; Receive Data Positive
3	Reserve
4	Reserve
5	Reserve
6	Reserve
7	Reserve
8	Reserve
9	Reserve (Could be a +5V Power Pin)

COM3 Port and Connector: Serial Port RS232
eTOP-EPC 1231T/eTOP-EPC 1531T/eTOP-EPC 1731T/eTOP-EPC 1931T
Only
(Ring or +5V Power for Pin 9)

Connector type: 9-pin D-Sub
2x5 10-pin header, 2.0mm pitch
Connector location: CN9



RS232


Pin	Definition
1	COM3_DCD
2	COM3_RXD
3	COM3_TXD
4	COM3_DTR
5	COM3_GND
6	COM3_DSR
7	COM3_RTS
8	COM3_CTS
9	COM3_RI (Could be a +5V Power Pin)
10	GND



Chapter 2: Jumpers and Connectors

COM4 Port and Connector: Serial Port RS232
eTOP-EPC 1231T/eTOP-EPC 1531T/eTOP-EPC 1731T/eTOP-EPC 1931T
Only
(Ring or +12V Power for Pin 9)


Connector type: 9-pin D-Sub
2x5 10-pin header, 2.0mm pitch
Connector location: CN10




Everything for your HMI running RS232

 sales@vicpas.com

 +86-15876525394



USB Ports
Connector type: Dual USB port
Connector location: USB1 and USB2



USB1

Pin	Definition	Pin	Definition
1	VCC5	5	VCC5
2	USB0-	6	USB1-
3	USB0+	7	USB1+
4	GND	8	GND

USB2


Pin	Definition	Pin	Definition
1	VCC5	5	VCC5
2	USB2-	6	USB3-
3	USB2+	7	USB3+
4	GND	8	GND

Pin	Definition
1	COM4_DCD
2	COM4_RXD
3	COM4_TXD
4	COM4_DTR
5	COM4_GND
6	COM4_DSR
7	COM4_RTS
8	COM4_CTS
9	COM4_RI (Could be a +12V Power Pin)
10	GND



LAN2 Port

Connector type: RJ45 port with LEDs
Connector location: LAN2



VICPAS
Everything for your LAN running
sales@vicpas.com
+86-15876525394

Act	Status
Yellow blinking	Data activity
Off	No activity


Link	Status
Steady green	1000M link
Steady orange	100M link
Off	10M or no link

Pin	Definition	Pin	Definition
1	LAN2M0+	5	LAN2M2-
2	LAN2M0-	6	LAN2M1-
3	LAN2M1+	7	LAN2M3+
4	LAN2M2+	8	LAN2M3-

LAN1 Port

Support Wake on LAN (WOL)

Connector type: RJ45 port with LEDs
Connector location: LAN1



Act	Status
Yellow blinking	Data activity
Off	No activity

Link	Status
Steady green	1000M link
Steady orange	100M link
Off	10M or no link

Pin	Definition	Pin	Definition
1	LAN1M0+	5	LAN1M2-
2	LAN1M0-	6	LAN1M1-
3	LAN1M1+	7	LAN1M3+
4	LAN1M2+	8	LAN1M3-



Chapter 2: Jumpers and Connectors

Line-out Jack

Connector type: 3.5mm Earphone Jack
Connector location: CN14



Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394

Pin		Definition
1		LOUT_R
2		JD
3		NC
4		LOUT_L
5		GND
6		GND




Chapter 2: Jumpers and Connectors

Internal Connectors

LVDS Channel 1

Connector type: 2x10 20-pin header, 1.25mm pitch
Connector location: CN5




VICPAS
Everything for your HMI running
sales@vicpas.com
+86-15876525394

Pin	Definition	Pin	Definition
1	NC	11	LVDS_CLK1+(Odd)
2	NC	12	LVDS_DAT1-(Odd)
3	VDD	13	LVDS_CLK1-(Odd)
4	LVDS_DAT0+(Odd)	14	GND
5	LVDS_DAT3+(Odd)	15	GND
6	LVDS_DAT0-(Odd)	16	+12V
7	LVDS_DAT3-(Odd)	17	LVDS_DAT2+(Odd)
8	VDD	18	+12V
9	GND	19	LVDS_DAT2-(Odd)
10	LVDS_DAT1+(Odd)	20	GND

LVDS Channel 2

Connector type: 2x10 20-pin header, 1.25mm pitch
Connector location: CN4




Pin	Definition	Pin	Definition
1	NC	11	LVDS_CLK2+(Even)
2	NC	12	LVDS_DAT5-(Even)
3	VDD	13	LVDS_CLK2-(Even)
4	LVDS_DAT4+(Even)	14	GND
5	LVDS_DAT7+(Even)	15	GND
6	LVDS_DAT4-(Even)	16	+12V
7	LVDS_DAT7-(Even)	17	LVDS_DAT6+(Even)
8	VDD	18	+12V
9	GND	19	LVDS_DAT6-(Even)
10	LVDS_DAT5+(Even)	20	GND




Chapter 2: Jumpers and Connectors

Panel Backlight Connector

Connector type: 1x7 7-pin header JST, 2.5mm pitch
Connector location: J7





Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394

Definition	Pin	Definition
VCC5	5	GND
12V	6	GND
12V	7	BKLEN
BKCTRL		

Touch Sensor Connector

Connector type: 1x5 5-pin header JST, 2.5mm pitch
Connector location: J9




Pin	4-wire	5-wire
1	Left	LL (L)
2	Top	UL (Y)
3	N/A	Sense (S)
4	Right	LR (X)
5	Bottom	UR (H)




Chapter 2: Jumpers and Connectors

USB Connector

Connector type: 1x6 6-pin header J5T, 2.5mm pitch
Connector location: J8





Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394



Pin	Definition
1	+5V
2	HUBUSB DM1-
3	HUBUSB DP1+
4	HUBUSB DM2-
5	HUBUSB DP2+
6	GND

Bluetooth Connector

Connector type: 1x10 10-pin header, 1.0mm pitch
Connector location: J6




Pin	Definition	Pin	Definition
1	GND	6	NC
2	HUBUSB_DP3+	7	NC
3	HUBUSB_DM3-	8	3.3V
4	NC	9	NC
5	NC	10	GND




Chapter 2: Jumpers and Connectors

SATA Connector

Connector type: Standard Serial ATAII 7P (1.27mm, SATA-M-180)
Connector location: CN3




Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394

Pin	Definition
1	GND
2	TX0+
3	TX0-
4	GND
5	RX0-
6	RX0+
7	GND

SATA DOM Power Connector

Connector type: 1x2 2-pin header, JST 2.5mm pitch
Connector location: J2



Pin	Definition
1	+5V
2	GND



Chapter 2: Jumpers and Connectors

Line-in/Mic-in Connector

Connector type: 2x4 8-pin header, 2.54mm pitch
Connector location: JP11




Mic-in

Definition	Pin	Definition
LINE IN_LP	2	MIC_L3
LINE IN_JD	4	MIC_JD
GND	6	GND
LINE IN_RP	8	MIC_R3

Speaker-out Connector

Connector type: 1x4 4-pin header, 2.54mm pitch
Connector location: J12



Pin	Definition
1	OUT-L+
2	OUT-L-
3	OUT-R+
4	OUT-R-




Chapter 2: Jumpers and Connectors

GPIO Connector
(eTOP-EPC1931T/eTOP-EPC1721T/eTOP-EPC1531T/eTOP-EPC1231T only)

Connector type: 2x5 10-pin header, 2.0mm pitch

DB15 male 10-pin

Connector location: JP2



GPIO Connector

Pin	Definition	Pin	Definition
1	+5V	2	GND
3	GPIO22 (GPO)	4	GPIO20 (GPI)
5	GPIO23 (GPO)	6	GPIO21 (GPI)
7	NC	8	NC
9	NC	10	NC

External Connector

Pin	Definition	Pin	Definition
1	+5V	2	GPIO20 (GPI)
3	GPIO21 (GPI)	4	NC
5	NC	6	GND
7	GPIO22 (GPO)	8	GPIO23 (GPO)
9	NC	10	NC




DIO Connector

Connector type: 2x8 16-pin header, 2.0mm pitch

DB15 male 15-pin

Connector location: CN2



VICPAS
Everything for your HMI running
sales@vicpas.com
+86-15876525394

Internal Connector

Pin	Definition	Pin	Definition
1	DI1	2	DO1
3	DI2	4	DO2
5	DI3	6	DO3
7	DI4	8	DO4
9	NC	10	NC
11	COM	12	NC
13	GND	14	GND
15	GND	16	GND

DI1~DI4: Isolated digital input pins
DO1~DO4: Isolated digital output pins
COM: Common pin for connecting inductive loads of isolated output channels DO1~DO4
GND: Isolated ground

External Connector


Pin	Definition	Pin	Definition
1	DI1	2	DI2
3	DI3	4	DI4
5	GND	6	COM
7	NC	8	NC
9	DO1	10	DO2
11	DO3	12	DO4
13	GND	14	GND
15	GND		




Chapter 2: Jumpers and Connectors

Power/HDD LED Indicator Connector

Connector type: 1x5 5-pin header J5T, 2.0mm pitch
Connector location: J10





Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394



Pin	Definition
1	HDD_GND
2	HDD_PWR
3	PWR_GND
4	5VSB
5	VCC5

Backlight Control Input Connector

Connector type: 1x4 4-pin header J5T, 2.0mm pitch
Connector location: J5





Pin	Definition
1	GND
2	Tact Switch input
3	PIR IN
4	VCC3



Dimming Control Button Connector

Connector type: 1x5 5-pin header JST, 2.0mm pitch
Connector location: J4





Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394



Pin	Definition
1	GND
2	Decreased input
3	Increased input
4	Light sensor input
5	VCC3

SIM Card Slot

Connector location: CN8




Pin	Definition	Pin	Definition
C1	UIM_PWR	C5	GND
C2	UIM_RST	C6	UIM_VCCP
C3	UIM_CLK	C7	UIM_DAT



Mini-PCIe Slot

Connector location: CN6



VICPAS®

.com

Everything for your HMI running

sales@vicpas.com

+86-15876525394

Definition	Pin	Definition
WAKE0#	2	+3.3V_MINI
NC	4	GND
NC	6	+1.5V_MINI
PCIE_CLKREQ	8	SIM_PWR
GND	10	SIM_DAT
GPP_CLK1-	12	SIM_CLK
GPP_CLK1+	14	SIM_RST
GND	16	SIM_VCCP
NC	18	GND
NC	20	MINICARD1_DIS#
GND	22	PCIE_RST#
PCIE_RX2-	24	+3.3V_MINI
PCIE_RX2+	26	GND


Pin	Definition	Pin	Definition
27	GND	28	+1.5V_MINI
29	GND	30	SMB_CLK
31	PCIE_TX3-	32	SMB_DAT
33	PCIE_TX3+	34	GND
35	GND	36	USB6-
37	GND	38	USB6+
39	+3.3V_MINI	40	GND
41	+3.3V_MINI	42	NC
43	GND	44	NC
45	NC	46	NC
47	NC	48	+1.5V_MINI
49	NC	50	GND
51	NC	52	+3.3V_MINI



Chapter 2: Jumpers and Connectors

Mini-PCIe Slot

Connector location: CN7



VICPAS.com

Everything for your HMI running
sales@vicpas.com
+86-15876525394

Pin	Definition	Pin	Definition
2	WAKE0#	2	+3.3V_MINI
4	NC	4	GND
6	NC	6	+1.5V_MINI
8	NC	8	NC
10	GND	10	NC
11	GPP_CLK1-	12	NC
13	GPP_CLK1+	14	NC
15	GND	16	NC
17	NC	18	GND
19	NC	20	MINICARD1_DIS#
21	GND	22	PCIE_RST#
23	PCIE_RX2-	24	+3.3V_MINI
25	PCIE_RX2+	26	GND


Pin	Definition	Pin	Definition
27	GND	28	+1.5V_MINI
29	GND	30	SMB_CLK
31	PCIE_TX3-	32	SMB_DAT
33	PCIE_TX3+	34	GND
35	GND	36	USB6-
37	GND	38	USB6+
39	+3.3V_MINI	40	GND
41	+3.3V_MINI	42	NC
43	GND	44	NC
45	NC	46	NC
47	NC	48	+1.5V_MINI
49	NC	50	GND
51	NC	52	+3.3V_MINI



Chapter 2: Jumpers and Connectors

CFast Card Slot

Connector type: Standard CFast connector
Connector location: J13



Definition	Pin	Definition
GND	PC6	NC
SATA_TX1+	PC7	GND
SATA_TX1-	PC8	CFAST_LED1_C
GND	PC9	CFAST_LED2_C
SATA_RX1-	PC10	NC
SATA_RX1+	PC11	NC
GND	PC12	NC
CFAST_CDI	PC13	VCC3
GND	PC14	VCC3
NC	PC15	GND
NC	PC16	GND
NC	PC17	CFAST_CDO

Power Button Connector

Connector type: 1x2 2-pin header, JST 2.0 mm pitch
Connector location: J11




Pin	Definition
1	PWRBT
2	GND



Block Diagram

eTOP-EPC 1930T/eTOP-EPC 1730T/eTOP-EPC 1530T/eTOP-EPC 1230T/eTOP-EPC 1235T

AP-D2550-1 Block Diagram




VICPAS®
Everything for your HMI running
sales@vicpas.com
+86-15876525394

51

eTOP-EPC 1230T/1231T/1235T/1530T/1531T/1730T/1731T/1930T/1931T User Manual

VICPAS®
Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394





CHAPTER 3: SYSTEM SETUP

Installing a SATA Hard Drive

Prior to removing the chassis cover, make sure the unit's power is off and disconnected from the power sources to prevent electric shock or system damage.



VICPAS
Everything for your HMI running
sales@vicpas.com
+86-15876525394

Remove the mounting screws around the chassis cover and then remove




The dots denote the locations of the screws.



Chapter 3: System Setup

2. Remove the mounting screws of the drive bay.



3. Remove the drive bay. The drive bay is used to hold a SATA hard drive.




VICPAS®
.com

Everything for your HMI running

✉ sales@vicpas.com

☎ +86-15876525394

4. Place the SATA hard drive on the drive bay.




5. Align the mounting holes that are on the sides of the SATA drive with the mounting holes on the drive bay and then use the provided mounting screws to secure the drive in place.



Chapter 3: System Setup

6. Place the SATA drive in the chassis and then use the provided mounting screws to secure the drive in the chassis.

Connect the SATA data cable and SATA power cable to the connector on the SATA drive.




Installing a CFast Card

1. The CFast card socket is located on the rear top side of the chassis.



2. Remove the mounting screws of the CFast socket's cover.



Chapter 3: System Setup

3. With the CFast card's label facing up, insert the card until it is completely seated in the socket.



4. Push the CFast card to remove the CFast card.



Installing a SODIMM

1. Remove the mounting screws around the chassis cover and then remove the cover.



Chapter 3: System Setup

2. Remove the mounting screws on the metal support plate.



VICPAS[®].com
Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394

3. Gently lift the motherboard support plate upwards and locate the SODIMM socket underneath.



Chapter 3: System Setup

4. Insert the module into the socket at an approximately 30 degrees angle. Apply firm even pressure to each end of the module until it slips into the socket. The gold-plated connector on the edge of the module will almost completely disappear inside the socket.

5. Push the module down until the clips on both sides of the socket lock into position. You will hear a distinctive “click”, indicating the module is correctly locked into position.



Note:

1. If only one SO DIMM is installed, please install to the one closest to the panel.
2. The maximum RAM size is 4G (2x 2G or 1x 4G)



Installing a SATA DOM

1. Remove the drive bay bracket. The SATA connector is readily accessible upon removing the bracket.

SATA connector





2. Remove the screw.






Chapter 3: System Setup

3. The SATA DOM package includes a supporting stud. The stud is used to stabilize the SATA DOM module.



4. Install the supporting stud. Make sure the stud is fastened in place.




VICPAS.com
Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394




Chapter 3: System Setup

5. Connect one end of the provided cable to the connector on the module.




Cable

Connector on the module



6. Install the module to the SATA port via the connector at the solder side of the module and then secure the module using the mounting screw you removed in step 2.




SATA DOM

Mounting screw

Chapter 3: System Setup

7. Connect the other end of the cable to the connector on the board.



Installing a Mini PCIe Module

The Mini PCIe module package includes the following items:

RALINK 802.11b/g/n 2T3R wireless mini card module kit QCOM:Q802XKN



Mini PCIe Module



Antennas



RF Cables

3.5G module kit Sierra Wireless MC8790V




802.11b/g QN-MU-A0028 wireless mini card module kit
INTEL 12.BNMMWG



Chapter 3: System Setup

If you are installing the 802.11b/g QN-MU-A0028 wireless mini card module (half-size), before proceeding with the installation, please assemble the Wi-Fi module bracket first by following the instructions below:

- 1. Align the mounting holes on the Wi-Fi mini card module to the mounting holes on the Wi-Fi module bracket.



- 2. Tighten screws onto the mounting holes to secure the bracket.



Installing the Half-Size Mini PCIe Module

1. Insert the Mini PCIe module into the Mini PCIe slot at a 45 degrees angle until the gold-plated connector on the edge of the module completely disappears inside the slot.



Mini PCIe slot

Mini PCIe module



2. Secure the module with mounting screws.



3. Please go to step 3 on page 69 to proceed.



Installing the Full-Size Mini PCIe Module

1. Insert the Mini PCIe module into the Mini PCIe slot at a 45 degrees angle until the gold-plated connector on the edge of the module completely disappears inside the slot.



VICPAS®
Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394

2. Secure the module with mounting screws.





Chapter 3: System Setup

3. Attach one end of the RF cables onto the module.



4. Push the antenna hole cover.



VICPAS[®].com

Everything for your HMI running


✉ sales@vicpas.com

☎ +86-15876525394




Chapter 3: System Setup

5. Remove the antenna hole covers.



6. Insert the antenna jack end of the cable through the antenna hole.





Antenna jack
end of the cable



VICPAS[®].com
Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394

7. Insert the ring onto the antenna jack end of the cable.



VICPAS.com
Everything for your HMI running
sales@vicpas.com
+86-15876525394

8. Connect external antennas to the antenna jacks.




Installing a Bluetooth Module

The Bluetooth module package includes the following items:

Bluetooth module



1. Remove the sticker on one side of the square rubber pad, then place that side on the back of the Bluetooth module.




2. Connect the cable to the connector on the Bluetooth module.




Chapter 3: System Setup

3. Remove the mounting screws of the drive bay.




Mounting screw


4. Remove the drive bay and locate the Bluetooth connector and mounting hole on the mainboard.



5. Remove the sticker on the square rubber pad



6. Align the mounting hole on the Bluetooth module to the mounting hole on the mainboard, then tighten screws to secure it. Once the module is secured, connect the cable to the Bluetooth connector.





Chapter 3: System Setup

7. Install the drive bay back to its original position.



8. Attach one end of the RF cable onto the module.



9. Mount the other end of the cable to the Bluetooth mounting hole located at the rear top panel of the chassis.

Placing Panel Mount Hole Blocks

The eTOP-EPC series comes with panel mount hole blocks to cover the panel mount openings on the chassis to prevent dust invasion. You can also choose to cover the panel mount holes when VESA mount is used.



Panel Mount Hole Block
(eTOP-EPC 1930T/eTOP-EPC1 931T)



Panel Mount Hole Block
(eTOP-EPC 1730T/eTOP-EPC 1731T/eTOP-EPC 1530T/
eTOP-EPC 1531T/eTOP-EPC 1230T/eTOP-EPC 1231T/
eTOP-EPC 1235T)

1. Locate the panel mount openings on the chassis.



Chapter 3: System Setup

2. Insert the hole block into the opening until it is pushed in completely.





Installing the Power Adapter Bracket

(For eTOP-EPC 193xT series only)

1. Locate the mounting screws for the bracket on the back side of the chassis.





2. Remove the mounting screws and store them in a safe place for later use.





Chapter 3: System Setup


- 4. Turn the bracket over to the back side, and place the cable tie into the two tie mounts.
- 5. Wrap the power adapter cable, then secure the cable firmly by tying the cable tie.





Chapter 3: System Setup

- 6. With the bracket still facing backwards, align the mounting holes on the bracket to the mounting holes on the back of the chassis, then tighten screws to secure it. Once secured, plug the power adapter cable into the DC input.




VICPAS
Everything for your HMI running
sales@vicpas.com
+86-15876525394



Plugging the DC Power Cable

1. Plug the DC 4-pin DIN power jack (male) into the DC 4-pin DIN power jack (female) that is on the system.
2. The table below shows the pin definition of the cable.



Color	Pin Definition
Black	GND
Red&Yellow	DC+
Blue&Black	DC-



Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394



Panel Mounting

1. Select a place on the panel where you will mount the Panel PC.
2. Cut out a shape on the panel that corresponds to the Panel PC's rear dimensions.


The thickness of the panel (e.g. steel board, plank, acrylic board, wall, etc.) where you will mount the Panel PC must not exceed 7mm for EPC 1230T/1231T/1235T/1730T/1731T, and 6mm for eTOP 1530T/1531T/1930T/1931T. If the distance between the front panel mount hole is too wide, it will not fit the panel mount kit.




Everything for your HMI running

 sales@vicpas.com


 +86-15876525394



eTOP-EPC 1530T/1531T




eTOP-EPC 1730T/1731T



eTOP-EPC 1230T/1231T/1235T



Chapter 3: System Setup



VICPAS
Everything for your HMI running
sales@vicpas.com
+86-15876525394

eTOP-EPC 1930T/1931T

6mm

- 3. Slide the Panel PC through the hole until it is properly fitted against the panel.
- 4. Position the mounting clamps along the rear edges of the Panel PC. The first and second clamps must be positioned and secured diagonally prior to mounting the rest of the clamps. Tighten the clamp's screw until it touches the panel.



Panel

Clamp



Do not overtighten the screws to prevent damaging the Panel PC.



CHAPTER 4: BIOS SETUP

This chapter describes how to use the BIOS setup program for the ETOP-EPC Series. The BIOS screens provided in this chapter are for reference only and may change if the BIOS is updated in the future.

To check for the latest updates and revisions, visit the EXOR Web site at www.exor.com.



BIOS Setup

The Basic Input and Output System (BIOS) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to suit your individual work needs. It is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters.

These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

With easy-to-use pull down menus, you can configure such items as:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

The settings made in the setup program affect how the computer performs. It is important, therefore, first to try to understand all the setup options, and second, to make settings appropriate for the way you use the computer.

When to Configure the BIOS

- This program should be executed under the following conditions:
- When changing the system configuration
- When a configuration error is detected by the system and you are prompted to make changes to the setup program
- When resetting the system clock
- When redefining the communication ports to prevent any conflicts
- When making changes to the Power Management configuration
- When changing the password or making other changes to the security setup

Normally, CMOS setup is needed when the system hardware is not consistent with the information contained in the CMOS RAM, whenever the CMOS RAM has lost power, or the system features need to be changed.



Default Configuration

Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.

Entering Setup

When the system is powered on, the BIOS will enter the Power-On Self Test (POST) routines. These routines perform various diagnostic checks; if an error is encountered, the error will be reported in one of two different ways:

- If the error occurs before the display device is initialized, a series of beeps will be emitted.
- If the error occurs after the display device is initialized, the screen will display the error message.

Powering on the computer and immediately pressing allows you to enter Setup. Another way to enter Setup is to power on the computer and wait for the following message during the POST:

TO ENTER SETUP BEFORE BOOT PRESS



Press the **Del** key to enter Setup:



Legends

Key	Function
	Moves the highlight left or right to select a menu.
	Moves the highlight up or down between sub-menus or fields.
	Exits the BIOS Setup Utility.
	Scrolls forward through the values or options of the highlighted field.
	Scrolls backward through the values or options of the highlighted field.
	Selects a field.
	Displays General Help.
	Load previous values.
	Load optimized default values.
	Saves and exits the Setup program.
	Press <Enter> to enter the highlighted sub-menu



Chapter 4: BIOS Setup

Scroll Bar

When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

Submenu

When "►" appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press .






Chapter 4: BIOS Setup

BIOS Setup Utility


Once you enter the AMI BIOS Setup Utility, the Main Menu will appear on the screen. The main menu allows you to select from several setup functions and one exit. Use arrow keys to select among the items and press  to accept or enter the submenu.

Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



Intel RC Version
Displays the Intel Reference Code version.





Chapter 4: BIOS Setup

System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Monday to Sunday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 1999 to 2099.

System Time

The time format is <hour>, <minute>, <seconds>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.



Everything for your HMI running
sales@vicpas.com
+86-15876525394


Access: Display access level of the current user in the BIOS.



Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.

 Setting incorrect field values may cause the system to malfunction.



Launch LAN1/2 PXE OpROM


Enables or disables the boot option for legacy network devices connected to LAN1 and LAN2.



Chapter 4: BIOS Setup

CPU Configuration

This section is used to configure the CPU.



Hyper-Threading

This field is used to enable or disable hyper-threading.

Execute Disable Bit

This field is used to enable or disable execute disable bit. When this field is set to Disabled, it will force the XD feature flag to always return to 0. XD can prevent certain classes of malicious buffer overflow attacks when combined with a supporting OS (Windows Server 2003 SP1, Windows XP SP2, SuSE Linux 9.2, RedHat Enterprise 3 Update 3).

Limit CPUID Maximum


The CPUID instruction of some newer CPUs will return a value greater than 3. The default is Disabled because this problem does not exist in the Windows series operating systems. If you are using an operating system other than Windows, this problem may occur. To avoid this problem, enable this field to limit the return value to 3 or lesser than 3.



Chapter 4: BIOS Setup

IDE Configuration

This section is used to configure the IDE devices.



Configure SATA as

Configures the SATA as IDE or AHCI mode.

- IDE This option configures the Serial ATA drives as Parallel ATA physical storage device.
- AHCI This option configures the Serial ATA drives to use AHCI (Advanced Host Controller Interface). AHCI allows the storage driver to enable the advanced Serial ATA features which will increase storage performance.

SATA Controller(s)


Enables or disables SATA controller.



Chapter 4: BIOS Setup

USB Configuration

This section is used to configure USB devices.



EHCI Hand-off

This is a workaround for OSs that does not support EHCI hand-off. The EHCI ownership change should be claimed by the EHCI driver.

Device reset time-out

Selects the USB mass storage device's start unit command timeout.

Legacy USB Support

Due to the limited space of the BIOS ROM, the support for legacy USB keyboard (in DOS mode) is by default set to Disabled. With more BIOS ROM space available, it will be able to support more advanced features as well as provide compatibility to a wide variety of peripheral devices.

If a PS/2 keyboard is not available and you need to use a USB keyboard to install Windows (installation is performed in DOS mode) or run any program under DOS, set this field to Enabled.



Chapter 4: BIOS Setup

Super IO Configuration

This section is used to configure serial ports 0 to 4.

Aprio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

Super IO Configuration

Super IO Chip

▶ Serial Port 0 Configuration

▶ Serial Port 1 Configuration

▶ Serial Port 2 Configuration

▶ Serial Port 3 Configuration

TT8783F

Set Parameters of Serial Port 0 (COMA)

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

Super IO Chip

Displays the Super I/O chip used on the board.

Serial Port 0 Configuration

This section is used to configure serial port 0.

Aprio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

Serial Port 0 Configuration

Serial Port

Device Settings

Change Settings

Onboard Serial Port 0 Mode

Onboard Serial Port Max Baud Rate

[Enabled]
IO=3F8h; IRQ=4;
[IO=3F8h; IRQ=4;]
[RS232]
[115200 bps]

Enable or Disable Serial Port (COM)

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

Serial Port

Enables or disables the serial port.

Change Settings

Selects an optimal setting for the Super IO device.

Onboard Serial Port 0 Mode

This field is used to configure the mode of serial port 0 as RS232, RS422, RS485 or RS485 AUTO.



Chapter 4: BIOS Setup

Onboard Serial Port Max Baud Rate

This field configures the maximum baud rate of the serial port 0, the options are 115200 bps and 921600 bps.

Apdio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

Serial Port 0 Configuration

Serial Port Device Settings

[Enabled]
IO=3F8H; IRQ=4;

Change Settings

Onboard Serial Port 0 Mode

[IO=3F8H; IRQ=4;]
[RS232]

Onboard Serial Port Max Baud Rate

[115200 bps]
921600 bps

Onboard Serial Port Max Baud Rate

115200 bps
921600 bps

Change the Serial Port Max Baud Rate. Select <115200 bps> or <921600 bps>

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

Everything for your HMI running
sales@vicpas.com
+86-15876525394

Serial Port 1 Configuration

This section is used to configure serial port 1.

Apdio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

Serial Port 1 Configuration

Serial Port Device Settings

[Enabled]
IO=2F8H; IRQ=3;

Change Settings

Onboard Serial Port 1 Mode

[IO=2F8H; IRQ=3;]
[RS232]

Onboard Serial Port Max Baud Rate

[115200 bps]

Enable or Disable Serial Port (COM)

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

Serial Port

Enables or disables the serial port.

Change Settings

Selects an optimal setting for the Super IO device.

Onboard Serial Port 1 Mode

This field is used to configure the mode of serial port 1 as RS232, RS422, RS485 or RS485 AUTO.

Copyright © 2014 EXOR International S.p.A. All Rights Reserved.

95

eTOP-EPC 1230T/1231T/1235T/1530T/1531T/1730T/1731T/1930T/1931T User Manual



Chapter 4: BIOS Setup

Onboard Serial Port Max Baud Rate

This field configures the maximum baud rate of the serial port 1, the options are 115200 bps and 921600 bps.

Apdio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

Serial Port 1 Configuration

Serial Port Device Settings

[Enabled]
IO=2F8H; IRQ=3;

Change Settings

Onboard Serial Port 1 Mode [RS232]

Onboard Serial Port Max Baud Rate [115200 bps]

Onboard Serial Port Max Baud Rate

115200 bps
921600 bps

Change the Serial Port Max Baud Rate. Select <115200 bps> or <921600 bps>

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

Everything for your HMI running

sales@vicpas.com

+86-15876525394

Serial Port 2 Configuration

This section is used to configure serial port 2.

Apdio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

Serial Port 2 Configuration

Serial Port Device Settings

[Enabled]
IO=3E8h; IRQ=7;

Change Settings

Onboard Serial Port Max Baud Rate [115200 bps]

Enable or Disable Serial Port (COM)

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

Serial Port

Enables or disables the serial port.

Change Settings

Selects an optimal setting for the Super IO device.

Copyright © 2014 EXOR International S.p.A. All Rights Reserved.

96

eTOP-EPC 1230T/1231T/1235T/1530T/1531T/1730T/1731T/1930T/1931T User Manual



Chapter 4: BIOS Setup

Onboard Serial Port Max Baud Rate

This field configures the maximum baud rate of the serial port 2, the options are 115200 bps and 921600 bps.

Apdio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

Serial Port 2 Configuration

Serial Port Device Settings

[Enabled]
IO=3E8H; IRQ=7;

Change Settings

Onboard Serial Port Max Baud Rate

115200 bps
921600 bps

Onboard Serial Port Max Baud Rate

Change the Serial Port Max Baud Rate. Select <115200 bps> or <921600 bps>

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

Everything for your HMI running
✉ sales@vicpas.com
☎ +86-15876525394

Serial Port 3 Configuration

This section is used to configure serial port 3.

Apdio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

Serial Port 3 Configuration

Serial Port Device Settings

[Enabled]
IO=2E8H; IRQ=6;

Change Settings

Onboard Serial Port Max Baud Rate

115200 bps

Onboard Serial Port Max Baud Rate

Change the Serial Port Max Baud Rate. Select <115200 bps> or <921600 bps>

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

Serial Port

Enables or disables the serial port.

Change Settings

Selects an optimal setting for the Super IO device.

Copyright © 2014 EXOR International S.p.A. All Rights Reserved.

97

eTOP-EPC 1230T/1231T/1235T/1530T/1531T/1730T/1731T/1930T/1931T User Manual



Chapter 4: BIOS Setup

Onboard Serial Port Max Baud Rate

This field configures the maximum baud rate of the serial port 3, the options are 115200 bps and 921600 bps.

APtIO Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

Serial Port 3 Configuration

Serial Port Device Settings

Change Settings

Onboard Serial Port Max Baud Rate

Onboard Serial Port Max Baud Rate

115200 bps

921600 bps

Change the Serial Port Max Baud Rate. Select <115200 bps> or <921600 bps>

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.14.1219, Copyright (C) 2011 American Megatrends, Inc.

Everything for your HMI running

sales@vicpas.com

+86-15876525394

VICPAS.com

H/W Monitor

This section is used to configure the hardware temperature, fan speed and voltages.

APtIO Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

Pc Health Status

CPU Temperature

System Temperature

CPU:Vcore

+3.3V

+5V

+12V

: +39 C

: +39 C

: +1.168 V

: +3.328 V

: +5.017 V

: +11.827 V


→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.14.1219, Copyright (C) 2011 American Megatrends, Inc.



Intel® IGD Configuration

This section is used to configure the Intel® IGD Graphic configurations.



IGFX – Boot Type

This field is used to configure which video device will be activated during POST. This has no effect if external graphics present. The options are CRT, LVDS, LVDS + CRT and CRT + HDMI.

Backlight Control Select

The available options are Pyroelectric sensor and Tact Switch. The default setting is Tact Switch for eTOP-EPC 1231T/eTOP-EPC 1531T/eTOP-EPC 1731T/eTOP-EPC 1931T, and the Backlight On/Off button is functional only in this mode.

Backlight On/Off Reverse

Please configure this option only when changing the panel, otherwise the display may not work.

Backlight Dimming Control Select

The options are Tact Switch, Manual and Light sensor.

The default setting is Manual for eTOP-EPC 1230T/1235T/1530T/1730T/1930T and the Backlight option below will be configurable.

The default setting is Tact Switch for 1231T/1531T/1731T/1931T and the Backlight option below will not be configurable, please use the brightness button on the panel to adjust it.

Backlight

Adjusts the brightness of the backlight.


Fixed Graphics Memory Size

This field is used to configure the memory size of the fixed graphics, the options are 128MB and 256MB.



Chapter 4: BIOS Setup

South Bridge



Azalia Controller

This section disables Azalia or enables HD Audio.

SMBus Controller

This section is used to disable or enable SMBus controller.

High Precision Timer

This section is used to configure High Precision Event Timer.

Restore AC Power Loss

Power Off

When power returns after an AC power failure, the system's power is off. You must press the Power button to power-on the system.

Power On

When power returns after an AC power failure, the system will automatically power-on.

Last State

When power returns after an AC power failure, the system will return to the state where you left off before power failure occurs. If the system's power is off when AC power failure occurs, it will remain off when power returns. If the system's power is on when AC power failure occurs, the system will power-on when power returns.

Blue-tooth

Enables or disables blue-tooth, settings for the optional Bluetooth module.

Beep


Enables or disables beep.



Chapter 4: BIOS Setup

Boot

This section is used to configure the boot features.



Quiet Boot

Enabled Displays OEM logo instead of the POST messages.
Disabled Displays normal POST messages.

GateA20 Active

Upon Request GA20 can be disabled using BIOS services.
Always Do not allow disabling GA20; this option is useful when any RT code is executed above 1MB.

Option ROM Messages

This field is used to set display mode for Option ROM.

Interrupt 19 Capture

Allows Option ROMs to trap Interrupt 19 when enabled.

Boot Option Priorities

Adjust the boot sequence of the system. Boot Option #1 is the first boot device that the system will boot from, next will be #2 and so forth.

Setup Prompt Timeout

This section configures the number of seconds to wait for the setup activation key.

Bootup NumLock State


This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys.



Chapter 4: BIOS Setup

Hard Drive BBS Priorities

Sets the order of the legacy devices in this group.





Security

MainAdvancedChipsetBootSecuritySave & Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

Administrator Password

If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup.

If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User Will have Administrator rights.

The password length must be in the following range:

Min	3
Max	20

Administrator Password

Set Administrator Password

←→: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Administrator Password

Select this to reconfigure the administrator's password.

User Password

Select this to reconfigure the user's password.

Save & Exit

MainAdvancedChipsetBootSecuritySave & Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

Save Changes and Exit

Discard Changes and Exit

Discard Changes and Reset

Save Options

Save Changes

Discard Changes

Restore Defaults

Save as User Defaults

Restore User Defaults

Boot Override

SATA SM: 4GB SATA Flash Drive

Launch EFI Shell from filesystem device

Save Changes and Exit

To save the changes and exit the Setup utility, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes. You can also press <F4> to save and exit Setup.

Discard Changes and Exit

To exit the Setup utility without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting. You can also press <ESC> to exit without saving the changes.

Copyright © 2014 EXOR International S.p.A. All Rights Reserved.

104

eTOP-EPC 1230T/1231T/1235T/1530T/1531T/1730T/1731T/1930T/1931T User Manual



Save Changes and Reset

To save the changes and reset, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Discard Changes and Reset

To exit the Setup utility and reboot the system without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting.

Save Changes

To save changes and continue configuring the BIOS, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Discard Changes

To discard changes, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes to discard all changes made and restore the previously saved settings.

Restore Defaults

To restore the BIOS to default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Save as User Defaults

To use the current configurations as user default settings for the BIOS, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Restore User Defaults

To restore the BIOS to user default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Boot Override

To bypass the boot sequence from the Boot Option List and boot from a particular device, select the desired device and press <Enter>.

Launch EFI Shell from filesystem device

To launch EFI shell from a filesystem device, select this field and press <Enter>.



APPENDIX A: GPIO PROGRAMMING GUIDE

GPIO (General Purpose Input/Output) pins are provided for custom system design. This appendix provides definitions and its default setting for the ten GPIO pins in the APPC series. The pin definition is shown in the following table:



GPIO mode	PowerOn Default	Address	Pin	GPIO mode	PowerOn Default	Address
+5V	-	-	2	GP120	High	A04h (bit0)
GP121	High	A04h (bit1)	4	NC	-	-
NC	-	-	6	GND	-	-
GPO22	Low	A04h (bit2)	8	GPO23	Low	A04h (bit3)
NC	-	-	10	NC	-	-

Control the GPO pin (7/8) level from I/O port A04h bit (2/3).
The bit is Set/Clear indicated output High/Low



Appendix A: GPIO Programming Guide

GPIO programming sample code

```
#define GPIO_PORT      0xA04
#define GPO7           (0x01 <<2)
#define GPO8           (0x01 <<3)

#define GPO7_HI        outportb(GPIO_PORT, 0x04)
#define GPO7_LO        outportb(GPIO_PORT, 0x00)
#define GPO8_HI        outportb(GPIO_PORT, 0x08)
#define GPO8_LO        outportb(GPIO_PORT, 0x00)
```

Everything for your HMI running
sales@vicpas.com
+86-15876525394

VICPAS®
.com



APPENDIX B: DIGITAL I/O PROGRAMMING GUIDE

Digital I/O (Digital Input/Output) pins are provided for custom system design. This appendix provides definitions and its default setting for the fifteen Digital I/O pins in the APPC series. The pin definition is shown in the following table:



Everything for your HMI running

sales@vicpas.com

+86-15876525394

	GPI/O mode	PowerOn Default	Address	Pin	GPI/O mode	PowerOn Default	Address
1							
2	DI1	High	A05h (bit0)	2	DI2	High	A05h (bit1)
3	DI3	High	A05h (bit2)	4	DI4	High	A05h (bit3)
5	GND	-	-	6	COM	-	-
7	NC	-	-	8	NC	-	-
9	DO1	Low	A05h (bit4)	10	DO2	Low	A05h (bit5)
11	DO3	Low	A05h (bit6)	12	DO4	Low	A01h (bit7)
13	GND	-	-	14	GND	-	-
15	GND	-	-				

Control the DO pin (9/10/11/12) level from I/O port A05h bit (4/5/6) and A01h bit (7).
The bit is Set/Clear indicated output High/Low



Appendix B: Digital I/O Programming Guide

GPIO programming sample code

```
#define DIO_PORT      0xA05
#define DIO_PORTI    0xA01
#define DO9          (0x01 <<4)
#define DO10         (0x01 <<5)
#define DO11         (0x01 <<6)
#define DO12         (0x01 <<7)


#define DO9_HI
#define DO9_LO
#define DO10_HI
#define DO10_LO
#define DO11_HI
#define DO11_LO
#define DO12_HI
#define DO12_LO

void main(void)
{
    DO9_HI;
    DO10_LO;
    DO11_HI;
    DO12_LO;
}
```



APPENDIX C: WATCHDOG PROGRAMMING GUIDE

eTOP-EPC Series Watch Dog Function Configuration Sequence Description:





Everything for your HMI running

✉ sales@vicpas.com

☎ +86-15876525394



Appendix C: Watchdog Programming Guide

```
=====
SetupWDT      PROC
mov dx, 2eh
mov al, 087h
out dx, al
nop
nop
mov al, 01h
out dx, al
nop
nop
mov al, 55h
out dx, al
nop
nop
mov al, 07h
out 2eh, al
mov al, 07h
out 2fh, al
ret
SetupWDT      ENDP

;=====
;Write operations to special address
;port (2E) for entering MB PnP Mode.

;Select logical device for Watch Dog.

=====
TimeBaseWDT   PROC
mov al, 72h
out 2eh, al
mov al, 10h
or al, 80h
;Set WDT reset upon PWVROK
;Here!! set 80h for second, set 00h for minute
=====
```

```
out 2fh, al
ret
TimeBaseWDT   ENDP

=====
TimeCountWDT  PROC
mov al, 73h ;WDT Time-out register.
out 2eh, al
mov al, 03h ;Here!! Set count 3.
out 2fh, al
ret
TimeCountWDT  ENDP

=====
ExitSetup     PROC
mov al, 02h
out 2eh, al
mov al, 02h
out 2fh, al
ret
ExitSetup     ENDP

=====
```



Everything for your HMI running

✉ sales@vicpas.com

☎ +86-15876525394



APPENDIX D: POWER CONSUMPTION

Power Consumption Management

Purpose

The purpose of the power consumption test is to verify the power dissipation of the system and the load of the power supply.

Test Equipment

- 1. Power Meter M-07 AC/DC CLAMP METER
- 2. Burn-in test ver:2.0

Dev Under Test

DUT #1/

Test Procedure

1. Power up DUT and then boot Windows 7.
2. Enter the standby mode (HDD power down).
3. Measure the power consumption and record it.
4. Run the Burn-in test program to apply 100% full loading.
5. Measure the power consumption and record it.

eTOP-EPC 1930T/1931T

	+12V	+24V	+30V
Full-Loading Mode	3.2A	1.65A	1.26A
Total	38.4W	39.6W	37.8W
Standby Mode	0.75A	0.41A	0.36A
Total	9W	9.84W	10.8W

eTOP-EPC 1730T/1731T

	+12V	+24V	+30V
Full-Loading Mode	4.2A	2A	1.63A
Total	50.4W	48W	48.9W
Standby Mode	0.74A	0.41A	0.34A
Total	8.88W	9.84W	10.2W



Appendix D: Power Consumption

eTOP-EPC 1530T/1531T

	+12V	+24V	+30V
Full-Loading Mode	2.5A	1.28A	1A
Total	30W	30.72W	30W
Standby Mode	0.76A	0.41A	0.36A
Total	9.12W	9.84W	10.8W

eTOP-EPC 1230T/1231T

	+12V	+24V	+30V
Full-Loading Mode	2.26A	1.11A	0.9A
Total	27.12W	26.64W	27W
Standby Mode	0.76A	0.41A	0.35A
Total	9.12W	9.84W	10.5W

eTOP-EPC 1235T

	+12V	+24V	+30V
Full-Loading Mode	2.5A	1.24A	1.01A
Total	30W	29.76W	30.3W
Standby Mode	0.79A	0.43A	0.36A
Total	9.48W	10.32W	10.8W



APPENDIX E: TROUBLESHOOTING

- 1. I cannot make voice calls using 3.5G mini-PCIe card as network connection.

Answer: eTOP-EPC series’ 3.5G connection only supports data transmission and does not support voice transmission.

- 2. The second VGA display is not working under DOS operating system.

Answer: Second VGA display is not supported under DOS operating system.

Answer: In Windows XP Device Manager, why is there an exclamation mark on Audio Device on High Definition Audio Bus?

Answer: Please disable Azalia controller in the BIOS menu to fix this issue, for more information on BIOS settings, please refer to Chapter 4: BIOS Setup of the user manual.

Answer: In Windows XP, there is no image on the screen when CRT+LVDS is selected as the option in BIOS.

Answer: Please configure the BIOS setting according to the table below:

Win XP	CRT	LVDS	HDMI	CRT+LVDS		CRT+HDMI		LVDS+HDMI	
BIOS	single	single	single	clone	extend	clone	extend	clone	extend
CRT	✓	✓	✓	✓	✓	✓	✓	✓	✓
LVDS	✓	✓	✓	✓	✓	✓	✓	✓	✓
CRT+LVDS	✓	✓	✓	✓	✓	✓	✓	✓	✓
LVDS+CRT (Default)	✗	✓	✓	✗	✗	✗	✗	✓	✓
CRT+HDMI	✓	✓	✓	✓	✓	✓	✓	✓	✓