

**DA-52s**

**Reference Manual  
Operation of Version 3  
English**

---

## Preface

This manual describes the operation of the Delem controller type DA-52s and is meant for operators who are instructed for operation of the total machine.

## Delem Limited warranty

- This manual does not entitle you to any rights. Delem reserves the right to change this manual without prior warning.
- All rights reserved. The copyright is held by Delem. No part of this publication may be copied or reproduced without written permission from Delem BV.

## Version history

The control software is updated regularly to increase performance and add new functionality. This manual is also updated as a result of changes in the control software. The following overview shows the relation between software and manual versions.

Software version	Manual version	Description
V3.2	V0812	first issue V3

This manual is valid for software version 3.2.

**Table of contents**

<b>1. Operation overview and general introduction .....</b>	<b>1.1</b>
1.1. The control unit .....	1.1
1.2. Operation modes .....	1.2
1.3. Programming modes .....	1.3
1.4. Other frontpanel keys .....	1.4
1.5. Software versions .....	1.5
<b>2. Product programming .....</b>	<b>2.1</b>
2.1. Program selection .....	2.1
2.2. Program edit .....	2.2
2.2.1. General properties .....	2.2
2.2.2. Parameters explanation .....	2.3
2.3. Bend programming .....	2.5
2.3.1. Introduction .....	2.5
2.3.2. Bend parameters - first page .....	2.5
2.3.3. Bend parameters - second page .....	2.8
2.3.4. Bend parameters - third page .....	2.9
2.3.5. All bends view .....	2.10
2.3.6. Bumping programming .....	2.11
<b>3. Programming of tools .....</b>	<b>3.1</b>
3.1. Introduction .....	3.1
3.2. Programming of Punches .....	3.2
3.2.1. Punch library .....	3.2
3.2.2. Punch parameters .....	3.3
3.3. Programming of bottom dies .....	3.4
3.3.1. Die library .....	3.4
3.3.2. Die parameters .....	3.5
<b>4. Program Constants .....</b>	<b>4.1</b>
4.1. Introduction .....	4.1
4.2. General .....	4.1
4.3. Materials .....	4.3
4.4. Program settings .....	4.4
4.5. Computation settings .....	4.6
4.6. Production settings .....	4.7
4.7. Backgauge dimensions .....	4.9
4.8. Maintenance .....	4.10
4.9. Data transfer .....	4.11
<b>5. Manual mode .....</b>	<b>5.1</b>
5.1. Introduction .....	5.1
5.2. Parameter Explanation .....	5.1
5.3. Zoomed values .....	5.4
5.4. Manual operation of the axes .....	5.5
5.4.1. General .....	5.5
5.4.2. To teach .....	5.6
<b>6. Automatic mode .....</b>	<b>6.1</b>
6.1. Introduction .....	6.1
6.2. Parameters .....	6.2

---

6.3. Zoomed values .....	6.3
6.4. Manual operation of the axes .....	6.4
<b>A. Parameter index .....</b>	<b>A.1</b>

## 1. Operation overview and general introduction

### 1.1. The control unit

The control looks as follows:



1.a

The precise outfit of your control may vary.

Operation of the control is done with the various keys on the front panel. A description of all keys and their functions is given in the next section.

---

## 1.2. Operation modes

The control has the 3 following modes:

**Manual mode**

In this mode it is possible to program all parameters of just one bending. This mode is useful for testing and for calibration.

**Programming mode**

In this mode bend programs can be programmed and executed.

**Manual movement**

In this mode any selected axis can be moved manually with the arrow keys.

Each mode can be selected by pressing the relevant push button. A LED in the push button indicates whether or not this mode is active.

## 1.3. Programming modes

The control has the following programming functions:



### Program constants

In this mode you program the general parameters for bend programming.



### Tools

In this mode you program and edit the tools. There are 30 different punches and 30 different dies to program in the program memory.



### Change view

Key to switch between various pages of a bend. It also serves to return to an active program.



### Program library

Open the library with bend programs on the control.

You select one of the programming modes in the manual- or automatic operation mode while the controller is in the 'stop'-status.

---

## 1.4. Other frontpanel keys

The frontpanel consists of the following items:

Keyboard:



10 numerical keys (0-9) incl. alphanumeric input


decimal point

plus/minus toggle


clear key: Clearance of the input data field in the bottom left corner on the monitor screen

enter key, to confirm a programmed value

Cursor path control:



Stop button   Start button





Return to previous function or abort parameter edit.

## 1.5. Software versions

The version of the software in your control is displayed at the upper side of the menu screen in the programming mode.

Example of version number:

**V 1.2**

V stands for version

1 is version number

2 is version level

The version number is increased when new features are added to the software, the level number is increased when minor corrections are needed in the existing version number.



## 2. Product programming

### 2.1. Program selection

To edit or create a program, proceed as follows:



Press this key to activate the automatic mode.




Press this key to open the program library.

The program library screen appears.

Product selection		Free space: 15.012 MB	Mach.no: 1 Prod.no: --		
product	▲	drawing number	no.bend	punch/die	dd-mm-yyyy
1		90DEGREE	1	5/5	29-11-2012
2		BOTTOMING	2	5/5	29-11-2012
3		ABSOLUTE AIR	3	5/5	29-11-2012
5			5	1/1	29-11-2012
9			5	1/1	29-11-2012
10			5	0/0	29-11-2012
11			1	1/1	29-11-2012
15			1	0/0	29-11-2012
65			3	1/1	29-11-2012
112			3	1/1	29-11-2012
123		EXAMPLE 123	1	1/1	29-11-2012
124			1	0/0	29-11-2012
127			1	1/1	29-11-2012
128		BUMPING	2	1/1	29-11-2012
569			4	1/1	29-11-2012

product no to load = | 1 new number = new product

2.a



Use the arrow keys to move to the desired program in the list.



Use the 'enter' key to select the highlighted program.

A program can also be selected by entering its number directly.

To create a new program:

Type a number that does not exist yet. When entered, the control asks whether or not to create a new program.

To delete a program:



Move the cursor bar to the correct program.

Press the 'clear' key. The program number changes to zero.

Press the ENTER key. The control will ask if you wish to delete the selected program. Choose yes (1) to confirm or no (0) to cancel.

## 2.2. Program edit

### 2.2.1. General properties

When a program has been selected (or created), a screen is shown with the general product parameters. These parameters are the same for every bend of the program.


Auto	PN: 123
Program 1	DN: EXAMPLE 123
<b>General</b>	
Drawing number	DN = EXAMPLE 123
Number of bends	NB = 1
Angle sel.	m $\alpha$ = 1 $\alpha$
Thickness	TH = 0.00 mm
Material	M = 1 STEEL (1.0037)
Punch	UP = 1
Die	UN = 1
Bending length	BL = 200 mm
Stock	ST = _____
<b>Corrections</b>	
G-corr. $\alpha$	G $\alpha$ = 0.00 °
G-corr. X	GX = 0.00 mm
DN =	EXAMPLE 123

2.b

This page gives all data which are the same for every bending of the program (main data of program).



Use the arrow keys up/down to move the cursor to the desired parameter.



After pressing the enter key the programmed value will be placed at the corresponding parameter.

## 2.2.2. Parameters explanation

### Drawing number .....DN

A name or description of the program. The maximum length is 20 characters.

### Number of bends .....NB

The number of bends in the current program.

When this value is increased, the additional bends are copied from the last bend.

When this value is decreased, the superfluous bends are deleted.

### Angle selection .....ma

Selection of the programming mode for the Y-axis.

0 = absolute: program the absolute Y-axis position for a bend.

1 = a: program the angle to bend. The required Y-axis position is computed.

Depending on this parameter, either the parameter 'angle' or the parameter 'bend position' will appear in a bend step.

### Thickness .....TH

Thickness of the sheet.

### Material .....M

Selection of one of the programmed materials, which are used to calculate the bending depths. The control contains 4 preprogrammed materials and 2 programmable ones. In total, 6 materials can be programmed on the control. See the chapter about programming constants how to program materials.

	E-MODULE (N/mm <sup>2</sup> )	TENSILE STRENGTH (N/mm <sup>2</sup> )
1 = Steel	210.000	400
2 = Aluminium	70.000	200
3 = Zinc	94.000	200
4 = Stainless steel	210.000	700
5 = Material 5	210.000	400
6 = Material 6	210.000	400

**Punch** ..... UP

Number of punch in library.


**Die** ..... UN

Number of die in library.

**Bending length** ..... BL

Length of sheet between tools.

When programming a bend, it is assumed the programmed tools have the necessary length.



2.c

**Stock** ..... ST

The number of products that should be created with this program.

**G-Corr α** ..... Gα

General correction of the angle, valid for each bend of the program. The value should be programmed in the same manner as for the correction per bend.

**G-Corr X** ..... Gx

General correction of the X-axis position, valid for each bend of the program. The value should be programmed in the same manner as for the correction per bend.

## 2.3. Bend programming

### 2.3.1. Introduction

The parameters of one bend are divided over 2 screen pages. The bend number, product number and drawing number are displayed in the top row on the screen.

Auto		BN: 1 / 1	PN: 123
		RP: 1 / 1	DN: EXAMPLE 123
Program 1			
Y = 0.00		X = _____.	
Method = 0 Angle = 90.00 Opening = 20.0 Force = 9		X-axis = 300.00 Retract = 0.00 R-axis = 0 Gauge pos = 0 Code = 2 Delay = 0 Deflect = 0	
Actual Repetition = 1 Corr.α1 = 0.00 Corr.α2 = 0.00		Corr.X = 0.00 Corr.DF = 0	
BM = 0 air bend			

2.d



Use the key 'change view' to switch to another page with bend parameters.  
When this key is pressed again, a screen with zoomed values appears.

The parameters below the line are corrections. They are not necessary when programming a product, but are used to correct the machine behaviour during production. They are described in chapter 6.

### 2.3.2. Bend parameters - first page

**Method** .....BM


Select the required bending method. The control supports 2 methods:

0 = Air bend

1 = Bottoming


---

## Bend methods:



air bend

The sheet is bent to the programmed angle by bringing the punch to the required depth. The control calculates the required Y-axis position to obtain the programmed angle.



bottoming

The sheet is bent by squeezing the sheet between the punch and the die. The control assumes the bottom of the die as required Y-axis position.

### Note:

When bottoming operation is selected, the end of bend position of the Y-axis beam is depending on the working tonnage. If however the force is sufficient for the beam to go to the calculated Y-axis end of bend position, the beam stroke will be limited by the position value.

### Angle ..... $\alpha$

The required angle of this bend. This parameter only appears if angle programming is selected with the parameter 'Angle sel.' and the bend method is an air bend.

### Bend position ..... Y

The required Y-axis position for this bend. This parameter only appears if absolute programming is selected with the parameter 'Angle sel.' This parameter also appears if the bend method is bottoming and/or flattening.

### Opening ..... DY

This parameter results in a certain gap opening between the punch and the die after the bend. A positive value is the gap opening above Mute, a negative value below Mute. When you want to limit the handling time of the product you can program a small positive or a negative value.

### Repetition ..... CY

0 = bending is skipped.  
1 through 99 = the number of times this bending will be repeated.

### X-axis ..... X

Backgauge position. When a negative sign is programmed this backgauge dimension is an incremental dimension. The incremental dimension is subtracted from the actual X-axis position. Therefore this parameter can also be used as a chaining measure.

### Retract ..... DX

Retract distance of backgauge during the bending. The "backgauge retract" is started at the pinching point of the sheet.

---

**Auxiliary axis .....** ..R/Z/Aux.

If you have one or more auxiliary axes (for instance a R-axis) the parameters of these axes appear here.

**Code .....** ..CX

Programmable parameter which determines when the parameter values for the next bending will be active. The possibilities are:

0 = Bending number change (step change) at end of decompression (next bend parameters active).

1 = Step change at muting position when the beam moves in opening direction.

2 = Step change at upper dead point.

3 = Step change at upper dead point without movement of any axis and the control goes to "stop".

4 = Step change if C-input signal becomes active, without movement of the beam. When you still have a beam movement there will be no retract function of the backgauge performed. See also code 5.

5 = Step change if C-input signal becomes active and the beam is in the upper dead point. Now you may move the beam and the retract function of the backgauge will be performed.

10= Step change at end of decompression with the Y-axis beam waiting at the pinching point until the backgauge is at the retract position.

11= Step change at mute position when the beam moves in the opening direction, with the Y-axis beam waiting at the pinching point until the backgauge is at the retract position.

12= Step change at upper dead point, with the Y-axis beam waiting at the pinching point until the backgauge is at the retract position.

13= Step change at upper dead point without movement of any axis. The Y-axis beam will wait at the sheet clamp point until the backgauge is at the retract position. After the bending with this code, the control goes to "stop".

15= Step change if C-input signal becomes active and the beam is in the upper dead point. The beam may be moved but not necessarily. The Y-axis beam will wait at the sheet clamp point until the backgauge is at the retract position.

The not mentioned CX-values have no meaning.

### 2.3.3. Bend parameters - second page

<b>Auto</b>	BN: 1 / 1	PN: 123																		
RP: 1 / 1	DN: EXAMPLE 123																			
<b>Program 1</b>																				
<b>Y = 0.00</b>		<b>X = _____.</b>																		
<table border="1"> <tr> <td>Speed</td> <td>=</td> <td>20.0</td> <td>Parallelism</td> <td>=</td> <td>0.00</td> </tr> <tr> <td>Decompr.</td> <td>=</td> <td>0.01</td> <td>Repetition</td> <td>=</td> <td>1</td> </tr> <tr> <td>Decomp speed</td> <td>=</td> <td>20.0</td> <td>Dwell time</td> <td>=</td> <td>0.1</td> </tr> </table>			Speed	=	20.0	Parallelism	=	0.00	Decompr.	=	0.01	Repetition	=	1	Decomp speed	=	20.0	Dwell time	=	0.1
Speed	=	20.0	Parallelism	=	0.00															
Decompr.	=	0.01	Repetition	=	1															
Decomp speed	=	20.0	Dwell time	=	0.1															
<table border="1"> <tr> <td>Actual Repetition</td> <td>=</td> <td>1</td> <td>Corr.X</td> <td>=</td> <td>0.00</td> </tr> <tr> <td>Corr.α1</td> <td>=</td> <td>0.00</td> <td>Corr.DF</td> <td>=</td> <td>0</td> </tr> <tr> <td>Corr.α2</td> <td>=</td> <td>0.00</td> <td></td> <td></td> <td></td> </tr> </table>			Actual Repetition	=	1	Corr.X	=	0.00	Corr.α1	=	0.00	Corr.DF	=	0	Corr.α2	=	0.00			
Actual Repetition	=	1	Corr.X	=	0.00															
Corr.α1	=	0.00	Corr.DF	=	0															
Corr.α2	=	0.00																		
<b>V = 20.0 mm/s</b>																				

2.e

This page contains the additional parameters of a bend.

**Force** ..... P

The required force during pressing (auto computed).

This force is precomputed from the bend properties Material, Thickness, Bending length and the V-opening of the die.

**Speed** ..... V

Working speed (pressing speed). Initially, the value for this parameter is copied from the parameter 'default pressing speed' in the programming constants menu.

**Dwell time** ..... T

Holding time of punch at bending point.

**Decompression** ..... DC

Decompression stroke after bending to release the working pressure

**Decomp speed** ..... BS


The decompression speed is the programmable speed which is active during the programmed decompression stroke.

**Delay time** ..... TX

Programmable delay time before step change (0-30sec).

**Parallelism . . . . . Y2**

Difference of left- and right hand side cylinder (Y1 and Y2). When positive, right hand side lower. When negative, right hand side higher. The programmed value is active below the clamping point.

**2.3.4. Bend parameters - third page**

When pressing the 'change view' button from any of the bend pages there is a third page available with large values. These "large actuals" are helpfull while working at the machine from a distance to the control. Most important values are displayed in a large charactersize and can be easily monitored.

Auto	BN: 1 / 1 RP: 1 / 1	PN: 123 DN: EXAMPLE 123
Program 1		
<b>Y = 0.00</b>		
<b>X = _____</b>		
<b>R = _____</b>		
<b>ST = _____</b>		

2.g

The control can be started from this view.

When pressing the 'change view' button again the first bend parameters page is displayed again.

### 2.3.5. All bends view

When pressing the 'change view' button from the general properties page of a bendprogram (Program tab) the list with all bends from the active program is displayed. Within this view all bends can be seen on one page and properties from each bend can be modified.

Auto		PN: 5 DN:							
Program		1	2	3	4	5			
Bend	Method	Angle	Opening	Repetition	Gauge pos	X-axis	Retract	R-axis >>	
1	0	90.00	20.0	3	0	200.00	0.00	0	
2	0	90.00	20.0	1	0	-20.00	0.00	0	
3	0	120.00	20.0	1	0	30.00	0.00	0	
4	0	90.00	20.0	1	0	40.00	0.00	0	
5	0	120.00	20.0	1	0	50.00	0.00	0	

Method =  0 air bend

2.h


The control can also be started from this view.

When pressing the 'change view' button again the general properties pages is displayed again.

## 2.3.6. Bumping programming

For big radius bends made with ‘bumping’ it is possible to simple program the required data in a numerical program. First the operator can select the bend method:

- 0 = Airbend
- 1 = Bottoming
- 2 = Bumping



2.i

When selecting the bend method ‘Bumping’ the operator can program the following parameters:

- Required bumping radius
- Total bumping angle
- The number of segments in the radius

The controller will calculate:

- The number of required bends
- The angles of the separate bends
- The backgauge positions of the separate bends

The first bend has an absolute backgauge position; the other bends will be treated as chained bends with relative backgauge positions.

Auto BN: 3 / 4 PN: 128  
RP: 5 / 5 DN: BUMPING

Program 1 2~ 3~ 4~

<b>Y</b>	=	<b>0.00</b>	<b>X</b>	=	_____.
Method	=	2	X-axis	=	-8.09
Angle	=	165.00	Retract	=	0.00
<b>Opening</b>	<b>=</b>	<b>20.0</b>	R-axis	=	10
Force	=	47	Gauge pos	=	0
Bumping angle	=	90.00	Code	=	10
Bumping radius	=	30.0	Delay	=	0
Segments	=	6	Deflect	=	2
Actual Repetition	=	5	Corr.X	=	0.00
Corr.α1	=	0.00	Corr.DF	=	0
Corr.α2	=	0.00	Corr.Bumping	=	0.00

DY =  mm

2.j

## 3. Programming of tools

### 3.1. Introduction

This chapter describes the programming of the tools.




Press this key for tool programming.

The first time this key is pressed, the screen for punch programming appears. To switch to programming of bottom dies, press this key again.

## 3.2. Programming of Punches


### 3.2.1. Punch library

The programming of punches is started by pressing the tools key.



3.a

A maximum of 30 punches can be programmed. Tools that are not programmed show an asterisk (\*) beside the tool number.



Use the arrow keys left/right to browse to the desired tool in the library.

### 3.2.2. Punch parameters

**Height** .....H

The height of the tool. Important: this height value will be used in bend depth calculation.

**Angle** .....a

The angle of the punch tip.

**Radius** .....RA

The radius of the punch.

This parameter has to be used as selection criterium, the value will not be used in computation formulas.


**Resistance** .....R

Maximum allowable force on punch in kN/mm.

### 3.3. Programming of bottom dies


#### 3.3.1. Die library

The programming of dies is started by pressing the tools key.



3.b

A maximum of 30 dies can be programmed.



Use the arrow keys left/right to browse to the desired tool in the library.

### 3.3.2. Die parameters


**Height** ..... H

The height of the tool. Important: this height value will be used in bend depth calculation.

**V-opening** ..... W

The V-opening of the die.

V-die opening:



The width V is the distance between the touching lines crossing.

**Angle** .....  $\alpha$


The angle of the die.

**Radius** ..... RA

The radius of the edges of the V-opening.

**Mute** ..... M

Muting distance. Distance above the sheet at which the speed change takes place.



---

**X-safe** ..... SN

Calculated safety zone (minimum X-axis value), which will be used in the case an R-axis is mounted. This to prevent finger to die collision. The indicated minimum value is computed automatically from the die dimensions as follows:

X-SAFE = FS +  $\frac{1}{2}$  V in which:

FS = flat section on the back side of the V-groove

V = opening value

In this formula also a small additional safety value (0.5 mm) has been added.

**Resistance** ..... R

Maximum allowable force on the die in kN/mm.

## 4. Program Constants

### 4.1. Introduction




Press this key to enter the program constants. The program constants are divided across several pages. They are discussed in the following sections.

### 4.2. General

The screenshot shows the 'Program constants' interface version 3.4. The 'General' tab is selected. At the bottom, there is a text input field labeled 'IS =' containing '0 mm'.

Parameter	Value	Unit	Action
Inch/mm-select	IS = 0	mm	⋮⋮⋮
Ton/kN-select	TS = 0	kN	⋮⋮⋮
Language	LA = English		⋮⋮⋮

4.a



Use the arrow keys left/right to browse through the various pages with parameters. Use the arrow keys up/down to select individual parameters.



At some parameters, a value can be selected with the 'constants' key. This is indicated by the symbol ⋮⋮⋮.

---

**Inch/mm-select .....**.IS

1 = dimensions in inches  
0 = dimensions in millimeters

**Ton/kN select .....**.TS

1 = Ton  
0 = kN

It is possible to select the units for all Force data to be expressed in Tons or kN.

**Language.....**.LA

Select the language for the user interface. The following languages are supported:

0 = English	11 = Polish
1 = German	12 = Lithuanian
2 = Danish	13 = Slowenian
3 = French	14 = Turkish
4 = Italian	15 = Russian
5 = Dutch	16 = Brazilian
6 = Swedish	17 = Hungarian
7 = Czech	21 = Chinese
8 = Spanish	22 = Chinese Traditional
9 = Finnish	23 = Korean
10 = Portugese	24 = Japanese

### 4.3. Materials

Program constants		V3.4				
General	Materials	Program settings	Computation settings	Production settings	Backgaug	▷
ID	Material name	$\sigma$		E		
1	STEEL (1.0037)	400		210000		
2	ALUMINUM	200		70000		
3	ZINC	200		94000		
4	STAINLESS STEEL (1.4016)	700		210000		
5	MATERIAL 5	400		210000		
6	MATERIAL 6	400		210000		

Tensile strength =  N/mm<sup>2</sup>

4.b

In this window, material properties can be programmed. You can edit existing materials, program new materials or delete existing materials. A maximum of 6 materials can be programmed on the control.

For each material, three properties are present and can be viewed and edited.

**Material name .....** ..NA

Name of the material. The maximum allowed length of the material name is 25 characters, the name must begin with a character (not a numeral).

**Tensile strength .....** ..S

Tensile strength of the selected material.

**E module .....** ..E

E- module of the selected material.


The materials are initially listed according to their material number, which is shown in the first column (ID).

To change an existing material, go to the relevant line and change the values as you see fit. Use the ENTER key to confirm a typed value.

To delete an existing material, move the cursor to the relevant line and press the function key 'delete material' (S6) to erase the values.

To program a new material, move the cursor to an empty space and start programming its values.

## 4.4. Program settings



4.c

### Machine number ..... .MN

When there are several bending machines in a factory, it can be useful to give the control on each machine a unique machine number.

The selected machine number will be stored with the bending program. This number will be checked when a program is read from USB key. When the machine number does not match you must confirm to read it anyway or not. If you do not confirm the question the action will be aborted.

The machine number is also stored in the filenames of tools. When the machine number is changed in this screen, you are prompted to make a new backup of your tools because the filenames of all tools have been changed according to the new machine number.

### Angle correction database ..... .CD

Toggle function, to switch the database with angle corrections on or off.

Angle corrections are entered in production mode (automatic/step by step). These corrections are stored in the product program. Beside this, it is also possible to store these corrections in a general database with angle corrections. This way corrections that have once been entered for certain bends remain available for future use in other products.

When this setting is switched on, the control checks during production whether corrections for similar bends are present in the database. If corrections for certain bends are available, then they will be offered. On other occasions, corrections can be interpolated and offered.

The correction database is adjusted by entering new corrections during production. When the database is enabled with this parameter, all new-entered corrections are stored in the database.

When searching for similar bends, the control searches for bends that have the same

---

properties as the active bend. The following properties of a bend are compared:

- Material properties
- Thickness
- Die opening
- Die radius
- Punch radius
- Angle

The first five properties of a bend must be exactly the same as the active bend to start a comparison.

If an angle is found with the same value as the angle of the active bend, the correction is offered.

If no matching angle is found, the control will attempt to interpolate a correction from already existing corrections. To compute a correction, the following two conditions must be obeyed:

- If the angle of the active bend must have a maximum difference of 10° with two adjacent bends.
- The corrections of these two adjacent bends may differ no more than 5°.

**Y opening default .....**.....13

Default Y-axis opening value.

The value programmed here is used as initial value for the parameter 'Y-axis opening' when making a new bend program.

**Default X-axis code .....**.....XC

Default value for the parameter 'code' in a bend program. This parameter determines the moment of step change in a bend program. Initially the code parameter is set to the value programmed here during postprocessing and during programming.

The default value of this parameter = 2.

See chapter 'program edit' for more information about the code parameter.


**Default X time .....**.....XT

Default waiting time for step change. With this parameter you can preset a longer waiting time when needed for product handling.

**Deafult hold time .....**.....HT

Default value for the dwell time, the time the pressbeam stays at the bending position.

## 4.5. Computation settings



4.d

**Data preparation bend allowance . . . . . BA**

0 = correction off


1 = correction on

With this parameter you can choose whether or not you wish to have programmed values corrected for bend-allowance. This on/off setting only refers to corrections during product programming of a new program in the menu 'program edit'. If a numeric program has been entered with corrections on, the axis corrections are calculated and stored in the program. These corrections can be viewed and edited in production mode (see 'Automatic mode').

**Bottoming Force Factor . . . . . BF**

The pressure needed for an airbend multiplied by this factor in order to obtain the coining pressure.

## 4.6. Production settings



4.e

### **Stock count mode . . . . . SC**

Setting for the stock counter in production mode, to have the stock counter (product counter) count up or down.

When downcounting is selected, the stock counter in production mode is decremented after each completion of a product. When the counter has reached zero, the control is stopped. On the next start action, the stock counting value is reset to its original value. When upcounting is selected, the counter is incremented after each completion of a product.

Downcounting can be useful if a pre-planned quota must be produced. Upcounting could be used to give a report on production progress.

### **Pressure correction . . . . . PC**

Percentage of calculated tonnages which actually controls the pressure valve.

### **Clamping correction . . . . . CC**

The position of the beam at which the sheet is clamped, is calculated. In order to have a firm clamped sheet it is possible to offset the calculated pinch point with the value here programmed. A positive value will result in a deeper position, a negative value in a higher position of the beam.

### **X-reference correction . . . . . C1**

When the actual, mechanical X-axis position is not corresponding with the displayed value than is it possible to correct the position with this parameter. Program the calculated difference.


Example:

- When the programmed and displayed value = 250 and the actual, mechanical position value = 252 the XR parameter = -2.
- When the programmed and displayed value = 250 and the actual, mechanical position value = 248 the XR parameter = +2.

---


**Intermediate R for X-movement.....RS**

Temporary position for the R-axis, to avoid collision as a result of movement of the X-axis. The value 0 disables this functionality. When programmed not equal to zero this position will be active when the X-axis has to move inside the safety zone of the die.



4.f


#### 4.7. Backgauge dimensions



4.g

**Gauge R offset .....** RO

An offset value for the R-axis when the X-axis position is outside the die safety zone.



4.h

A negative value gives a lower backgauge position. This offset is only valid for gauge position 0.

**Finger height .....** FH

The height of the default finger level.

Used to correct the R-axis position in case of lay-on.


**Finger length .....** FL

The length of the first finger level.

Used to correct the X-axis position in case of lay-on.

---

## 4.8. Maintenance



4.i

**Hours** .....

The number of hours the machine is running.

**Strokes** .....

The number of strokes the pressbeam has executed.

#### 4.9. Data transfer



4.j

From this menu, all program data on the control can be stored on an external USB device or restored from such a device.

Backup products	Copy all products from the control to the USB disk. Existing products on the USB disk with the same name are replaced.
Restore products	Copy all products present on the USB disk to the control. Existing products on the control with the same name are replaced.
Backup tools	Copy all tools from the control to the USB disk. Existing tools on the USB disk with the same name are replaced. Beside the tools, also the program constants are stored.
Restore tools	Copy all tools present on the USB disk to the control. Existing tools on the control with the same name are replaced.



## 5. Manual mode

### 5.1. Introduction



**Manual mode** By pushing this key the CNC is in manual mode.

In manual mode you program the parameters for one bending.  
After pushing the 'Start' button all parameters are active and the backgauge will go into position. It is also possible to move the axes manually, see section 5.2.

Manual	
<b>Y =</b> _____	<b>X =</b> _____
Punch = 1	X-axis = 150.00
Die = 1	Retract = 0.00
Material = 1	R-axis = 0
Thickness = 1.00	Deflect = 4
length = 1000	
Method = 0	
Corr.α = 0.00	
Angle = 90.00	
Y1-axis = 111.66	Opening = 20.0
Y2-axis = 111.66	Speed = 10.0
Mute = 105.00	
Decompr. = 0.04	Decomp speed = 10.0
Force = 94	Dwell time = 0.1
	Parallelism = 0.00
UP = 1	

5.a



Use the key 'change view' to switch to a screen with zoomed values.

### 5.2. Parameter Explanation

All the parameters can be programmed independently of the programs in memory.

**Punch** ..... UP  
Number of selected punch in the library.


**Die** ..... UN  
Number of selected die in the library.

---

<b>Material</b>	.....MA
	Selection of one of the programmed materials, which are used to calculate the bending depths. The control contains 4 preprogrammed materials. In total, 6 materials can be programmed on the control. See the chapter about programming constants how to program materials.
<b>Thickness</b>	.....TH
	Thickness of the sheet.
<b>Length</b>	.....BL
	Length of the sheet between the tools.
<b>Method</b>	.....BM
	Select the required bending method. The control supports 2 methods: Air bend Bottoming See chapter 2 for more information about possible bend methods.
<b>Corr. <math>\alpha</math></b>	..... $C\alpha$
	Correction on angle to bend The angle correction should be entered as follows: - Programmed value of 90 degrees. - Measured value of 92 degrees. Then it is required to program Corr._ with -2. - Programmed value of 90 degrees. - Measured value of 88 degrees. Then it is required to program Corr._ with +2.
<b>Angle</b>	..... $\alpha$
	Angle to bend.
<b>Y1-axis</b>	.....Y
	The programmed or calculated Y-axis value to realise a certain angle.
<b>Y2-axis</b>	.....Y
	The programmed or calculated Y-axis value to realise a certain angle. Normally Y2 is copied from Y1. Y2 can be programmed differently in case of conical bending.

**Mute** .....M

Sequence point where the Y-axis is switched from fast closing speed to pressing speed.  
It is programmed here as a Y-axis position value.



5.b

**Decompression** .....BP

Decompression stroke after the bending to release the working pressure. The same parameter as DC in the auto mode.

**Force** .....P

The required force during pressing (auto computed).

This force is precomputed from the bend properties Material, Thickness, Bending length and the V-opening of the die.

**X-Axis** .....X

The programmed value in X- direction to get a certain backgauge position.

**Retract** .....DX

Retract distance of backgauge during the bending. The "backgauge retract" is started at the pinching point of the sheet.

**Auxiliary axis** .....R

If you have one or more auxiliary axes (for instance a R-axis, Z-axis or part support) the parameters of these axes appear here.

**Opening** .....DY

This parameter results in a certain gap opening between the punch and the die after the bend. A positive value is the gap opening above Mute, a negative value below Mute.

When you want to limit the handling time for the product you can program a small positive or a negative value.

**Speed** .....S

Pressing speed.

**Decomp speed** .....BS

The decompression pressure speed is the programmable speed of the beam during the decompression stroke.


**Hold time** .....T

Dwell time of punch at the bending point.

---

## Parallelism . . . . . Y2

Difference of left- and right hand side cylinder (Y1 and Y2). When positive right hand side lower. When negative right hand side higher. The programmed value is active below the clamping point.



After pushing the start button all the programmed parameters are active.

### 5.3. Zoomed values

A screenshot of a manual control interface titled "Manual". The screen displays the following parameter settings:

- Y = 111.66
- X = \_\_\_\_\_
- R = \_\_\_\_\_
- DF = 0

The "DF" row is highlighted with a dark grey background. At the bottom of the screen, there is a horizontal bar with several small icons.

5.d

In this screen, the values of the controlled axes are displayed.

## 5.4. Manual operation of the axes

### 5.4.1. General




Press this key to activate the manual movement mode.

It is possible to move an axis by pressing the arrow keys on the front panel of the control. After pressing the key 'manual pos', the following screen appears:

Manual	
Programmed	Actual position
Y = 111.66	_____.
Y1 = 111.66	_____.
Y2 = 111.66	_____.
X = 150.00	< [ ] >
R = 0	_____

20.5

5.e



Put the cursor bar on the axis you wish to move with the arrow keys. Then simply press the keys and watch the movement of the intended axis.

The procedure for moving the axis depends on the axis you wish to move.

- Auxiliary axes:

With the keys the backgauge can be positioned manually. This operation is only possible in "Stop" + "Manual Mode".

---

First you select the respective backgauge axis with help of the "Manual positioning"-key, so that you will see the cursor bar at the required axis. Then you can move the axis with help of the keys.

- Y-axis:

With the keys the punch can be positioned manually in the same way as for the auxiliary axes. This operation is only possible in "Start" + "Manual Mode". Furthermore, the following conditions must be met:

- The 'adjust' function must be active, indicated on the screen by "Adjust" in the lower righthand corner.
- The Y-axis must be below mute-point.
- A pressing command must be given to the CNC.

#### **5.4.2. To teach**

You can teach an axis a correct position within the manual positioning mode. When you have moved an axis to a certain position with the cursor keys, you may want to store this position. To do so, press the ENTER key within this screen.

The actual axis value (left side) will appear in the programmed axis field (right side).

## 6. Automatic mode

### 6.1. Introduction

<b>Auto</b>	BN: 1 / 1 RP: 1 / 1	PN: 123 DN: EXAMPLE 123																																											
<b>Program 1</b>																																													
<b>Y = 0.00</b>		<b>X = _____.</b>																																											
<table border="1"> <tr> <td><b>Method</b></td> <td>= 0</td> <td><b>X-axis</b></td> <td>= 300.00</td> </tr> <tr> <td><b>Angle</b></td> <td>= 90.00</td> <td><b>Retract</b></td> <td>= 0.00</td> </tr> <tr> <td><b>Opening</b></td> <td>= 20.0</td> <td><b>R-axis</b></td> <td>= 0</td> </tr> <tr> <td><b>Force</b></td> <td>= 9</td> <td><b>Gauge pos</b></td> <td>= 0</td> </tr> <tr> <td></td> <td></td> <td><b>Code</b></td> <td>= 2</td> </tr> <tr> <td></td> <td></td> <td><b>Delay</b></td> <td>= 0</td> </tr> <tr> <td></td> <td></td> <td><b>Deflect</b></td> <td>= 0</td> </tr> <tr> <td colspan="2"><b>Actual Repetition</b></td> <td>= 1</td> <td><b>Corr.X</b></td> <td>= 0.00</td> </tr> <tr> <td colspan="2"><b>Corr.α1</b></td> <td>= 0.00</td> <td><b>Corr.DF</b></td> <td>= 0</td> </tr> <tr> <td colspan="2"><b>Corr.α2</b></td> <td>= 0.00</td> <td></td> <td></td> </tr> </table>			<b>Method</b>	= 0	<b>X-axis</b>	= 300.00	<b>Angle</b>	= 90.00	<b>Retract</b>	= 0.00	<b>Opening</b>	= 20.0	<b>R-axis</b>	= 0	<b>Force</b>	= 9	<b>Gauge pos</b>	= 0			<b>Code</b>	= 2			<b>Delay</b>	= 0			<b>Deflect</b>	= 0	<b>Actual Repetition</b>		= 1	<b>Corr.X</b>	= 0.00	<b>Corr.α1</b>		= 0.00	<b>Corr.DF</b>	= 0	<b>Corr.α2</b>		= 0.00		
<b>Method</b>	= 0	<b>X-axis</b>	= 300.00																																										
<b>Angle</b>	= 90.00	<b>Retract</b>	= 0.00																																										
<b>Opening</b>	= 20.0	<b>R-axis</b>	= 0																																										
<b>Force</b>	= 9	<b>Gauge pos</b>	= 0																																										
		<b>Code</b>	= 2																																										
		<b>Delay</b>	= 0																																										
		<b>Deflect</b>	= 0																																										
<b>Actual Repetition</b>		= 1	<b>Corr.X</b>	= 0.00																																									
<b>Corr.α1</b>		= 0.00	<b>Corr.DF</b>	= 0																																									
<b>Corr.α2</b>		= 0.00																																											
<b>BM = 0 air bend</b>																																													

6.a

In the automatic mode a bend program can be executed automatically bend by bend after pushing the 'start'-key. When a new bending program is selected you must check your tools and tool positions in your machine.

In the header information is displayed on the number of bends, the repetition of a bend, the product number and the drawing number.

Above the horizontal line the programmed and computed parameters are displayed. See chapter 2 about programming of these parameters.

The parameters below the horizontal line are corrections on the programmed values.

If the key lock is active, the program parameters (above the line) cannot be changed. The correction parameters (below the line) can always be changed.



Use the key 'change view' to switch to another page with bend parameters.

When this key is pressed again, a screen with zoomed values appears.

---

## 6.2. Parameters

**Select repeat** .....CY  
Selection of one of the repeated steps of one bend. Useful if a bend has a repetition value larger than 1.

**Corr  $\alpha$ 1** .....C $\alpha$

**Corr  $\alpha$ 2** .....C $\alpha$   
Corrections on angle values (C $\alpha$ ) in this bending.  
Angle corrections can be programmed for both sides of the machine, Y1 and Y2. When correction  $\alpha$ 1 is entered for one side, this value is automatically copied to the  $\alpha$ 2 correction for the other side. The correction for the other side can then be changed. When both angle corrections have been entered, the resulting corrections for Y-axis and parallelism are calculated. The corrections will be saved in the active bending program. The angle correction should be entered as following examples indicate:

1) Programmed value of 90 degrees.

Measured value of 92 degrees.

Then it is required to program Corr.  $\alpha$  with -2.

2) Programmed value of 90 degrees.

Measured value of 88 degrees.

Then it is required to program Corr.  $\alpha$  with +2.

In case the angle correction database has been switched on, the control checks whether a correction exists for this type of bend in the database. The result of this check is prompted in the entry field:

**No stored correction.** No correction has been found for this bend

**Stored correction.** A correction that matches the current bend has been found

**Interpolated correction.** A correction has been calculated (interpolated) based on other existing corrections

If a correction is entered, it will be stored in the database. At each next bend with the same properties, this same correction will be offered.

See the chapter 'Program constants' for more information on the angle correction database.

**Corr X** .....Cx  
Corrections on X-axis positions (Cx) in this bending. In case bend allowance is activated (see PROGRAM CONSTANTS) and a program has been entered in data preparation, the X-axes correction values are the result of bend allowance calculation. The corrections will be saved in the active bending program.

The X-axis correction should be entered as following examples indicate:

1) Programmed value of 200 millimeters.

Measured value of 202 millimeters.

Then it is required to program Corr.x with -2


2) Programmed value of 200 millimeters.

Measured value of 198 millimeters.

Then it is required to program Corr.x with +2

### 6.3. Zoomed values

When the function key 'zoomed values' has been pressed, the control switches to a new view with only axes values on the screen.



6.b

---

#### 6.4. Manual operation of the axes



Press this key to activate the manual movement mode.

It is possible to move an axis by pressing the arrow keys on the front panel of the control. After pressing the key 'manual pos', the following screen appears:

<b>Auto</b>	<b>Bend: 3 of 4</b>
<b>Programmed                          Actual position</b>	
Y =	_____.
X = -8.09	<b>&lt;</b> <b>.</b> <b>&gt;</b>
R = 10	_____
DF = 2	0
21.9	

6.c

The procedure for manual movement is described in section 5.2.

**A. Parameter index**

This appendix contains a list of all parameters described in this manual, in alphabetic order.

Angle . . . . .	2.6
Angle . . . . .	3.3
Angle . . . . .	3.5
Angle . . . . .	5.2
Angle correction database . . . . .	4.4
Angle selection . . . . .	2.3
Auxiliary axis . . . . .	2.7
Auxiliary axis . . . . .	5.3
Bend position . . . . .	2.6
Bending length . . . . .	2.4
Bottoming Force Factor . . . . .	4.6
Clamping correction . . . . .	4.7
Code . . . . .	2.7
Corr $\alpha_1$ . . . . .	6.2
Corr $\alpha_2$ . . . . .	6.2
Corr X . . . . .	6.2
Corr. $\alpha$ . . . . .	5.2
Data preparation bend allowance . . . . .	4.6
Default hold time . . . . .	4.5
Decomp speed . . . . .	2.8
Decomp speed . . . . .	5.3
Decompression . . . . .	2.8
Decompression . . . . .	5.3
Default X time . . . . .	4.5
Default X-axis code . . . . .	4.5
Delay time . . . . .	2.8
Die . . . . .	2.4
Die . . . . .	5.1
Drawing number . . . . .	2.3
Dwell time . . . . .	2.8
E module . . . . .	4.3
Finger height . . . . .	4.9
Finger length . . . . .	4.9
Force . . . . .	2.8
Force . . . . .	5.3
Gauge R offset . . . . .	4.9
G-Corr $\alpha$ . . . . .	2.4
G-Corr X . . . . .	2.4
Height . . . . .	3.3
Height . . . . .	3.5
Hold time . . . . .	5.3
Hours . . . . .	4.10
Inch/mm-select . . . . .	4.2
Intermediate R for X-movement . . . . .	4.8
Language . . . . .	4.2
Length . . . . .	5.2
Machine number . . . . .	4.4
Material . . . . .	2.3
Material . . . . .	5.2
Material name . . . . .	4.3
Method . . . . .	2.5

Method . . . . .	5.2
Mute . . . . .	3.5
Mute . . . . .	5.3
Number of bends . . . . .	2.3
Opening . . . . .	2.6
Opening . . . . .	5.3
Parallelism . . . . .	2.9
Parallelism . . . . .	5.4
Pressure correction . . . . .	4.7
Punch . . . . .	2.4
Punch . . . . .	5.1
Radius . . . . .	3.3
Radius . . . . .	3.5
Repetition . . . . .	2.6
Resistance . . . . .	3.3
Resistance . . . . .	3.6
Retract . . . . .	2.6
Retract . . . . .	5.3
Select repeat . . . . .	6.2
Speed . . . . .	2.8
Speed . . . . .	5.3
Stock . . . . .	2.4
Stock count mode . . . . .	4.7
Strokes . . . . .	4.10
Tensile strength . . . . .	4.3
Thickness . . . . .	2.3
Thickness . . . . .	5.2
Ton/kN select . . . . .	4.2
V-opening . . . . .	3.5
X-axis . . . . .	2.6
X-Axis . . . . .	5.3
X-reference correction . . . . .	4.7
X-safe . . . . .	3.6
Y opening default . . . . .	4.5
Y1-axis . . . . .	5.2
Y2-axis . . . . .	5.2

