



**SEW**  
EURODRIVE



## DOP11A Operator Terminals

EE410000

Edition 09/2004

11276916 / EN

# System Manual





<b>1 Important Notes.....</b>	<b>5</b>
<b>2 Safety Notes .....</b>	<b>7</b>
<b>3 Unit Information, Installation and Hardware.....</b>	<b>9</b>
3.1 Introduction .....	9
3.2 Unit designation, nameplates and scope of delivery .....	14
3.3 Unit design DOP11A-10.....	15
3.4 Unit design DOP11A-20.....	16
3.5 Unit design DOP11A-30.....	17
3.6 Unit design DOP11A-40.....	18
3.7 Unit design DOP11A-50.....	19
3.8 Accessories and options .....	20
<b>4 Installation .....</b>	<b>22</b>
4.1 Installation instructions for basic unit .....	22
4.2 UL compliant installation .....	23
4.3 Connection of basic unit DOP11A-10 to DOP11A-50 .....	23
4.4 Connection to a PC .....	24
4.5 RS-485 connection (DOP11A-10 and DOP11A-30 only).....	25
4.6 Connection RS-422 via UWS11A .....	28
4.7 Connection PFE11A ETHERNET option .....	29
4.8 Connection PFP11A PROFIBUS-DP option .....	30
4.9 Connection to a Siemens S7 via MPI and PCM11A .....	31
<b>5 Startup.....</b>	<b>32</b>
5.1 Initial operation.....	32
5.2 Operator terminal functions.....	35
<b>6 Operation and Service .....</b>	<b>44</b>
6.1 Project transfer with PC and HMI-Builder .....	44
6.2 Operating display at unit start .....	48
6.3 Error Messages.....	49
6.4 SEW electronics service .....	51
<b>7 Programming.....</b>	<b>52</b>
7.1 Creating a project.....	52
7.2 Communication with MOVIDRIVE® and MOVITRAC® 07 .....	59
7.3 Programming with the programming software .....	68
7.4 Graphic display and control.....	118
7.5 Text-based display and control .....	159
7.6 Transferring projects .....	163
7.7 Expansion cards for ETHERNET and PROFIBUS-DP .....	170
7.8 Index addressing.....	178



<b>8 Unit functions .....</b>	<b>182</b>
8.1 Message library .....	182
8.2 Alarm handling .....	184
8.3 Recipe management .....	190
8.4 Passwords .....	196
8.5 Printing reports .....	198
8.6 Time control .....	201
8.7 Language handling .....	202
8.8 Unicode .....	206
8.9 LEDs .....	209
8.10 Function keys .....	210
8.11 Trends .....	213
8.12 Macros .....	217
<b>9 Network Functions and Communication .....</b>	<b>220</b>
9.1 Communication .....	220
9.2 Network communication .....	229
9.3 Network functions in the terminal .....	237
9.4 Network services .....	252
9.5 Network accounts .....	262
<b>10 Technical Data and Dimension Drawings .....</b>	<b>264</b>
10.1 General technical data .....	264
10.2 Pin assignment .....	267
10.3 DOP11A-10 .....	270
10.4 DOP11A-20 .....	271
10.5 DOP11A-30 .....	272
10.6 DOP11A-40 .....	273
10.7 DOP11A-50 .....	274
<b>11 Appendix .....</b>	<b>275</b>
11.1 Membrane keypad .....	275
11.2 Downloading the system program .....	277
<b>12 Index .....</b>	<b>278</b>



## 1 Important Notes

### *Safety and warning notes*

**Always observe the safety and warning instructions contained in this publication!**



#### **Hazard**

Indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.



#### **Warning**

Indicates an imminently hazardous situation caused by the product which, if not avoided, **WILL** result in death or serious injury. You will also find this signal to indicate the potential for damage to property.



#### **Caution**

Indicates a potentially hazardous situation which, if not avoided, **MAY** result in minor injury or damage to products.



#### **Note**

Indicates a reference to applications, for example for startup, or other useful information.



#### **Documentation reference**

Indicates a reference to a document, such as operating instructions, catalog, data sheet.

You must adhere to the operating instructions to ensure:

- Fault-free operation
- Fulfillment of any rights to claim under limited warranty

Consequently, read the operating instructions before you start working with the unit!

The operating instructions contain important information about servicing. Therefore, keep the operating instructions close to the unit.

### *Notes on terminology*

The operator terminals of the DOP11A series (Drive Operator Panel) can communicate with SEW frequency inverters and selected programmable logic controllers (PLC) via different communication paths at the same time.

For simplicity sake, we will be referring to **both units (PLC and inverter)** as **controller** in this document.

***Designated use***

The operator terminals of the DOP11A series are units for operation and diagnostics of industrial and commercial systems.

Do not start up the unit (take it into operation in the designated fashion) until you have established that the machine complies with the EMC Directive 89/336/EEC and that the conformity of the end product has been determined in accordance with the Machinery Directive 89/392/EEC (with reference to EN 60204).

***Operational environment***

**The following uses are forbidden unless measures are expressly taken to make them possible:**

- Use in explosion-proof areas.
- Use in areas exposed to harmful oils, acids, gases, vapors, dust, radiation, etc. You will find a list of the approved materials in the appendix.
- Use in non-stationary applications that are subject to mechanical vibration and shock loads in excess of the requirements in EN 50178.

***Safety functions***

The operator terminals of the DOP11A series may not execute any safety functions without master safety systems.

Use higher level safety systems to guarantee the protection of machinery and people.

***Disassembly and waste disposal***

- Complete or partial recycling of the operator terminal is subject to local regulations.
- Note that the following components contain substances that may represent a health hazard and cause environmental pollution: Lithium battery, electrolyte condensers and display.



## 2 Safety Notes

### **General information**

- Read the safety precautions carefully.
- Check the delivery for transport damage. If damage is found, advise your supplier.
- The terminal fulfills the requirements of article 4 of EMC directive 89/336/EEC.
- Do not use the terminal in an environment with high explosive hazard.
- SEW-EURODRIVE is not liable for modifications, changes, additions and / or alterations to the product.
- Use only spare parts and accessories manufactured according to SEW-EURODRIVE specifications.
- Read the installation and operating instructions completely and carefully prior to installation, use or repair of the terminal.
- Never allow fluids to penetrate the slots or holes in the terminal. This may lead to a fire or cause the equipment to become live.
- Operation of the terminal is restricted to qualified personnel.

### **Installation and startup**

- The terminal has been designed for stationary installation.
- Place the terminal on a stable base during installation. The terminal may be damaged if it is dropped.
- Install the terminal according to the accompanying installation instructions.
- The unit must be grounded according to the accompanying installation instructions.
- The installation must be performed by qualified personnel.
- Route high-voltage cables, signal cables and supply cables separately from one another.
- Make sure that the voltage and polarity of the electrical power source are correct before you connect the terminal to the power supply.
- The openings in the housing are designed to allow air to circulate and must not be covered over.
- Do not install the terminal in locations where it will be exposed to a powerful magnetic field.
- **Do not install or operate the terminal where it will be exposed to direct sunlight.**
- The peripheral equipment must be suitable for the application.
- On certain terminal models, the display glass is covered with a laminated foil to protect it from scratches. Pull off the foil carefully following installation to prevent static electricity causing damage to the terminal.



- Make sure that **preventive measures** and **protection devices** correspond to the **applicable regulations** (e. g. EN 60204 or EN 50178).

Required preventive measures:      Grounding the unit


Necessary protective devices:      Overcurrent protective devices

#### ***Operating notes***

- Always keep the terminal clean.
- **Emergency stop and other safety functions should not be controlled from the terminal.**
- Do not touch the keys, displays, etc. with sharp objects.
- Bear in mind that the terminal is ready to operate even if the backlighting no longer functions. This means keyboard and touchscreen inputs will still be registered.

#### ***Service and maintenance***

- The agreed limited warranty applies.
- Clean the display and face of the terminal with a soft cloth and mild detergent.
- Repairs must be performed by qualified personnel.







## 3 Unit Information, Installation and Hardware


### 3.1 Introduction

Production rates in modern industrial environments are steadily increasing and operator tasks at machines or on production lines are becoming increasingly more complex and involve more responsibility. The operator must be able to obtain information on the current status quickly and easily, and be able to influence the operation of the machine just as easily. The functions in the control systems are also increasing and becoming more advanced, enabling more complicated processes to be controlled efficiently. The operator terminals make human-machine communication simple and safe even for the most advanced processes.

The graphical operator terminals have been developed to meet the requirements set for human-machine communication when controlling or monitoring different applications in the manufacturing and process industries, etc. They simplify the operators work since they can easily be adapted to the working environment, that means the operator can continue to use the concepts her or she is familiar with.

Projects in the terminal can be built up as menu hierarchies or as sequences. A menu hierarchy consists of a main menu (with, for example, an overview) and a number of underlying menus with more detailed information on special sections. The operator normally selects which menu is to be shown.


The menus in the operator terminals are called blocks.



53717AEN



A sequence is also based on a main menu, from which the operator selects a sequence showing the blocks in a predetermined order. Control of block display usually takes place via the program in the controller.



53719AEN

The functions of the operator terminals allow for a graphical or text-based display of the process. There are also functions for

- Alarm handling
- Print
- Trends
- Recipe handling
- Time control

The functions are not only easy to use in the panel, they are also cost-efficient in comparison with conventional solutions with buttons, indicator lamps, time relays, preset counters and seven-day clocks. There are also functions to increase the application of the drive electronics.



### **Programming**

You program the operator terminal via PC and the HMI-Builder software.



10575AXX

The operator terminal is to a large extent object-oriented, i.e. first an object is selected and then the function the object is to have. All types of signals are defined on this principle.

The programmed project is stored in the operator terminal.

### **Connection of the terminal to the SEW frequency inverter**

There are many advantages in using a terminal together with the controller system:

- The user does not need to make any changes or additions in the existing controller programs
- and the terminal does not block any of the inputs or outputs in the controller system.
- Overview of controller functions will be optimized, e.g. time control and alarm handling.



#### **Status display and control**

The operator is familiar with indicator lamps as well as analog and digital display instruments since these are used in the majority of applications today. The same applies to push buttons and rotary and thumbwheel switches for controlling a system. The terminal enables the operator to have all status displays and controls in one unit.

The operator can easily see and influence information in the controller system. Moreover, it is possible to clearly see and influence all the signals affecting a specific object, e.g. a pump or a drive unit, which further simplifies the work.

This is possible thanks to the fact that the interchange of all information takes place through the so-called blocks in the terminal. Blocks can be of the text block type, with only text information, or of the graphic block type, with full graphical presentation.


The operator terminals are equipped with function keys for direct control. Maneuvering is controlled by linking different commands to the function keys. This optimizes the maneuvering process.

If several blocks are used, the operator can jump between the different blocks by using jump commands. This creates a menu hierarchy, which produces a structured application.

#### **Setting up the operator terminal**

The terminal should be placed at the workplace to ensure maximum usability. This will enable the operator to receive all necessary information and work effectively. Set up the terminal at the correct height so that the user can see and operate it without problems. Visibility of the screen is influenced by distance, height, angle, light and color selection.

Monitoring, control and maintenance are remote functions and can be executed, for example, from a different location in the building or a different city. Communication in such instances can take place via LAN (Local Area Network), Internet or modem. If there is a long production line with a large number of workplaces it is possible to connect several terminals to one or several controller systems in the network.



10553AXX


#### **Compact solutions**

External units such as barcode scanners, weighing machines, modems, etc. can be connected through the terminal to the controller system. All that is required is for the unit to be connected to an RS-232 interface, and that communication is made through ASCII protocol. Data entering the terminal is written directly to the controller register.



It is also possible to connect a unit working in parallel, such as an additional terminal or a PC with the MOVITOOLS® programming tool for the inverter. The terminal then makes it possible to program the controller system while also communicating with the controller system.

When the PLC and the inverter are connected to one terminal (two drivers in the terminal), data can be exchanged between the two units (analog and digital signals).





## Unit Information, Installation and Hardware

### Unit designation, nameplates and scope of delivery

### 3.2 Unit designation, nameplates and scope of delivery

#### Example unit designation




Figure 1: Unit designation

53648AEN

#### Example nameplate

The unit nameplate is attached to the side of the unit.




Figure 2: Unit nameplate

53030AXX

#### Scope of delivery

The scope of delivery includes:

- DOP11A operator terminal
- Installation material and installation template
- Operating instructions with assembly and installation notes
- DC 24 V plug connector Phönix COMBICON 5 mm 3-pole (except DOP11A-50)



### 3.3 Unit design DOP11A-10

Part number: 8248001



53473AXX

Figure 3: DOP11A-10


- [1] Display
- [2] Function keys
- [3] Navigation keys
- [4] Numerical keys

- 2 x 20 character LCD text display (monochrome) with background illumination
- DC 24 V voltage supply, 200 mA
- Three serial interfaces (RS-232, RS-422 and RS-485); two can be used simultaneously
- IP65 membrane keypad with navigation keys, numeric keypad and 3 function keys
- 64 Kbytes Flash EEPROM
- Outer dimensions 142 x 90 x 46.5 mm



#### 3.4 Unit design DOP11A-20

Part number: 8248028



53472AXX

Figure 4: DOP11A-20

- [1] LEDs red / green
- [2] Display
- [3] Function keys
- [4] Navigation keys
- [5] Labeling tiles
- [6] Numerical keys


- 240 x 64 pixel LCD graphic display (monochrome) with background illumination
- DC 24 V voltage supply, 450 mA
- Two serial interfaces (RS-232 and RS-422); two can be used simultaneously
- IP65 membrane keypad with navigation keys, numeric keypad and 8 function keys
- 16 LEDs (two colors red / green)
- 1 expansion slot
- 400 Kbytes Flash EEPROM
- Outer dimensions 214 x 194 x 75 mm





### 3.5 Unit design DOP11A-30

Part number: 8248036



10367AXX

Figure 5: DOP11A-30

- 320 x 240 pixels, ¼ VGA touch display (256 colors, STN, 5.7") with background illumination
- DC 24 V voltage supply, 450 mA
- Three serial interfaces (RS-232, RS-422 and RS-485); two can be used simultaneously
- IP65
- Horizontal or vertical installation
- 1 expansion slot
- 400 Kbytes Flash EEPROM
- Outer dimensions 200 x 150 x 74 mm



### 3.6 Unit design DOP11A-40

Part number: 8248044




Figure 6: DOP11A-40

53474AXX


- [1] LEDs red / green
- [2] Navigation keys
- [3] Numerical keys
- [4] Display
- [5] Function keys
- [6] Labeling tiles

- 320 x 240 pixels, ¼ VGA graphic display (256 colors, STN, 5.7") with background illumination
- DC 24 V voltage supply, 550 mA
- Two serial interfaces (RS-232 and RS-422); two can be used simultaneously
- IP65 membrane keypad with navigation keys, numeric keypad and 16 function keys
- 16 LEDs (two colors red / green)
- 2 expansion slots
- 400 Kbytes Flash EEPROM
- Outer dimensions 276 x 194 x 92.3 mm



### 3.7 Unit design DOP11A-50

Part number: 8248052



10361AXX





Figure 7: DOP11A-50

- 640 x 480 pixels, VGA touch screen (256 colors, 10.4") with background illumination
- AC 100 - 240 V voltage supply, 350 mA
- Two serial interfaces (RS-232 and RS-422); two can be used simultaneously
- IP65
- 2 expansion slots
- 1600 Kbytes Flash EEPROM
- 290 x 247 x 114 mm





### 3.8 Accessories and options

Cables for programming of the DOP11A operator terminal and communication between operator terminal and MOVIDRIVE®.

<p>PCS11A (Panel Cable Serial)</p>	<p>Connection cable between operator terminal (RS-232), and PC (RS-232) for programming of the operator terminal. Set length of 3 m (10ft.).</p> <p style="text-align: center;"><b>PCS11A</b></p> 	<p>8248087</p>
<p>PCM11A (Panel Cable MPI)</p>	<p>Communication cable between operator terminal (RS-232, max. 57.6 kbit/s) and SIMATIC S7 via MPI (max. 12 Mbit/s). Set length of 3 m (10ft.).</p> <p style="text-align: center;"><b>PCM11A</b></p> 	<p>8248303</p>
<p>PCC11A (Panel Cable Converter)</p>	<p>Communication cable between operator terminal (RS-422) and UWS11A or USS21A (RS-232) interface converters. For communication with SEW frequency inverters. Set length of 3 m (10ft.).</p> <p style="text-align: center;"><b>PCC11A</b></p> 	<p>8248095</p>
<p>PFE11A (Panel Fieldbus ETHERNET)</p>	<p>Option card ETHERNET TCP/IP (10 Mbit/s)</p> <p>To connect the DOP11A operator terminal to the customer's PC network. The following functions become available by using the ETHERNET option:</p> <ul style="list-style-type: none"> <li>• Operation of the HMI-Builder software for programming the operator terminal via ETHERNET (projects can be uploaded and downloaded more quickly).</li> <li>• Using the integrated WEB server for operation and control of the operator terminal via Internet Explorer.</li> <li>• For operation of MOVITOOLS® via ETHERNET and using the pass-through function. Additional software is required for rerouting the PC communication port (Com1 to Com9) to the Ethernet IP-address of the operator terminal.</li> </ul>	 <p>8248079</p>



<p>PFP11A (PROFIBUS panel field-bus)</p>	<p>PROFIBUS-DP interface</p> <p>To connect the DOP11A operator terminal to the customer's PROFIBUS fieldbus interface.</p> <p>The operator terminal serves as a slave in PROFIBUS and is linked to the PLC process image.</p> <ul style="list-style-type: none"><li>I/O range: 32 ... 200 bytes</li><li>Baud rate: 9.6 kbit/s ... 12 Mbit/s</li><li>Identity code: 1002</li></ul> <p>PLC independent option for data exchange between control and operator terminal.</p> <p>You can communicate at the same time to the drive components via the serial interface.</p>	<p>PROFI-BUS DP option card</p> 	<p>8248060</p>
<p>UWS11A</p>	<p>Interface converter for DIN rail mounting RS-232 ↔ RS-485</p> 	<p>822689X</p>	



## 4 Installation

### 4.1 Installation instructions for basic unit



It is essential to comply with the safety instructions in section 2 during installation!

#### Separate cable ducts

Route **power cables** and **electronics cables** in **separate cable ducts**.

#### Cross sections

- Voltage supply: **Cross section according to rated input current.**
- Electronics cables:
  - 1 conductor per terminal 0.20 ... 0.75 mm<sup>2</sup> (AWG 20 ... 17)
  - 2 conductors per terminal 0.20 ... 0.75 mm<sup>2</sup> (AWG 20 ... 17)

#### Shielding and earthing

- Use **shielded control cables** only.
- Connect the **shield by the shortest possible route and make sure it is earthed over a wide area at both ends**. You can ground one end of the shield via a suppression capacitor (220 nF / 50 V) to avoid ground loops. If using double-shielded cables, ground the outer shield on the controller end and the inner shield on the other end.




Figure 8: Example of correct shield connection with metal clamp (shield clamp) or metal cable gland

00755BXX

- **Shielding** can also be achieved by laying the cables in **grounded sheet metal ducts or metal pipes**. In this case, the **power cables and control cables** should be **routed separately**.
- The unit is grounded via the connector for 24 V / 240 V voltage supply.



## 4.2 UL compliant installation

Note the following points for UL compliant installation:

Use only copper conductors with a temperature range of 60 / 75 °C as connection cables.



Electrical connection according to the methods described in class 1, paragraph 2 (article 501-4(b) according to National Electric Code NFPA70).



Use only tested units with a **limited output voltage** ( $V_{\max} = \text{DC } 30 \text{ V}$ ) **limited output current** ( $I \leq 8 \text{ A}$ ) as an **external DC 24 V voltage source**.



UL certification does not apply to operation in voltage supply systems with a non-earthed star point (IT systems).

## 4.3 Connection of basic unit DOP11A-10 to DOP11A-50

### Voltage supply



Ensure correct polarity when connecting the terminal. Incorrect polarity will damage the unit.






Make sure that the operator terminal and the controller system have the same electrical grounding (reference voltage value). Communication errors may occur if this is not the case.



## Installation

### Connection to a PC

<p>DOP 11A-10, DOP11A-20 &amp; DOP11A-40</p>  <p>[1] [2] [3]</p>	<p>DOP 11A-30</p>  <p>[3] [2] [1]</p>	<p>DOP 11A-50</p>  <p>[1]</p>
<p>Voltage supply DOP11A-10 to DOP11A-40</p>	<p>Voltage supply DOP11A-50 (AC 100 - 240 V)</p>	
<p>53031AXX</p>	<p>53630AXX</p>	

- [1] Ground
- [2] 0 V
- [3] +24 V

#### 4.4 Connection to a PC




Figure 9: Connection to a PC

53040AXX

Programming of the operator terminal takes place via the HMI-Builder software.

You need the PCS11A communication cable to program the operator terminal.



**The power must be switched off when connecting the units.**





#### 4.5 RS-485 connection (DOP11A-10 and DOP11A-30 only)

You can connect up to 31 MOVIDRIVE® units to one operator terminal with the RS-485 interface.

Connection of the DOP11A to a MOVIDRIVE® frequency inverter directly via RS-485:


- DOP11A-10 via 25-pin Sub-D connector
- DOP11A-30 via Phoenix plug-in terminal strip

#### Wiring diagram RS-485 interface



53475AXX

Figure 10: RS-485 connection



53760AEN

Figure 11: Pin assignment DOP11A-30



## Installation

RS-485 connection (DOP11A-10 and DOP11A-30 only)




Figure 12: Pin assignment DOP11A-10

53762AEN

**Cable specification** Use a 2x2 core twisted and shielded copper cable (data transmission cable with braided copper shield). The cable must meet the following specifications:

- Core cross section 0.5 ... 0.75 mm<sup>2</sup> (AWG 20 ... 18)
- Cable resistance 100 ... 150 Ω at 1 MHz
- Capacitance per unit length ≤ 40 pF/m (12 pF/ft) at 1 kHz

The following cable is suitable, for example:

- Lappkabel, UNITRONIC® BUS CAN, 2 x 2 x 0.5 mm<sup>2</sup>.

### Shielding

Apply shield on both ends over large area at the controller electronics shield clamp and in the housing of the 25-pin Sub-D connector of the operator terminal.

**Do not connect the shield ends with DGND!**

### Line length

The permitted total cable length is 200 m (660 ft).

### Terminating resistor

The controller and the UWS11A interface converter come equipped with dynamic terminating resistors. Do not connect **any external terminating resistors** in this instance!



If the DOP11A-10 operator terminal is connected with the frequency inverters via RS-485, you will have to activate the terminating resistor in the 25-pin Sub-D connector of the DOP11A-10 (jumper between pin 6 and pin 19) in case the operator terminal is the first or last station.



There must not be any difference of potential between the units connected using the RS-485. Take suitable measures to avoid a potential displacement, e.g. by connecting the unit ground connectors using a separate lead.




## Installation

### Connection RS-422 via UWS11A


#### 4.6 Connection RS-422 via UWS11A

Connecting the DOP11A to a MOVIDRIVE® frequency inverter via UWS11A.



53288AXX

Figure 13: Connection via serial connection (UWS11A)



53763AEN

Figure 14: Pin assignment UWS11A

#### RS-485 connection

See section 4.5, "Connection RS-485 (DOP11A-10 and DOP11A-30 only)" for the cable specification.



#### 4.7 Connection PFE11A ETHERNET option

Connection of DOP11A with PFE11A Ethernet option card (not available with DOP11A-10) to a PC for programming and remote maintenance via Ethernet and TCP / IP.




Figure 15: Connection PFE11A ETHERNET option

53331AXX

There are four LEDs on the front of the PFE11A expansion card. These LEDs have the following functions:

Function	Color	Description
SEL	Yellow	This LED will light up if there is a contact between terminal processor and expansion card connection.
TxD	Yellow	This LED lights up when you send ETHERNET data.
RxD	Yellow	This LED lights up when you receive ETHERNET data.
LINK	Green	This LED lights up when the ETHERNET cable (twisted pair cable) has been connected correctly.

**Cable specification** Use a shielded standard Ethernet cable with shielded RJ45 connectors and cables according to specification CAT5. The maximum cable length is not to exceed 100 m (300ft.).

The following cable is suitable, for example:

- Lappkabel, UNITRONIC® LAN UTP BS flexible 4 x 2 x 26 AWG



You will find a description for determination of the Ethernet (MAC) address of the option card in section 5.2, in the paragraph "Configuration mode (SETUP)".



#### 4.8 Connection PFP11A PROFIBUS-DP option

Data exchange of a PLC with a DOP11A via PFP11A and PROFIBUS DP. (See section 3.8 "Accessories and options" for a description of the PFP11A.)




Figure 16: Connection PFP11A PROFIBUS option

53043AXX




Figure 17: Connection PFP11A PROFIBUS option

53632AXX

- [1] 9-pin Sub-D socket
- [2] **PROFIBUS terminating resistor**  
If the panel is located at the beginning or end of a PROFIBUS segment and if only one PROFIBUS cable is connected to the panel, you will either have to activate the connector in the terminating resistor (if present) or set the switch on the PFP11A card to "On".  
Never activate both terminating resistors in the connector and card at the same time!
- [3] The LEDs on the expansion card have the following functions:
 

1:ERR	Red	Displays configuration or communication errors. The LED lights up red until the unit is configured and indicates a time violation.
2:PWR	Green	Displays a voltage supply with DC 5 V.
3:DIA	Green	Displays a diagnostics error in the PROFIBUS network. Is not used by the panel.
- [4] The PROFIBUS station address is set using two rotary switches.

The GSD type files required for configuration of the PROFIBUS are available on the HMI-Builder software ROM or at [www.sew-eurodrive.de](http://www.sew-eurodrive.de) in the Software tab.



**Cable specification** Use a two-core, twisted and shielded copper cable to PROFIBUS specification for conductor type A to EN 50170 (V2).

The following cable is suitable, for example:

- Lappkabel, UNITRONIC® BUS L2/F.I.P.

#### 4.9 Connection to a Siemens S7 via MPI and PCM11A





Figure 18: Connection to a Siemens S7 via MPI and PCM11A

53044AXX



## 5 Startup

### 5.1 Initial operation



**It is essential to comply with the safety notes during startup!**

#### General startup instructions

##### Prerequisite

Requirement for a successful startup is the correct electrical connection of the operator terminal.

The functions described in this section will enable users to upload a project to the operator terminal and establish the unit in the necessary communication pathways.




Do not use the DOP11A operator terminals as safety devices for industrial applications. Use monitoring systems or mechanical protection devices as safety features to avoid possible damage to property or injury to people.

#### Preliminary work and resources

- Check the installation.
- Prevent unintentional start of motor via connected frequency inverter by suitable measures.
  - Remove the electronics input X13.0/controller inhibit in MOVIDRIVE® or
  - clear the supply voltage (24 V back-up voltage still has to be present)
  - Remove terminals "CW operation" and "Enable" in MOVITRAC® 07

Furthermore, additional safety precautions must be taken depending on the application to avoid injury to people and damage to machinery.

- Connect operator terminal with corresponding cable to MOVIDRIVE® or MOVITRAC® 07.



53243AXX

Figure 19: Connection between operator terminal and MOVIDRIVE® MDX60B/61B

- Connect operator terminal with the PC via PCS11A (RS-232) programming cable. Operator terminal and PC must be de-energized when you do this, otherwise undefined states may be adopted. Turn on PC and start HMI-Builder configuration software; install software if not present yet.






Figure 20: Connection between PC and operator terminal

53250AXX

- Start 24 V supply for operator terminal and connected frequency inverters.

Units are delivered without loaded project.


Units with membrane keypad (DOP11A-10, DOP11A-20 and DOP11A-40) will report the following information when they are initially taken into operation:




53253AXX

Figure 21: Initial image DOP11A-10 in delivery state

Units with membrane keypad DOP11A-10, DOP11A-20 and DOP11A-40 will remain in [Edit] / [Transfer] mode. You will find a description of the individual functions in the following section.



The touchscreen units DOP11A-30 and DOP11A-50 report that no inverter or PLC communication driver have been loaded.



53602AXX


Figure 22: Initial screen DOP11A-50 in delivery state



## 5.2 Operator terminal functions

This chapter describes the different modes in the operator terminal, the keyboard and the information page in the terminal.

### The keyboard in the terminal



52609AXX

- [1] Integrated function keys (not DOP11A-10)
- [2] Arrow keys
- [3] Alphanumeric keys

**Alphanumeric keys** From the alphanumeric keyboard the following characters can be entered in dynamic text and numerical objects during run mode in the operator terminal.

0-9

A-Z

a-z

! ? < > ( ) + / \* = ° % # : ' @

National characters



You cannot enter characters via the keyboard of the DOP11A-10 terminal because it is not equipped with alphanumeric keys.

Numeric values are entered by pressing the respective key once.

Enter capital letters (A to Z) by pressing the respective key two to five times.

Enter lower case letters (a to z) by pressing the respective key six to nine times.

The delay time interval between pressing can be set. If the key is not pressed within the delay time interval the cursor moves to the next position.

Enter national characters by pressing key <2> (C1C4) two to nine times. This option offers characters that are not included in the standard character set of the alphanumeric terminal keyboard.



You can use all characters of the selected character set in the HMI-Builder except those characters reserved for static text. Enter the required character by pressing the <ALT>+<0> key combination on the numeric keyboard of the PC; then enter the character code. You select the used character set in the HMI-Builder.

#### *Reserved characters*

The ASCII characters 0-32 (Hex 0-1F) and 127 are reserved for internal terminal functions and must not be used in projects or files in the terminal. The characters are used as control characters.

#### *Arrow keys*

Use the arrow keys to move the cursor in a menu or dialog.


#### *Built-in function keys*

Not all the keys are available on all terminals.

Key	Description
Enter key	Use the ENTER key to confirm the setting made and to go to the next line or level.
<PREV>	Use this key to return to the previous block.
<LIST>	Use this key to bring up the alarm list.
<ACK>	Use this key to acknowledge alarms in the alarm list.
<MAIN>	Use this key to jump to block 0 in run mode.
<<->	Use this key to delete characters to the left of the cursor.












When the main block (block number 0) was displayed, the <PREV> key will not work because the block history is deleted once the main block has been reached.



**Key combinations**

The terminal has key combinations for the following functions:

Key combination	Function
<←> <MAIN>	Toggle between SETUP and RUN.
<←> <F1>	Hold this key combination pressed during startup to activate the mode for downloading the system program (see section 4, "Installation").
<←> <PREV>	Open information window.
 + 	Hold the key combination pressed during start up to activate the self-test function.

Terminal type	Function			
	Sysload	Self-test	Toggle between SETUP and RUN	Diagnostics window
DOP11A-10	<←> + <F1>	 + 	<←> + <ENTER>	<←> + 
DOP11A-20	<←> + <F1>	 + 	<←> + <MAIN>	<←> + <PREV>
DOP11A-40	<←> + <F1>	 + 	<←> + <MAIN>	<←> + <PREV>



## Startup

### Operator terminal functions

*Switches on DOP11A-30 and DOP11A-50 terminals*

Interrupt power supply to terminal to call up individual modes for DOP11A-30 and DOP11A-50.

Turn the rotary switch on the side or back of the terminal to the position shown in the following table. You can now turn on the power supply once again.

Switch position	Function
0	Run mode (RUN, standard operation)
1	Sysload
2	Calibrate touch
3	Cursor
4	Configuration mode (SETUP)
5	Transfer mode, TRANSFER
8	Activates self-test function
9	Erases the clock memory

#### ***RUN and SETUP operating modes***

The terminal has two operation modes.

- **Configuration mode (SETUP):** All basic settings are made in this mode, such as selection of controller system and menu language.
- **Run-time mode (RUN):** This mode is for running the application.

#### *Transfer*


Here you manually set the terminal to transfer mode. When the terminal is in transfer mode it is possible to transfer projects between the terminal and the programming software. By using the automatic terminal switching function [RUN] / [TRANSFER] in the programming software, the software automatically sets the terminal to transfer mode.

#### *Switching between modes*

##### **Switch between RUN and SETUP**

Press <←> and <MAIN> simultaneously to enter configuration mode (SETUP). You can now press any key when the start-up menu is shown to enter the configuration mode, SETUP. To return to run mode, press <←> and <MAIN>.

In DOP11A-30 and DOP11A-50 you set the switch on the side/back of the terminal in position 4 to access the configuration mode (Setup). The switch should be in position 0 for standard operation.



*Configuration  
mode (SETUP)*

This section contains a description of those functions that cannot be carried out with the HMI-Builder.

**Erasing the memory**

In the [setup] menu in the terminal there is a function [Erase Memory]. Use this function to erase the application memory of the terminal. All blocks and definitions for alarms, time channels, function keys and system signals are erased.

Parameters	Description
Enter key	Memory is erased. The configuration menu is shown automatically when the erasure is completed.
<PREV>	Return to previous level without erasing the memory.



When the memory is erased all data stored in the terminal will be lost. The language selection parameter is not affected by this function. All other parameters will be erased or given their default values.

**Contrast setting**

Operator terminal	Contrast setting
DOP11A-10	Contrast is set with a rotary regulator on the back of the terminal.
DOP11A-20	Contrast is set in operating mode by jumping to system block 997. The monitor will be brighter by pressing the <+> function key. You reduce brightness by pressing the <-> function key. Return to the previous level by pressing <EXIT>.
DOP11A-30	
DOP11A-40	
DOP11A-50	The color intensity of the display can be controlled through a data register and the [DIM] command, specified in the command line under [Setup] / [System signals] of the programming software.



The contrast depends on the ambient temperature. If the terminal is programmed at a room temperature far below the one at the installation site, you will have to adjust the contrast at the actual ambient temperature after 15 - 30 minutes.



#### **Determining the Ethernet (MAC) address:**

The Ethernet address of the PFE11A option card is displayed in configuration mode (SETUP). Use the key combination <←> <MAIN> (DOP11A-20 and DOP11A-40) or switch position 4 (DOP11A-30 and DOP11A-50) to enter configuration mode.

The physical Ethernet address is displayed in the menu item [Expansion Cards - Slot 1 - PFE].

#### **Run mode (RUN)**

The application is executed in run mode. Block 0 will automatically be shown on the display when changing to run mode.

The built-in keyboard in the terminal is used to highlight and change values in run mode.

If a communication error occurs between the terminal and the controller system, an error message will be shown on the display. The terminal starts automatically once the communication is resumed. If you press an I/O key combination while a communication error is present, the combination will be stored in the terminal buffer and transferred to the controller system once communication resumes.

The terminal clock can continuously send data to a register in the controller to activate a monitoring function. The controller can use this monitoring function to detect a possible communication error. The controller system checks if the register is updated, and if not an alarm indicating a communication error is activated in the controller system.

The functional principle of individual objects and functions in operating mode will be explained in connection with the description of the respective objects and functions.

#### **Setting the real-time clock**

The real-time clock of the terminal is set in the [Setup] menu under [Date / Time.].


Select the option [Set terminal clock]. The date and time will now be displayed. Press <SET> to change the setting. Enter the required date and time. Move the cursor with the arrow keys in editing mode. Press <NEXT> to return to the previous menu or cancel the setting before you press the Enter key.

The real-time clock can also be set in run mode through a maneuverable clock object and during the transfer of projects from a PC to the terminal.



A digital signal set by a command can let operators know when it is time to change the battery for the real-time clock.





### Information page

The terminal contains an information page. The information page is activated by pressing the key combination <←> and <PREV> simultaneously in run mode. A function or touch key can also be used or configured to call up the information page.


The current terminal, system program version and hardware version are shown at the top of the information page.

Parameters	Description
STARTS	Number of terminals starts
RUN	Operating time of the terminal
CFL	Number of hours the backlighting has been switched on.
32°C MIN: 21 MAX: 38 (example)	Current operating temperature, lowest and highest temperature measurement
DYNAMIC MEMORY	Available RAM memory (working memory) in number of bytes.
FLASH MEM PROJ	Available Flash memory (project memory) in number of bytes.
FLASH MEM BACK	Reserved
FLASH CACHEHITS	Percent of block / allocation cache hits in the file system.
FLASH ALLOCS	Maximum percent of used or active allocations per block in the file system.
DRIVER 1	Current driver and driver version.
DIGITAL I/Os	The number of digital signals linked to controller system 1 continuously monitored (STATIC) and the number in the current block (MONITOR).
ANALOG I/Os	The number of analog signals linked to controller system 1 continuously monitored (STATIC) and the number in the current block (MONITOR).
I/O POLL	The time in ms between two readings of the same signal in controller 1.
PKTS	The number of signals in each package transferred between the terminal and controller 1.
TOUT1	The number of timeouts in communication with controller 1.
CSUM1	The number of checksum errors in communication with controller 1.
BYER	The number of byte errors in the communication.
DRIVER 2	Current driver and driver version. The parameters for Driver 2 are only shown if controller 2 is defined in the project.
DIGITAL I/Os	The number of digital signals linked to controller 2 continuously monitored (STATIC) and the number in the current block (MONITOR).
ANALOG I/Os	The number of analog signals linked to controller 2 continuously monitored (STATIC) and the number in the current block (MONITOR).
I/O POLL	The time in ms between two readings of the same signal in controller 2.
PKTS	The number of signals in each package transferred between the terminal and controller 2.
TOUT2	The number of timeouts in communication with controller 2.
CSUM2	The number of checksum errors in communication with controller 2.
1 / 2 / 3	Current port for FRAME, OVERRUN and PARITY. 1 = RS-422 port, 2 = RS-232 port and 3 = RS-485 port.
FRAME	The number of frame errors in each port.
OVERRUN	The number of overrun errors in each port.
PARITY	The number of parity errors in each port.

### Joystick function

Applicable for DOP11A-20 and DOP11A-40 only.

This function makes it possible to use the arrow keys as function keys. Enter the command "AK" and an address in the command line under [system signals]. Example: "AKM100" (command AK and memory cell M100).



53107AEN

Figure 23: System signals

Memory cell M100 is the enable signal and the following four memory cells have functions according to the following control block:

Memory cell	Description
Mn0	Active = Joystick function. Disabled = normal function.
Mn1	LEFT ARROW
Mn2	DOWN ARROW
Mn3	UP ARROW
Mn4	RIGHT ARROW

If you press on an arrow when the enable signal is on, the memory cell corresponding to the key you press will be set to one. When the enable signal is set to one, the arrow keys will not have their normal functions.



*Example*

Use the following example to toggle between joystick function and normal function.

Perform the following steps:

- Use the DEMO driver.
- Enter the text "AKM1" under [system signals] / [commands].
- Generate a text block.
- Enter the static text "JOYSTICK."
- Create a digital object with the following settings:
  - Digital signal: M1
  - Text 0: OFF
  - Text 1: ON
  - Activate input: YES
- Create four additional digital objects to observe the memory contents of M2, M3, M4 and M5.

Display of text block according to sample settings:

JOYSTICK # - - -

M2#

M3 #

M4 #

M5 #




## 6 Operation and Service


### 6.1 Project transfer with PC and HMI-Builder

You need the HMI-Builder software for starting up the operator terminal with your PC.

1. Start the HMI-Builder program.
2. Select the language in the [Settings] / [Menu language] selection field.




10375AEN



10376AEN




3. Use the [File] / [Open] function to open the project file you would like to transmit to the operator terminal.



10377AEN

4. In the selection field [Transfer] / [Comm. settings], select the communication connection [Use serial transfer] and enter the necessary parameters:



10378AEN


### Serial transfer when using the PCS11A programming cable.

Enter following information:

- Communication port of the PC (e.g. Com1)
- Baud rate (default 57,600)
- Timeout period (free entry, default 10,000 ms)
- Number of retries in case of communication problems (default 3)



If a project is transferred to the terminal for the first time, the transfer will take place via serial connection and the PCS11A programming cable.





10379AEN

5. The project can now be transferred to the terminal with the selection field [Transfer] / [Project].

The following functions are active as standard and must remain in this setting.

- Test project on send
- Send complete project
- Automatic terminal RUN/TRANSFER switching
- Check terminal version

Download of files takes place after activation of [Send] button.



The following steps will be executed one after the other:


- Switching the terminal to transfer mode (TRANSFER)
- Transfer of download driver for inverter and PLC
- Transfer of project data
- Switching the terminal to RUN mode

The individual steps will be displayed during transfer in the terminal display.

After completed transfer, exit the dialog window with the [Exit] button and close the HMI-Builder.




#### 6.2 Operating display at unit start



53588AXX

- [1] Firmware version of the operator terminal
- [2] Status of the boot process  
e.g.:  
PROJECT STATUS  
TCP/IP ADDRESS  
CHECKING PLC 1  
CHECKING PLC 2  
...
- [3] Communication driver loaded in Controller 1  
e.g.:  
DEMO  
SEW\_MOVIDRIVE  
...
- [4] Communication driver loaded in Controller 2  
e.g.:  
DEMO  
SEW\_MOVIDRIVE  
...
- [5] Communication status of Controller 1  
e.g.:  
NO CONNECTION  
DEMO  
MOVITRAC 07  
MOVIDRIVE A  
MOVIDRIVE B  
...
- [6] Communication status of Controller 2  
e.g.:  
NO CONNECTION  
DEMO  
MOVITRAC 07  
MOVIDRIVE A  
MOVIDRIVE B  
...
- [7] Version of operator terminal boot routine





### 6.3 Error Messages


Errors in RUN mode will be displayed in the upper left hand corner of the display as error message.

They are divided into two groups:

- Boot error (no inverter connected)
- Operation errors - Comm Errors (error list)

#### **Boot error (no inverter connected)**

Boot error "1: Comm Error 254" means: no communication with connected inverters.



53590AXX

- [1] Controller where the communication error occurs.  
e.g 1 or 2
- [2] Error type  
e.g. operation error - Comm Error
- [3] With RS-485 address:  
E.g.  
01 - 99  
254 (= Point to Point!)



### Operation errors - Comm Errors (error list)

Message from operator terminal	Error code	Description
no error	00 00	No error
invalid parameter	00 10	Illegal parameter index
fct. not implement	00 11	Function / parameter not implemented; <ul style="list-style-type: none"> <li>Controller does not know parameter addressed by the operator terminal. Check correct selection of MOVILINK<sup>®</sup> driver. Individual parameters of the MOVITRAC<sup>®</sup> 07, MOVIDRIVE<sup>®</sup> A and MOVIDRIVE<sup>®</sup> B controllers are slightly different.</li> <li>Another reason for this error may be the controller firmware. Recently added parameters may not be included in older versions of the unit firmware.</li> </ul>
read only access	00 12	Read access only <ul style="list-style-type: none"> <li>No write access to addressed parameter. Deactivate [Activate input] function in project of operator terminal.</li> </ul>
param. lock active	00 13	Parameter lock is active <ul style="list-style-type: none"> <li>The [Parameter block] function was activated via parameter P803 in the addressed controller. Set parameter P803 to "OFF" by using the controller keypad or the PC software MOVITOOLS<sup>®</sup> to deactivate the parameter lock.</li> </ul>
fact. set active	00 14	Factory setting is active <ul style="list-style-type: none"> <li>Controller is performing a factory setting. Parameter change option is locked for a few seconds. Communication will be automatically reactivated once factory setting is complete.</li> </ul>
value too large	00 15	Value too large for parameter <ul style="list-style-type: none"> <li>Operator terminal is trying to write a value to a parameter that is not within the permitted value range. Adapt the project of the operator terminal in the [Access] area to be within the limits of the minimum and maximum input values. You will find the respective limit values in the parameter list of the controller.</li> </ul>
value too small	00 16	Value too small for parameter <ul style="list-style-type: none"> <li>Operator terminal is trying to write a value to a parameter that is not within the permitted value range. Adapt the project of the operator terminal in the [Access] area to be within the limits of the minimum and maximum input values. You will find the respective limit values in the parameter list of the controller.</li> </ul>
option missing	00 17	Required option card missing for this function / this parameter.
system error	00 18	Error in system software of controller <ul style="list-style-type: none"> <li>Contact SEW service.</li> </ul>
no RS485 access	00 19	Parameter access via RS-485 process interface on X13 only
no RS485 access	00 1A	Parameter access via RS-485 diagnostic interface only
access protected	00 1B	Parameter is access-protected <ul style="list-style-type: none"> <li>No read or write access to this parameter; parameter not suitable for use in operator terminal.</li> </ul>
inhibit required	00 1C	Controller inhibit required <ul style="list-style-type: none"> <li>The addressed parameter can only be altered with inhibited controller. Activate the controller inhibit status by removing the terminal X13.0 or via fieldbus (control word 1/2 basic block = 01hex).</li> </ul>
incorrect value	00 1D	Incorrect value <ul style="list-style-type: none"> <li>Some parameters can only be programmed to certain values. You will find the respective limit values in the parameter list of the controller.</li> </ul>
fact. set active	00 1E	Factory setting was activated.
not saved in EEPROM	00 1F	Parameter was not saved in EEPROM <ul style="list-style-type: none"> <li>Power-failure save failed.</li> </ul>
inhibit required	00 20	Parameter cannot be changed with enabled output stage <ul style="list-style-type: none"> <li>The addressed parameter can only be altered with inhibited inverter. Activate the controller inhibit status by removing the terminal X13.0 or via fieldbus (control word 1/2 basic block = 01hex).</li> </ul>



## 6.4 SEW electronics service

### **Send in for repair**

Please contact the **SEW Electronics Service** if a fault cannot be rectified.

When contacting the SEW electronics service, always quote the digits of the unit designation so that our service personnel can assist you more effectively.



**Please provide the following information when sending the unit in for repair:**

- Serial number (→ nameplate)
- Unit designation
- Brief description of the application
- Nature of the error
- Accompanying circumstances
- Your own presumption of what has happened
- Any unusual events preceding the problem, etc.



## 7 Programming

### 7.1 Creating a project

#### Basics

This chapter describes the system structure of the terminal and its basic functions. There is also an explanation of the general principles, object parameters and joint functions applicable in the terminal.

#### Method for programming a project

The graphical structure of the application in the terminal constitutes a well-arranged monitoring tool for the operator. It is important to organize the application well and to consider which functions are necessary. Start with the overall view, and then work down to the detailed level. When a project is programmed you start with the functions in your application. Each function becomes one or more blocks, depending on the complexity of the function. A project can contain both graphic and text blocks, and each block can contain static and dynamic objects. The blocks should be arranged in hierarchies to achieve a structured application, and to simplify work procedures for the machine operator. The application can also be organized as sequence controls.

The application can be tested in full or in part prior to startup.




Figure 24: Block structure



*Effective  
communication*

Read the following notes on signal transmission and their optimization for fast and effective communication between terminal and controller.

**Signals that influence the communication time**

Only signals for objects in the current block will be read continuously. These include dynamic object signals. Signals for objects in other blocks will not be read. The number of blocks does not affect the communication time.


In addition to signals for objects in the current block, the terminal continuously receives the following signals from the controller:

- Display signals (block header)
- Block print signals (block header)
- LED register
- Alarm signals
- External confirmation signals for alarms and alarm groups
- Login signal (password)
- Logout signal (password)
- Trend curve register
- Register for column objects when min. / max. indicators are used
- New display register
- Buzzer register
- Background lighting signal
- Cursor control block
- Recipe control block
- Library index register
- Index register
- Register for PLC clock if used in terminal
- List erase signal (alarm settings)
- No protocol mode control register
- No protocol signal

**Signals that do not influence the communication time**

The following signals do not affect the communication time:

- Signals for function keys
- Time channels
- Objects in alarm texts



#### Optimize communication

##### Grouping controller signals

The signals from the controller (see list on page 49) will be read fastest if they are bundled in one group, such as: If you have defined 100 signals you will reach the highest reading speed by grouping them (e. g. H0-H99). If the signal transfer takes place in individual steps (e. g. P104, H17, H45, etc.), then the update will take much longer.

#### Effective block change

You will reach an optimum block change by using the block jump function of the function keys or via the jump object. The display signal in the block header may only be used if the controller is to enforce the opening of another block. If the controller is to change the display, you can use the new display register. This option affects the communication less than a larger number of display signals.

#### Signal packages

Transfer of signals between terminal and controller does not take place for all data at the same time. The information is separated into packages that contain several signals each. The number of signals in each package depends on the selected driver.

A minimization of the number of packages is necessary to have the communication take place as quickly as possible. Grouped signals require merely a minimum number of packages. Such programming is not possible in all cases. There may be spaces in between two signals in such cases. A space represents the maximum distance between two signals that are part of the same package. The size of the space depends on the selected driver.

Signal	1	2	3	4	5	6	7	8	9	10
Use	X	X					X	X	X	

Space

53572AEN

#### User interface

Use graphic blocks for the user interface.


Text blocks are mainly for printout of reports. They are slower and require more memory than graphic blocks.

Use 3D effects for an appealing user interface.


You can accomplish a visually impressive design by combining objects with frame and 3D rectangles. Such a design emulates a light incidence from top left. Such an angle creates shadow effects at the lower and right side of raised objects as well as on the upper and left side of lowered objects.

#### Menu structure

The terminal is divided into two modes: *configuration mode* and *run mode*. In each respective mode there are a number of different levels, depending on the function. Each level consists of a menu where you make a selection or enter parameters before going to the next level (menu).



The application is built up of blocks, graphic blocks and /or text blocks (primarily for report printouts). Values from the controller system are shown and changed in the blocks. Each block has a number between 0 and 989 allocated by the programmer. The blocks 990-999 are reserved for special purposes, so-called system blocks. The terminal is object oriented, which means that a block can contain all the signals linked to an object for the control and monitoring of, for example, a pump.



53376AEN

Figure 25: Configuration mode and run mode



#### Blocks

A block header is defined for each block. The header contains the block number, block type, status word, etc. The following functions can also be invoked as blocks:

- Alarms
- Time channels
- System monitor
- E-mail
- Contrast settings

These are designated system blocks.

150 blocks are permitted for the DOP11A-10. In the other terminals a maximum of 990 blocks can be defined.




The block type cannot be changed for a defined block.

#### Signal formats

The following signal formats are available in the dialog for each object, on the assumption that the selected driver supports the signal format.

Format type	Area
Signed 16-bit	-32768 – +32767
Unsigned 16-bit	0 – +65535
Signed 32-bit	-2147483648 – +2147483647
Unsigned 32-bit	0 – +4294967295
Float with exponent, 32-bit	$\pm 3.4E38$ , numbers larger than 1,000,000 are shown with exponent (not with MOVILINK <sup>®</sup> driver).
Float without exponent, 32-bit	Parameter positions (including decimal point and characters) and decimals indicate the available area. For example, 8 positions and 3 decimals result in $\pm 999.999$ (not with MOVILINK <sup>®</sup> driver).
BCD Float	0 – 9999.9999 (not with MOVILINK <sup>®</sup> driver)
BCD 16-bit	0 – 9999 (not with MOVILINK <sup>®</sup> driver)
BCD 32-bit	0 – 99999999 (not with MOVILINK <sup>®</sup> driver)
HEX 16-bit	0 – FFFF
HEX 32-bit	0 – FFFF FFFF
Seconds 16-bit	The object Analog numeric can be displayed in the time format. Syntax: <Hours:Minutes:Seconds> (not with MOVILINK <sup>®</sup> driver).
Seconds 32-bit	The object Analog numeric can be displayed in the time format. Syntax: <Hours:Minutes:Seconds> (not with MOVILINK <sup>®</sup> driver).
Character string	Character string which can be used in the dynamic function for graphic objects in DOP11A-20 to DOP11A-50. Example: In the object Static symbol, Digital symbol and Multisymbol, the dynamic property Symbol can be linked to a register with the Character string format.





Format type	Area
Array 16-bit	Table format which can be used for an event in the dynamic function for graphic objects in DOP11A-20 to DOP11A-50. Example: A group of registers is to be allocated different values when the value entered is equal to 99. The first value in the field Value will then be entered to register D21 in the field Signal. If the field Value appears as follows <1,2,3,4> the value 2 will be entered in the next subsequent register (D22), etc.

### HMI-Builder installation

#### Programming software

The HMI-Builder is a programming software used to develop projects for operator terminals of the DOP11A series. The functions in the HMI-Builder depend on the selected terminal.

We recommend using a mouse as the input device for the programming software. Refer to the Windows Users Guide for information on key combinations.

A project is created with graphic blocks and text blocks in the programming software, which are then transferred to the operator terminal.

Help texts are available for all functions. The help text for the current function is obtained by pressing the <F1> key. Information on the function is shown by pressing the help button in the toolbox and then clicking on a function.

#### System requirements

HMI-Builder needs a PC with at least 55 MB of available memory and the Microsoft Windows 95 / 98 / NT / 2000 / XP operating system. The programming software can be used on either a color or monochrome screen.

#### Installation of HMI-Builder

The programming software is supplied on a CD. When you place the CD in your CD ROM drive the installation will start automatically. If not, select [Run] from the start menu and enter the command `D:\setup.exe` (if D is the CD ROM drive). Install the programming software by clicking on the name and following the instructions.

The installation wizard creates an icon for the programming software in the program group of the programming software. To start the programming software, click on [Start] and select [Programs] / [Drive Operator Panels DOP] / [HMI-Builder]. The manual can be read directly from the CD by clicking on [Manuals].



#### Menu

From the menu bar you can reach a number of drop-down menus.

Menu	Description
File	Contains functions that affect the entire project.
Edit	Contains, among others, the following functions: <ul style="list-style-type: none"> <li>• Cut</li> <li>• Copy</li> <li>• Paste</li> </ul>
View	The following menus can be invoked: <ul style="list-style-type: none"> <li>• Block manager</li> <li>• Alarm handling</li> <li>• Symbol manager</li> </ul>
Functions	In this menu you can configure the function keys, LEDs, passwords and macros. Alarm texts are entered and alarm groups are defined in this menu as well.
Setup	Here you will set the basic configuration for the terminal.
Object	Is available in the managers only and holds all objects. The objects are also included in the toolbox.
Layout	Is available in graphic block manager only and includes functions for positioning of objects in graphic blocks.
Block manager	Settings for visual representation of block manager
Transfer	The functions in the Transfer menu are used to transfer projects between the programming software and the terminal.
Window	Contains all general Windows functions. You can also make grid settings and define the search path to external programs, such as Paintbrush.
Help	Contains the help functions for the program.

#### Status bar

The status bar is located at the bottom of the HMI-Builder program window. In the [View] menu there is a function to show / hide the status bar.

The left part of the status bar describes the menu function selected in the menu. A short description of the function the cursor points to is shown for the functions in the toolbox.

The right part of the status bar indicates which of the following keys are activated:

**OVR** Overwrite (Paste key)

**CAP** Caps Lock

**NUM** Num Lock

Coordinates, line and column, in the block manager are also shown.



53108AXX

Figure 26: Status bar



## 7.2 Communication with MOVIDRIVE® and MOVITRAC® 07

This chapter describes the communication between operator terminal and SEW frequency inverters MOVIDRIVE® and MOVITRAC® 07.

There is also an explanation of how parameters and variables can be addressed and read. Constellations with more than one inverter connected via RS-485 are also described.

### Serial connection between operator terminal and inverter

Use the PCS11A cable for connecting PC and operator terminal. The operator terminal is programmed via this cable.

#### PCS11A programming cable

Connection cable between operator terminal and PC for programming the operator terminal.

Set length of 3 m (10ft.).




Figure 27: PCS11A programming cable

53250AXX



### Communication settings in the HMI-Builder

#### Setup of communication between operator terminal and inverter

The settings for communication between operator terminal and inverter are made in the HMI-Builder under [Setup] / [Peripherals].




Figure 28: Communication settings

10771AEN

To change the communication port, select [Controller 1] (or [Controller 2]), hold the left mouse button pressed and drag the controller to the other communication port.

To enter the communication parameter, press the right mouse button.



## Default settings



Figure 29: Default settings

10772AXX

Port	RS-232C or RS-422
Baud rate	9600
Data bits	8
Stop bits	1
Parity	Even

## Settings

The RS-485 inverter address is defined under Settings.

Parameter	Description
Default station	A communication is established with the inverter address entered under Default station during startup of the operator terminal after power on. This inverter address will always be used if no other RS-485 address is specified when defining the communication objects.

You can enter values between 0-99, 254 and 255.

Address	Use / description
0-99	Individual inverter address
254	Peer-to-peer communication This address must not be used when several inverters are connected with the operator terminal via RS-485.
255	Broadcast address All inverters connected to the RS-485 bus receive data but do not return a response to the operator terminal.



### Advanced settings

Advanced settings	Description
Interval	Cannot be set in the MOVILINK® driver
Timeout	Time in [ms] for repeated transmission.
Retries	Number of repeated transmissions until a communication error is triggered.
Retry time	Timeout for resetting the communication error. Communication will be reestablished after this time has elapsed.

### Addressing of parameters and variables

#### Addressing

The MOVILINK® driver knows the following data formats:

P	For parameters (volatile writing)
NVP	For parameters (non-volatile writing)
X	For index (volatile writing)
NVX	For index (non-volatile writing)
H	For IPOS variables (volatile writing)
NVH	For IPOS variables (non-volatile writing H0 - H127)


Without the suffix NV, the data are written to the RAM of the inverter and are lost when the inverter is switched off.



The suffix NV is required for non-volatile storage. In this case, the data are written to the EEPROM of the inverter. Note that only a limited number of write services is to be executed to the EEPROM. Therefore, use the suffix NV carefully.

#### Digital data (bit-wise access)

Device	Minimum address	Maximum address	Comment
P <i>rr</i> . <i>bb</i>	P0.0	P963.31	Bit <i>bb</i> in register <i>rr</i>
NVP <i>rr</i> . <i>bb</i>	NVP0.0	NVP963.31	Bit <i>bb</i> in register
X <i>rr</i> . <i>bb</i>	X8192.0	X24575.31	Bit <i>bb</i> in register <i>rr</i>
NVX <i>rr</i> . <i>bb</i>	NVX8192.0	NVX24575.31	Bit <i>bb</i> in register <i>rr</i>
H <i>rr</i> . <i>bb</i>	H0.0	H511.31 (H1023.31 for MOVIDRIVE® B)	Bit <i>bb</i> in register <i>rr</i>
NVH <i>rr</i> . <i>bb</i>	NVH0.0	NVH511.31 (NVH1023.31 for MOVIDRIVE® B)	Bit <i>bb</i> in register <i>rr</i>
B <i>rr</i>	B0	B63 (local bits, which are stored in the operator terminal)	Bit <i>bb</i>



More than one piece of information is stored in some inverter parameters. This means parameters P10, P11 and P12 are coded via index 8310. You can use the following notation to partially evaluate these parameters:

- H100.0-15 Low word of IPOS variable H100
- H100.16-32 High word of IPOS variable H100

#### Digital data (partial access)

Device	Minimum address	Maximum address	Comment
P <i>rr</i> . <i>a-b</i>	P0.0-1	P963.0-31	P <i>rr</i> . <i>a-b</i> a = Start bit b = Number of bits to be read  <b>Example</b> H 100 . 7-8 Data are read from bit 7 to bit 14 inclusively.
NVP <i>rr</i> . <i>a-b</i>	NVP0.0-1	NVP963.0-31	
X <i>rr</i> . <i>a-b</i>	X8192.0-1	X24575.0-31	
NVX <i>rr</i> . <i>a-b</i>	NVX8192.0-1	NVX24575.0-31	
H <i>rr</i> . <i>a-b</i>	H0.0-1	H511.0-31 (H1023.0-31 for MOVIDRIVE® B)	
NVH <i>rr</i> . <i>a-b</i>	NVH0.0-1	NVH511.0-31 (NVH1023.0-31 for MOVIDRIVE® B)	

#### Analog signals

Device	Minimum address	Maximum address	Comment
P <i>rr</i>	P0	P963	Register <i>rr</i>
NVP <i>rr</i>	NVP0	NVP963	Register <i>rr</i>
X <i>rr</i>	X8192	X24575	Register <i>rr</i>
NVX <i>rr</i>	NVX8192	NVX24575	Register <i>rr</i>
H <i>rr</i>	H0	H511 (H1023 for MOVIDRIVE® B)	Register <i>rr</i>
NVH <i>rr</i>	NVH0	NVH511 (NVH1023 for MOVIDRIVE® B)	Register <i>rr</i>
R <i>rr</i>	R0	R63 (Register, stored in the operator terminal)	Register <i>rr</i>



All parameters, variables and indices are 32-bit values.



### Communication with inverters con- nected via RS-485

After power on, the operator terminal addresses the RS-485 address that was entered as *Default station* in the driver parameters.

This address is also used when no other address is specified.

The following notation is used for addressing inverters with a defined RS-485 address:

#### Example

Default station RS-485 address 254 (peer-to-peer). Only to be used if one single inverter is connected to the operator terminal.

P100	Communication with parameter P100. The address that was entered in the [Default station] input field when configuring the driver is used as communication address.
2:P100	Communication with parameter P100 of the inverter with address 2
4:H102	Communication with IPOS variable H102 of the inverter with address 4

### Process data

The MOVILINK® driver can operate one to three process data per inverter depending on the setting.

A distinction is made between process output data (PO data from the PLC to the inverter) and process input data (PI data from the inverter to the PLC).

The number of process data is set in the MOVILINK® driver *Dialog*. The inverter parameter P90 PD configuration must have the same value.

#### Bit-wise access to process data

Device	Minimum address	Maximum address	Comment
PO <i>rr</i> . <i>bb</i>	PO1.0	PO3.15	Bit <i>bb</i> in register <i>rr</i>
PI1 <i>rr</i> . <i>bb</i>	PI1.0	PI3.15	Bit <i>bb</i> in register

#### Word-by-word access to process data (16-bit)

Device	Minimum address	Maximum address	Comment
PO <i>rr</i>	PO1	PO3	Register <i>rr</i>
PI <i>rr</i>	PI1	PI3	Register <i>rr</i>





### Indexed communication with inverters connected via RS-485

In addition to directly specifying the RS-485 address, communication can also be performed via index. This means the RS-485 address is stored in a variable of the operator terminal and can be set by the operator.

#### Example

A project is created in which the operator can enter the RS-485 address of the inverter. This has the advantage that the actual address of the inverter must not be known when creating the DOP project. The operator can enter and specify the address during system operation.

The actual speed of a drive is to be read via index. The actual speed is displayed in parameter P000.

1. Define the register R1 to which the RS-485 address of the inverter to be addressed will be stored in the HMI-Builder under [View] / [Name list] and define Parameter P000 as symbolic name for the actual speed:

Project 1: Name list

Name:

Address:

Comment:

Data type:  Index:

Controller systems

☒ 1: MOVILINK/MOVIDRIVE B 3.12.13

☐ 2:


☐ Internal variables

Name	I/O	Data type	Index	Comment
Actual...	P0	Signed 32-bit		

10784AEN




2. Now link index register 1 to terminal register R1 under [Setup] / [Index registers]:




10785AEN

3. Next, define the object Analog numeric **Q3** to enable the operator to enter the RS-485 address. Link this object with register R1 and select the Enable operator input checkbox on the [Access] tab.



10786AEN




10787AEN

Note the minimum and maximum input values.

4. Now define another Analog numeric object **03** to display the actual speed. Link this object with parameter P000 and enter the necessary scaling (0.001 in the example). Index register I1 is then treated like a preset RS-485 address: I1:P000.

This means the inverter address that corresponds with the content of index register I1 will be addressed.

Enter a gain of 0.001 to display the unit of actual speed in [1/min].



10788AEN



### 7.3 Programming with the programming software

All functions in the HMI-Builder can be called up using the menu.

File Edit View Functions Setup Block Manager Transfer Window Help

10397AEN

#### Starting the HMI-Builder

Click on [Start] / [Programs] / [Drive Operator Panels DOP] / [HMI-Builder] / [HMI-Builder].

The following menus are available when starting the HMI-Builder without having loaded a project:


- File
- Settings
- Window
- Help

#### Choose language

Choose the language for the user interface (including menu texts, object names, etc. under [Settings] / [Language]. It is assumed in this manual that you have chosen *English*.


#### Creating a project

To create a new project, select [File] / [New] from the menu. In the [Project settings] dialog, you can select [Terminal], [Controller system] and [Color scheme]. Not all options are available for all terminals. To create a new project, click [OK].




10403AEN

Figure 30: Project settings



## Terminal

Click on [Change].




10404AEN

Figure 31: Select the terminal

Select a terminal and the version (system program) of the selected terminal type.

## Controller

Here you define the controller to which the operator terminal will be connected. Clicking the [Change] button opens the following dialog. The list shows all installed drivers. Select [Brand name], [Protocol] and [Model]. Click [OK] to confirm your selection. To cancel your selection, click [Cancel].



10405AEN

Figure 32: Controller

Two drivers can be used in a project (terminal). The driver for the second controller is selected like the first one.

For more detailed information on using two drivers in one terminal, refer to section "Communication with two controllers (two drivers)" in chapter 9.1, "Communication".



#### Color scheme

In this window, you can create an individual color scheme and save it under a different name. You can also define the colors for your background, menus, dialog boxes, objects, etc. When selecting an object from the toolbox or menu, the colors of the object correspond with the colors defined in the color scheme.

Clicking the [Change] button opens the following dialog. Here you can change an existing color scheme or create a new one.




Figure 33: Color scheme

10406AEN

Clicking the [Apply] button updates all colors in the project except for lines, circles, rectangles and curves.

#### Updating drivers

##### From the Internet

To update available drivers to the latest version or to install new drivers, use the function [File] / [Update terminal driver] / [Download driver from the Internet].

Close all projects before using this function. The computer must be connected to the Internet. A web browser is not required. After the connection is established, a list with all drivers that can be downloaded from the Internet will be displayed.





Figure 34: Downloading a driver from the Internet

10407AEN

The list shows the version numbers of available and already installed drivers. Select the driver(s) to be installed in the HMI-Builder. The function [Mark newer] highlights all drivers of a higher version that are not installed. Next, click [Download]. Each driver file size is about 500 kB and is ready to use directly after download.

#### From disk

To update available drivers to the latest version or to install a new driver, select [File] / [Update terminal driver] / [from disk]. Close all projects before you use this function. Open the MPD file in the driver directory. A list opens with all drivers that can be installed.

The list shows the version numbers of available and already installed drivers. Select the driver(s) to be installed in the HMI-Builder. The [Select as new] function highlights all drivers that are available in a later version or that are not installed. Next, click [Download]. Each driver file size is about 500 kB and is ready to use directly after download.

***Changing the project settings***

The selected terminal or controller can be changed for a project. To do so, select [File] / [Project settings] from the menu and click [Change] next to the parameter *Terminal* and/or *Controller*.

***Changing the operator terminal***


When updating the system program in the terminal, the terminal version must be adjusted accordingly in the [Project settings] menu. Else, the scope of functions provided by the new terminal version will not be available.

***Changing the controller***

If you exchange the controller in a project against another controller with different signal names, then you also have to change these signals. Use the internal name list for this purpose. See the section "Name list" on page 96.

1. Select [View] / [Name list] from the menu.
2. Click the [Undefined] button to add all I/Os used in the project to the name list.
3. Click [Export] to output the name list as text file. Enter a name and click on [Save]. Define a separator for the text file.
4. Open the text file with an editor, such as Wordpad.
5. Change all I/Os into signals that will be used in the new controller. Save the file in a text format.
6. In the dialog [Name list], click the [Import] button and answer the question whether you are sure you want to delete all invalid I/Os with [No].
7. Click [Reconnect] to update all new I/Os in the project with the new name.
8. Select [File] / [Project settings] from the menu and click [Change].
9. Select the new controller and double-click [OK].





**Creating blocks  
with the Block  
Manager**

The Block Manager appears on the screen once you have created a project. The Block Manager shows which blocks belong to the application. The main block (block number 1) is automatically generated when creating a new project.




Figure 35: Creating blocks

10408AEN










The DOP11A-10 and DOP11A-50 operator terminal types do not have the [Contrast] block. Only the types DOP11A-30, DOP11A-40 and DOP11A-50 have the [System monitor] block. The DOP11A-10 type does not have the [Mail] block.

The Block Manager offers a toolbox with the following functions.

	Select a block and create a new block
	Add a new block
	Define a block header for the selected block
	Jump to the new block, which is created by pointer



	Press function key to jump to new block, which is created by pointer
	Add jump to block for touch key
	Erase selected block
	Open selected block for editing
	Block Manager settings
	Maximize
	Minimize

### Defining blocks

Adding a block opens the following dialog. The dialog is a simplified representation of the complete block header. Click [OK] to open and display the created block.





Figure 36: Creating a new block

10409AEN



Parameters	Description
Block name	You can enter a name for the block in this field. The block name will be displayed in the Block Manager and in the block list.
Block no.	The block number is specified in this field. If the entered number was already assigned to a block, the defined values will appear automatically. Block 0 is automatically created at the start of the program and must exist in every project.
Block type	Select whether you want the block to be a graphic block or a text block.
Block width	Define the font size for a text block. The font size cannot be changed for a defined block.
Template	Clicking this button inserts a block template or saves the current block as block template.

### Defining the complete block header

The [Block header] menu contains basic parameters that apply to each individual block. The appearance of the block header depends on the selected block type. To define a complete block header, click the block and select [Block Manager] / [Block Header] from the menu. The following parameters can be defined in the block header dialog.

10410AEN

Figure 37: Block header



The terms used for defining the block header are explained below:

**Block no.**

The block number is specified in this field. If the entered number was already assigned to a block, the defined values will appear automatically. Block number 0 is automatically created at the start and must exist in every project.

**Block name**

You can enter a name for the block in this field. The block name is listed in the block list.

**Display signal**

Digital signal that displays the selected block on the terminal screen. Use display signals in series to change blocks as quickly as possible. No entry is made in this field if you use another block changing method.

**Print signal**

Digital signal that sends the block to the connected printer. Display and print signals can be identical. Use print signals in series for fastest possible printing.

**Completion signal**

Digital signal that is output by the terminal when the print process has been completed. The signal is enabled by default. Selecting the [Reset] option resets the signal when the print process has been completed.

**Recipe directory**

Select a recipe directory where all recipes created in the block will be stored.

**Send mail signal**

When the specified digital signal is enabled, the text block will be sent as e-mail. The block name corresponds to the subject of the e-mail.



Only text blocks can be sent as e-mail.

**Mail completion signal**

Digital signal that is output by the terminal after an e-mail has been sent. The signal is enabled by default. Selecting the [Reset] option resets the signal when the e-mail has been sent.



### **Mail to address**

The e-mail address of the recipient is entered in this field. Clicking this button enables you to select up to eight recipients from a list. The list with e-mail addresses is created under [Setup] / [Network] / [Services] / [SMTP client]. Open the corresponding dialog by clicking the [Edit] button.

### **Append file**

Enter the name of a trend or recipe file you want to attach to your mail. If a trend file and a recipe file have the same name, the trend file will be attached.

### **Security level**

Define the security level (0-8) for the block. If you enter a security level  $>0$ , you will have to logon with a password that corresponds to the defined security level or higher.

### **Background block**

Applies to graphic blocks only. You can select another block that acts as background block for the current block, for example if you want to have the same background for several blocks. When the graphic block manager is activated, you can define whether the background block is shown when editing the selected block using the function [Window] / [Show background block] function.

### **Cursor color**

Applies to graphic blocks only. In this field you can define the cursor color in the graphic block.

### **Cursor thickness**

Applies to graphic blocks only. You can choose from three settings for the cursor thickness.

### **Block type**

In this field you define whether the block is of the graphic block or text block type. Once you have defined a block, you cannot change the block type anymore.

### **Block width**

This option is only available for text blocks. Define the font size for a text block. Once you have defined a block, you cannot change the font size anymore.

### **F keys**

Here you can define local function keys for the block. For further information, refer to chapter 8.10 "Function keys".



#### Keypad

Applicable for DOP11A-10 and DOP11A-20 only.

Here you can define quick infos for the function keys. Enter a text with up to 6 (DOP11A-20) or up to 5 (DOP11A-10) characters.

The bottom line is used in the block. For information on the other terminals, refer to the section "Graphic objects" on page 121.

#### Template

Clicking this button inserts a block template or saves the current block as block template.

#### Status

Defines the appearance of the screen in run mode. The status word does not have an effect on the system blocks. The parameters in the status words perform the following functions:

Parameter	Description
Cursor off (text block only)	Indicates whether the cursor is visible in the block in run mode.
Place cursor on first maneuverable object	Defines whether the cursor is to be positioned on the first maneuverable object in the block instead of in the top left hand corner.
Disable the <MAIN> key	Indicates whether the <MAIN> key is to be disabled in run mode when the block is displayed on the screen.
Disable the <LIST> key	Indicates whether the <LIST> key is to be disabled in run mode when the block is displayed on the screen.
More info (text block only)	Defines whether the [+] sign is to appear at the bottom and top right corner of the screen if the block contains more characters than can be displayed on the screen.
Autom. data entry	Indicates whether the cursors automatically jumps to the next maneuverable object after a data entry. In this mode, the cursor can only point to maneuverable objects.
Disable the <PREV> key	Defines whether the [PREV] key and the [Go to previous block] function are to be disabled for the function keys in run mode when the block is displayed on the screen.
Disable the Enter key	Only applies to digital objects. Defines whether the Enter key is to be disabled in run mode when the block is displayed on the screen.

#### **Show terminal around the work area**


The terminals provide the menu entry [View] / [Options] / [Show terminal]. Selecting this option shows the current terminal around the work area of the active block. You can click on the function keys, LEDs and text fields of the terminal view.

#### *Defining function keys*

You can select whether you want to define a local or global function key by double-clicking a function key. The double-click opens the manager for the selected function. For further information on defining function keys, refer to chapter 8.10 "Function keys."

#### *Defining LEDs*


Double-click an LED to open the manager for defining LEDs. For further information on defining LEDs, refer to chapter 8.9 "LEDs".



**Creating text strips** Double-clicking a text strip field opens a dialog where you can enter a text and define orientation and font of the text. This function enables you to define text strips and print them out.

**I/O browser** When creating a local name list in your project, you can select I/O signals from this list when defining objects.

To do so, click on [I/O]. The [I/O] button is available in all fields where an address can be entered. The [I/O browser] has an incremental search algorithm. This means a search is initiated by entering characters into the field for a name or signal. The I/O list is sorted by signals or names.



10411AEN

Figure 38: [I/O browser]



### Programming blocks

Double-click the required block in the block manager. The double-click opens the work area for the block and the toolbox. The work area shows the graphic block or text block manager depending on whether you open a graphic block or a text block. The toolbox contains all objects that can be created in the block.

To select an object, click on the object in the toolbox and move the cursor to the position in the work area where you want to place the object. A mouse click activates the dialog box for the selected object. Enter the parameters into the dialog and click [OK]. The object now appears on the work area. Static text or graphics are displayed directly on the work area.

General object parameters are described in chapter 7.1, section "Basics". Graphic and text objects are explained in chapters 7.4 "Graphical display and control" and 7.5 "Text-based display and control".





Figure 39: Programming blocks

10412AEN





### **Graphic block manager**

Not applicable for DOP11A-10.

This section describes the graphic block manager in the HMI-Builder. The method of functioning and appearance are based on the Windows standard.

In the graphic block manager, graphic blocks are created using static and dynamic graphic elements.

### **Opening the graphic block manager**

To open the [Graphic block manager] menu, double-click on a defined graphic block in the [block manager] or in the [Block list].


### **Mouse, keys and cursor**

The following section explains what you can do with the mouse and keys in the graphic block manager and also explains the different cursor shapes.

#### **Use the mouse to perform the following actions:**

- Select objects from the toolbox
- Select objects by clicking on them
- Select several objects (by clicking next to the objects, keeping the left mouse button pressed down and drawing a selection rectangle around the required objects.)
- Move objects (by keeping the left mouse button pressed down while the cursor is positioned over an object and moving the mouse.)
- Resize object
- Open the parameter dialog (by double-clicking an object)

The figure below shows what a selected object looks like.



10413ADE

Figure 40: Selected object







#### Use the keys to perform the following actions:

- Create objects using the [Object] menu
- Use the arrow keys to move the cursor
- Move the cursor pixel-wise (by pressing the key combination <Ctrl> + arrow key)
- Select or deselect an object (by positioning the cursor over the object and pressing the space bar)
- Select/highlight several objects (by selecting [Object] / [Select block] from the menu and drawing a border around the objects by pressing the space bar and arrow keys)
- Move an object (by positioning the cursor over the object, keeping the space bar pressed down and pressing the arrow keys)
- Change the size of an object (by positioning the cursor over an object handle, keeping the space bar pressed down and pressing the arrow keys)
- Open the dialog for a selected object (by pressing the Enter key)

#### Cursor















The cursor can take four different shapes:



	Within an object
	The size of the object can be changed
	In the graphic work area
	When selecting a function from the menu or the toolbox



### Toolbox

The graphic block manager provides a toolbox to create objects in a block. All functions are also available via the menu bar. The following list describes the toolbox functions.

	Pointer
	Select
	Create a symbol
	Maximize
	Minimize
	Grid
	Item on top
	Item on bottom
	Line pattern
	Thickness
	Font size
	Background color for the block
	Foreground color for objects
	Background color for objects



#### *Creating objects*

Click on the required object in the toolbox and move the cursor to the position in the work area where you want to place the object. Make a mouse click to position the object.

Static graphics are displayed when clicking on the work area. For dynamic objects, a dialog opens for the current object. The object is displayed on the screen when clicking [OK] in the object dialog.

Once the object is displayed it has handles and selection mode is active.

#### **Static graphic**

Static graphic objects comprise

- Line
- Curve
- Ellipsis
- Rectangle
- Symbol
- Text
- Decorations

for drawing background graphics. You can change static graphic objects into dynamic objects by linking them to the objects on the [Dynamic signals] tab.

#### **Dynamic objects**

Dynamic objects are linked with signals to generate control and monitoring functions, among others. For further information on defining objects, refer to chapter 7.4 "Graphic display and control".

#### *Selecting several objects*

There are two ways of selecting several objects in the graphic block manager.

- Press the left mouse button and keep it pressed down while drawing a selection rectangle around the required objects. The last object you have created will be displayed with filled handles.
- Select the pointer from the toolbox. Hold the shift key pressed while selecting the required objects. The last object you have selected will be displayed with filled handles.



**Positioning objects** The [Layout] menu offers several functions for easily positioning objects:


- Align
- Make same size
- Space evenly
- Tile

You can also invoke these functions from a separate toolbox.

This function can only be invoked when at least two objects have been selected. The functions perform their positioning calculations based on one or two reference objects.

The functions [Align], [Make same size] and [Tile] refer to the object that was last selected or created. See the section "Selecting several objects" on page 80.

The function [Space evenly] takes the object furthest down to the bottom/top or left/right as reference object. The functions do not affect the reference object.



10414AEN

Figure 41: [Layout] menu

## Align

The [Align] function offers six menu options for aligning objects vertically or horizontally.

Left	Aligns the selected objects flush left with the reference object.
Right	Aligns the selected objects flush right with the reference object.
Top	Aligns the selected objects flush with the top of the reference object.
Bottom	Aligns the selected objects flush with the bottom of the reference object.
Vertical center	Centers the selected objects vertically based on the reference object.
Horizontal center	Centers the selected objects horizontally based on the reference object.



#### Make same size

The [Make same size] option offers three functions to make selected objects the same size.

Width	Matches the width of the selected objects to that of the reference object.
Height	Matches the height of the selected objects to that of the reference object.
Both	Matches the size of the selected objects to that of the reference object.

#### Space evenly


The [Space evenly] option offers two functions to change the distance between two selected objects.

Vertical	Matches the position of the selected objects to have an identical vertical distance. The objects closest to the top and bottom are not moved. At least three objects must have been selected.
Horizontal	Matches the position of the selected objects to have an identical horizontal distance. The objects closest to the left and right side are not moved. At least three objects must have been selected.

#### Tile

The [Tile] option offers two functions that enable you to position two objects next to each other

Vertical	Changes the vertical position of the selected objects so they are adjacent to the reference object.
Horizontal	Changes the horizontal position of the selected objects so they are adjacent to the reference object.



### Grouping objects

The [Layout] menu offers functions for grouping several objects. Select the required objects and choose [Layout] / [Group] from the menu. The group of objects will now be treated like a single object and you can resize the objects all at once. You can still define the color and font individually for each object in the group. Clicking an object in the group opens the edit dialog for the corresponding object.



10415AEN

Figure 42: Grouping objects

The [Layout] / [Ungroup] function allows you to separate a group into individual objects.

### Saving and loading grouped objects

You can save or load grouped objects by clicking the [Library] button in the toolbox in the graphic block manager.

### Creating tables

Object tables in a graphic block can be created as follows:

1. First, create two rows or columns with the same object.



10416ADE

Figure 43: Object tables



2. Select the objects and choose [Object] / [Create series of] from the menu.



10417AEN

A dialog box opens.

3. If you want to create a table, define the number of rows and columns and the direction into which you want to expand the table.

Clicking [OK] has the programming software create a table with the defined number of rows or columns.



The quick info text must end with a number, else the table cannot be created. The object alarm banner cannot be included in a table.

### Symbols

There are three ways to create symbols:


- Via the Symbol manager
- Via the function [Create symbol]
- by inserting a graphic from another Windows application via the clipboard.

See the section "Symbol manager" on page 87.

#### [Create a symbol] function

1. Select [Create symbol] from the toolbox.
  2. Draw a selection rectangle around the graphic you want to save as symbol.
  3. Enter a name for the symbol. The name must not exceed eight characters.
- The symbol will then be saved in the symbol library under the specified name.





### Copy a graphic from another application

1. Copy an object in another application, such as Paint, to the clipboard.
2. Open the graphic block manager in the programming software and select the [Paste] command.
3. Specify a name for the symbol. The name must not exceed 8 characters.

The symbol will then be stored in the system library under the specified name.

Graphics and symbols can be copied from one block to another and from one project to another in the HMI-Builder using the [Copy] and [Paste] functions.



A user defined symbol will be copied from one project to another if it does not yet exist in the target project.

### ***Text block manager***

Dialogs and reports are created in the text block manager. A text block can consist of static text and dynamic objects. Static text is not changed during program execution whereas dynamic objects are linked with controller signals.

Seven dynamic object types are available:

- Digital
- Analog
- Jump
- Date / time
- Bar
- Multiple selection
- Text object

### *Opening the text block manager*

To open the text block manager, double click on a defined text block in the block manager or in the block list. Select a defined block from the block list or create a new text block.

### *Mouse and keys*

Click on the begin of the text to be selected and drag the mouse pointer over the text. To select text using keys, hold down the shift key and select the text using the arrow keys.

Selected text is deleted using the [Cut] function.

You can insert an end of line using the key combination <Ctrl> + Enter key.

To view an object's properties, double-click an object and press the <F4> key.




### *Toolbox*

The block manager provides a toolbox with the following functions.

- Maximize
- Minimize
- Resizable



All functions are also available from the menus. For further information on defining and using the various objects in text blocks, refer to chapter 7.5 "Text-based display and control".

	Maximize
	Minimize
	ASCII selection list. For selecting characters that cannot be directly entered using the keyboard.

#### *Defining text blocks*

##### **Static text**

The text block manager is a text manager for entering static text. The Windows functions [Copy] and [Paste] can be used to copy and paste text in a block from one block to another or from one program to another (e. g. Microsoft Word). This is an easy way of documenting an application.

##### **Dynamic objects**

Dynamic objects can be defined at any text position. Select the object type from the toolbox or the [Object] menu. This opens a dialog where you can define the object.

The dynamic object is marked with a rhomb (#) followed by one or several hyphens (-) depending on the position. For further information on defining dynamic objects, refer to chapter 7.5 "Text-based display and control".




**Symbol manager** Not applicable for DOP11A-10.

The symbol manager is opened by selecting [View] / [Symbol manager] from the menu. The symbol manager provides functions for importing and exporting bitmap symbols. You can also add user defined symbols to the symbol library or delete symbols from the library. The symbol list shows all user defined symbols. Predefined symbols are not shown as they cannot be changed.

For information on creating symbols, refer to the paragraph "Graphic block manager" on page 77.

The scope of delivery of the HMI-Builder includes several symbol libraries that contain different symbols, such as predefined pump symbols.



10419AEN

Figure 44: Symbol manager


**Transp. color** When importing a symbol you can define a symbol color as transparent.

**Number of colors** Here you can define the number of colors displayed on a color terminal: 16 or 256.

**Exporting symbols** You can export symbols in bmp format and use them in other applications.

**Importing symbols** The import function enables you to reuse symbols from other programs. Image files can be imported from other Windows applications, such as Paint, to the symbol library in the following formats: bmp, cmp, dcx, fpx, jpg, mpt, pcd, png, tga, tif and pcx. For the DOP11A-20, only black and white bmp files can be used.

The scope of delivery of the HMI-Builder includes several symbol libraries that contain different symbols, such as predefined pump symbols. The symbols are saved in the following directory: C:\Programs\DOP\HMI-Builder\lib\bitmap\.



#### Create

You can draw a new symbol using the [Create] function. After clicking the [Create] button, you will be prompted to enter a name for the new symbol. Next, click [OK]. The symbol editor opens. The symbol editor is used like a normal graphic program. There are restrictions depending on the terminal in use.




Figure 45: Symbol editor

10420AEN

Clicking the right mouse button uses the background color for drawing. If white is set as background color, you can delete it this way.

#### Edit

The [Edit] function opens the bitmap manager for a defined symbol.

#### Duplicate

Use this function if you want to save the current symbol under a different name.

#### More

Click the [More] button to add more information to a symbol:

Parameters	Description	
File name	Displays the file name for the symbol if it was imported from a file.	
Creation date	Displays the date when the symbol was created.	
Source	Displays information on the source of the symbol.	
	None	Unknown source
	Bitmap file	Imported from a bitmap file
	Clipboard	Inserted via clipboard (using copy & paste)
	Graphic block	Created in a graphic block
Comment	Here you can enter a comment on the symbol.	




### Delete

Use [Delete] to delete a symbol from a project.

### Add a static symbol to a block

Click [Symbol] in the toolbox and move the cursor over the block in the work area where you want to place the symbol. Next, make a mouse click. Clicking on the work area opens the [Static symbol] dialog.



10421AEN

Figure 46: Static symbol

### [General] tab

Parameter	Description
Symbol	Select the symbol you want to display.
Use dynamic bitmaps	For DOP11A-50 only
Resizable	If this option is enabled, you can change the x or y size of the object.

### Other tabs

The functions on the [Dynamics] tab are described in the section "General parameters" in chapter 7.4 "Graphic display and control".




### I/O change

The [I/O change] enables you to change I/Os or move an entire I/O range. I/O changes can be made for the entire project or only for selected objects.

The function can be used in the following areas:

- Blocks in the block list
- Objects in graphic and text blocks
- Lines in the alarm list
- Lines in the function key manager
- Lines in the LED manager
- Lines in the cross reference list


Select [Edit] / [I/O change] from the menu.



10422AEN


Figure 47: I/O change

Parameter	Description
Change I/O in	Define whether I/Os are to be changed in the entire project or for selected objects.
Change	Select whether an individual I/O is to be changed or an entire I/O area is to be moved.
From I/O, end I/O, to I/O	Enter the I/O to be changed and define the area to which you want to move the I/Os.
Confirm each change	Enable this checkbox if you want to confirm each I/O change for an object.



**BDTP station  
change**

This function enables you to change the index numbering for a BDTP client project in a BDTP network, e. g. from station 1 to station 3. Select [Edit] / [BDTP station change] from the menu.




10423AEN

Figure 48: BDTP station change

Parameter	Description
Change station in	Define whether the index numbering is to be changed in the entire project or for selected objects.
From station, to station	Specify the index number to be changed as well as the BDTP station index number in this field.
Confirm each change	Enable this checkbox if you want to confirm each BDTP station change for an object.

**I/O cross  
reference**

The [I/O cross reference] function is used to enable documentation of I/Os. Select this function via [View] / [I/O cross reference].




10424AEN

Figure 49: [I/O cross reference]

Enter [Start I/O] and [End I/O] in the dialog that opens. If you do not enter a value in the [Start I/O] field, all I/Os will be included up to the value in the [End I/O] field. If you do not enter a value in the [End I/O] field, all I/Os from the value in the [Start I/O] field will be included. If you do not enter a value in any field, all I/Os will be included in the list.

**Representation**

The results output by this function will be displayed in a list with two levels. The first level lists the existing I/Os and the number of objects belonging to the respective IO. To open the second level, click the plus symbol next to I/O. The second level displays all objects in the selected I/O. The plus symbol then changes to a minus symbol.



10425AEN

Figure 50: Display [I/O cross section]

You can select a row in the list and copy it to the clipboard from where you can paste it, for example, into a Microsoft Word document.

#### Other managers

HMI-Builder also provides managers for managing

- Function keys
- LEDs
- Alarms
- Alarm groups
- Passwords
- Time channels
- Message library
- Macros
- Data exchange


They are opened via the [Functions] menu. The parameters in the respective manager are described in the corresponding sections.

The definitions for function keys, LEDs, alarms, alarm groups, time channels, message library, macros and data exchange are listed in the relevant manager. Insert new definitions using the [Append] or [Insert] functions.

To change a definition, select the definition you want to change, make the change and click [Update]. To easily change several definitions, click [Update] or [Append] only once and then confirm each change with the Enter key.

The [Append] and [Update] functions remain active until another function is called. Use the [Delete] function to delete a selected definition. To close the manager, click [Close]. The following example applies to the alarm manager.





Alarms are numbered automatically. Clicking [Append] adds an alarm definition to the end of the alarm list. Clicking [Insert] inserts the new definition over the selected row in the list. The subsequent alarm definitions will be renumbered. Click [Update] to confirm your changes.




Figure 51: Alarm manager

10426AEN


### [File] menu

The [File] menu includes functions for creating, opening, saving and closing projects. This menu provides the following options:

- Print setup
- Print preview
- Document header
- Print

There are also functions to test a project and change project settings.

Using the [Export project transfer file] enables you to transfer a project to a palm pilot for temporary storage. The project cannot be displayed on the palm pilot but can only be exported to another terminal. You can use this function, for example, to copy projects from one terminal to another (e. g. for a project update).



10427AEN

Figure 52: [File] menu

### [Edit] menu

The [Edit] menu comprises the following functions:

- Cut
- Copy
- Paste
- Undo
- Select all

The [Find] function is available for editing texts in different languages. The function also allows for accessing the functions [I/O change], [BDTP station change] and [Default controller].



10428AEN

Figure 53: [Edit] menu



### [View] menu

The [View] menu includes

- Block manager
- Symbol manager
- I/O cross reference
- Name list

The menu also provides functions for setting various display modes in the program. Some functions appear in Windows applications as standard, others are HMI-Builder specific. Below a description of HMI-Builder specific functions.

View	Functions	Setup	Object
	Block list		Ctrl+B
	Block manager		Ctrl+M
	Symbol manager...		Ctrl+Y
	I/O cross reference...		
	Name list...		
	Toolbars		▶
	Options		▶
	Zoom		▶

10429AEN

### Block list

The [Block list] menu shows the blocks belonging to the application. To create a new block, click on [New] in the block list. To open an already defined block, click on [Open]. Clicking the [New] button opens the [Block header] dialog. Here you can define basic parameters for the block. To open the [Block header] dialog for a selected block in the list, click on the [Block header] button. To delete a selected block, click [Delete].

No.	Type	Size	Block Name
0	Graphic	356	Main
990	Graphic	484	Alarms
991	System	130	Time channels
992	Graphic	504	System Monitor
993	System	124	Mail
997	System	130	Contrast

10430AEN

### Block manager

In the [Block manager] menu, all blocks in an application are presented graphically. With this menu, you can create new blocks, define the block header and define jumps via tool-box functions.



#### Symbol manager

This menu option opens the symbol manager where you can create your own symbols or edit existing symbols. You can also create a library with symbols in bmp format. The symbols in the symbol manager will then be available in the symbol list when you create static or dynamic symbol objects.


#### I/O cross reference

Using the [I/O cross reference] menu, you can list I/Os.

#### Name list


The [Name list] menu enables you to define a local name list for the signals used. You can add signals in the project that do not have a name to the name list via the [Undefined] function. You can insert new signals or edit and update existing signals. Use the [Update] function to update the project with the changes you have made in the name list.

You can export a name list to a text file. You can also import a text file to a name list. Tab, semicolon, comma or blank can be used as separator for the file contents. You can sort an internal name list. The text file must not contain special national characters, such as B, Ä, Ö and Ü.



10431AEN

If a driver-specific name list is linked to your project, you can choose the I/O signals from this name list. To do so, click the [Connect file] button.



### Tool bar

You can show/hide tool bars using the [Tool bars] menu item.

Parameters	Description
Tool bar	Shows/hides the tool bar.
Controller tool bar	Shows/hides the controller tool bar.
Language tool bar	Shows/hides the language tool bar.
Status bar	Shows/hides the status bar.
Block manager tool box	Shows/hides the block manager tool box.
Toolbox	Shows/hides the toolbox.
Align toolbox	Shows/hides the toolbox for the alignment function.

### Options

Parameters	Description
Show terminal	Selecting this option displays a terminal around the work area in the graphic manager. The managers for LEDs, function keys and text strips can be opened via the terminal view. Double-clicking a function (e. g. a function key) opens the corresponding edit dialog.
Show background block	Applies to graphic blocks only. With this option, you can show the background block when working in the graphic block manager.
View language index	For multi-language support only. Shows the index number for the text in the application.
Quick info	A quick info for a function is displayed when the cursor is moved onto the function.
Use block list	Here you can define whether you want the program to open the block list or the block manager when you create a new project.
Use terminal font	Here you choose whether you want the program to show the text you enter in dialog boxes in terminal font.
Select Unicode font	Select a Unicode font from the dialog. This font will be used in the programming software for multi-language support.




**[Functions] menu** The [Functions] menu includes managers for:

- Function keys
- LEDs
- Alarms
- Time channels
- Passwords
- Message library
- Macros
- Data exchange




10432AEN

Function	Description
Function keys	Here you can define global and local function keys. See chapter 8.10 "Function keys".
LED	With this option you can define functions for the LEDs. See chapter 8.9 "LEDs."
Alarm groups	With this option, you can group alarms (e. g. by severity levels) to allow for recognizing and clearing them more efficiently. See chapter 8.2 "Alarm handling."
Alarms	With this option you can define alarm messages and signals that trigger an alarm. See chapter 8.2 "Alarm handling."
Time channels	With this option you can define time channels that control events in processes at a certain time. See chapter 8.6 "Time control."
Passwords	With this option you can define passwords for the various security levels in the application. See chapter 8.4 "Passwords."
Message library	With this option you can create message tables where values between 0 and 65535 are linked with texts. See chapter 8.1 "Message library."
Macros	With this option you can create events that affect all function and touch keys. See chapter 8.12 "Macros."
Data exchange	With this option you can define the conditions for data exchange between the selected controllers.



### [Setup] menu

The [Setup] menu includes functions for configuring the terminal.



10433AEN

### System signals

With this option you can define handshake signals between terminal and controller.

#### Current display register

Data register in the controller that contains the number of the block (in run mode) to be displayed on the screen. The data register is automatically updated when the block is changed. This register does not affect block selection.

#### New display register

Data register in the controller that defines which block will be displayed on the screen.

#### Buzzer register

Not applicable for DOP11A-10.

The value of this register defines the buzzer tone. Tones and scales are given in the table below. Value 0 means there is no tone. All values in the table are given in Hz.

	C	D	E	F	G	A	H
Contra	33	37	41	44	49	55	62
Large	65	73	82	87	98	110	123
Small	131	147	165	175	196	220	247
One	262	294	330	349	392	440	494
Two	523	587	659	698	784	880	988
Three	1046	1174	1318	1397	1568	1760	1975
Four	2093	2348	2636	2794	3136	3520	3950
Five	4186						



#### Background lighting signal

Digital signal that activates or deactivates background lighting.

#### Cursor control block

Not applicable for DOP11A-10.

The start register for a control block is specified in the terminal. The start register writes the current cursor position in the graphic block to the data register in the controller.

Register	Description
0	Current graphic cursor position X (in pixels): 0-239 for DOP11A-20 and 0-319 for DOP11A-40.
1	Current graphic cursor position Y (in pixels): 0-63 for DOP11A-20 and 0-239 for DOP11A-40.
2	Status register
0	Normal
1	The user attempts to move the cursor downward but there is no object at the selected position.
2	The user attempts to move the cursor upward but there is no object at the selected position.
3	The user attempts to move the cursor to the left but there is no object at the selected position.
4	The user attempts to move the cursor to the right but there is no object at the selected position.

Start register in a control block in the DOP11A-30 and DOP11A-50 terminals that writes the current cursor position in the graphic block to a controller register.

Register	Description
0	x-coordinate (in pixels): 0-319
1	y-coordinate (in pixels): 0-239
2	Status register 0 Not pressed 1 Pressed

#### Cursor motion register

Not applicable for DOP11A-10.

Cursor positioning in the graphic block can be defined using a register. The register values and their meaning are explained in the table below. Value 0 must be assigned to the register between the same command for the motion. We recommend to also use the [Cursor control block] function to optimize the function.

Register value	Description
1	Moves the cursor to the first maneuverable object.
2	Moves the cursor to the next maneuverable object.
3	Moves the cursor up one step.
4	Moves the cursor down one step.
5	Moves the cursor left one step.
6	Moves the cursor right one step.





### Print status register

The status of the connected printer can be read from a register. The register can have the following values:

Register value	Description
0	OK. The printer works properly.
1	General error. Check the port and printer settings.
2	No paper. Reload printer paper.
3	No memory. The printer memory is full.
4	Not connected. The printer is not connected correctly. Check the port and printer settings as well as the printer cable.

Values 1 to 4 in the register mean that the printer does not work properly. In this case, the terminal will ignore printing until the value in the register is 0 again.

### Library index register

This register is used for indexing the message library. The library number from which the texts are to be retrieved is indicated in the message object. When defining an index register, its contents is added to the number specified in the object. This means a register can control from which library the texts are to be retrieved.

### Commands

One or more of the following commands can be entered in the command line. Commands are separated by blanks. All commands are capitalized.


Command	Description	Models
Rx	Maximum number of transmission attempts, x = number of attempts. Applies for communication with the controller. Example: R5@2 applies to controller 2.	DOP11A-10 to 50
Tx	Global timeout in x ms. Applies for communication with the controller. Example: T10000@1 applies to the timeout for controller 1.	DOP11A-10 to 50
AKx	Activates the joystick function. See the "Joystick function" section in chapter 5.2 "Terminal functions".	DOP11A-10 to 50
DD	Disable Delete. Disables the deletion of alarms from the alarm list. When this command is issued, inactive or acknowledged alarms will not be deleted from the alarm list.	DOP11A-10 to 50
LOBx	Activates the digital signal x when the battery of the real-time clock needs to be replaced. Example <b>LOBM0</b> activates M0 when the battery needs to be replaced.	DOP11A-10 to 50
MDx	When using two drivers: If communication is interrupted by one controller, the terminal will continue communication with the other controller. The terminal will attempt to reestablish the interrupted communication with the controller every 10 seconds. You can change the interval using the <b>MDx</b> command, where x indicates the time in ms.	DOP11A-10 to 50
NTx	Timeout in x ms for a message in no protocol mode.	DOP11A-10 to 50
RPD	RUN/PROG Disable. Disables the option to toggle between RUN/PROG using the backspace key and the <MAIN> key. When the <b>RPD</b> command is issued, the mode can only be changed via HMI-Builder.	DOP11A-10 to 50
SW	Converts text with Swedish ASCII characters (7-bit) when printing to the expanded IBM PC-ASCII character set (8-bit).	DOP11A-10 to 50



Command	Description	Models
BFF	Block Form Feed. Adds a page break after each block during printing.	DOP11A-20 to 50
BCTO	Displays the error message "BDTG comm. Error" only the first time a BDTP client attempts to reestablish a connection with a BDTP server.	DOP11A-20 to 50
DGP	Removes the alarm group from alarm printouts.	DOP11A-20 to 50
FTNO	Deletes the line with the OFF indicators in trend files when using FTP.	DOP11A-20 to 50
JAAL	Locks keys and touchscreen of the operator terminal as long as a terminal applet is running.	DOP11A-20 to 50
PDxxxxxxx	Password protecting access to the [Transfer] menu.	DOP11A-20 to 50
PSxxxxxxx	Password that has priority over all other password levels. Is used for support and maintenance, for example. For further information, refer to chapter 8.4 "Passwords".	DOP11A-20 to 50
SJAFx	Displays the name of the logged-on user when the Java applet is active. If no name was specified, JAVA will be displayed instead. The name appears in the top right corner. x = represents the character size and can have a value between 1 and 7.	DOP11A-20 to 50
TESOSn	Only a trend sample is saved when selecting the <i>Activate</i> signal. When <b>n=*</b> , the setting applies to all trend objects. When <b>n=T</b> , the setting only applies to trend objects beginning with T.	DOP11A-20 to 50
TBUP	Is used to create backup copies of trend files on expansion cards.	DOP11A-30 to 50
DBKL	Unlocks keyboard and touchscreen when the background lighting needs to be replaced. The default setting locks keyboard and touchscreen when the background lighting fails.	DOP11A-30 to 50
DNBW	Disables the warning "No block x". Else, the warning appears for instance when a block jump to a non existing block number was configured, or when the function [New display register] is used to control via data register in the controller which block is to be displayed on the screen.	DOP11A-30 to 50
NHD	This command allows for printing graphic blocks without block header (which includes block name, block number, date and time) on a laser printer.	DOP11A-30 to 50
NMAN	Activates the warning "Not maneuverable" for operator terminals with touchscreen.	DOP11A-30 and 50 with touchscreen
TCD	The "Touch Calibrate Disable" prevents calibration of the touchscreen.	DOP11A-30 and 50 with touchscreen
DIMxxx	Data register xxx that contains a value between -63 and +63 and serves to control the color intensity. -63 represents the darkest and +63 the brightest value. The standard value is 0.	DOP11A-50

#### Index registers

Index addressing of dynamic objects. For further information, refer to chapter 7.8 "Index addressing".



## Country settings

### Character set

The selected character set determines which character table will be used in the terminal and which national special characters will be available.

Character set	Character table in graphic based terminals
Swedish	437
German	437
French	850
Spanish	850
Norwegian / Danish	850
Russian	866
Slavic	852
Greek	869
Unicode	-

Special character tables are used for the text based terminal (DOP11A-10). The same character table is used disregarding the selected character set. Different national characters are used depending on the selected character set.

	Swedish	German	French	Spanish	Norw. / Danish
C1	Å	Ü	È	Ñ	Å
C2	Ä	Ä	É	É	Æ
C3	Ö	Ö	Ê	Ó	Ö
C4	å	ß	è	Á	Ø
C5	ä	ü	é	ñ	å
C6	ö	ä	ê	é	æ
C7		ö		ó	ö
C8		ß		á	ø

The national characters are not used when Slavic or Russian is selected.

### System language

Menu language selection: British English, German, Swedish or American English. By default, the menu texts in the terminal are set to British English.



#### Multi language

Menu	Description
New language	Starts the wizard for creating multi language applications.
Edit	With this option you can edit or translate texts in the application.
Setup	This function displays the tree structure for the languages in the application. For further information on possible settings, refer to chapter 8.7 "Language handling".
Export	This function exports the languages used for the project application to a text file in ANSI, OEM or Unicode format. Specify whether you want to export languages used for the project application or system languages. Next, the [Multi Language Text-Export] dialog opens. Enter the destination and the format of the file to be saved. Under [Encoding], you can select [ANSI/OEM] (all languages created in ANSI/OEM format will be exported) or [Unicode] (all languages will be exported in one file in Unicode format).
Import	This function imports a language for use in the terminal. Specify whether application or system languages will be imported. Next, the [Multi Language Text-Import] dialog opens. Enter the name of the text file to be imported. If the project language is in ANSI/OEM format and a language is to be imported in Unicode format, the imported language will be converted into ANSI/OEM format. As a result, all characters outside the ANSI/OEM range will be represented as question marks.
Show index	This function displays the index in objects instead of texts. You can also enter a text when using index view. This way, the new text obtains a new index.
Cross reference	Shows a cross reference with the indices in the application blocks.
Reuse index	If this function is active when copying an object, a new object will be created with the same index.
Choose Unicode font	Choose a Unicode font for use in the programming software.

#### Date/time format

Setting the date and time format.

##### Date format

The following date formats are possible:

- YY-MM-DD
- YYMMDD
- DD.MM.YY
- DD/MM/YY
- DD/MM/YY


Y=year, M=month, D=day.

##### Time format

The following time formats are possible:

- HH:MM:SS
- HH:MM

H=hours, M=minutes, S=seconds.



### Activate clock

Select this checkbox to activate the clock in the terminal. When controller 1 or 2 is selected, the clock refers to the clock in controller 1 or 2.



This function cannot be used with MOVIDRIVE® and MOVITRAC® inverters.

### Clock → controller 1/2

Select this option if you want to transfer the data of the terminal clock to a data register in controller 1 or 2.



If the controller has an activated real-time clock and the terminal clock sends data to the same data register, the controller clock will have priority.

### Update interval

Here you can define how often the terminal sends clock data to the controller. Enter the value in seconds. The recommended value is 60 seconds. Shorter update intervals slow down the communication between terminal and controller.

### Controller register

Enter the start address for saving date and time in the controller.

For information on saving date and time, refer to the manual of the controller in use. The terminal saves information in the sequence as defined in the basic setting of the controller.



This function cannot be used with MOVIDRIVE® and MOVITRAC® inverters.

### Daylight saving time

Here you can specify dates for start and end of daylight saving time. Enter day of week, week of month, month, hour and setting. You can choose between Europe and US standard time.

To disable daylight saving time, leave both month fields blank.

### Online settings

Allows for changing the selected function in run mode.




#### Terminal options

Option	Description
BG	Click on [BG] to define the background color of the terminal.
FG	Click on [FG] to define the foreground color of the terminal.
Window	Here you can select the window color of the terminal.
Screen saver time (min)	Enter the screen saver activation time in minutes. The default setting is 0 which means the screen saver is disabled. A screen saver extends the life of your monitor.
Key delay (ms)	Time interval in milliseconds between 2 hits of the same key before the cursor automatically moves to the next position. Is used when ASCII characters (A-Z, etc.) are entered. See the section "Alphanumeric function" in chapter 5.2 "Terminal functions".
Key tone	Define whether the terminal produces a signal tone when a key is pressed.
Key repetition	Specifies whether a function is repeated as long as a key is being pressed. This does not apply to function keys and the entry of alphanumeric characters (A-Z, etc.).
Trend settings	General trend settings are made in this field.
Save modified patterns	Only saves modified patterns in the trend if the value has changed since the last measurement.
Save all patterns	Saves all patterns in trends if the value has not changed since the last measurement. These parameters affect all defined trends.
FTP delimiter	The terminal can save the contents of all files that are created in the terminal and that can be accessed via FTP using different separators. The content of recipe or trend files, for example, can be delimited using tab, semicolon or comma. See also chapter 9.3 "Network functions in the terminal".

#### Alarm settings

General alarm list settings are made in this field. For further information, refer to chapter 8.2 "Alarm handling".



## Peripherals

All communication settings are made under [Setup] / [Peripherals]. Selecting [Peripherals] from the menu opens a list with units defined for the system. You can move the units using drag & drop.



10434AEN

## Ports

Clicking on [Ports] opens a dialog with the current configuration. You can change the configuration.




The maximum transfer speed for the model DOP11A-10 is 38400 baud.

## RS-232C

Select the [RS-232C] port and click the right mouse button. The following dialog opens. Assign the following parameters to the port:

- Baud rate
- Parity
- Data bits
- Stop bits



10435AEN



## Programming

### Programming with the programming software

#### RS-422

Select the [RS-422C] port and click the right mouse button. The following dialog opens.

Assign the following parameters to the port:

- Baud rate
- Parity
- Data bits
- Stop bits



10436AEN


#### RS-485

For DOP11A-30 only:

Select the [RS-485] port and click the right mouse button. The following dialog opens.

Assign the following parameters to the port:


- Baud rate
- Parity
- Data bits
- Stop bits



10437AEN

For communication with MOVIDRIVE®, set 9600, even, 8 data bits, 1 stop bit.






The DOP11A-30 terminal has three physical ports. Only two ports can be used simultaneously. This is why the ports are referred to as "Port 1" and "Port 2" in the [Peripheral configuration] window.

### Expansion slots


Select [Expansion slots] and press the right mouse button. You can now define the expansion slot you want to use and the settings for the relevant card. You will find detailed information in the manual on the corresponding expansion card.



10438AEN

### Printer

Select [Printer] and press the right mouse button to open the printer settings dialog.



10439AEN



Parameters	Description
Printer type	Choose a printer: None, HP PCL5 or standard text.
Page length	Here, you define the number of lines before a page break. No page break is created when the page length is set to 0. The default setting is 60.
Paper type	Select the paper type.
Graphic orientation	Specify whether you want to print the graphic in portrait or landscape format.
Text orientation	Specify whether you want to print text in portrait or landscape format.
Graphic size	Specify the size of the graphic print-out.
Printer disable signal	Digital signal which cancels printing if enabled.
Handshake	Specify the required handshake type between printer and terminal: XON/XOFF or CTS/RTS. Refer to the printer manual for information on the correct handshake setting.
New line character	Specify the end of line character: None, CR/LF, CR, or LF.
Screen dump	Option for screenshots. Select standard or inverted.



The printer settings apply to parameters such as *Character table*, *Font size* and *Margins*.

### No protocol mode

Select [No protocol mode] and press the right mouse button. The following dialog opens.



10440AEN

Parameters	Description
No protocol control register	This register is the first control register in no protocol mode. Refer to chapter 9.2 "Communication" for a description of the no protocol mode.
No protocol signal	Digital signal for switching between no protocol mode and transparent mode. This signal is used for switching between the two modes during operation, for example to establish a connection with a computer and to send a message.

### Recipe settings

Here, you define the recipe management settings. See chapter 8.3 "Recipe management".



**[Block manager]  
menu**


The [Block manager] menu comprises functions for programming blocks.



10441AEN

**Block manager  
settings**

The display in the block manager is configured under [Block manager] / [Settings].



10442AEN

Tab	Description
Block	Define the appearance of data for the block and the block in the block manager.
Reference	Here, you can set the block manager view.
Edit	This tab provides special functions for the representation in the block manager.



#### **[Object] menu**

The [Object] menu lists all objects available in the program. The number of objects depends on the terminal type. Refer to chapter 7.4 "Graphic display and control" and chapter 7.5 "Text-based display and control" for a description of the objects.



10443AEN

#### **[Layout] menu**

The [Layout] menu offers functions for aligning several objects. These functions are described in the section "Positioning objects" on page 81.




10444AEN



### **[Transfer] menu**

The [Transfer] menu offers functions for transferring projects, selected blocks and communication settings between PC and terminal. See chapter 7.6 "Project transfer".




10445AEN



The communication settings for programming software and terminal must be identical.

### **[Window] menu**


The [Window] menu contains general Windows functions.



10446AEN

### **[Help] menu**

The [Help] menu contains the help functions and information on the program version.



10447AEN



#### 7.4 Graphic display and control

This chapter is not applicable to DOP11A-10.

This chapter lists all graphic objects in tables and explains each graphic object. This chapter only applies to terminals that support graphic display.

##### General parameters

###### Colors

Color terminals can display objects and bitmap graphics with 256 colors.

The use of colors allows for creating more realistic objects with 3D effect and shading. Apart from the background and foreground colors for a block, you can select colors for scales, curves, etc. in graphic objects.

The colors for background, text and windows are defined when configuring the terminal. Colors for axes and curves in graphic objects can also be defined.

###### Engineering units scaling

The parameters *offset* and *gain* are used to scale the register value to a display value according to the following equation.

Display value = *Offset* + *gain*\*register value

If you change a value for an object via the terminal, the display value will be scaled according to the following equation:

Register value = (display value-*offset*)/*gain*


The scaling neither affects the defined maximum/minimum values nor the number of decimal places.



The functions for incrementing and decrementing affect the register value for the maneuverable object but not the display value.

###### Calculating technical units

The function [Offset Gain Calculation] serves to calculate the parameters *offset* and *gain*. Enter the values for *offset* and *gain* of the object under the tab [General] and click



on [Calculation]. The following dialog opens:

10591AEN

In this dialog, you define the interval for the controller and terminal value. The function determines the correct values for the *offset* and *gain* parameters.


## Font

10592AEN

Option	Description
Font size	Selecting the [Resizable] checkbox enables you to change the font by highlighting the required text and sizing it using the handles. Selecting the [Fixed] option enables you to choose a fixed size for the text from the drop-down list. If Unicode and [Resizable] are selected, the graphic display will slow down.
3D effect	Here you can specify a 3D effect for the text.
Style	Select whether you want the text with the formattings to appear in italics or underlined. If no option is selected, the font will appear without any special formatting.
Shadow	Here you can define a shadow for the text.



#### Access




10593AEN

Under the [Access], tab you define whether you want the object to be a maneuverable object. Enter the [Minimum input value] and [Maximum input value] for the object (and the access). You can also specify the security level for the object. You define security levels under [Functions] / [Passwords].

#### Dynamics


This section describes the functions on the [Dynamics] tab.

#### Property



10594AEN





Under [Properties], you enter a signal to control a property. You can choose between digital and analog control.

#### 1. Digital

- Select the property from the list you want to have controlled by the controller. The property can only be used once per object / signal. A property being used is marked red. Enter a signal or click on the [I/O] button to select a signal using the I/O browser. You can also specify an [OFF value] and an [ON value]. If you do not specify OFF / ON values, the OFF value is set to 0 and the ON value to 1 by default.

#### 2. Analog

- Select the property you want to have controlled by the controller in the list. The property can only be used once per object / signal. A property being used is marked red. Enter a signal or click on the [I/O] button to select a signal using the I/O browser. You can define a length if the format type is "Character string."



If you select and then deselect analog control for a property that can only accept digital values, then the property will remain set as long as the signal has a value unequal 0.



In order to influence *Offset / gain* in an object, *Offset / gain* must be defined other than 0 / 1 in the object right from the beginning.




The *Visible* property must not be used simultaneously with the *Positions* property.



Dynamic texts are not converted into Unicode format. Instead, a question mark will appear.



#### Size




10595AEN

Under the [Size] tab you can define the values for [Width], [Height] and [Origin]. Define two analog signals where the signal values determine the size of the object in terms of x-coordinate (width) or y-coordinate (height).




If you enter an illegal value, for example a value that does not enable the object to be displayed on the screen, the value will be ignored.

Parameters	Description
Signal	Enter an analog signal.
Value min. width / height	Enter the minimum value of the analog signal.
Value max. width / height	Enter the maximum value of the analog signal.
Min. width / height	Enter the minimum value for the width / height of the object in pixels at which the minimum value corresponds to the defined value.
Max. width / height	Enter the maximum value for the width / height of the object in pixels at which the maximum value corresponds to the defined value.
Origin	Select the original position of the object for display on the screen.



## Move



10596AEN

Under the [Move] tab, enter two analog signals the values of which determine the x (width) and y (height) coordinates of the object.




If you enter an illegal value, for example a value that does not enable the object to be displayed on the screen, the value will be ignored.

Signal	Enter an analog signal.
Value from	Enter the minimum value of the analog signal.
Value to	Enter the maximum value of the analog signal.
From X / Y position	Enter the x and y coordinates of the object, i.e. the pixel value on the screen at which the value of the parameter <i>corresponds with the value of the defined value</i> .
To X / Y-Position	Enter the x and y coordinates of the object, i.e. the pixel value on the screen at which the value of the parameter <i>corresponds with the value of the defined value</i> .




#### Event



10597AEN

Under the [Event] tab you can define the parameters described below. You can update existing events, add new events or delete events by clicking the corresponding buttons in the dialog box.

Parameters	Description	
Event name	Enter a name for the event or select an entry from the list.	
Condition	Select a condition from the list. You can choose between four conditions:	
	Equal to	The event will be triggered after the specified signal where the object value corresponds with the value you have defined in the value checkbox. The value has to be entered by the user.
	Not equal to	The event will be triggered after the specified signal where the object value does NOT correspond with the value you have defined in the value checkbox. The value has to be entered by the user.
	Greater than	The event will be triggered after the specified signal where the object value is greater than the value you have defined in the value checkbox. The value has to be entered by the user.
	Less than	The event will be triggered after the specified signal where the object value is smaller than the value you have defined in the value checkbox. The value has to be entered by the user.
Action	Select one of the following options: <ul style="list-style-type: none"> <li>Digital signal</li> <li>Analog signal</li> <li>Macro</li> </ul>	
Signal	Select the signal that will be influenced if the condition is fulfilled.	
Value	Enter the value for the affected signal if the condition is fulfilled.	



## Graphic objects

### Static / dynamic graphic objects

Static graphic objects are used when creating graphics. Under the [Dynamics] tab you can assign dynamic properties to graphic objects.



Static objects are always placed behind dynamic objects when being displayed.

Icon	Object
	Line
	Curve
	Rectangle, filled, 3D
	Symbol
	Static text
	Ellipsis, filled
	Keypad object
	Polygon line






#### *Dynamic bitmap handling*


For DOP11A-50 only.

If you activate the [Use dynamic bitmaps] checkbox for a static symbol object, the terminal will retrieve the specified bitmap file (namn.bmp) from the [IMAGES] library in the terminal file system. The bitmap graphic is displayed on the terminal screen in run mode. The graphic to be displayed must be transferred to the [IMAGES] library in the terminal via ftp. You can add, exchange or delete dynamic bitmap graphics via ftp. You can overwrite, save or delete BMP files in the [IMAGES] library. The image for a dynamic bitmap graphic object is displayed on the terminal in run mode only. The bitmap graphics in the library are not displayed in the programming software and do not exist there.

#### *Dynamic digital graphic objects*

Digital graphic objects are linked to signals in the controller.

Icon	Object	Description
	Digital text	Changes between two texts depending on the state of the digital signal.
	Digital symbol	Changes between two symbols depending on the state of the digital signal.
	Digital fill	Is used for filling a selected area with one of two colors. The color depends on the state of the digital signal.








*Dynamic analog  
graphic objects*

Analog graphic objects are linked to registers in the controller.

Icon	Object	Description
	Analog numeric	Entry and display of numerical values.
	Bar	Displays a value in the form of a bar diagram.
	Diagram	Is used for drawing an x / y diagram that corresponds to the data register content.
	VU-meter	Creates a graphic Volume-Unit-meter on the screen.
	ASCII	Controls ASCII character strings in graphic blocks.
	Slider	Allows for increasing or decreasing the value for an analog signal.
	Trend	Displays the values retrieved from data registers in the form of a curve.
	Speedometer	Creates a graphic speedometer on the screen.
	Analog fill	Is used for filling a selected area with one of 16 colors. The color depends on the register value.
	Multiple symbol	Shows one of up to eight symbols. The symbol depends on the data register value. Allows for moving symbols on the screen.
	Multiple selection	Is linked to a data register that can have up to eight different states. A text with up to 30 characters can be assigned to each state.
	Message	Object that displays texts from a message library.
	Analog numeric table	Creates a table with numeric objects.




#### Other objects

Icon	Object	Description
	Jump	Jump to another block.
	Alarm banner	Is used to display a line from the alarm list.
	Analog clock	Object to display an analog clock.
	Digital clock	Object to display a digital clock.
	TCP/IP command entry	Object for transferring a TCP/IP command to other units. Only applies for terminals that are connected to a TCP/IP network.

#### Digital text




Text object that is used for changing between two entered texts depending on the state of a digital signal. The text can have up to 30 characters.



10632AEN





### [General] tab

Parameters	Description
Digital signal	Signal of the digital address.
Text Off	Text that is to be displayed when the signal state is 0.
Text On	Text that is to be displayed when the signal state is 1.
Alignment	Specify whether you want the text left-justified or centered.
Border style	Select whether you want the object to appear with a border.
BG	Define a background color for the object.
Text	Define a color for the text in the object.


### Other tabs

The functions on the [Font], [Access] and [Dynamics] tab are explained in the section "General parameters" on page 114.

### Digital symbol



Object that is used to change between two selected symbols depending on the state of the digital signal.



10633AEN

### [General] tab

Parameters	Description
Digital signal	Signal address.
Symbol OFF	Select the symbol you want to have displayed when the signal state is 0.
Symbol ON	Select the symbol you want to have displayed when the signal state is 1.
Resizable	When this option is active, you can change the x or y size of the object.

### Other tabs


The functions on the [Access] and [Dynamics] tab are explained in section "General parameters" on page 114.



#### Digital fill



Object that is used for filling a selected area with any color.



54663AEN



The filling of very irregular areas may lead to system errors during operation. In certain cases, the filling process will slow down the loading time of images.

#### [General] tab


Parameters	Description
Digital signal	Signal of the digital address.
Pattern	Specify whether you want the closed area to be filled throughout or dot-wise when the signal is output. Applicable for DOP11A-30 and DOP11A-60 only.
On	Define the object color for signal value 1.
Off	Define the object color for signal value 0.

#### Other tabs

The functions on the [Access] and [Dynamics] tab are explained in the section "General parameters" on page 114.

#### Object positioning

The program calculates which area will be filled. The object must therefore be positioned correctly. Incorrectly positioned objects may cause application errors during operation. The area to be filled is only limited by static objects and static parts of dynamic objects. Filled objects can be replaced by digital symbol objects or multiple symbol objects to achieve a higher efficiency in a project.



53958AXX

X = Object positioning


Correct: Draw a frame around the text in the area to be filled to speed up image loading.

Incorrect: Image loading is slowed down because the program must perform extensive calculations for filling the area between the letters.

## Jump



Object used for jumping to another object. This object allows for creating a menu tree in the project. You can go back to the previous block (up to nine levels back) by pressing the <PREV> button on the terminal. See chapter 8.10 "Function keys".




10635AEN

Figure 54: Jump to another block

### [General] tab

Parameters	Description
Current block	The number of the current block is displayed in this field. This number cannot be changed.
Jump to block	Enter the number or name of the block you want to jump to.
Text	Enter any text you want to appear in the object.
Positions	Number of positions for the text
Alignment	Specify whether you want the text left-justified, centered or right-justified.
Border style	Select whether you want the object to appear with a border.
Text	Define a color for the text in the object.
BG	Define a background color for the object.



If a jump to a non existing block is initiated during operation, an error message will appear.



#### Other tabs

The functions on the [Font] and [Dynamics] tabs are explained in the section "General parameters" on page 114.

#### Analog numeric

03

Object for entering and displaying numerical values. This object is used, for example, for creating input fields.




10636AEN

#### [General] tab

Parameters	Description
Analog signal	Signal address
Positions	Number of positions for displaying the entered value including comma and minus sign.
Zero fill	Specify whether you want empty positions filled with zeros.
Decimals	Number of decimal places for displaying the entered value.
Engineering units scaling	These fields are used for scaling the register value. See section "General parameters" on page 114.
Border style	Specify whether you want the object to appear with a border.
Alignment	Specify whether you want the input field to be formatted right-justified or centered.
Text	Define a color for the text in the object.
BG	Define a background color for the object.

#### Other tabs


The functions on the [Font], [Access] and [Dynamics] tabs are explained in the section "General parameters" on page 114.



## Bar graph



Object that displays integers or floating point numbers in the form of bar graphs.



10637EN

### [General] tab

Parameters	Description
Analog signal	Signal address
Scale division	Specifies which scale division is used.
Box	Select whether you want to have a box drawn around the graph.
Scale ticks	Specifies the interval between the indicated scale ticks.
Scale	Select whether you want to have a scale displayed on the graph.
Minimum value	Minimum value of the signal.
Maximum value	Maximum value of the signal.
Pattern	Specify whether you want the graph to be filled completely or dot-wise. For DOP11A-20 only.
Direction	Specify whether you want the border to appear on the top, bottom, right, or left.
Border style	Specify whether you want the object to have a border.
Indicators	Here you specify whether the highest or lowest value will be indicated for the signal on the axis. The indicators are reset when starting the terminal. This reset can be performed in run mode by selecting the graph with a mouse click and pressing the Enter key. (Point to the graph if your terminal has a touchscreen.) The indicators support 16-bit characters only.
Engineering units scaling	Is used for scaling the register value. See section "General parameters" on page 114.
Scale	Define a color for the scale in the object.
Fill	Choose a filling color.
BG	Define a background color for the object.



### [Dynamics] tab


The functions on this tab are explained in section "General parameters" on page 114.

### Diagram




Object used for creating an x / y diagram that corresponds to the register content in the controller. This function is a realtime function. As a rule, this object is used for time-independent displays. Time-independent representation with an update cycle of <1 s is possible if the controller performs data acquisition. In the following example, the value in register 0 serves as first x-coordinate and the value in register 10 as first y-coordinate. The number of register pairs is four. The table and figure below illustrate the example.

X-coordinate	Register	Value	Y-coordinate	Register	Value
X0	0	0	Y0	10	11
X1	1	41	Y1	11	40
X2	2	51	Y2	12	85
X3	3	92	Y3	13	62




10638AEN



### [General] tab

Parameter	Description
Scale division	Interval between the scale marks on the y or x axis.
Scale ticks	Interval between the displayed scale ticks on the y or x axis.
Minimum value	Minimum value for the y or x coordinate.
Maximum value	Maximum value for the y or x coordinate.
Border style	Specify whether you want the object to appear with a border.
Grid	Select this checkbox to show the grid in the diagram.
BG	Define a background color for the object.
Scale	Define a color for the scale in the diagram.
Grid	Define a color for the grid in the diagram.

### [Curves] tab



10639AEN

Parameters	Description
Graph name	Enter a name for the respective curve.
X analog signal	Data register that contains the first x-coordinate for the corresponding curve.
Y analog signal	Data register that contains the first y-coordinate for the corresponding curve.
Register pair count	Number of register pairs to be drawn (as points or bar).
Value form	Specify whether you want the diagram to appear as bar or line diagram. In a bar diagram, a bar is drawn for each register pair. In a line diagram, the x / y coordinates are displayed as points connected with a line.
Curve	Define a color for the corresponding curve.
Thickness	Specify the line thickness for the curve.

Only one curve can be defined in the DOP11A-20 terminal. DOP11A-30, DOP11A-40 and DOP11A-50 terminals allow for defining two curves.



#### [Access] tab

For DOP11A-50 only.

Parameters	Description
Current diagram signal	The register value determines which curve is to be processed in run mode.
Current cursor signal	The register value determines which point on the curve will be processed in run mode.
X processing step	Specifies the interval between the steps at which you press the arrow keys in run mode.
Y processing step	Specifies the interval between the steps at which you press the arrow keys in run mode.
Activate user input curves 1-2	Specify which curve will be maneuverable in run mode.


#### [Dynamics] tab

The functions on this tab are explained in section "General parameters" on page 114.

#### VU-meter



Object used for creating a graphic VU-meter on the screen.




10640AEN

#### [General] tab

Parameter	Description
Analog signal	Signal address
Scale division	Indicates the type of scale division used.
Scale ticks	Specifies the interval between the displayed scale ticks.
Minimum value	Minimum signal value.
Maximum value	Maximum signal value.
Border style	Specify whether you want the object to appear with a border.
Engineering units scaling	Is used for scaling the register value. See section "General parameters" on page 114.
Needle	Define a color for the pointer needle in the object.
Scale	Define a color for the scale in the object.
BG	Define a background color for the object.






### [Dynamics] tab

The functions on this tab are explained in section "General parameters" on page 114.

### ASCII



Objects for controlling ASCII character strings in graphic blocks. Texts that are stored in the data register of the CPU can be displayed in ASCII objects. The texts must be available in expanded IBM ASCII format. Entering "SW" in the command line under system signals converts the text from the expanded IBM-ASCII character set (8-bit) into the Swedish ASCII character set (7-bit).



AAAAAAAA

10641AEN

### [General] tab

Parameters	Description
Analog signal	Specify the data register where you want to store the text for the first position.
Positions	Specify the number of positions for the text on the screen.
Alignment	Specify whether you want the text left-justified or centered.
Border style	Specify whether you want the object to appear with a border.
Text	Define a color for the text in the object.
BG	Define a background color for the object.

### Other tabs



The functions on the [Access], [Font] and [Dynamics] tab are described in section "General parameters" on page 114.



#### Slider



Object that displays the value for an analog signal in a slider and allows for increasing and decreasing the value for the analog signal.



10642AEN

#### [General] tab

Parameters	Description
Analog signal	Signal address
Scale division	Specifies which scale division is used.
Scale ticks	Specifies the interval between the displayed scale ticks.
Minimum value	Minimum value of the object.
Maximum value	Maximum value of the object.
Engineering units scaling	These fields are used for scaling the register value. See section "General parameters" on page 114.
Direction	Specify whether you want the object to appear on the top or left.
Border style	Specify whether you want the object to appear with a border.
Scale	Define a color for the scale in the object.
Button	Define a color for the button in the object.
BG	Define a background color for the object.



The file format BCD float without exponent cannot be used for SEW communication drivers.

#### Other tabs

The functions on the [Access] and [Dynamics] tabs are explained in section "General parameters" on page 114.



## Trend



Not applicable for DOP11A-10.

Object that displays values acquired by analog signals.



10643AEN



#### [General] tab

Parameters	Description
Name	Enter a name for the trend object. Each object must be assigned an unambiguous name. The object name must not exceed eight characters. The parameter is mandatory. Not applicable for DOP11A-20.
Sample interval	Time interval between data acquisition. The minimum value is 1 s.
Sample count	Number of values to be stored. The maximum number of values is 65534. Not applicable for DOP11A-20.
Sample full limit	Enter the number of samples where the Sample full signal is to be enabled. Not applicable for DOP11A-20.
Sample full signal	Specify a digital signal that is to be activated when the number of samples under Sample full limit has been reached. Not applicable for DOP11A-20.
Enable sampling signal	Digital signal that, if enabled, starts data acquisition. Acquisition stops when the signal is reset. Parameters need not be specified. Not applicable for DOP11A-20.
Erase samples signal	Define a digital signal that, if enabled, deletes all trend data in the history. Not applicable for DOP11A-20.
Y scale	Specify whether you want the y-scale be hidden, appear left, right, or on both sides.
Minimum value	The minimum value on the y-axis is called from the specified register.
Maximum value	Maximum value on the y-axis that is read from the specified controller register.
Division	Specifies which scale division is used on the y-axis.
Ticks	Specified the interval between the displayed scale ticks.
Time range	Time range to be displayed in the trend diagram.
Division	Specifies which scale division is used on the x-axis.
Ticks	Specifies the interval between the displayed scale ticks.
Border style	Specify whether you want the object to appear with a border.
Grid	Specify whether you want to display a grid in the object.
Scale	Define a color for the scale in the object.
Grid	Choose an appropriate color for the grid.
BG	Define a background color for the object.



### [Curves] tab

10644AEN

Parameter	Description
Analog signal	Analog signals acquired by the object and for which the values are to be displayed. Only 16-bit numbers must be used.
Color	Choose the color for the corresponding curve.
Offset and gain	Is used for scaling the register value. See section "General parameters" on page 114.



Only two curves can be used with the DOP11A-20 model. The DOP11A-20 provides realtime trend only.

### [Dynamics] tab

The functions on this tab are explained in section "General parameters" on page 114.



If you copy a block with trend data, you will have to rename the trend object. Do not use the same name for two trend objects.



## Programming

### Graphic display and control

#### Speedometer



Object for creating a graphic speedometer on the screen.




10645AEN

#### [General] tab

Parameter	Description
Analog signal	Signal address
Scale division	Specifies which scale division is used.
Scale ticks	Specifies the interval between the displayed scale ticks.
Minimum value	Minimum value which the object can display.
Maximum value	Maximum value which the object can display.
Angle	Specifies the angle (work area for the object) within 10-360 degrees.
Engineering units scaling	These fields are used for scaling the register value. See section "General parameters" on page 114.
Border style	Specify whether you want the object to appear with a border.
Needle	Define a color for the pointer needle in the object.
Scale	Define a color for the scale in the object.
BG	Define a background color for the object.
Show bar	Select this checkbox to display an arc around the speed indicator. Enabling this option means the associated configuration options are available.
Indicator	Choose needle, arc or both.
Arc settings	Define minimum and maximum values and the colors for the different ranges.

#### [Dynamics] tab


The functions on this tab are explained in section "General parameters" on page 114.



## Alarm banner



Object used for displaying a line from the alarm list.



10646AEN

### [General] tab

Parameters	Description
List line number	Enter the line number in the alarm list from which you want to retrieve information (1=first line, 2=second line, etc.) when the specified alarm group is shown in the alarm list.
Positions	Number of positions to be displayed.
Alarm group	Specify the alarm group you want to display. The object is shown in the color defined for the alarm group.
Show day of the week	Select whether you want the day of the week to be displayed.
Show date	Select whether you want the date to be displayed.
Show time	Select whether you want the time to be displayed.
Show symbol	Select whether you want alarm symbols to be displayed. See chapter 8.2 "Alarm handling".
Show active alarms only	Specify whether only active alarms are to be displayed. The alarm banner object remains empty if no active alarm was triggered.
Show repeat count	Indicates how often the alarm was repeated. See chapter 8.2 "Alarm handling".
Border style	Specify whether you want the object to appear with a border.
BG	Define a background color for the object.



For acknowledging an alarm in the alarm banner, you have to activate the [Enable acknowledge] checkbox on the [Access] tab.



The foreground color for the alarm text is specified by the color defined for the alarm group.

#### Other tabs

The functions on the [Font], [Access] and [Dynamics] tabs are explained in section "General parameters" on page 114.

See also chapter 8.2 "Alarm handling".

#### Analog fill



54664AEN


Object used for filling a selected area with one of 256 colors. The color depends on the register value. See the table below for the assignment of color and register content.

Parameter	Description
Analog signal	Enter the data register the content of which controls the object color. See the following table.

Register content	Color	Register content	Color
0	Black	8	Gray
1	Blue	9	Light blue
2	Green	10	Light green
3	Cyan	11	Light cyan
4	Red	12	Bright red
5	Magenta	13	Light magenta
6	Yellow	14	Light yellow
7	Light gray	15	White

For limitations and information on object positioning, refer to section "Digital fill" on page 126.






## Analog clock



Time object for displaying an analog clock.



10648AEN

### [General] tab

Parameter	Description
Border style	Specify whether you want the clock to appear with a border.
Seconds	Select whether you want a second hand to be displayed.
BG	Define a background color for the object.
Scale	Define a color for the scale in the object.
Hand	Define a color for the hand in the object.



You have to define a maneuverable date / time object (digital clock) to set the clock in run mode.

### [Dynamics] tab


The functions on this tab are explained in section "General parameters" on page 114.



#### Digital clock



Time object for displaying digital clock, day of the week and date.



10649AEN

#### [General] tab


Parameter	Description
Week day	Select whether you want the week day to be displayed.
Date	Select whether you want the date to be displayed.
Time	Select whether you want the time to be displayed.
Time format	The time can be displayed in 12 or 24 hour time mode.
Border style	Specify whether you want the object to appear with a border.
BG	Choose a background color.
Text	Define a color for the text in the object.



You have to define a maneuverable date / time object (digital clock) to set the clock in run mode.

#### Other tabs


The functions on the [Font], [Access] and [Dynamics] tabs are explained in section "General parameters" on page 114.



### Multiple symbol



Object that can display one of up to eight symbols. The symbol depends on the data register value.



10650AEN

### [General] tab

Parameter	Description
Analog signal	Data register that controls the symbol to be displayed. If the register value is 1, symbol 1 will be displayed, etc.
Symbols 0-7	Select the symbol you want to display. If the register value is 0, symbol 0 will be displayed, etc.
Resizable	The x or y size of the symbol can be changed when this checkbox is selected. The permitted x value for DOP11A-20 is between 0 and 239. The value for DOP11A-40 is between 0 and 319, and for DOP11A-50 between 0 and 639. The permitted y value is 0-63 for DOP11A-20, 0-239 for DOP11A-40 and 0-479 for DOP11A-50.

### [Dynamics] tab


The functions on this tab are explained in section "General parameters" on page 114.



#### Multiple selection



Object that can have several states. The object is linked to a data register that can have up to eight different states. A text with up to 30 characters can be assigned to each state.



10651AEN

#### [General] tab

Parameter	Description
Analog signal	Data register that controls the text to be displayed.
Texts 0-7	Texts to be displayed for the specific object state.
Operator selectable 0-7	Selecting the corresponding checkbox allows for moving the object in run mode from the terminal to this status.
Alignment	Specify whether you want the text left-justified, centered or right-justified.
Border style	Specify whether you want the object to appear with a border.
BG	Define a background color for the object.
Text	Define a color for the text in the object.

#### Other tabs

The functions on the [Font], [Access] and [Dynamics] tabs are explained in section "General Parameters" on page 114.




## Touch key



Only applies to DOP11A-30 and DOP11A-50. See section "Using touchscreen" on page 151 and chapter 8.10 "Function keys".

This object creates a touch-sensitive surface that corresponds to a function key. The object can be used to change the display, control memory cells, etc.



10653AEN

### [General] tab

Parameter	Description
I/O	Signal type influenced by the object. For a description of predefined functions, refer to chapter 8.10 "Function keys".
Event	Indicates how the signal is influenced by the object. The signal is activated via the Settings option when the object is triggered.
Grouped	All signals belonging to a touch key with current group number are reset. The group number is specified under Group no. A group comprises a maximum of eight touch keys.
Dec. Analog	In this field, the analog signal linked to the function key is decreased by the value entered under <i>value</i> .
Momentarily	Here, the signal is activated as long as the touch key is being pressed.
Reset	Here, the signal is reset when the touch key is being pressed.
Set analog	In this field, the analog signal linked to the function key is assigned the value defined under <i>value</i> .
Toggle	The signal is activated and reset in turns when the touch key is being triggered.
Inc. Analog	In this field, the analog signal linked to the function key is increased by the value defined under <i>value</i> .
Jump to block	Jumps to another block when the touch key is pressed. Enter number of name of the block to which you want to make the jump.
Other function	For a description of the function, refer to chapter 8.10 "Function keys".
Macro	Refer to chapter 8.12 "Macros" for a description of this function.
Button style	Select the required button style: circular, rectangular or invisible.
BG	Define a background color for the object.



You can use an invisible touch-sensitive area to define areas that enable jumping between blocks in an overall view (e.g. for a machine). The detailed views are linked to invisible touch-sensitive areas that are positioned at certain parts of the machine. Pressing one of these areas will display the corresponding detailed view.


#### Other tabs

The functions on the [Access] and [Dynamics] tabs are explained in section "General parameters" on page 114.

#### Message



Object that displays texts from a message library.




10654AEN

#### [General] tab

Parameter	Description
Analog signal	Analog signal that controls which text from the selected message library will be displayed.
Library	Select the number of the required message library. You define the number under [Functions] / [Message library].
Positions	Number of places for displaying text; 0=automatic length adjustment.
Alignment	Specify whether you want the text left-justified or centered.
Border style	Specify whether you want the object to appear with a border.
Text	Define a color for the text.
BG	Define a background color for the object.

The required maneuvering range is set on the [Access] tab. An area with a maximum of 64 texts can be maneuvered in run mode. Enter the number for the first and last text in the area.



When using the function for an indexed message library, the number of positions must not be 0, else automatic length adjustment will not work.

For further information, refer to chapter 8.1 "Message library".

### Other tabs


The functions on the [Font], [Access] and [Dynamics] tabs are explained in section "General parameters" on page 114.

### Analog numeric table



Not applicable for DOP11A-20.

Object used for creating a table with analog numeric objects.



10655AEN

### [General] tab

Parameter	Description
Analog signal	The first signal that appears in the table.
X size	Number of table columns
Zero fill	Specify whether you want empty positions to be filled with zeros.
Y size	Number of table rows
Positions	Number of positions for displaying the entered value.
Decimals	Number of decimal places for displaying the entered value.
Alignment	Specify whether you want the input field to be formatted left-justified or centered.
Table border style	Specify whether you want the table to appear with a border.
Item border style	Specify whether you want each table cell to appear with a border.
Text	Define a color for the text in the object.
BG	Define a background color for the object.
Engineering units scaling	These fields are used for scaling the register value. See section "General parameters" on page 114.



The table orientation is specified on the [Access] tab: "horizontal" or "vertical". The table signals are calculated according to the specified orientation.

#### Other tabs

The functions on the [Font], [Access] and [Dynamics] tabs are explained in section "General parameters" on page 114.




Minimum and maximum values are only used when the object is a maneuverable object.

#### TCP/IP command prompt



Window where you can enter a TCP/IP command and send it to terminals and PCs within a TCP/IP network. You can call the previous command during operation by using the up and down arrow keys.




10656AEN

#### [General] tab

Parameter	Description
No. of columns	Window width
No. of rows	Window height
Border style	Specify the border type to be drawn around the window.
Enable accelerator keys	Specify whether you want to enter predefined commands in the window using F1-F4 function keys or 1-4 touch keys.
Accelerator keys	Enter any command you want to appear at the prompt when hitting the corresponding key.
BG	Define a background color for the window.
Text	Define a color for the text in the window.





### Other tabs

The functions on the [Access] and [Dynamics] tabs are explained in section "General parameters" on page 114.

### Commands for TCP/IP command prompt

Command	Description
IPCONFIG	Retrieves and displays the current IP address for the terminal.
PING	Checks whether a value is available.
ROUTE	Serves to display, add and delete routes.
ARP	Serves to display, add and delete IP hardware addresses.

For further information on TCP/IP networks, refer to chapter 9.2 "Network communication".

### Operating graphic blocks


Not applicable for DOP11A-30 and DOP11A-50.

Press the arrow keys to change between maneuverable objects. A selected object is identified by a blinking border.

### Selecting maneu- verable objects

Press the arrow keys to change between maneuverable objects. The object is selected according to the following principle:

The cursor is positioned in the middle of a cross. Pressing the right arrow key selects the first object located in area "A" (see figure). If the system does not find an object in the narrow area on the right side, it will browse area "a". Pressing the down arrow key searches for objects in areas "B" and "b". Press the left arrow key to search in areas "C" and "c". Press the up arrow key to search objects in areas "D" and "d".



53964AXX

x = cursor position



#### *Digital objects*

Digital objects, text objects, symbol objects and filled objects change their state when pressing the Enter key. If the functions for incrementing and decrementing are linked to function keys, the signal linked to the object of these keys will be enabled or reset.

#### *Analog objects*

##### **ASCII objects**

Move the cursor over the object and press the Enter key. Enter the required text and confirm the entry by pressing the Enter key.

##### **Message objects**

Move the cursor over the object and press the Enter key. Doing so opens a selection list with all available states. Select the required state and press the Enter key. This way, you define the analog signal linked to the object.

##### **Multiple selection objects**

Move the cursor over the object and press the Enter key. This opens a selection list with all available states. Select the required state and press the Enter key. This way, you define the analog signal linked to the object.

##### **Numeric objects**

To control a numeric object, enter a value and press the Enter key. If the entered value is too high or too low, the possible minimum or maximum value for the object will be displayed. This information will also be issued if you press the Enter key while the object is maneuverable.


##### **Numeric table objects**

If a table object is highlighted, press the Enter key to select the first table row. You can now move the cursor over the cells using the arrow keys. Change the value of a selected cell and press the Enter key.

##### **Slider objects**

You control the object using the arrow keys by moving the cursor over the object and pressing the Enter key. You can now increase or decrease the value using the arrow keys. Confirm your entry by pressing the Enter key. The value increases or decreases by the number that corresponds to the object setting under scale ticks. Complete the process by pressing the Enter key.

The object can also be controlled using the functions for incrementing and decrementing. The object must be linked to function keys for this purpose. See chapter 8.10 "Function keys".



### Bar objects

To change (reset) the minimum and maximum indicators for a specific value in bar objects, place the cursor on the object and press the Enter key.

In terminals with touchscreen, you reset the minimum and maximum indicators by pointing on the bar.

### Trend objects

Not applicable for DOP11A-20.

Trend curves display trend history data in run mode. Select the required trend object and press the Enter key. A dialog box opens. Select a time interval and date for the data to be displayed. "History" is displayed at the bottom of the dialog. To go back to real-time display, press the Enter key again. The trend data are stored in files. You specify the name when defining the trend object.



10657AXX

### Other objects

#### Digital clock

The digital clock (real-time clock) is set by selecting the object and entering the required time. To complete the process, press the Enter key.



If you use the controller clock, you have to set the time in run mode.

#### Jump objects

Select the required object and press the Enter key.

#### TCP/IP command prompt

TCP/IP commands can be entered in a selected line. To call up the previous command, press the up and down arrow keys.

This paragraph refers only to DOP11A-30 and DOP11A-50.

Terminals with touchscreen do not have a built-in keyboard. Control takes place entirely via the touchscreen. You should always touch only one spot on the touch-sensitive

### Using touch-screen



screen. If you touch two spots at the same time, the spot between the two spots you have touched will be chosen.



When using terminals with touchscreen, objects **CANNOT** be controlled in the text block.



If you touch a non-maneuverable object, the message "Not maneuverable" will appear. If you touch a password protected object, the message "Access denied" will appear.

#### *Digital objects*

Digital objects, text objects, symbol objects and filled objects change their state when you touch them with your finger.

#### *Analog objects*

##### **ASCII objects**

To select an object on the screen, touch it with your finger. This displays an alpha-numeric keyboard on the screen. Enter the required text by touching the keyboard. Complete your entry by pressing the Enter key.

##### **Multiple selection objects**

Touch the object with your finger to open a selection list. To select an object on the screen, touch it with your finger.

##### **Numeric objects**

Touch the object with your finger. The numeric keyboard will be displayed. Enter the required value by touching the keyboard. Complete your entry by pressing the Enter key.

##### **Numeric table objects**


Touch a cell in the table object with your finger. The numeric keyboard will be displayed. Enter the required value by touching the keyboard. Complete your entry by pressing the Enter key.

##### **Slider objects**

Control the object by touching and then dragging the buttons.

##### **Bar graph objects**

Touch the bar to reset the minimum / maximum indicators.



### Trend objects

In run mode, trend curves can display continuously measured values. Touch the object with your finger. This opens a button bar under the trend.

Double arrows	Scroll the trend horizontally by one screen
Single arrows	Scroll the trend horizontally by half a screen
–	Maximizes the trend display
+	Minimizes the trend display
^	Go back to the basic setting

To go back to real-time display, click on the object again.



10658AXX

### Other objects

#### Digital clock

Touch the object with your finger. The numeric keyboard will be displayed. Enter the required time by touching the keyboard. Complete your entry by pressing the Enter key.

#### Jump objects

Touch the object with your finger to perform a jump.


### Alphanumeric keyboard

The alphanumeric keyboard appears, for example, when controlling an ASCII object.




10659AXX



Key	Description
A-Z	These keys are used for entering the required text.
ESC	Hides the keyboard and returns to the previous menu.
←	Deletes one character left to the current position.
CLR	Clears all characters you entered.
DEL	Deletes the character where the cursor is currently positioned.
	Confirms the setting made and hides the keyboard.
@	Is used to type the @ character.
>>	Moves the cursor to the right.
<<	Moves the cursor to the left.
a-z	Toggles between upper and lower case.
0-9	Toggles between letters, numbers, and special characters.
SPC	Opens a drop-down list with special characters.
MAIL	Opens a list with e-mail addresses.

#### Selection lists


Selection lists are displayed in addition to the alphanumeric and numeric keyboards. In certain cases you can use the <LIST> accelerator key for displaying a selection list. Use the arrows in selection list to view the top or bottom list entry. To close the list without selecting any entry, press [CANCEL].



10660AXX

#### Calibrating the touchscreen

The touchscreen must be calibrated once a year. To do so, disconnect the power supply to the terminal. Move the switch on the side or back of the terminal to position 2 and then reconnect the power supply.



## 7.5 Text-based display and control

Text-based display and control are suited for creating different report printouts, such as daily reports, status reports, etc. A report consist of text blocks, which may comprise both static and dynamic text. Refer to section 8.5, "Printing reports" for more information on the structure of a report.

This section gives an overview of text objects in a table followed by a description of each object.



Text-based printouts are not supported when using Unicode.

### General parameters

#### Engineering units scaling

The *offset* and *gain* parameters are used to scale the register value to a display value according to the following formula.

Display value =  $Offset + gain * \text{register value}$

If you alter the value for an object via the terminal in run mode, the display value will be scaled according to the following formula.

Register value =  $(\text{display value} - \text{offset}) / \text{gain}$

The scaling neither affects the defined maximum/minimum values nor the number of decimal places.



The functions for increasing/decreasing values affect the register value for the maneuverable object but not the display value.

#### Calculating technical units

The [Offset/gain calculation] function serves as tool for calculating the parameters *offset* and *gain*. Enter the value for *offset* and *gain* of the object under the tab [General] and



click on [Calculate]. The following dialog opens.

Input		Lower	Upper
Controller value range:		10	3000
Panel value range:		10	3000

Output	
Calculated Offset:	0
Calculated Gain:	1

OK Cancel

10661AEN

Enter the range for the controller and terminal values. The function determines the correct values for the *offset* and *gain* parameters.

#### Access

General | Font | Access | Dynamics

Minimum input value: 10    ☒ Enable operator input

Maximum input value: 3000

Security Level: 0

OK Cancel Apply Help


10662AEN

Under [Access], define whether the object should be maneuverable. Also enter the minimum and maximum input values. You can also specify the security level for the object. You define security levels under [Functions] / [Passwords]. See chapter 8.4 "Passwords".





The [Message] dialog looks as follows:



10663AEN



Specify the [Input range] for the first and last text in the area. An area with a maximum of 64 texts can be maneuvered in run mode.

### Text objects

#### Dynamic text objects

Icon	Object	Description
	Analog numeric	Displays the value in numerical form.
	Date / time	Set date and time.
	Digital text	Toggles between two texts depending on the state of a digital signal.
	Multiple selection	Is linked to a data register that can have up to eight different states. A text with up to 30 characters can be assigned to each state.
	Jump	Jump to another block.
	Bar graph	Displays the value in the form of a bar graph.



Icon	Object	Description
	Text	Controls ASCII character strings.
	Message	Object that displays text from a message library.

### Operating text blocks

A text block consists of rows of text with static and dynamic objects. The dynamic objects indicate the current state of signals to which the objects are linked. Certain dynamic objects can be maneuvered. Their status can be changed in run mode.

To change a maneuverable object, use the arrow keys and move the cursor over the object you want to change. Text blocks can be scrolled vertically but not horizontally.



Objects in text blocks cannot be controlled when using terminals with touchscreen.

### Digital objects

Digital objects are operated by selecting the required object. Press the Enter key to change the object status.

### Analog objects

#### Analog objects and date / time objects


To operate these objects, move the cursor over the required object. Enter the new value. Complete your entry by pressing the Enter key. You can cancel your entry before pressing the Enter key. To cancel your entry, exit the field using the [↑] or [↓] key. The original value will be retained.

#### Text objects

To operate a text object, select it and press the Enter key. This opens an input field. The input field will appear in the first or last line depending on the position of the object on the screen. If the text is longer than the width of your screen, the input field will be scrolled. Press the Enter key to confirm your entry.

#### Message objects

To operate a message object, move the cursor with the arrow keys to the required object and press the Enter key. A selection list with all available states will appear on the screen. Select the required state and press the Enter key. The analog signal linked to the object will be changed.



### Multiple selection objects

To operate a multiple selection object, move the cursor with the arrow keys to the required object and press the Enter key. This displays a selection list with all available states on the screen. Select the required state and press the Enter key. The analog signal linked to the object will be changed.

### Jump objects

Select the required object and press the Enter key.

### Bar objects

You can set the indicators for the minimum and maximum values to the current value for the bar object. To do so, select the object and press the Enter key.

## 7.6 Transferring projects

To make the project available to the terminal, you have to transfer the project from the PC (where it was programmed) to the terminal.

Connect the PC on which the HMI-Builder is installed to the terminal using the PCS11A cable.

### Setting up your terminal

The terminal parameters usually need not be set. The project transfer is controlled by the HMI-Builder. If required, you can set the transfer parameters in the terminal in configuration mode under [Setup] / [Port parameters] / [HMI-Builder].



The communication settings for HMI-Builder and terminal must be identical.




#### Transfer settings

The transfer is controlled by the HMI-Builder. In the HMI-Builder, you can set transfer parameters under [Transfer] / [Project].


10703AEN

Parameter	Description
Percent complete	Progress indicator that displays the upload status in percentage completed.
Byte count (kB)	Indicates how many kB have already been uploaded.
Time elapsed	Indicates how much time has elapsed since the send, receive, or verify functions have been performed.
Status	Indicates the transfer status and the project section that is currently being uploaded, such as settings, individual blocks, alarm groups, individual symbols and function keys.
Info	Displays the specified driver that is loaded to the terminal.
Retries	If problems occur during the upload, the HMI-Builder will reattempt the upload several times before aborting the process.
Terminal version	Displays the current terminal type and version number of the system program after the connection with the terminal is reestablished.
Test project on send	Using this option automatically verifies the project before it will be transferred.
Automatic terminal RUN/TRANSFER switching	If this checkbox is enabled, the terminal will automatically switch to transfer mode. The terminal will return to the previous state after completed transfer.
Check terminal version	If this option is enabled, the system program version of the terminal will be compared with the project version set in the HMI-Builder.
Send complete project	Specify whether you want to send the complete project.



Parameter	Description	
Partial send options	Block	
	All	All blocks will be transferred to the terminal.
	None	No blocks will be transferred to the terminal.
	From To	Specify the block sequence to be transferred to the terminal.
	Alarms	Alarms will be transferred to the terminal.
	Symbols	Symbols will be transferred to the terminal.
	Time channels	Time channels will be transferred to the terminal.
	LEDs	LEDs will be transferred to the terminal.
	Message library	The message library will be transferred to the terminal.
	Setup	The configuration under Setup will be transferred to the terminal.
	Function keys	The function keys will be transferred to the terminal.
	Passwords	The passwords will be transferred to the terminal.
	Data exchange	The data exchange will be transferred to the terminal.
Delete	Trend data	All trend data stored in the terminal will be deleted.
	Recipe data	All recipe data stored in the terminal will be deleted.
Download driver	Never	The driver is never downloaded.
	Always	The driver is always downloaded.
	Automatic	The driver will be downloaded to the terminal if the drivers in the terminal differ from those in the current project or have the same version.
Set terminal clock	The PC clock will be transferred to the terminal.	
Send	Sends the project to the terminal using the defined settings.	
Receive	HMI-Builder loads the project in the terminal. This means the active project in the HMI-Builder will be overwritten. There must be an active project in the HMI-Builder to allow for loading a project from the terminal.	
Verify	Verifies whether the active project in the HMI-Builder is identical with that in the terminal.	
Stop	Clicking this button stops the ongoing loading process.	
Settings	Clicking this button enables you to configure transfer parameters. The transfer values must correspond with the values in the terminal.	

You can call up the communication parameters under [Transfer] / [Comm. settings] or by clicking on the [Settings] button in the [Project Transfer] dialog.




10704AEN

#### Settings in the communication parameters dialog.

Parameter	Description
Use TCP/IP transfer	Specify whether you want to transfer the project using TCP/IP. See section "TCP/IP transfer" on page 163.
Use serial transfer	Specify whether you want to transfer the project using serial transfer. See section "Serial transfer" on page 163.
Use modem transfer	Specify whether you want to transfer the project using the modem. See section "Modem transfer" on page 163.
Port	Select a communication port for the PC.
Baud rate	Specify the baud rate.
Timeout (ms)	Specify the number of milliseconds between two transfer attempts.
Retries	Enter the number of transfer attempts after interrupted transfer.
Speed set manually	Only required for older terminal versions with modem communication. The transfer speed must be set manually to the same value in the terminal and the HMI-Builder. The terminal must be switched to transfer mode manually.
Parity	Select a parity check type.
Data bits	Number of data bits for the transfer. The value must be 8.
Stop bits	Select the number of stop bits used for transfer.



Communication errors may occur if other Windows applications are being run during project transfer. Close all other programs to eliminate this error source.  
Existing links to symbols are taken account of when blocks are being transferred.



### TCP/IP transfer

Not applicable for DOP11A-10.

To transfer a project via TCP/IP, select the [Use TCP/IP transfer] option from the [Transfer] / [Communication parameters] menu. Clicking the [Send] button in the [Project Transfer] dialog opens the following window:

10705AEN

Parameter	Description
Host address	The IP address for the target terminal is entered in this field.
Terminal control port	Specifies the TCP/IP port number for the changeover from RUN to transfer mode. This value usually need not be changed. The default setting is 6001.
Transfer port	Specifies the TCP/IP port number for the transfer (project transfer server). This value usually need not be changed. The default setting is 6000.
User ID	Type the user name that is used when checking the changeover from RUN to transfer mode. The user ID is not required when the terminal is already in transfer mode.
Password	Type the password that is used when checking the changeover from RUN to transfer mode. The password is not required when the terminal is already in transfer mode.
Save password in project	Select this checkbox if you want to save your password and user ID. You will then not be prompted for them anymore.

### Serial transfer

For serial transfer, select the [Use serial transfer] option under [Transfer] / [Comm. settings]. To transfer the project to the terminal, click the [Send] button in the [Project Transfer] dialog.

### Modem transfer

For transfer via modem, select the [Use modem transfer] under [Transfer] / [Comm. settings]. To transfer the project to the terminal, click the [Send] button in the [Project Transfer] dialog.



#### Modem settings

Use the following settings for the modem connected to the operator terminal:

AT &F E0 Q1 &D0 &K0 &W

Use the following settings for the modem connected to the PC:

AT &F &D0 &K0 &W


The modem commands are described in the following table.

Command	Description
AT	Tells the modem that it will receive commands. AT precedes all commands.
&F	Resets the modem to factory defaults.
&E0	Deactivates echo.
Q1	Result codes are not returned.
&D0	Modem ignores DTR.
&K0	No flow control.
&W	Saves settings.




The modem must be set to "autoanswer" to enable transfer.






Communication  
settings

1. Configure the modem.
2. Make the communication settings in the HMI-Builder under [Transfer] / [Comm. settings]. Select [Use modem transfer].



10706AEN

3. Specify a port and set [Baud rate], [Parity] and [Stop bits].
4. Use the program [DOP Tools] / [DOP Modem Connect] to establish the connection.
5. Next, select [Transfer] from the HMI-Builder menu.



10707AEN

6. Select [Automatic terminal RUN/TRANSFER switching].



#### 7.7 Expansion cards for ETHERNET and PROFIBUS-DP

This section does not apply to DOP11A-10.

Operator terminals DOP11A-20 to DOP11A-50 can be equipped with various expansion cards to increase communication options.

PFE11A and PFP11A expansion cards are used for integrating the operator terminals into an ETHERNET network with TCP/IP communication or into a PROFIBUS-DP network. PROFIBUS-DP is an open, vendor independent industrial fieldbus standard for use in numerous applications.

PROFIBUS-DP enables units from different suppliers interconnected in a network to efficiently communicate with each other.

The PFP11A expansion card for PROFIBUS-DP is supplied with a disk (GSD file), which includes the device information on the PROFIBUS configuration of the operator terminal.

#### Settings in the programming software

The DOP series operator terminals from SEW-EURODRIVE come equipped with integrated option card. This means the required settings in the HMI-Builder are factory-set as the corresponding project is already loaded at the factory.

Nevertheless, the required settings in the programming software are described in the following section.

#### PFE11A expansion card for ETHERNET TCP/IP


Settings in the programming software

#### Specifying the option slot

1. Select [Setup] / [Peripherals] from the menu.



10774AEN




2. Assign the matching slot to the option card.

Use the following assignment:

Operator terminal	Option card	Option slot
DOP11A-10	Option not possible	
DOP11A-20	PFE11A	1
DOP11A-20	PFP11A	1
DOP11A-30	PFE11A	1
DOP11A-30	PFP11A	1
DOP11A-40	PFE11A	1
DOP11A-40	PFP11A	1
DOP11A-40	PFE11A and PFP11A	1 (PFE11A)
		2 (PFP11A)
DOP11A-50	PFE11A	1
DOP11A-50	PFP11A	1
DOP11A-50	PFE11A and PFP11A	1 (PFE11A)
		2 (PFP11A)

3. Right-click on the corresponding option slot and select [Properties].




10775AEN



## Programming

### Expansion cards for ETHERNET and PROFIBUS-DP

- Choose the expansion card type, in this case PFE11A.



10776AEN

- Next, click [OK].

### TCP/IP settings

The TCP/IP settings are made under [Peripheral configuration].



10777AEN

Figure 55: Peripheral configuration

- Drag [TCP/IP Connection 1] with the mouse from [Unused functions] to [PFE11A] under [Slot].

The blinking arrows indicate the positions where you can drop the dragged item.

You have to select [TCP/IP Connection 1] before [TCP/IP Connection 2] will be available.



2. Select [TCP/IP Connection 1]. Right-click and select [Properties] to open the dialog for making the TCP/IP network settings.

10778AEN

In the dialog, type the connection and define IP address and subnet mask.

Parameter	Description
Connection name	Type a name for the connection. This parameter is optional.
Host configuration	If [Manual] is selected, the settings specified in the TCP/IP setting dialog will be used. All other options are used when a server assigns one or several TCP/IP parameters to the terminal.
IP address and subnet mask	Enter the network ID for the node. The network connection takes place according to ETHERNET standard. IP addresses in the range of 192.168.1.1 and 192.168.1.254 are recommended for a local network that only consists of terminals.
Gateway	Enter the network unit in the local network that is capable of identifying the other networks in the Internet.
Primary DNS and secondary DNS	Enter the server(s) that include information on part of the DNS database.


3. Finally, click [OK] to confirm your settings.



### ETHERNET connections

The following section gives an example for ETHERNET connections.

#### Connection between several terminals.




54509AXX

Figure 56: Connection between several terminals.


- The maximum distance between terminal and hub is 100 m.
- The maximum number of terminal per hub depends on the number of ports available on the hub.
- The cable is a shielded twisted pair CAT7 cable with RJ45 connectors.

#### TCP/IP settings in the nodes



10779AEN

Figure 57: TCP/IP network connection



### PFP11A expansion card for PROFIBUS-DP

Settings in the programming software

#### Specifying the option slot

1. Choose [Setup] / [Peripherals] from the menu.



10774AEN

2. Assign the matching option slot to the option card.

Use the following assignment:


Operator terminal	Option card	Option slot
DOP11A-10	Option not possible	
DOP11A-20	PFE11A	1
DOP11A-20	PFP11A	1
DOP11A-30	PFE11A	1
DOP11A-30	PFP11A	1
DOP11A-40	PFE11A	1
DOP11A-40	PFP11A	1
DOP11A-40	PFE11A and PFP11A	1 (PFE11A) 2 (PFP11A)
DOP11A-50	PFE11A	1
DOP11A-50	PFP11A	1
DOP11A-50	PFE11A and PFP11A	1 (PFE11A) 2 (PFP11A)



## Programming


### Expansion cards for ETHERNET and PROFIBUS-DP

3. Right-click on the corresponding option slot and select [Properties].




10775AEN

4. Choose the expansion card type, in this case PFP11A.  
Next, click [OK].



10781AEN


5. Open the [Settings] dialog to define the [Input/Output area size] for the PROFIBUS-DP configuration.




10782AEN

The default value is 32 bytes. If you change the setting, you have to restart the terminal after completed transfer of the project. Briefly disconnect the power supply to the terminal for this purpose. The new setting will now become effective.





6. Click [OK] to confirm your settings.
7. Drag the controller that acts as PROFIBUS-DP master (controller 1 or controller 2) from [Unused functions] to the option slot with the installed expansion card.



10783AEN

8. Complete the configuration of the [PFP11A] expansion card by closing the [Peripheral configuration] window.



### 7.8 Index addressing

Without index addressing, an object is always linked to the same register (IPOS variable or parameter number). Consequently, only the value of this register can be displayed in the object.


Index addressing enables you to choose in run mode from which register you want the object to read the display value. For this purpose, the value in the index register can be added to the address for the register that displays an analog signal in the object. The following basically applies:

**Display value = Register content (object address + index register content)**

If the index register content is 2 and the address of the register specified in the object is 100, the value displayed in the object will be retrieved from register 102. If the value in the index register is changed to 3, the value for the object will be retrieved from register 103 instead.

The index register is defined in the individual projects. This setting can be made under [Setup] / [Index register]. Up to eight index registers can be used in each project. Each index register can be used for more than one object.




The objects used in the project specify whether index addressing is used and which register acts as index register. In the object dialog, select I1 to I8 for the object next to the specified analog signal.



10448AEN

The following example shows how to control three motors from one block. The motor parameters for torque and speed are stored in six different registers. One of the motors is selected in a block. The current torque and speed for the selected motor are displayed in the block. When selecting another motor, the current torque and speed of the other motor should be displayed instead. Index addressing is used for this purpose.




Motor 1	Motor 2	Motor 3
		
Torque in register D101 Speed in register D201	Torque in register D102 Speed in register D202	Torque in register D103 Speed in register D203

Register D0 is defined as [Index register 1] under [Setup] / [Index registers]. The value in the register controls for which motor torque and speed will be displayed.


10449AEN

If the value in D0 is 1, then torque and speed of motor 1 are to be displayed. If the value is 2 or 3, then the parameters for motor 2 or 3 are to be displayed. The value in register D0 is controlled by a multiple selection object in which the texts motor 1, motor 2, and motor 3 appear. In addition, these three options are created as being maneuverable.




10450AEN

Torque and speed are displayed in the form of two numeric objects. In the object for the torque, "D100" is defined as analog signal and "I1" as index register.



10451AEN

In the object for the speed, D200 is defined as analog signal and I1 as index register. The maneuverable multiple selection object allows for calling up the motor 1, motor 2, and motor options in run mode. The values 1, 2 or 3 are stored in register D0 depending on what you have selected. The value in register D0 is added to the addresses of the objects that display torque and speed. Consequently, the object can display the values of register D101, D102 or D103, or register D201, D202 or D203.




- [1] Multiple selection objects - analog signal D0
- [2] Numeric object - analog signal D100, index register D0
- [3] Numeric object - analog signal D200, index register D0



Other suffixes can be specified in addition to index registers. The index register is not counted twice when using 32-bit registers.



If you connect the terminal to a BDTP network, you have to specify the same index register both in the server and the client because indexing takes place in the server driver.



## 8 Unit Functions

### 8.1 Message library

The [Message library] function enables you to create text tables where values between 0 and 65535 are linked with texts. The [Message library] function is used among others to display each sequence in a sequence control. The function can also be used to display error codes. An analog signal creates error codes that are linked with texts in a text block. The function is also used for assigning specific values to analog signals depending on the selected text.

The message library consists of one or several text tables with up to 512 text character strings. Each text string can have up to 40 characters. Activate this option under [Functions] / [Message library].


Parameter	Description
Library	Specify a number for the message library.
Name	Define a name for the message library.

You can edit a message library by selecting the library and clicking [Edit]. Several edit windows can be opened at the same time.


Parameter	Description
Text no.	Enter a number for the text (0 - 65535).
Text	Any text that is called once the current signal shows the text number for the text.

#### Example

Below a simple example to explain the function. Each sequence step in our sequence control is displayed by a text.



- [1] The object is placed onto the conveyor belt.
- [2] Mount tool X
- [3] Mount tool Y
- [4] Remove object from the conveyor belt



Begin by creating a message library with the name "Maskin2."

1. Select [Functions] / [Message library] from the menu.
2. Assign a number (in this case "2") and a name ("Maskin2") to the library.
3. Click on [Add].

You have now created a message library with the name "Maskin2." Next, you have to define the various texts in the library.

4. Select the library and click [Edit].

Define the text number and text in this dialog. The text number represents the value for the analog signal linked to the message object. The text that will appear in the message object is displayed under Text.

After having completed the message library, you have to create a message object in the application. You can create the library message in the text block or in the graphic block.

5. To do so, select the [Message] object from the toolbox. Move the pointer to the position where you want to place the object and make a mouse click.
6. Define the analog signal that controls the text display.
7. In the [Library] field, you can select the message library from which the text is to be retrieved.
8. Select whether the object should be maneuverable and between which texts it has to be able to toggle during operation.



## 8.2 Alarm handling

This chapter is not applicable to DOP11A-10.

The [alarm handling] function alerts the operator to incidents in the process that require immediate action.

Function	Description
Alarm groups	Alarms can be divided into groups, for example to categorize them according to their severity levels.
Alarm message	This function defines which signal will trigger an alarm and which text will be displayed when the signal is activated.
Alarm list	Lists alarms that occurred during operation.



Text-based printouts are not supported when using Unicode.

### Alarm grouping

Alarms can be divided into several groups in the terminal depending on the terminal type in use.

You can assign different color attributes to each group (DOP11A-30 to DOP11A-50). Alarms can be sorted by groups in the alarm block. Alarm groups need not be defined.


Terminal	Number of alarm groups
DOP11A-20	4
DOP11A-30	3 ... 5 (depending on the selected font size)
DOP11A-40	16
DOP11A-50	7 ... 11 (depending on the selected font size)

### Defining alarm groups

You define alarm groups [Functions] / [Alarm groups]. The properties of the alarm group are defined in following dialog.

Parameter	Description	
Group name	User defined name for the alarm group	
Summary notify	Active	Digital signal that is output by the terminal when the print process has been completed.
	Unacknowledged	Digital signal that is activated if alarms in the group have not been acknowledged.
	Remote acknowledge	Digital signal that, if enabled, acknowledges all alarms in the group at the same time.
Colors	Define the colors for active, acknowledged and inactive alarms as well as for alarms in normal state. For DOP11A-30 to DOP11A-50 only.	



**Alarm message**

Alarm messages are defined under [Functions] / [Alarms]. Enter your alarm message in this dialog.

**Maximum length of the alarm message**

Terminal	Maximum length of the alarm message
DOP11A-20	38 characters
DOP11A-30	38 characters
DOP11A-40	38 characters
DOP11A-50	78 characters

The smaller you choose the font in the alarm list the more characters will be displayed. The message may contain digital or analog dynamic data (like a text block). The alarm text can display data from analog numerical objects and digital text. If you move the cursor to the alarm text input field, the toolbox will appear and you can add an object.

You can define 300 alarms depending on the application.

Parameter	Description
Alarm text	Any alarm text (may also include certain dynamic objects).
Signal	Specifies the signal (digital or analog) that triggers the alarm when it changes to the defined state.
Alarm if	Digital signal is
	On/Off      Select [On] if an alarm is to be issued when the signal is enabled. Select [Off] if an alarm is to be issued when the signal is disabled.
	Analog signal is
	Equal to      An alarm will be issued if the value of the specified analog signal equals the value entered in the following field.
	Not equal to      An alarm will be issued if the value of the specified analog signal does not equal the value entered in the following field.
	Less than      An alarm will be issued if the value of the specified analog signal is smaller than the value entered in the following field.
Greater than	An alarm will be issued if the value of the specified analog signal is greater than the value entered in the following field.
Acknowledge notify	Digital signal which is influenced when acknowledging the alarm. The signal is enabled by default.
Reset	Selecting the [Reset] checkbox disables above mentioned signal when acknowledging an alarm.
Remote acknowledgement	Digital signal which acknowledges the alarm if enabled.
Alarm group	Specifies the alarm group for the definition (alarm).
Info block	A block number or a block name for a text or graphic block is entered in this field. This way, the operator is provided with help information with details on the alarm and possible remedial measures. If no entries are made in the field, no block will be linked with an alarm. If the info block is a text block it will be sent as attachment when the alarm is sent as e-mail. See section "Alarms in run mode" on page 184.
Mail to address	Alarms can be sent as e-mail to a predefined recipient. This mail contains the alarm text. See section "Alarm settings" on page 184.
Ack. required	Indicates whether the alarm needs to be acknowledged or not. The alarm must be acknowledged when the checkbox is activated. If the checkbox is deactivated, the alarm will only serve as event alarm which means as information.
History	Indicates when the alarm should be deleted from the alarm list. An activated checkbox means the alarm remains in the alarm list until the list is full. A deactivated checkbox indicates that the alarm will be deleted from the alarm list once it has been acknowledged. The alarm will then no longer be active. If the <i>Ack. required</i> parameter is not selected, the alarm will be deleted from the list once it is no longer active.



Parameter	Description
To printer	This parameter defines whether the alarm message will be output directly to the printer when the alarm status changes.
Repeat count	If the checkbox is activated, a counter for the alarm in the alarm list will be displayed. The counter is incremented each time an alarm is triggered. The alarm must be acknowledged to enable the alarm to appear in the list as new alarm message.
Import	See section "Alarm import" on page 183.



The value defined for an analog alarm signal cannot be controlled via register. Hysteresis is not supported. Only 16-bit values are supported.

### Alarm settings

General settings for alarms and the alarm list are made under the menu item [Setup] / [Alarm settings]. The space required by alarms in the alarm lists depends on the length of the alarm text and the number of objects. The space required by an alarm can be calculated using the following formula.

$$S = 42 + NC$$

S = Number of bytes


NC = Number of characters in the alarm text

The alarm list will be rewritten when it is full. 25% are deleted from the list when it is rewritten. This means 75% of the previous content will be retained.

#### Example:

The length of the alarm text is 38 characters. This means each alarm requires 80 bytes in the alarm list. The result is 1024 (list size=1 kB)/80 => maximal 12 alarms in the alarm list. When the 13th alarm is issued, the alarm list will be rewritten and only includes the last nine alarms.

Parameter	Description
Active signal	Indicates the digital signal that will be issued by the terminal if the alarm is active.
Unack. signal	Indicates the digital signal that will be issued by the terminal when the alarm is not acknowledged.
List erase signal	Indicates the activated digital signal that deletes deactivated alarms from the alarm list.
Reset	Means that the list erase signal is deactivated when the alarm list is cleared.
List size (kilobytes)	Provides the list size in kB for DOP11A-20 to DOP11A-50 Note: If the system assigns the same amount of memory as is indicated for the list size, the list size will double. If the list size exceeds 10 kB, the performance of the project will be influenced negatively.
Enable alarm signal	Digital signal that, if enabled invokes alarm handling in the terminal. This parameter allows to activate or deactivate alarm handling in the terminal. Do not use this parameter if you want alarm handling to be active permanently.
Default font size	Specifies the preset font size for the alarm list. The standard font size in the alarm list is always displayed after a start or restart and when switching between operating modes.



Parameter	Description	
Alarm symbol	Specifies when the alarm symbol is to be displayed. In the text block, "ALARM" will be displayed and in the graphic block a clock in the top right corner of the screen.	
	No	The alarm symbol is never displayed.
	Unacknowledged	The alarm symbol is displayed when the alarm list includes unacknowledged alarms.
	Active	The alarm symbol is displayed when the alarm list includes active alarms.
	All	The alarm symbol is displayed when the alarm list includes active or unacknowledged alarms.
Send e-mail	Specifies when alarms are to be sent as e-mail.	
	Always	An alarm is always sent as e-mail when its status changes.
	Active	An alarm is sent as e-mail when it is activated.
	Inactive	An alarm is sent as e-mail when it is deactivated.
	Acknowledge	An alarm is sent as e-mail when it is acknowledged.
Backlight	Informs when the background lighting should be switched on if an alarm is issued.	
	On	Means that the lighting is to be switched on when the alarm symbol is displayed (default setting).
	Off	The background lighting is not affected by the alarm.
	Timer	The lighting is switched on when a new alarm is activated. The lighting is switched off when the screen saver time has elapsed.
Alarm cursor	DOP11A-30 to DOP11A-50 terminals allow for changing the cursor color in the alarm list.	

### Alarm import


Alarm texts can be imported from name lists created with the programming tools for the controller. Before importing alarms, the project in HMI-Builder must be linked to a name list. Select the corresponding name file under [View] / [Name list]. Next, call [Functions] / [Alarms] and click on the Import button to define the settings.

### Start I/O

Enter the address for the start I/O when importing alarms from the name file. The signal can be analog or digital.

### End I/O

Enter the address for the end I/O when importing alarms from the name file. The signal can be an analog or digital signal. However, the signal type must be identical with that for the start I/O.



#### Alarm settings

All alarms (start I/O to end I/O) that are imported by clicking the Import button will have the settings you have specified under Alarm settings in the Alarm Import dialog. For a description of the individual parameters, refer to section "Alarm message" on page 181.

You have to specify the parameters, signal type, analog or digital, and the alarm group before importing the alarm.

#### Alarms in run mode

In the text block, an alarm is signaled by "ALARM" appearing in the top right corner of the screen. In the graphic block, an alarm is signaled by a blinking clock in the top right corner of the screen. You can disable alarm signaling in configuration mode or in the programming software under [Setup] / [Alarm settings].

Alarms are displayed in an alarm list with predefined alarm texts. The alarm list includes the last triggered alarms and is sorted by the defined alarm groups. The alarm triggered last is displayed first in the list. You can define the alarm list size in kB in configuration mode under [Setup] / [Alarm settings] in HMI-Builder. Jumping to the alarm block (system block no. 990) will display the alarm list.

The following information is displayed in the selected display format for each alarm:

- Number of times the alarms were triggered (if selected)
- Alarm status
- Time when the alarm was triggered
- Deactivation
- Acknowledgement

The repeat counter in the alarm list (if enabled) is displayed as follows:

Display format	Description
(12)	Means the alarm was issued twelve times. The alarm must be acknowledged to enable the alarm to appear in the list as new alarm message.
>999)	Means the alarm was issued more than 999 times without having been acknowledged. The counter counts up to maximum 999 values.

An alarm can have one of the following states:

Symbol	Status
*	Active, not acknowledged
\$	Not active, not acknowledged
–	Active, acknowledged
<empty>	Not active, acknowledged



Alarm times can be displayed in the following formats:

Display format	Description
S	Time when the alarm was activated. If alarms occur repeatedly, the time when the alarm was activated first will be displayed.
E	Time when the alarm became inactive. If alarms occur repeatedly, the time when the alarm was deactivated last will be displayed.
A	Time when the alarm was acknowledged.

To go to the alarm block, either define a jump to system block 990 in a block, press <LIST> or have the controller retrieve the list for block 990 via the display signal.

To acknowledge an alarm, move the cursor over the corresponding line in the list and press <ACK>, point to the symbol ✓ or confirm using a function key.

If a printer is connected, the alarm can directly be output by the printer depending on the sequence or status change. This is specified when defining alarms.

The alarm is printed with the following information:

- Frequency of occurrence
- Date
- Time
- Status
- Alarm text

To return to the previous block, press <PREV> on the terminal or <ESC> on the touch-screen.

Output of the print signal for block 990 allows for printing the respective alarm list contents.

#### *Linking blocks with alarms*

Text or graphic blocks can be linked with alarms. To display the block linked with the alarm, press <INFO> for an alarm in the alarm list. This block may contain information on the alarm and corresponding recommendations for measures. The <INFO> key can only be activated when the corresponding alarm is linked with a block. To return to the alarm list, press <PREV>.



#### **Graphic alarm page in run mode**

The page is displayed graphically and can be edited by the user. You can assign functions to function keys or touch keys to maximize or minimize alarm page text and to browse through the pages. You can also select date and time as function. Alarms can be sorted by groups and the required group can be displayed.

The status is indicated by different colors that are defined when setting the alarm group. With models DOP11A-20 and DOP11A-40, you select the alarm group using the left and right arrow keys.



The graphic alarm page (alarm list) is printed in text form.

### **8.3 Recipe management**


The [Recipe management] function allows for saving all dynamic data of one or several blocks (i.e. signals and their values) in a file in run mode.

The operator can transfer the file to the controller where the load values are further processed. You can reuse comprehensive parameter configurations with the help of the recipe management function. Users can set up a recipe directory with files offering different parameter settings. This function makes for an efficient design of production runs with tight schedules that require a fast product change, such as in the production of identical products in different colors.

The recipe files can be created on a terminal, controller or PC using the DOP tools software.

The recipe files are stored in the terminal. To use the recipe handling function, the functions for saving, loading, deleting and adding recipes have to be linked with function or touch keys. See chapter 8.10 "Function keys".

You can send recipe files as attachments from terminals with e-mail function.



### **Calculating the recipe size**

The following formula is used for determining the recipe size in the project memory. (The formula does not always provide exact results due to the complexity of the file system).

$$S = 90 + ?(IOGi + 28)$$

S = Number of bytes. If the calculated value S is smaller than 360, the value 360 must be assumed for S.

? = Number of I/O series

IOGi = Number of I/Os in each I/O series

### **Example**

Our recipe consists of three I/O series H0-H109 (=110 double words) and H200-H299 (=100 double words).

This results in the following calculation:

Calculating the various series sums:

$$896 = (4 * 110 + 28) + (4 * 100 + 28)$$

This results in the following sum:

$$S = 90 + 896$$

$$S = 986 \text{ bytes}$$

### **Recipe settings and recipe directories**

Under [Setup] / [Recipe settings], you define the settings for recipe handling and create, edit and delete recipe directories.

#### **Recipe control block**

Control block for saving, reading, and deleting recipes via controller.

See section "Creating and transferring recipes using the controller program" on page 190.


#### **Current recipe register**

Enter the first of four 16-bit registers where the terminal stores the name of the recipe that was last loaded to the controller. This name can then be represented as ASCII object. The function occupies all four registers (8 characters) disregarding the length of the recipe name.

#### **Enable directories**

Selecting this option enables you to create recipe directories in the terminal.

See section "Recipe directory" on page 188.



## Unit Functions

### Recipe management

#### *Current directory register*

Enter the first of four 16-bit registers where the terminal stores the name of the recipe directory that was specified for the block. This name can then be represented as ASCII object. The function occupies all four registers (8 characters) disregarding the length of the recipe directory.

#### *Recipe directory*

Recipes created in the terminal can be stored in various recipe directories (folders) in the terminal memory.

Using recipe directories allows for a clear structure and easier recipe handling in applications with many recipes.

You can create 32 different recipe directories (or eight with DOP11A-10) in one level. Recipe directories are created in the recipe library [RECIPE] in the root library of the terminal memory. A recipe directory is linked with one or several blocks in the block header of a block. All recipes created in a block are stored in the selected recipe directory.

You can create, edit, and delete a recipe directory in HMI-Builder under [Setup] / [Recipe settings]. Defined recipe directories are displayed in a list that corresponds to the library structure. You can add a new recipe directory by clicking the [Add directory] button. The name of a recipe directory can have up to eight characters. The first character must be a letter or a number. Permitted characters for the name are A-Z, 0-9 and \_ (underscore). The same file name conventions apply as for MS-DOS.

To make modifications to a recipe directory, select it and click [Edit]. Clicking [Delete] deletes the selected recipe directory.

#### *Recipe directories in run mode*

You can create and delete recipe directories in run mode using the [Create recipe directory] and [Delete recipe directory] functions. The functions are linked with function keys or touch keys.


You can modify and select recipe directories for the current block in run mode using the [Change recipe settings] function for function keys or touch keys. Pressing the function key or touch key for [Change recipe directory] opens a pick-list with available recipe directories. Select a file and press the Enter key. The recipes in the block are then stored in the selected recipe directory. See chapter 8.10 Function keys".



Recipe directories created in HMI-Builder cannot be deleted using the function or touch key linked with the [Delete recipe directory] function. Recipe directories created in the terminal are not included in the terminal project when a project is transferred from the terminal to HMI-Builder (via receive function in the [Project transfer] dialog).

Recipe handling between terminal and PC takes place using the applications [DOP Tools] / [DOP File Transfer] and [DOP Tools] / [DOP FTP Transfer]. See section "Using recipes in the PC" on page 190.





### ***Creating recipes on the terminal***

The block(s) used for storing the recipe is (are) defined when programming the application. The [Append recipe] function is also available in run mode. All signals to be included in the recipe are defined in the recipe block. All dynamic values of the block are saved in a recipe file. Apart from trend objects, you can use all digital and analog objects as recipe parameters.

In run mode, a jump is performed to the block containing the recipe parameters. Enter the required values in the dynamic objects and press the function or touch key that is linked with [Save recipe]. The name can have up to eight characters. The first character must be a letter or a number. Permitted characters for the name are A-Z, 0-9 and \_ (underscore). The same file name conventions apply as for MS-DOS.

The recipe file is stored in the terminal; either in the recipe directory specified for the block or in the same recipe directory unless you have created specific recipe directories under [Setup] / [Recipe settings].

### ***Append recipe***

You can link the [Append recipe] function with function or touch keys. This function allows for adding signals and the associated values of the current block to an existing recipe in run mode. This way, you can store signals and the associated values of different blocks in a common recipe. New signals are added when doing so. Already existing signals are updated when the function is executed.

When pressing the function or touch key for [Append recipe], you have to specify the name of the recipe to which you want to add the current block signals and the associated values. If no recipe is stored in the terminal when the function is executed, a new recipe will be created in the terminal. A new recipe will also be created if you do not have specified the same recipe directory for the blocks.

The same or no recipe directory must be specified to add signals from another block to a recipe.



If a new character string is added to an already existing recipe with character strings, you have to separate the character strings using address separators. Else, the already existing character string will be expanded by the new one.

### ***Transferring recipes to the controller***

In run mode, the recipe is transferred to the controller using the [Load recipe] function. This function transfers the signals and values saved in the files to the controller. Pressing the function or touch key for [Load recipe] opens a pick-list with available recipe files. Select a file and press the Enter key. The controller now runs with the loaded values.



## Unit Functions

### Recipe management

---

#### **Delete recipe**

In run mode, the specified recipe can be deleted from the terminal memory using the [Delete recipe] function. Press the function or touch key linked with [Delete recipe]. Doing so opens a selection list with available recipe files. Select the file you want to delete and press the Enter key. To confirm that you want to delete the file, press Enter. To cancel the action, press <PREV>.

#### **Use recipes in the PC**

The [DOP Tools File Transfer] program (icon in the DOP Tools program group) installed on your PC makes for addressing the terminal like a PC drive. This means the PC can be used for creating backup copies of terminal files (e.g. recipe files). This way, new recipes can be created in the PC and transferred to the terminal.

The recipe file is saved in SKV format on the PC and can be called up in Excel. The files can be edited in Excel and can then be used again in the plant. Complete the file with the "END" command.

#### **Example**

```
P100;3  
P102;0  
H50;12  
END
```

You can also transfer recipe files between terminal and PC via FTP. Use the [DOP Tools] / [DOP FTP Transfer] (Standard FTP Client) program for this purpose.




There are restrictions for recipes in SKV format when using Unicode. For further information, refer to chapter 8.8 "Unicode".

#### **Creating and transferring recipes using the controller program**

Recipe data can be created, transferred and deleted via a control block in the controller. The files created with the controller program are compatible with the recipe files of the terminal. Consequently, the terminal can receive files created by the controller program and vice versa.




The control block looks as follows:



54249AEN

You can define the first register in the control block under [Setup] / [Recipe settings]. This register as well as the seven subsequent registers are used as control registers. The control block is described in the following table.

Register	Content	Description
Ctrl. reg. 0	Command	The command register is defined by the controller. Available commands: 0. No command 1. Save recipe in the terminal 2. Recipe received by terminal 3. Delete recipe in the terminal 4. Create recipe directory 5. Change recipe directory 6. Delete recipe directory
Ctrl. reg. 1	Result code	Handshake register defined by the terminal 0. Ready for new command 1. OK 2. Write error in the recipe file 3. Recipe file does not exist.
Ctrl. reg. 2	File name characters 1-2	Name of the recipe file or recipe directory in the terminal.
Ctrl. reg. 3	File name characters 3-4	
Ctrl. reg. 4	File name characters 5-7	
Ctrl. reg. 5	File name characters 7-8	
Ctrl. reg. 6	Start data register	First data register that is loaded from the recipe file or is to be saved in the recipe file.
Ctrl. reg. 7	Number of registers	Number of registers to be loaded from the recipe file or to be saved in the recipe file.



Management takes place as follows:

1. The result code register must be 0. If not, check whether the command register is set to 0.
2. Save the command in the command register.
3. Wait for the ready signal or the error code in the result code register.
4. Set the command register to 0. The terminal will then set the result register to 0.



Recipe directories that were created in the HMI-Builder programming software cannot be deleted in run mode.

#### *Limitations*

Recipes created in the controller can contain a maximum of 1000 registers.

Only data registers can be used.

The following characters are not permitted in recipe names:

! ? < > ( ) + / \* = ° % # : . [space characters], and -

## 8.4 Passwords

This function can be used to create a security system for the machine. Operators can be assigned user-specific authorizations for the system.

A security level can be assigned to the following objects:

- Blocks
- Function keys
- Touch keys
- Maneuverable objects

Each security level is protected by a password. To gain access to the individual levels, the user must register with a password for the current level or a higher security level. This function is optional.

#### **Defining security levels**

When the input is activated you define a security level (0-8) in the dialog for the relevant object via the [Access] tab. Security level 0 means all users can access the object. In this case, you will not be prompted for a password.

**Defining  
passwords**

The passwords for security levels 1-8 are defined under [Functions] / [Passwords].

Parameter	Description
Password 1-8	Enter the password for security levels 1-8.
Confirm question 1-8	Enter a security question with a maximum of 20 characters that is to be answered by the user before being able to access an object with a certain security level. This function is not available if you have defined a security level for a function or touch key.
Comment 1-8	Enter a comment or description for the password or security level. This parameter is optional.
Login signal	This parameter specifies the digital signal that creates an input field for login when enabled. You can also link the login input field with a function or touch key.
Logout signal	This parameter specifies a digital signal that logs out the current user when enabled. This function can also be linked with a function or touch key. See chapter 8.10 "Function keys".
Login level reg.	Here you can specify a register in the controller that controls the security level. The register controls the security level for all objects to which a security level (password) has been assigned. The register value determines the current security level: Value 0 = no security level, 1 = security level 1, etc.
Current level reg.	This parameter specifies a register from which the terminal can retrieve data for displaying the corresponding security level (0-8).
Login timeout	This parameter specifies the amount of idle time for a terminal in minutes after which a user is automatically logged out. Entering 0 deactivates logout.
Password RUN / PROG.	Here you can enter a password that is mandatory when changing manually from RUN to PROG mode. This function does not apply when changing from PROG to RUN mode or when using automatic terminal changeover from RUN/TRANSFER mode in HMI-Builder.
Automatic login	This parameter specifies whether the login screen opens automatically when password-protected blocks, objects or keys are accessed. This function only applies to terminals with touchscreen as well as to function keys on all other terminals because the cursor cannot be positioned on password-protected objects without already being logged in with security level access corresponding to the object.

**Login**


If the [Automatic login] checkbox under [Functions] / [Passwords] has not been activated, log in takes place either via function or touch key, or via a digital signal from the controller (login signal). The login input field opens when pressing the function key that is linked with the [Login] function on the defined security level, or by activating the digital signal. The password is entered in this field. The password is linked with a security level. See section "Defining security levels" on page 192.

**Passwords for  
project transfer**

In the command line under [Setup] / [System signals], you can enter the command "PDxxxxxxx". This command prompts for a password (xxxxxxx) to allow the user gain access to the functions in the terminal menu [Transfer]. This password must be entered in the terminal when transferring a project from HMI-Builder to the terminal.

**Multi-access  
password**

In the command line under [Setup] / [System signals], you can enter the command "PSxxxxxxx". This password (xxxxxxx) grants access to all terminal functions. This command is used, for example, for support and maintenance purposes. Only capital letters can be entered in the command line.



#### **Changing passwords during operation**

The [Change login password] function allows for changing passwords for function or touch keys during operation. Pressing the function or touch key linked with [Change login password] opens a dialog where you can change the password for the relevant security level. See chapter 8.10 "Function keys".



No security level can be entered for block [0].



After logoff, the <PREV> key and the [Return to previous block] function are disabled for function and touch keys to prevent unauthorized users from accessing password-protected blocks.

## 8.5 Printing reports

Various reports (such as daily reports or event reports) can be easily created for tracking the production process.

#### **Printer connection**

The printer should have a serial interface and an IBM character set (850).


The printer settings are made in the dialog under under [Setup] / [Peripherals]. For information on the printer configuration, refer to the printer manual.

Example for possible printers:

Serial printer = Panasonic KX-P1092

#### **Printing projects**

To print a project, select [File] / [Print] from the menu. Select the corresponding checkboxes to define which parts of the project will be printed. Click [Setup] to configure the printer. Click [Preview] to open a print preview.

**Printing text blocks**

Reports are created as text block with static and dynamic text. The maximum width of the report is 150 characters. You can enter any text in the text block, for example the table header or another static text, that is always to be printed. To output process values, dynamic objects have to be defined that represent the value for the signal with which the object is linked.

The time when the report is to be printed can be defined, for example, via time channels.



The printing of text blocks is not possible with Unicode.

**Printing graphic blocks**

With DOP11A-20, DOP11A-30, DOP11A-40 and DOP11A-50, graphic blocks can be output on a printer that is compatible with Epson FX-80.

Graphic blocks can only be printed when they are displayed on the screen. Only black and white graphic display is supported.

Entering the command "NHD" in the command line under [Setup] / [System signals] has the laser printer print the graphic block without block header (contains the normal block name, block number, date and time).



Epson FX-80 graphic does not support grayscale.



The printer buffer must have a size of at least 5 MB to print graphic blocks.



The alarm block, i.e. the graphic block with the alarm list, is printed in text form.



Pressing the <PREV> key on the terminal when a graphic block is being printed cancels printing.



#### Defining printouts

Printouts are defined in the block header. You access the block header via the block manager or the block list. The *Print signal* parameter in the block header specifies the digital signal that triggers printing for the block when activated. This parameter also specifies the digital end signal that is activated by the terminal when printing is finished. Selecting the [Reset] option resets the signal.

#### Printer settings

You make the printer settings under [Setup] / [Peripherals] / [Printer] / [Edit]. You will find detailed information in the manual on the corresponding printer. The printer must support the expanded IMB-ASCII character set.

For printing the graphic block, the printer must support the graphic for Epson FX-80, HP PCL5 or HP PCL6.


Parameter	Description
Printer type	Select the printer, none, normal text or the installed printer, e.g. Epson FX-80
Page length	Here, you define the number of lines before a page break. No page break is created when the page length is set to 0.
Paper type	Choose the paper type matching the installed printer.
Graphic orientation	This parameter specifies whether the graphic is printed in portrait or landscape format.
Text orientation	Specify whether you want to print the report in portrait or landscape format using an FX80 compatible printer.
Printer disable signal	Digital signal that cancels printing when enabled. The port to which the printer is connected can be used for another communication (e.g. for transparent mode).
New line character	Character for the end of line: CR/LF, CR, LF or none.
Handshake	Specify whether the handshake between printer and terminal takes place via XON/OFF or CTS/RTS.
Screenshot	Allows for printing a screenshot: normal or inverted.

#### Setting up a communication port

The settings for the communication port are made under [Setup] [ [Peripherals]. Select [RS-232] or [RS-422] and make a right mouse click. For information on how to correctly set up the connected printer, refer to the printer manual.

Parameter	Description
Baud rate	Define the communication speed (in baud). The speed must correspond with the baud rate of the external units.
Parity	Specify the parity. The parity must correspond with the parity of the external units.
Data bits	Specify the number of data bits. The number of data bits must correspond with that of the external units.
Stop bits	Specify the number of stop bits. The number of stop bits must correspond with that of the external units.



**Control codes for the printer**

Not applicable for DOP11A-10.

Enter the control codes for the printer in a text block. Type "%%" and add a number between 1 and 31. The numbers 1 to 31 represent the control codes for the printer. Type "%%12" for example. This entry refers to the page break. For a description of the control code, refer to the printer manual. A command must be followed by a blank. The page break ("%%12") must be entered at the end of the line. The "%%" character is not permitted in the text. Several commands are permitted in a line.

**Print status**

The status of the connected printer can be read using a printer register. This register is specified under [Setup] / [System signals].

## 8.6 Time control

The [Time control] function allows for enabling and disabling digital signals depending on the realtime clock. You can use this function for controlling events in the process via the terminal at specified times (e.g. switching motors on and off). Time channels replace time relays and 7-day time switches.

**Defining time channels**


Time channels are defined under [Functions] / [Time channels].

Parameter	Description
Interval text	Enter any text for the time channel.
Signal	Define a digital signal that will be activated at the specified time intervals.
Interval	Specify days and times for the interval. You can define four different intervals for each time channel.

**Display in run mode**

The page with the time channels is displayed when system block 991 is activated. The system block is either activated by a jump object or a digital signal that is linked with the block. The time channel values can read and modified. The [Time channels] option under [Setup] / [Online settings] must be selected to modify time channel values in run mode.

To read or modify the values for a time channel, move the cursor to the required line and press the Enter key. You can also touch the required line if the terminal has a touch-screen. Press [OK] to confirm the time channel definition. Close the time channel menu with <PREV> or press <CANCEL> if the terminal has a touchscreen. Doing so displays the block from which the time channel block was activated.



### **8.7 Language handling**

The programming software supports multi language applications for DOP operator terminals. We recommend to create the entire application in one language using the programming software. Multi language support enables you to translate all texts of the application into other languages. The translation can be carried out directly in the programming software. You can also export all texts in the form of a text file and do the translation in another software. The translated file will then be reimported into the programming software. A maximum of 10 languages can be created per application.

A user defined index is assigned to each text in the application. To optimize the function and minimize the amount of text, you can copy and paste text that is frequently used in the application. Copied texts are linked with the same index.

The application language also contains user texts and is linked with a system language that contains system texts. User texts are texts that are entered when programming the project. System texts are texts that already exist when a new project is created as well as texts in the system program of the terminal.

#### ***Creating several application languages***

Select [Setup] / [Multi Language] / [New Language]. This function calls up a wizard for creating several application languages. Follow the instructions of the wizard and select the required parameter values or names, or enter them.

Specify whether you want to have all texts copied from an existing language (which means an already created language). Language 1 is the language in which the application was created (basic language).

The software suggests language names. You can change these names.

Select the character set for use in the terminal as well as national special characters under [Character table]. See section "Country settings" in chapter 7.3 "Programming with the programming software".

Under [System language], you can choose between [Built in] or [User defined]. Selecting [Integrated in] will display the system texts in the terminal in the selected language. Selecting [User defined] enables you to translate an integrated system language and link it with the system language for the application language (requires that the terminal is connected with a PC).

In the language control register field, the data register in the controller is specified. In run mode, the data register value (0-9) controls the application language (0-9) to be used by the terminal.

Click [End] to quit the function. This opens a directory tree with all languages you have created.



### ***Translating and editing texts in the programming software***

Select [Setup] / [Multi Language] / [Edit].

Enter the translation for the respective language in a table cell. Use the arrow keys to move the cursor through rows and columns. Browse the text list via [Edit] / [Find].

You can also export application languages as text file and translate them in another program (e.g. Excel or Notepad). The text file will then be reimported into the application. See sections "Export" and "Import" on page 200.

### ***Application language settings***

Select [Setup] / [Multi Language] / [Setup].

Right click on [User language] to change the registers for controlling the language.

You can make the following settings by right clicking the language name:

Parameter	Description
Make copy	Make copy of the current language
Character set	Select / change character set
System language	Select / change system language
Delete language	Delete current language
Change name	Change name of the current language
More	Define the date registers that determine the value for the language display.

To change the character set for the language (also Unicode), right click [Character set].

To change the system language or create a new one, right click [System language].



#### **User defined system language**

To create a user defined system language, select [User defined], choose the source language and click [Receive]. The [Language transfer] dialog opens. Click [Load] to load the integrated system languages from the terminal. Under [Setup] / [Multi Language] / [Edit], you can also edit system texts. You can also export texts as text file and edit the text in another program.

All system texts in the terminal (passwords, time channels, etc.) support multi language applications. You can either use the predefined system languages or own (new) languages. All characters in the selected character set are available for the application languages. A text character sequence can be linked with several objects. The maximum number of text character sequences for each language depends on the available project memory in the terminal.

The following memory space is available for each language:

Operator terminal	Memory space
DOP11A-10	16 kB / language
DOP11A-20	64 kB / language
DOP11A-30	64 kB / language
DOP11A-40	128 kB / language
DOP11A-50	128 kB / language

The left bottom area of the application language dialog shows information on the memory size for the selected language (language file). The information is displayed in X/Y format where X stands for the occupied memory and Y for the free memory available for each language, e. g. size 7/128.

#### **Export**

Languages can be exported, e. g. to Excel, where they can be translated and then be reimported to the programming software.

Select [Setup] / [Multi Language] / [Export]. Choose user texts (or system texts). Enter the name of the export file in the dialog that opens and select ANSI, OEM or Unicode as format.

Selecting ANSI/OEM means that all languages created in ANSI/OEM format will be exported. Selecting Unicode means that all languages are exported to a file in Unicode format. To edit a file in Unicode format in another program, a Unicode font must be selected in the relevant software.

#### **Import**

Select [Setup] / [Multi Language] / [Import]. Next, select [User texts] (or [System texts]). The [Import multi language texts] dialog opens. Enter the name of the text file to be imported. If the project language is in ANSI/OEM format and a language is to be imported in Unicode format, the imported language will be converted into ANSI/OEM format. All characters outside the ANSI/OEM range will be represented as question marks.



When opening a project with several application languages in an older programming software version, all objects with several application language texts will be replaced by the @ character followed by an index number, e. g. "@55".



### **Show index**

Each object, which represents text in an application with multi language support, is linked with an index. An index can be linked with various objects containing the same text. To display the index numbers for the object texts, select [Setup] / [Multi Language] / [Show index].

### **Cross reference**

Select [Setup] / [Multi Language] / [Cross reference]. In the cross reference list that opens, you can edit objects by right-clicking them. The cross reference list supports the incremental search algorithm when entering index numbers.

### **Copying object**

If the [Copy cross reference index] function is active while copying an object, the same index will be assigned to the copy. This way, objects with the same index need only be translated once. Changes made to a text affect all texts with the same index number.




If you delete an object that has copies with the same index number, only the selected object will be deleted.

### **Choose Unicode font**

Here you choose a Unicode font if an expanded character set is required for creating the application language.

### **Application languages in run mode**

The application language can be changed in the terminal in run mode. To do so, change the value (0-9) in the specified language selection register. Note that the terminal updates the entire displayed block when a new language is selected in run mode. If the terminal has a cursor, it will be positioned on the first maneuverable object in the current block after having performed the change.



## **8.8 Unicode**

### **Introduction**

Unicode is a global character coding standard that uses 16-bit values for displaying the characters of almost any language. Earlier character coding standards (e. g. the Microsoft Windows ANSI character set) use 8-bit values or combinations of 8-bit values to represent the characters used in a certain language or region.

Microsoft Windows 2000 and Windows XP have input locales installed. This enables the computer user to enter complex characters and symbols (e.g. Chinese characters) using a normal keyboard. The character sets installed in the computer are used. You can select input locales for various languages via the Control Panel. When installing new character sets, all required characters will be added to the system.

### **Unicode in the programming software**

The DOP11A-20 to DOP11A-50 operator terminals support Unicode if the latest system program version (firmware) is installed. Unicode characters can be used in projects and/or system texts.

The Microsoft Windows XP and Windows 2000 operating systems support Unicode.


The programming software uses a Unicode character set to display Unicode characters in the dialogs on the computer. Only the Unicode characters used in the project are downloaded when transferring a project.

### **Terminal font**

The operator terminal uses a terminal character set to display Unicode characters. The character set in the terminal comprises approximately 35 000 characters but is not complete according to Unicode standard. When transferring a project to the terminal, only the characters used in the terminal will be downloaded. If a character is used that is not available, a black rectangle will appear instead in the programming software and in the operator terminal. The project test, which can be carried out when transferring a project, checks whether all characters used are included in the terminal character set.

### **Font size for user texts and system texts**

Unicode characters are processed as bitmaps (point matrix). The predefined font size is 8 x 16 pixels. This value can be changed. Certain complex characters (e. g. Chinese characters) require a font size of 16 x 16 pixels to ensure that all pixels are displayed and misunderstandings avoided. When selecting a large font size on small terminals, the screen may not be large enough to display the entire menu.



### Multi language functions

#### *Toggling between object text and index number*

When you click the [T] button in the [Language] tool bar, the programming software shows the index number (@number) instead of the object text. New text (in ANSI format, not in Unicode) can also be entered in @ mode to link the object with a new index and to delete the link to other objects with the original index. You can link an object with a new index by specifying @number.

#### *Exporting and importing files in Unicode format*

System and user texts can be exported and imported under [Setup] / [Multi Language]. You can edit an exported file in Unicode format in a text editor, such as Notepad. Select a Unicode font in the text editor for this purpose.

When exporting a file, you can choose between ANSI, OEM or Unicode format. When selecting ANSI/OEM, only languages in ANSI/OEM format will be exported to a file with ANSI/OEM format. When selecting Unicode, all languages will be exported to a file in Unicode format.

When importing a file in ANSI/OEM format, you can define whether an existing language is to be updated or a new language to be added.

When importing a file in Unicode format, you can define whether an existing language is to be updated or a new language to be added. If the existing language is in ANSI/OEM format and you want to import a language in Unicode format, the imported language will be converted into ANSI/OEM format. Characters not included in the ANSI/OEM character set are replaced by a question mark.

### Memory requirements


A memory is assigned according to the following formulas when using Unicode.

Language size	Each character string requires 22 bytes + amount of characters in the character string x 4 bytes.
Character set size	The transferred character set requires the amount of unambiguous characters x 34 bytes. The transfer of 1000 characters consequently requires 34 kB.
Unicode	The memory requirements for a Unicode language corresponds to the language size + character set size.

### Performance

Unicode characters are loaded a little slower than ANSI/OEM characters because Unicode characters contain a larger amount of pixels.

The Unicode character set is read to the memory when starting the operator terminal. This process may take some time if the character set is large.



#### ***Limitations of Unicode***

##### *Text blocks*

Unicode does not support text blocks.

##### *Saving recipe and alarm history*

The [DOP Tools] \ [DOP File Transfer] program and the DOP FTP client do not support Unicode characters. Using Unicode means that the SKV file, which can be used for editing recipes or for the alarm history on a PC, will contain index numbers (@xxx) instead of block texts. You can search for the terminal text in the project. If you want text to appear in the SKV file, you have to change the terminal character set to ANSI format.

##### *Dynamic texts*


Text in objects can be controlled by system signals. To do so, select [Dynamics] / [Properties] for the selected object.

Dynamic texts are not converted into Unicode format. Questions marks will appear instead.

##### *Time channel block*

In the DOP11A-20 operator terminal, the time channels standard block that can be configured in run mode must use the predefined font size 8 x 16. Else, the input window will be too large for the screen so you cannot configure the block.






## 8.9 LEDs

Only applies to operator terminals with LEDs.

The operator terminal has integrated LEDs that are linked with a register. The LEDs are defined under [Functions] / [LED]. The register content determines the color and, if required, the flashing frequency of the LED as shown in the following table.

Register value (Hex)	Register value (Dec)	Flashing frequency (Hz)	Color
00	0	-	None
01	1	-	Green
02	2	-	Red
11	17	5	Green
12	18	5	Red
21	33	2,5	Green
22	34	2,5	Red
31	49	1,2	Green
32	50	1,2	Red
41	65	0,6	Green
42	66	0,6	Red



#### 8.10 Function keys

You link a function key to a signal by entering the signal's address according to the relevant key or by choosing the corresponding function from the selection list. The function key linked to a signal will be activated according to the function you have specified when defining the function key.



Only two function keys linked to signals can be activated at the same time. If more than two function keys are pressed simultaneously, only the two signals that were triggered first will be activated.

The number of function keys depends on the terminal type.

#### **Defining function keys**

You can define function keys in two ways:


- Globally
- Locally

##### **Global definition**

- Global function keys are defined and used in the entire application and apply to all blocks.
- A global definition is always available in run mode if the block displayed on the screen does not have any local definitions for the current function key.
- Global definitions are made under [Functions] / [Function keys].

##### **Local definitions**

- Local function keys are defined and used for a block.
- Local definitions have a higher priority than global definitions.
- Local definitions are made under [F keys] in the block header of the current block.



Function	Description
IO	Signal that is activated by the function key. (The subsequent field is used for specifying possible index registers and signal formats.)
Event	The IO event function serves for defining the effect of the function key on the specified signal. The Event function provides the following options:
	Momentary      The signal is output as long as the key is active.
	Toggle          The signal is output and reset alternately as long as the key is active.
	Set              The signal is activated when the key is pressed and remains in this state.
	Reset           The signal is reset when the key is pressed and remains in this state.
	Grouped        All signals are reset that are linked to a function key with the current group number. The group number is entered in the [Group no.] field. A group comprises a maximum of eight functions. Via the [Set analog] option, the analog signal linked to the function key is assigned the value defined in the <i>value</i> field.
	Inc. Analog     The analog signal linked to the function key is incremented by the value defined in the [value] field.
	Dec. analog    The analog signal linked to the function key is decremented by the value defined in the [value] field.
Set analog object to	Assigns the entered value to the maneuverable analog object selected with the cursor.
Increment analog object with or set digital object	Increases the value of the selected maneuverable analog object by the entered value or activates a selected maneuverable digital object.
Decrement analog object with or reset digital object	Decreases the value of a maneuverable analog object by the entered value or resets a selected maneuverable digital object.
Set digital object momentarily	Activates a selected digital object as long as the key is being pressed.
Jump to block	Jumps to the block with the specified name or number.
Security level	You can define security levels for function keys. The operator must login with a password for this or another security level to being able to use the function key.
Other functions	Function or touch keys are linked to the functions in the pick-list. See the separate table "Other functions of function keys and touch keys" on page 208.
Macro	The selected macro is executed. You can change the name of the selected macro or change the macro event for the selected event by clicking the [Edit] button.



#### *Other functions of function keys and touch keys*

Function	Description
Load recipe	Load recipe from the terminal memory.
Save recipe	Save recipe in the terminal.
Delete recipe	Delete recipe in the terminal.
Append recipe	Attaches signals and their values of the current block to an existing recipe. See chapter 8.3 "Recipe handling".
Login to specified security level	Log in See chapter 8.4 "Passwords."
Log off	Log off
Change login password	Change password
Scroll up one page	Scroll text pages in the text block and in the alarm list.
Scroll down one page	Scroll text pages in the text block and in the alarm list.
Zoom up text size	Increase text size in the alarm list.
Zoom down text size	Decrease text size in the alarm list.
Save recipe on memory card	Save the recipe to the memory card defined as backup medium.
Load recipe from memory card	Load the recipe from the memory card defined as backup medium.
Erase recipe on memory card	Erase the recipe from the memory card defined as backup medium.
Save project on memory card	Save the project to the memory card defined as backup medium.
Load project from memory card	Load the project from the memory card defined as backup medium.
Erase project on memory card	Delete the project from the memory card defined as backup medium.
Acknowledge alarm	Acknowledge alarm in the alarm list.
Show alarm list	Show alarm list (block 990).
Jump to info block connected to the alarm	Jump to the block linked to the alarm. Applies to selected alarm banners or alarms in the alarm list.
List alarm groups	Specify the alarm group from which the alarm is to be displayed in the alarm list.
Return to previous block	Shows the previous block. You can go back up to nine levels. When block 0 is displayed, this function will not execute a jump to the previous block. If logging in in run mode on a higher security level than the current one, this function will not execute a jump.
Jump to main block (block 0)	Shows the start block, block number 0.
Show object info	Shows the minimum and maximum values for the analog objects in the text block in run mode.
Enter	Corresponds to pressing the Enter key.
Show diagnostics page	Shows the diagnostics page.
Connect TCP/IP	Initiates connection for serial TCP/IP connection.
Disconnect TCP/IP connection	Disconnects the serial TCP/IP connection.
Change recipe directory	Edit recipe directory in the terminal.
Create recipe directory	Create recipe directory in the terminal.
Delete recipe directory	Delete recipe directory in the terminal.



### Using function keys to jump to block

This function allows for jumping to blocks using function keys without display signal. Choose [Jump to block] from the selection list when defining the keys (locally or globally).

Changing to a block can be performed easiest using function keys. No digital signal in the controller is assigned.

## 8.11 Trends

This chapter does not apply to DOP11A-10.

**Continuous trend** Does not apply to DOP11A-10 and DOP11A-20.

With this function, the controller constantly acquires analog values and displays them in a trend object during operation. The values are displayed in curves. The recorded values are stored in the operator terminal's project memory.

Several independent trend curves can either be displayed in the same block or in different blocks. The number of curves is restricted by the size and capacity of the project memory.

The trend object displays, for example, the time interval between the data recordings and the number of values.

### Calculating the trend data size

Use the following formula to calculate the trend data size in the project memory:

$$S = TOG + AK (28 + (645 \times ((AM / 100) + 1)))$$

TOG	Size of the trend object (If all parameters for a trend object are changed, the value for TOG = 320 bytes.)
AK	Number of curves defined in the trend object
AS	Number of samples that are rounded off to the next hundredth
S	Number of bytes



The RAM memory can also limit the number of trends in an object. This limitation depends on other objects and functions used in the project.



#### *Display in run mode*

In run mode, trend curves can display continuously measured values. Select the required trend object and press the Enter key. This opens a dialog box. Select a time interval and date for the data to be displayed. "History" is displayed in the bottom area of the dialog. To go back to real-time display, press the Enter key again. The trend data are stored in files. You specify the name when defining the trend object.

#### **Real-time trend**

Only applies to DOP11A-20.

The real-time trend displays analog values from the controller in a trend object during run time. The values are displayed in curves. No values are stored in the project memory of the terminal. No continuously measured data are displayed.

Several independent trend curves can either be displayed in the same block or in different blocks. A maximum of 10 trends can be used per application.

#### **Defining trend objects**

You can define trend objects in a block exactly like other dynamic objects. You can link the object with up to six analog signals (maximum 10 trends per projects with DOP11A-20).

Unlike other objects, the trend object name must be specified using 1-8 characters. The first character must either be a letter or a number. A-Z, 0-9 are permitted characters for the trend name. The same file name conventions apply as for MS-DOS.

You can define the following parameters for the trend object. Under [Setup] / [Terminal options], you can define if you want to save changed trends or all samples.



## [General] tab

Parameter	Description
Name	Enter a name for the trend object. Each object must be assigned an unambiguous name. The object name must not exceed eight characters. This parameter is mandatory. Not applicable for DOP11A-20.
Sample interval	Time interval between data acquisition. The minimum value is 1 s.
Sample count	Number of values to be stored. The maximum number of values is 65534. Not applicable for DOP11A-20.
Sample full limit	Enter the number of samples at which the sample full limit is to be activated. Not applicable for DOP11A-20.
Sample full signal	Specify a signal that is to be activated once the number of samples under Sample full limit is reached. Not applicable for DOP11A-20.
Enable sampling signal	Digital signal that starts recording data once it is activated. Recording stops when the signal is reset. Parameters need not be specified. Not applicable for DOP11A-20.
Delete trend data	Specify a digital signal that deletes all trend data in the trend once it is activated. Not applicable for DOP11A-20.
Y scale	Specify whether you want the y-scale be hidden, appear left, right, or on both sides.
Minimum value	The minimum value on the y-axis is called from the specified register.
Maximum value	Maximum value on the y-axis that is read from the specified controller register.
Scale division	Specifies which scale division is used on the y-axis.
Scale ticks	Specifies the interval between the displayed scale ticks.
Border style	Specify whether you want the object to appear with a border.
Grid	Specify whether you want to display a grid in the object.
Scale	Define a color for the scale in the object.
Grid	Choose an appropriate color for the grid.
BG	Define a background color for the object.



#### [Curves] tab

Parameter	Description
Analog signal	Analog signals that apply to the object and for which the values are to be displayed. Only signed 16-bit numbers are permitted.
Color	Choose a color for the respective curve.
Offset and gain	Is used for scaling the register value.



Only two curves can be used with the DOP11A-20 model.  
DOP11A-20 only has real-time trend.

#### [Dynamics] tab

The functions on this tab are explained in section "General parameters" in chapter 7.4 "Graphic display".



If you copy a block with trend data, you will have to rename the trend object.  
Two trend objects must not have the same name.

#### Transferring trend data

Not applicable for DOP11A-20.

If the [DOP Tools] \ [DOP File Transfer] program is installed on your PC, you will be able to transfer trend data, recipes and alarm lists to and from the PC for statistical calculations, display or for storage purposes.


You can also transfer the following data between PC and terminal using FTP:

- Trend data
- Recipes
- Alarm lists
- HTML files
- Terminal applets
- Bitmap graphics

An FTP client must be installed on the PC for this purpose. The DOP Tools program group provides the DOP FTP Transfer application that acts as standard FTP.

You can directly open trend files for statistical calculations, e. g. in Excel.



**Trend files**

The name for each trend file is specified when defining the trend object. The suffix SKV is assigned to the file.

Line format of the trend file:

DDDD;TTTT;AAAA;BBBB;CCCC;DDDD;EEEE;FFFF:

Format	Description
DDDD	Date format defined under Setup.
TTTT	Time format defined under Setup.
AAAA	Trend curve 1
BBBB	Trend curve 2 (if defined)
CCCC	Trend curve 3 (if defined)
DDDD	Trend curve 4 (if defined)
EEEE	Trend curve 5 (if defined)
FFFF	Trend curve 6 (if defined)

The oldest value is displayed in the first file line, the newest in the last line. The SKV format can be directly exported to Microsoft Excel. The diagram wizard in Excel is used for creating statistical diagrams. You cannot change files and send them to the terminal.

**8.12 Macros**


A macro combines several events in the terminal into a single command. If you frequently call up certain commands or settings in the terminal, you can automate these processes by creating a macro. A macro is triggered via local or global function keys or touch keys. You call up the [Macros] function under [Functions] / [Macros].

**Adding a macro**

Clicking on the [Add macro] button opens the selection dialog.


Enter a name for the macro in the dialog. The name must be unambiguous. Clicking [OK] displays the macro in the list under the name you have defined.

The number of user-definable macros is unlimited.



## Insert event / Add event

Clicking on the [Insert event/Add event] button opens the following selection dialog:



10789AEN

Each macro can include a maximum of eight different events (lines).

Parameter	Description	
I/O	With this parameter you define the signal to be linked with an event in the macro. In the [Choose event], field you select the event to be linked with the signal in the macro. You can choose from the following events:	
	Set	The digital signal is activated when the macro key is pressed and remains in this state.
	Grouped	Signals that are linked to a function key with the current group number are reset. The group number is entered in the [Group no.] field. A group comprises a maximum of eight functions.
	Dec. analog	Activating the macro by pressing a key will decrement the analog signal by the value defined in the [value] field.
	Reset	The digital signal is deactivated when the macro key is pressed and remains in this state.
	Set analog	Activating the macro by pressing a key will assign the value defined in the [value] field to the analog signal.
	Toggle	The digital signal is activated and deactivated alternately when pressing the macro key.
	Inc. analog	Activating the macro by pressing a key will increment the analog signal by the value defined in the [value] field.
Jump to block	Enter the number or name of the block you want to jump to when pressing the macro key. A block jump can only be the last event in a macro because it completes the macro.	



### ***Edit***

You can change the name of the selected macro or change the macro event for the selected event by clicking the [Edit] button. Instead, you can also double-click [Macro] or [Macro event].

### ***Activating macros***

You activate a macro via function or touch keys. Each key (global or local) can be linked to a macro. You select the macro for the corresponding key in the dialogs for local and global function keys and touch keys.



## 9 Network Functions and Communication

### 9.1 Communication

#### *Communication with two controllers (two drivers)*

You can activate two different drivers in the terminal. This means the terminal is capable of simultaneously communicating with two different controllers.

You can connect the controllers to the serial terminal interface, or to the PFE11A expansion card via ETHERNET connection.

Signal addressing to the controller takes place according to the usual procedure for the relevant controllers (see driver documentation for more details).

- Call up [File] / [Project settings] from the menu in HMI-Builder.
- Select the controller by clicking [Change] for system 1 or system 2. If the driver selected for system 1 does not support two drivers, then you cannot select a driver for system 2.
- Click [OK].
- Call up [Setup] / [Peripherals].
- Drag [Controller 1] and [Controller 2] to the connection ports to which the respective controller is connected. Available interfaces are RS-232C, RS-422, RS-485 (DOP11A-30) as well as the PFP11A and PFE11A expansion cards.

Refer to the driver documentation for more details on how to connect controller and terminal.

#### *Addressing*

Signal addressing to the controller takes place according to the usual procedure for the respective controller (see driver documentation for more details). To define the controller to which a created object should be linked, click the button for the required controller ([1] or [2]) in the tool bar in HMI-Builder.

Controller 1 is set by default when you create or open a project.

Clicking the [1] button links the signal of an object to be created with controller 1. Clicking the [2] button links the signal of an object to be created with controller 2.

Instead, you can also click the [I/O] button in the object to be created and select the object to be linked to the controller using the I/O browser.

To address a signal in controller 2 when controller 1 is preset, add "@2" to the signal (or vice versa "@1" for controller 1 if controller 2 is preset).

#### **Example**

Controller 1 is preset. Register D0 in controller 2 is to be linked to a slider. Enter "D0@2" under analog signal in the slider dialog.



**I/O cross reference** The [I/O cross reference] function for displaying an overview of I/Os can be used both for controller 1 and controller 2. The cross reference indicates the preset controller.

**Name list** Controller 1 and controller 2 support the name list with all associated functions.



If communication is interrupted by one controller, the terminal will continue communication with the other controller. The terminal will attempt to reestablish the interrupted communication with the controller every 10 seconds. As the communication with the connected system may be affected, you can change the interval using a command. See section "Commands" in chapter 7.3.

### **Data exchange between controllers**

When the terminal is connected to two controllers (two drivers in the terminal), data can be exchanged between the two controllers (analog and digital signals). You can also connect two controllers via separate terminals in a BDTP network.

The signal type need not be identical in the two controllers. Data are exchanged via a virtual data channel between controller 1 and controller 2. You can define eight different data channels. Data exchange can be time controlled or based on events. You define the conditions for the exchange of data as well as for the signal intervals for each data channel under [Functions/ [Data exchange].

Parameter	Description	
Area	Start I/O 1	Start address for the data channel for controller 1. (The subsequent field is used for specifying possible index registers and signal formats.)
	Start I/O 2	Start address for the data channel for controller 2. (The subsequent field is used for specifying possible index registers and signal formats.)
Mode	Specify whether the signals for the data channel are analog or digital signals.	
Size	Specify the number of signals to be transferred in the data channel (start address + subsequent). The maximum number of signals for a data channel is 255.	
Flow 1 → 2	Trigg signal	Digital trigger signal that controls the data exchange for the data channel from controller 1 to controller 2. Meaning of the signal status:
		0 Inactive
	1	Transfer The terminal deactivates the signal after successful transfer.
	Interval	Indicates the time in seconds that elapses between cyclic transfers in the data channel. Set the interval parameter to zero if there is no cyclic transfer. When the value is higher than zero (1), the parameter has priority over the trigger signal. In this case, a trigger signal will not be able to initiate a transfer. The maximum number of seconds is 65535.



Parameter	Description	
Flow 2 → 1	Trigg signal	Digital trigger signal that controls the data exchange for the data channel from controller 2 to controller 1. Meaning of the signal status:
		0 Inactive
		1 Transfer The terminal deactivates the signal after successful transfer.
	Interval	Indicates the time in seconds that elapses between cyclic transfers in the data channel. Set the interval parameter to zero if there is no cyclic transfer. When the value is higher than zero (1), the parameter has priority over the trigger signal. In this case, a trigger signal will not be able to initiate a transfer. The maximum number of seconds is 65535.

When you have completed your data channel settings, click [Add].



The [Data exchange] function has the same priority as all other terminal functions. Example: If the terminal is working at full capacity (because other functions are being executed) when you request a data exchange, the data transfer time between the controllers will increase.

#### **Transparent mode**

In transparent mode, you can use a communication port (programming / printer port) on the terminal that is not connected with the controller to connect other parallel units to the controller. Such units can be terminals, a PC with programming tools for the controller or a higher-level operator system.

Refer to the driver manual for information whether the connected controller supports transparent mode.

#### **Connecting PCs or other computer systems**

PCs with a programming tool or another computer system are directly connected with a communication port (in this case programming/ printer port) of the terminal.



### Settings in terminal and PC

Make the following PC and terminal settings to enable transparent mode.

Make the communication settings in the terminal project in HMI-Builder under [Setup] / [Peripherals].

- Drag the [Transparent mode] element to the required communication port (i.e. the port to which the PC is connected with the terminal).
- Right-click the element to configure transparent mode (if supported by the driver, see the driver manual for details).

The settings for the port to which the PC is connected must be identical with the settings in the PC program (programming software for the controller).

Parameter	Description
IP settings	This parameter is only used for communication in transparent / pass-through mode via ETHERNET. The transparent mode unit must be connected with a TCP/IP port for this purpose. The port number 6004 usually need not be changed. Select the required protocol: UDP or TCP.
Controller systems	This parameter is only used for communication in transparent / pass-through mode via ETHERNET. The transparent mode unit must be connected with a TCP/IP port for this purpose. Define whether you want the transparent / pass-through mode to apply for controller 1 or 2.
Mode	Select transparent or pass-through mode as communication type. Timeout: enter a time interval in seconds after which the terminal will change from pass-through mode to run mode if no pass-through communication has taken place.

### Connecting two terminals in pass-through mode

You can connect several terminals to the same computer in transparent mode. The following section explains how to connect two terminals. Several terminals can be connected in the same way.

### Cable connections

When connecting two terminals to one controller, the first terminal is connected as described in the installation manual. The two terminals are connected with a cable. The cable connects to the free port of the first terminal and the corresponding port of the second terminal. If the communication distance via RS-232 ports exceeds 15 m, you will require a signal amplifier.

### Setting up the first terminal

Make the communication settings in HMI-Builder under [Setup] / [Peripherals]. Make the settings for the port connected to the controller as usual. The settings for the port connected to the second terminal can be defined by the user.

### Setting up the second terminal

Make the communication settings in HMI-Builder under [Setup] / [Peripherals]. The controller must be connected to the port provided for connecting the second terminal to the first terminal. The settings on this port correspond to those of the port of the first terminal to which the second terminal is connected.

### Baud rate

The baud rate is between 600 and 75 600 baud. We recommend you use the highest baud rate between the terminals for optimum performance. The communication speed decreases with increasing number of connected terminals (see the following table).



#### Access time to the controller

Terminals	Terminal 1	Terminal 2	Terminal 3	Terminal 4
1	100 %	–	–	–
2	50 %	50 %	–	–
3	50 %	25 %	25 %	–
4	50 %	25 %	12,5 %	12,5 %

#### Connecting three terminals in pass-through mode

You can connect a third terminal to terminal two in the network using a cable. Setup is the same as for the second terminal.

#### Pass-through mode

The [pass-through mode] function allows for setting the terminal in such a way that communication can take place between the PC programming software (in this case MOVITOOLS®) for the connected controller and the controller itself (MOVIDRIVE® or MOVITRAC® 07) via operator terminal.

The function is analog to the transparent mode function and also only supports one controller. Consequently, transparent or pass-through mode can only be performed on one communication port of the terminal.

If pass-through mode is active and the PC communicates with the controller via terminal, the communication between terminal and connected controller will be interrupted. This is the difference between pass-through mode and transparent mode. A terminal on which a communication in pass-through mode takes place will be locked for the operator and only show an empty screen with a reference made to the pass-through mode.

Pass-through mode for one of the connected controllers is activated or deactivated via the [DOP Tools] / [DOP Connect] program. You find the program as icon in the [DOP Tools] program group.



DOP11A-10 does NOT support pass-through mode with DOP Connect.



The MOVILINK® driver for MOVIDRIVE® and MOVITRAC® 07 units only supports pass-through mode. Transparent mode is not supported.

#### Terminal and PC settings

The following PC and terminal settings are required to enable pass-through mode:

Make the communication setting in the terminal project in HMI-Builder under [Setup] / [Peripherals]. Drag the [Transparent mode] element to the required communication port (i.e. the port to which the PC is connected with the terminal).

To configure pass-through mode, right-click the element. The settings for the port to which the PC is connected must be identical with the settings in the PC program (programming software for the controller).





Parameter	Description
IP settings	This parameter is only used for communication in transparent / pass-through mode via ETHERNET. The transparent mode unit must be connected with a TCP/IP port for this purpose. The port number 6004 usually need not be changed. Select the required protocol: UDP or TCP.
Controller systems	This parameter is only used for communication in transparent / pass-through mode via ETHERNET. The transparent mode unit must be connected with a TCP/IP port for this purpose. Define whether you want the transparent / pass-through mode to apply to controller 1 or 2.
Mode	Select transparent or pass-through mode as communication type. Refer to the relevant section for further information on pass-through mode. Timeout: Enter a time interval in seconds after which the terminal will change from pass-through mode back to run mode if no pass-through communication has taken place.

You can use pass-through mode for serial communication as well as for connection via ETHERNET.

### ***Using the terminal as communication interface (no protocol mode)***

The no protocol mode is used for connecting different controllers or for connecting external devices (e. g. barcode scanners or weighing machines) to the controller. The controller monitors data transfer to the communication port. The data arriving at the communication port are stored in registers. Communication takes place by transferring the data register range that corresponds to the following control block.


Make a right mouse click on [No protocol mode] under [Setup] / [Peripherals].



Register	Description
Ctrl. reg. 0	Start register for transfer data buffer <ul style="list-style-type: none"> <li>The first register in the buffer area contains the total number of bytes to be transferred.</li> <li>The subsequent registers contain the transfer data.</li> <li>The maximum buffer size is 127 registers = 254 bytes.</li> </ul>
Ctrl. reg. 1	Command register for transfer <ul style="list-style-type: none"> <li>Is set to 1 by the controller if transfer is requested.</li> <li>Is set to 0 by the terminal after successful transfer.</li> </ul>
Ctrl. reg. 2	Start register for receive data buffer <ul style="list-style-type: none"> <li>The first register in the buffer area contains the total number of bytes received.</li> <li>The subsequent register contains the received data. The maximum buffer size is 127 registers = 254 bytes.</li> </ul>
Ctrl. reg. 3	Command register for reception <ul style="list-style-type: none"> <li>Is set to 0 by the controller if it is ready to receive data.</li> <li>Is set to 1 by the terminal when the message is available.</li> <li>Will be set to -1 (FFFF), if the message is missing (e. g. too short).</li> <li>Is set to 2 by the controller when the port buffer is to be deleted.</li> <li>Is set to 3 by the controller when the port buffer was cleared.</li> </ul> <p>The port buffer is automatically cleared when starting the unit and when changing between transparent mode and no protocol mode. The register is assigned the value 3.</p>
Ctrl. reg. 4	End code (1 or 2 bytes) in the received message.
Ctrl. reg. 5	Length of the received message. The end code will be used if the register content is 0.

Drag the element to the required communication port under [Setup] / [Peripherals]. Make a right mouse click to define the register that should be listed as first control register in the transfer area. This register as well as the five subsequent registers will be used as control registers.

In run mode, the controller can change between no protocol mode and transparent mode / printer mode. Enter a digital signal in the dialog under the *No protocol signal* parameter.




54250AEN



### Example of using no protocol mode

The following example describes the use of no protocol mode in a weighing system. The following figure illustrates the communication in a block diagram.



54251AEN

The terminal acts as master for the weighing system. It permanently queries the current weight in the weighing system.

### Connecting a modem

A modem is used for establishing a connection with a PC. You make the connection settings under [Setup] / [Peripherals]. Call up the dialog by selecting the [Modem] entry and use the right mouse button to click on the selection.



#### Control block register

Communication is established using three control registers in a control block. The first register in the control block is defined next to the control block register in the dialog. The table below describes the control register functions.

Register	Description
Ctrl. reg. 0	Contains the command that describes how the controller establishes a connection and communication.
	0      Wait for command
	1 ... 10      Establish a connection using the phone number entered in the [Phone no.] field. Maximal 40 characters are permitted.
	11      Establish a connection using a phone number stored in the controller. The phone number is stored as ASCII character string that begins in the third control register and in the subsequent register. The character string must not exceed 40 characters, i.e. 20 registers are permitted. Not all registers must be used. The last register to be read must contain the ASCII code 0.
	101 ... 110      An initialization character string is transferred to the modem. Enter the Hayes modem command in the [Phone no.] (1 ... 10) field. The command 101 sends the character field entered in the [Phone no. 1] field, etc.
	111      An initialization character string stored in the controller is sent to the modem. Enter the Hayes modem command that begins in the third control register. See command 11 for more details.
	255      End command
Ctrl. reg. 1	The other control register is used as status register. The register contains the result of the modem commands. The register can have one of the following states:
	Status codes
	0      Command was executed correctly
	1      A connection is being established
	2      Modem has established a connection
	3      Modem has received a ring signal.
	Error codes
	101      No connection
	102      Modem recognizes lost carrier wave
	103      Unknown modem fault
	104      Modem does not receive a dial tone
	105      Busy while establishing a connection
	106      No response while establishing a connection
	107      No response from the modem
	255      Unknown fault / status
Ctrl. reg. 2	The terminal can establish a connection using a phone number stored in the controller. The phone number is stored as ASCII character string that begins in the third control register and in the subsequent register. The character string must not exceed 40 characters, i.e. 20 registers are permitted. Not all registers must be used. The last register to be read must contain the ASCII code 0.



**Init**

Setup string for the modem

**Timeout (ms)**

Number of seconds after which an inactive line is interrupted. The predefined value is 30 s. You can enter a time between 5 and 600 s.

**Dial method**

Pulse or touch-tone dialing.

**Phone no. 1-10**

Complete phone number for establishing a connection.

## **9.2 Network communication**

Not applicable for DOP11A-10.

Network communication takes place using TCP/IP (Transmission Control Protocol / Internet Protocol). TCP/IP is a standard protocol that enables communication with other systems and devices.

Operator terminals can be integrated in the network in different ways: via ETHERNET or serial. When connecting operator terminals via ETHERNET, all terminals must be equipped with PFE11A expansion cards.

The terminal network is a client / server network. Only clients can access data in the network. Servers only make data available to the clients. A terminal can be client and server at the same time. This way, it provides data and can also access the data of other terminals. Up to 20 different clients can retrieve data from the same server. One client can access the data of up to 16 different servers.

Each terminal must have an IP address. IP addresses in the range from 192.168.0.0 to 192.168.254.254 are recommended for internal networks.

Standard Internet tools, such as web browser, mail server and FTP client, can be used for working on the terminal. You can create a web page on the PC that can be called up from the terminal. This web page can contain real-time data from the controller or terminal. You can then change values, set signals, acknowledge alarms, etc. via Internet and web browser using a script.

The terminal can also send e-mails, such as alarms and status reports, when certain events have occurred.



#### **Network communication via *ETHERNET***

The terminals must be equipped with PFE11A expansion cards if you want to connect them to a TCP/IP network via ETHERNET.

##### *Making the connection*

Call up [Setup] / [Peripherals] in HMI-Builder. Select the required expansion card slot and make a right mouse click on the selection. Select the network card. Select [TCP/IP connection] and keep the left mouse key pressed while moving the mouse to the selected expansion card. Now release the mouse key.

##### *Settings*

Select [TCP/IP connection 1] and make a right mouse click to make the settings for the TCP/IP network.

##### *Connection name*

Enter a connection name. Parameters need not be specified.

##### *Host configuration*

If [Manual] is selected, the parameter settings specified in the TCP/IP setting dialog will be used. If you select one of the other options, a network server will assign one or several TCP/IP parameters.

##### *IP address and subnet mask*

Enter the network ID for the node (terminal). The network connection takes place according to ETHERNET standard. IP addresses in the range of 192.168.0.0 and 192.168.254.254 are recommended for a local network that only consists of terminals.

##### *Gateway*

Enter the network unit in the local network that is capable of identifying the other networks in the Internet.


##### *Primary DNS and secondary DNS*

Enter the server(s) that contain information on part of the DNS database.  
Click [OK] to confirm your settings.



### ETHERNET connections

The following section gives three examples for ETHERNET connections.



### Connection between two operator terminals with twisted-pair cable (TP)

The cables have RJ45 connectors. The cable is a shielded or unshielded twisted pair (crossed) CAT5 cable.



If communication does not function correctly and the "Link" LED on the IFC ETTP card does not light up, connections 3 and 6 have probably been mixed up.

### TCP/IP settings in nodes 1 and 2 ([Setup] [Network] [TCP] [IP Connections])

TCP/IP Network Connection \*

Connection name

Terminal 1

Host configuration

Manual

TCP/IP Settings

IP Address

192.168.1.1

Subnet mask

255.255.255.0

Gateway

0.0.0.0

Primary DNS

0.0.0.0

Secondary DNS

0.0.0.0

OK

Cancel

TCP/IP Network Connection \*

Connection name

Terminal 2

Host configuration

Manual

TCP/IP Settings

IP Address

192.168.1.2

Subnet mask

255.255.255.0

Gateway

0.0.0.0

Primary DNS

0.0.0.0

Secondary DNS

0.0.0.0


OK

Cancel

10779AEN



#### Connection between more than two operator terminals with twisted-pair cable (TP)



54413AXX

The maximum length between operator terminal and hub is 100 m. The maximum number of nodes per hub depends on the number of connections on the hub. The cables have RJ45 connectors. The cable is a shielded or unshielded twisted pair CAT5 cable.

#### Serial network communication

##### Making the connection

Call up [Setup] / [Peripherals] from the menu. In the [Peripheral configuration] dialog, select a TCP/IP connection and keep the left mouse button pressed while moving the mouse to the [RS-232C] or [RS-422] entry. Now release the mouse key. TCP/IP connection 2 will only be available when TCP/IP connection 1 has been used.



The parity on the port for the TCP/IP connection must be set to "None".

##### Settings

Select [TCP/IP connection 1] and make a right mouse click to make the settings for the TCP/IP network.

##### Connection name

Enter a connection name. Parameters need not be specified.

##### Serial protocol

The PPP protocol is used for serial communication.





*User name* Enter the user name used for login.

*Password* Enter the password used for login.

*Connect signal* Digital signal that establishes the connection when enabled and disconnects the connection when disabled.

*Connected register* Analog register that can have one of the following states:

Register	Description
0	Disconnected (PPP client)
1	Waiting for a connection (PPP server)
2	Connected as a PPP client
3	Connected as a PPP server
7	Connection error

*Use logon script* This function is used to automate the establishment of a serial connection. The script may differ depending on the connected server and modem.

The terminal supports the following commands:

Parameter	Description
1 WAIT: Text, x	Waits x seconds for text. x need not be specified.
2 SEND: Text	Sends text.
3 LABEL: Label	The label marks a reference point in a script.
4 ONERR: Label	Jumps to label if an error occurs in the previous command.
5 MESSAGE: Message	Opens a message window.
6 END	Ends the script.
7 SLEEP: x	Interrupts the process for x seconds.
8 COUNTER: y	Counts the pulses each time COUNTER is activated. When the value is reached, an error is output that is processed by ONERR.



Variables	Description
% USER NAME	Comparison with the user names defined for existing accounts.
% PASSWORD	Comparison with the passwords defined for existing accounts.

#### Example 1:

```
WAIT: login:, 10
SEND: KALLE
WAIT: password:, 10
SEND: HELLO
```

#### Example 2:

The following script will send the text "CLIENT". If the sending process fails, a "Send Failed" message will appear. If sending was successful, wait for the text "CLIENTSERVER". If this text does not appear within 10 seconds, a "Receive Failed" message will be displayed.

```
SEND: CLIENT
ONERR: Send Failure
WAIT: CLIENT SERVER, 10
ONERR: Receive Failure
END:
LABEL: Send Failure
MESSAGE: Send Failed
END:
LABEL: Receive Failure
MESSAGE: Receive Failed
END:
```

#### Example 3:

The following script will send the text "login". It waits for the remote end to send a user name. The name is then verified whether it corresponds with one of the user names for defined accounts. After verification, the script continues to run and sends the "password". It waits for the remote end to send a password. The received value is compared with the password in the account for which the user name has already been verified.

Usually, no script needs to be executed. Use the following script if your terminal is connected to a Windows NT server:

```
SEND: login:
WAIT: % USER NAME
SEND: password:
WAIT:%PASSWORD
```



<i>PPP login validation method</i>	Choose a method for validating the user ID. This value usually need not be changed. The parameter is only used with PPP connections.
<i>Act as client / server</i>	When the connection is a PPP connection, you have to define whether the terminal should act as PPP client and/or PPP server, or whether the terminal establishes the connection or acts as remote end.
<i>Connect at boot</i>	With a PPP connection, the terminal can be automatically connected at startup with terminal or PC.
<i>Advanced</i>	Choosing Advanced enables you to define more parameters.
<i>Use VJ compressing of IP headers</i>	The IP header is compressed. This value usually need not be changed. The parameter is only used with PPP connections.
<i>Request / provide remote address</i>	The IP address for the remote node is requested and provided. Should be set to 0.0.0.0 if the IP address is to be assigned by the remote node. The parameter is only used with PPP connections.
<i>Use remote address as gateway</i>	Activate this option if you want to use the IP address of the remote node as gateway (connection port to another network). The option is disabled by default. The parameter is only used with PPP connections.



Network communication is not possible if the [Use remote address as gateway] checkbox is disabled when you use a subnetwork. In this case, you can send e-mails from the terminal but external login on the terminal is not possible (e. g. via FTP client or web browser).



## Network Functions and Communication


### Network communication

#### *Request / provide local address*

The local IP address is requested and provided. Should be set to 0.0.0.0 if the IP address is to be provided by the remote node. The parameter is only used with PPP connections.



If the terminal acts as server or as server and client, and you change the addresses under [Request / provide local address], the new addresses will be saved. If the terminal acts as client, the addresses are set to 0.0.0.0. If you change the terminal status to server or server and client, the stored addresses will be used.




#### *Modem*

You will have to configure the parameters in the [Modem] window if you want to establish a connection using the modem. A special cable is required for this purpose.



[Setup] / [Peripherals]



- Select [Setup] / [Peripherals] from the menu.
- Select the TCP/IP connection on the serial port and click on [Edit].
- Next, click the [Modem] button.



Parameter	Description
Enable modem	Check the modem checkbox if you use a modem.
Disconnect if idle (min)	Interrupts the connection if it has been idle for the specified number of seconds. Entering 0 means the connection will never be interrupted.
Phone number	Enter the phone number to be dialed.
Modem setup string	Character string for modem initialization. Refer to the modem manual for more information.
TCP/IP	TCP/IP connection parameters.
Host configuration	If Manual is selected, the parameter settings specified in the TCP/IP setting dialog will be used. If you select one of the other options, a network server will assign one or several TCP/IP parameters to the terminal.
IP address and subnet mask	Enter the network ID for the node (terminal). The network connection takes place according to ETHERNET standard. IP addresses in the range of 192.168.0.0 and 192.168.254.254 are recommended for a local network that only consists of terminals.
Gateway	Enter the network unit in the local network that is capable of identifying the other networks in the Internet.
Primary DNS and secondary DNS	Enter the server(s) that contain information on part of the DNS database.

### 9.3 Network functions in the terminal

This chapter is not applicable to DOP11A-10.

#### FTP server

FTP (File Transport Protocol) is a standard Internet protocol and the easiest way of exchanging files between computers in the Internet. FTP is an application protocol using the TCP/IP Internet protocol. FTP is usually used to transfer web sites from the computer where they were created to a server connected to the Internet. FTP can also be used for downloading programs and other files from another server (terminal) to your computer. Files can be transferred from or to the terminal when the terminal acts as FTP server. An FTP client must be installed on the PC for file transfer, such as DOP Tools, Internet Explorer, Windows Commander or another FTP standard software.

Files with a length of 0 are displayed in certain libraries. The reason is that these files contain dynamic data so their size varies. This means a file of the length 0 is not necessarily empty. As the terminal does not work with the file date the displayed dates are irrelevant. The terminal can save the contents of all files that can be accessed via FTP using various separators. You can use the following characters as separator for the file contents: Tabulator (→), semicolon (;) or colon (:).


Make the FTP separator setting in HMI-Builder under [Setup] / [Terminal options]. The file name must not contain national special characters, such as B, Ä, Ö and Ü. The FTP server of the terminal can process up to three connected clients simultaneously.



The files in the individual libraries increase the project memory load. For information on available project memory, refer to the file `info.txt` in the root library [ROOT].



#### Root library



10808AXX

The root library (current terminal name) comprises the following libraries:

- ALARMS
- HTML
- RECIPE
- TRENDS

The DOP11A-50 type has the [IMAGES] file available in addition. See section "Library [IMAGES]" on page 237.

Only libraries for which the user has access rights (per account) are shown. The root library also includes the `info.txt` file that includes information on the terminal.

#### *info.txt* file

The `info.txt` file provides information on the terminal as shown in the following example:

#### **DOP11A-40**

Boot version: 4.07  
 Firmware version: V4.00  
 Build number: 320  
 Driver1: MOVILINK V3.11.1  
 Driver2: MODBUS Master V3.00.4  
 Dynamic memory: 304237 bytes free  
 Project memory: 184700 bytes free  
 IP address: 192.168.98.1

No files can be deleted from the root library even if the user has write access. Deleting the [HTML], [RECIPE] or [IMAGES] libraries (DOP11A-50) deletes the contents of the respective library. The library itself will not be deleted.



*Alarm library*  
[ALARMS]

This library is only shown if alarms have been defined in the terminal and the terminal is in run mode. In this library, the alarm groups are displayed as SKV files with a length of 0. This does not necessarily mean that there are no alarms. They are read-only files.

*File format*

Each alarm is stored in a line ending with a carriage return and a line feed: [carriage return][line feed].

**Syntax (DOP11A-40 and DOP11A-50)**

A semicolon (;) is used as separator.

Status;Activation date;Activation time;Deactivation date;Deactivation time;Acknowledgement date;Acknowledgement time;Alarm text

All fields are always available. The date and time fields of unacknowledged alarms are empty.

Syntax (other terminals):

Status;Activation date;Activation time;Alarm text

The file is completed with "END" [carriage return] [line feed].

*HTML library*  
[HTML]

This library contains files that are managed by the web server. You can create sub-libraries. The start file (HTML page shown as start page in the web browser) must always have the name `index.htm`.

*File format*

The file name depends on the file type. Standard file formats such as HTML are used.

*Recipe library*  
[RECIPE]

The individual recipes in the respective recipe libraries are displayed as SKV files with a length of 0. This does not mean the recipe is empty. Read and write access is possible on files in this library.



#### *File format*

Each recipe value is stored in a line ending with a carriage return and a line feed: [carriage return][line feed].

#### **Syntax**

A semicolon (;) is used as separator.

e.g. unit;value;file type;length

The file is completed with

"END" [carriage return][line feed].

If the file is of the "Array" (AR) type, each line will contain a value. The first line looks as described above. All subsequent lines only have the following entry:

;value

#### *Data types for analog signals*

Type	Description
Un-assigned	16-bit character
+	No 16-bit character
L	32-bit character
L+	No 32-bit character
RB	BCD float format
RF	Float with exponent
SB	16-bit BCD format
LB	32-bit BCD format
SH	16-bit hexadecimal
LH	32-bit hexadecimal
RD	Floating point number
AR	Array 16-bit
ST	Character string
BI	Bit 0 or 1

#### *Trend library [TRENDS]*

This library is only available if trends have been defined in the terminal and the terminal is in run mode. In this library, the various trend objects are displayed as SKV files with a length of 0. They are read-only files. Curve 1 must be used to make a trend valid.





*File format*

Each measured value is stored in a line ending with a carriage return and a line feed: [carriage return][line feed].

**Syntax**

A semicolon (;) is used as separator.

The file is completed with

"END" [carriage return] [line feed].

Only the number of curves available in the trend (no empty fields) will be transferred.

In the following cases, "OFF" is included in the measured value and identifies an interruption when acquiring the value.

- When the terminal changes to run mode, a copy of the latest sample will be saved. The copy is marked with "OFF". As soon as the terminal has received the valid value, the new values will be saved without the "OFF" mark.
- When the signal for trend activation is output, a sample will be marked with "OFF". When the signal is output, a new value is saved without the "OFF" mark.
- When the stored value is transferred using FTP or HMI-Tools, a sample will be saved marked with "OFF". After the transfer is complete, a new value will be saved without the "OFF" mark.

*Library [IMAGES]*

For DOP11A-50 only.

The DOP11A-50 terminal also includes an [IMAGES] library. You can save graphics in BMP format in the library. Bitmap graphics can be displayed in static symbol objects when the terminal is in run mode.

Files in this library can be written, overwritten and deleted. It is not possible to create new sub-libraries. If you activate the [Use dynamic bitmaps] checkbox for a static symbol object, the terminal will retrieve the specified bitmap file (*namn.bmp*) from the [IMAGES] library in the terminal's file system. In run mode, the bitmap graphic will be displayed on the terminal screen.

The graphic to be displayed must be transferred to the library via FTP. You can add, exchange or delete dynamic bitmap graphics via FTP by overwriting, saving or deleting BMP files in the [IMAGES] library. The image for a dynamic bitmap graphic object is only displayed on the terminal in run mode.

The bitmap graphics are not available in HMI-Builder and can therefore not be displayed.



Use the same X and Y size for the BMP graphic in the library and for the symbol object defined in HMI-Builder.

Files cannot be accessed from the [IMAGES] library.

When a BMP file is sent to the [IMAGES] library, transfer is stopped briefly for the duration of time the terminal converts the standard BMP format into the special BMP format of the terminal.

**SMTP client**

SMTP (Simple Mail Transfer Protocol) is a TCP/IP protocol used for sending and receiving e-mails. SMTP is usually used together with one or two other protocols (POP3 or IMAP) as SMTP only provides limited functions for saving received messages. These protocols allow the user to save messages in a server mailbox and retrieve them later. This means SMTP is used for sending e-mails and POP3 or IMAP are used for retrieving e-mails from the local server.

The terminals can act as SMTP client (send e-mails). A mail server is required for using the SMTP client function.

You can use the mail server of your Internet service provider for this purpose. You can also use a local mail server.

**Terminal mirroring - terminal applet**

Where the object-oriented programming language Java is used in the Internet, an applet is a small application sent to the user together with the data of a web site. Terminal applets can execute interactive animations, direct computations or other simple tasks without sending a request back to the server.

You can mirror the terminal in a web browser (e. g. Microsoft Internet Explorer) on a PC. This means the applet represents a terminal on the screen. The mirrored image is updated at specified regular intervals. The mirrored terminal fulfils the same function as the actual terminal. You can control the terminal by pressing the buttons on the terminal user interface using the mouse or keyboard. Or you directly touch the screen if your terminal has a touchscreen. Text strips for the terminal are not represented in the applet.

The applet is compressed in a CAB file. This file installs in the browser the first time the applet is loaded. You can load the file either via the terminal file system or the local hard disk of your PC. Do not extract a CAB file manually. The file will be extracted by the browser.

You need to transfer the CAB file to the HTML library via FTP to allow the applet to be installed and executed by the terminal. A web site (HTML file) containing the HTML code for loading and executing the applet must also be transferred to the HTML library in the terminal. The web server must be activated in the web server.

Enter the host name or IP address of the terminal as well as the file name of the web page in the web browser (e. g. "terminal1.domain.com/terminal1.htm" or "192.168.98.75/terminal1.htm") to establish a connection to the web server of the terminal. The terminal icon [Terminal Interaction] will appear once the web page has loaded. Click this symbol to start the applet. The applet will then establish a connection to the terminal controller network service (port number 6001 is preset). You can configure the port number in HTML code via an applet parameter. The relevant dialog will appear if a login was defined for the terminal controller function. The user data entered in the dialog are compared with the entries made under [Setup] / [Network] / [Accounts].



If you execute the applet locally, you can store the CAB and HTML files anywhere on your hard disk. You have to enter the host name of the terminal in the HTML code (e. g. "terminal1.domain.com" or "192.168.98.75"). In this case, the CAB file is directly loaded from the hard disk and the web server is bypassed. Apart from this, the procedure for executing the applet is the same as described above (load the HTML file).

The CAB file is only loaded to the browser the first time or when the applet is reinstalled.

### Signed applet

Signing the applet with a software certificate allows for installing it in the browser. A security dialog pops up when you call up the certificate the first time (i.e. the first time a signed applet is loaded).

The dialog informs you that the applet was signed with a certificate from SEW-EURODRIVE. To install the applet, answer the security dialog with [Yes]. In the dialog, you can define whether you always want to trust the contents signed with this certificate. Any signed applet that is signed using the same certificate will be trusted automatically in the future. The certificate will be added to your browser and no security dialog will pop up again.

To see which applets are installed in your browser, select [Extras] / [Internet options] / [Contents] / [Certificates] from the Internet Explorer menu. The tab shows the applet version and time of installation. You can deinstall applets if you do not need them. You can influence the setting and appearance of the applet via the following parameters in the HTML code:

Parameter	Description	Default value
TermCtrlPort	Port number for the network service	6001
Background	Background color for the terminal mirror image on the web page in RRGGBB format (hexadecimal 00-FF)	B7F58D (light green)
Title	Title in the applet window	Terminal view
HostNameInTitle	Specifies whether the host name should be included in the title e. g. "Terminal view - 192.168.98.1" or "Terminal view - Terminal1.domain.com".	YES
ScrUpdInterval	Start value for the update interval in seconds	10
Label	Heading in the applet view	Terminal Interaction
LabelFontSize	Font size for the heading	12
LabelBoldStyle	Specifies whether the heading should appear in bold text.	NO
LabelColor	Foreground color for the heading in RRGGBB format (hexadecimal 00-FF)	000000 black
LabelXPos	X position of the heading in the applet view	5
LabelYPos	Y position of the heading in the applet view	15
Icon	Specifies whether the terminal icon should appear in the browser.	YES
IconXPos	X position of the icon in the applet view	5
IconYPos	Y position of the icon in the applet view	17
MouseInputFeed-back	Mouse feedback	YES
KeyboardInput-Feedback	Keyboard feedback	NO
AppletHostname	Host name of the terminal e. g. "192.168.92.1" or "terminal1.domain.com"	" " (the local address is used)
ForcePacking	Specifies whether screen data should be compressed. No compressing will take place with ETHERNET if this parameter is not active. Compressing will take place when using PPP.	NO



#### Input feedback and wait cursor

Input feedback and wait cursor are controlled via the applet parameters *MouseInputFeedback* or *KeyboardInputFeedback*. These parameters prevent that mouse or keyboard input are handled using a queue with the applet being updated with each input.

The presettings are YES for *MouseInputFeedback* (no queue for mouse input) and NO for *KeyboardInputFeedback* (queue for keyboard input).

The wait cursor is activated with a mouse input feedback. Disabling the keyboard input feedback allows for a more efficient keyboard input. Above values apply if no parameters are set in the HTML code. The *KeyboardInputFeedback* description is set to YES to make keyboard input more reliable.

To deactivate the wait cursor, both parameters must be set to NO. This means *MouseInputFeedback* is also set to NO. This way, any input will be added to the queue and can take effect without the applet being updated between each input.



If you use the *Background* parameter, you have to enter a value that corresponds to an RGB color code. Do not leave the field empty.



An object cannot be activated temporarily using the [Set digital object temporarily] function for function and touch keys in the terminal mirror.

#### Activating the Java console

In the Microsoft Internet Explorer, it is recommended to activate the Java console for troubleshooting.

1. Select [Extras] / [Internet options] from the menu.
2. Change to the [Expanded] tab.
3. Select the [Java console active] option (restart required).
4. Restart the browser.



Make sure you have the latest version of Microsoft Virtual Machine installed on your PC. You can download the latest version from [www.microsoft.com](http://www.microsoft.com)



### WWW server

A web server (www server) is a program using the client / server model and the Hyper-text Transfer Protocol (HTTP) to transfer files that form web sites of Internet users (with computers with HTTP clients). A web server program must also be installed on all PCs or terminals in the Internet that contain a web site.

### SSI script

An SSI (Server-Side Include) is a variable value (e. g. a file) that a server can add to an HTML file before sending it to a user. Do the following to insert an SSI into an HTML file when creating a web site:

```
<!--#echo var="LAST_MODIFIED"-->
```

The following SSI scripts are supported to display terminal values in HTML pages:

Name	Parameter	Description	Example
get_ipaddr.fn	None	Indicates the IP address of the web server. Is used in the CGI script.	<!--#exec cgi="get_ipaddr.fn"-->
get_domainname.fn	None	Indicates the domain name of the web server.	<!--#exe cgi="get_domainname.fn"-->
get_date.fn	Date format e.g. MM/DD/YY or YY-MM-DD. If not specified, the terminal settings will be used.	Indicates the terminal date.	<!--#exec cgi="/get_date.fn MM/DD/YY"-->
get_time.fn	Time format e.g. HH:MM:SS or HH:MM. If not specified, the terminal settings will be used.	Indicates the terminal time.	<!--#exec cgi="/get_time.fn HH:MM"-->
get_device.fn	X, Y, Z X = device Y = display format (see separate table) Z = length	Indicates the device value (signal value) of the controller.	<!--#exec cgi="/get_device.fn D5"--> <!--#exec cgi="/get_device.fn D5LH"--> <!--#exec cgi="/get_device.fn M7"--> <!--#exec cgi="/get_device.fn D9ST,30"--> <!--#exec cgi="/get_device.fn D0AR,10"-->
get_diag.fn	None	Indicates the diagnostics window of the terminal.	<!--#exec cgi="/get_diag.fn"-->
get_mode.fn	None	Indicates the operating mode of the terminal: [RUN] / [PROG] / [SETUP] / [TRANSFER]	<!--#exec cgi="/get_mode.fn"-->



#### Display format for get\_device.fn

Name	Length	Description	Example
None	None	Indicates the value in signed 16-bit format.	<!--#exec cgi=/get_device.fn D1"-->
+	None	Indicates the value in unsigned 16-bit format.	<!--#exec cgi=/get_device.fn D3+"-->
L	None	Indicates the value in signed 32-bit format.	<!--#exec cgi=/get_device.fn D7L"-->
L+	None	Indicates the value in unsigned 32-bit format.	<!--#exec cgi=/get_device.fn D2L+"-->
RB	None	Indicates the value as 32-bit BCD float (SIMATIC).	<!--#exec cgi=/get_device.fn D10RB"-->
RF	None	Indicates the value as 32-bit IEEE float.	<!--#exec cgi=/get_device.fn D8RF"-->
RD	None	Indicates the value as 32-bit IEEE float without exponent.	<!--#exec cgi=/get_device.fn D1RD"-->
SB	None	Indicates the value in 16-bit BCD format.	<!--#exec cgi=/get_device.fn D3SB"-->
LB	None	Indicates the value in 32-bit BCD format.	<!--#exec cgi=/get_device.fn D7LB"-->
SH	None	Indicates the value in 16-bit HEX format.	<!--#exec cgi=/get_device.fn D2SH"-->
LH	None	Indicates the value in 32-bit HEX format.	<!--#exec cgi=/get_device.fn D1LH"-->
AR	None	Indicates the number of values in signed 16-bit format.	<!--#exec cgi=/get_device.fn D5AR,10"-->
ST	None	Indicates the number of registers as character string.	<!--#exec cgi=/get_device.fn D9ST,30"-->

#### Automatic refresh

The HTML page is usually not automatically refreshed. Adding the following code to the HTML page will enable automatic refresh.

```
<meta http-equiv="Refresh"CONTENT="5">
```

CONTENT specifies how often the page should be refreshed (in seconds).

#### Example of an HTML page with SSI script

```
<HTML>
<HEAD>
<meta http-equiv="Refresh"CONTENT="5">
</HEAD>
<!--#exec cgi="/get_ipaddr.fn"--><BR>
<!--#exec cgi="/get_domainname.fn"--><BR>
<BR>
One IO:<BR>
<!--#exec cgi="/get_date.fn MM/DD/YY"--><BR>
<!--#exec cgi="/get_time.fn HH:MM"--><BR>
D5 = <!--#exec cgi="/get_device.fn D5"--><BR>
M7=<!--#exec cgi="/get_device.fn M7"--><BR>
D9 (string) = <!--#exec cgi="/get_device.fn D9ST,30"--><BR>
D0-D9 =<!--#exec cgi="/get_device.fn D0AR, 10"--><BR>
D8013 = <!--#exec cgi="/get_device.fn D8013"--><BR>
</HTML>
```



### CGI script

CGI (Common Gateway Interface) is a standard method for a web server for managing data for and from the user. When the user opens a web site (by clicking a link or entering an address in the web browser) the server sends back the required page. If you fill in and send a form on a web site, it will usually be received by the application program. The server will return a confirmation. The procedure for data transfer between server and application is referred to as CGI and belongs to the HTTP protocol.

The following CGI scripts are supported to allow for changing values in the terminal:

Name	Parameter	Description	Example
set_date.fn	Date format, e. g. MM/DD/YY or YY-MM-DD. If not specified, the terminal settings will be used.	Is used with FORM to set the date in the terminal.	<pre>&lt;FORM ACTION="http://&lt;!--#exec cgi="/get_ipaddr.fn"--&gt;/ set_date.fn" METHOD="POST"&gt; &lt;INPUT SIZE=10 MAXLENGTH=10 NAME="YY:MM:DD"&gt; &lt;INPUT TYPE="submit" VALUE="Submit"&gt; &lt;/FORM&gt;</pre>
set_time.fn	Time format, e. g. HH:MM:SS or HH:MM. If not specified, the terminal settings will be used.	Is used with FORM to set the time in the terminal.	<pre>&lt;FORM ACTION="http://&lt;!--#exec cgi="/get_ipaddr.fn"--&gt;/ set_time.fn" METHOD="POST"&gt; &lt;INPUT SIZE=10 MAXLENGTH=10 NAME="HH:MM:SS"&gt; &lt;INPUT TYPE="submit" VALUE="Submit"&gt; &lt;/FORM&gt;</pre>
set_device.fn	XY X = device Y = display format (see separate table) e. g. D0L + D5SH	Is used with FORM to set a device (signal) in the controller.	<pre>&lt;FORM ACTION="http://&lt;!--#exec cgi="/get_ipaddr.fn"--&gt;/ set_device.fn" METHOD="POST"&gt; &lt;INPUT SIZE=10 MAXLENGTH=10 NAME="D0L"&gt; &lt;INPUT TYPE="submit" VALUE="Submit"&gt; &lt;/FORM&gt;</pre>
set_mode.fn	RUN PROG SETUP TRANSFER	Is used with FORM to change the operating mode of the terminal.	<pre>&lt;FORM ACTION="http://&lt;!--#exec cgi="/get_ipaddr.fn"--&gt;/ set_mode.fn" METHOD="POST"&gt; &lt;SELECT NAME="MODE"&gt; &lt;OPTION VALUE="RUN"&gt;Run &lt;OPTION VALUE="PROG"&gt;Prog &lt;OPTION VALUE="SETUP"&gt;Setup &lt;OPTION VALUE="TRANSFER"&gt;Transfer &lt;/SELECT&gt; &lt;INPUT TYPE="submit" VALUE="Submit"&gt; &lt;/FORM&gt;</pre>
push_key.fn	(see separate table)	Is used to simulate an activated terminal key	<pre>&lt;FORM ACTION="http://&lt;!--#exec cgi="/get_ipaddr.fn"--&gt;/ push_key.fn" METHOD="POST"&gt; &lt;SELECT NAME="F2"&gt; &lt;OPTION VALUE="SET"&gt;Set &lt;OPTION VALUE="RESET"&gt;Reset &lt;OPTION VALUE="TOGGLE"&gt;Toggle &lt;/SELECT&gt; &lt;INPUT TYPE="submit" VALUE="Submit"&gt; &lt;/FORM&gt; &lt;FORM ACTION="http://&lt;!--#exec cgi="/get_ipaddr.fn"--&gt;/ push_key.fn" METHOD="POST"&gt; &lt;INPUT SIZE=1 MAXLENGTH=1 NAME="Key"&gt; &lt;INPUT TYPE="submit" VALUE="Submit"&gt; &lt;/FORM&gt;</pre>



#### Display format for set\_device.fn

Name	Description
None	Indicates the value in signed 16-bit format.
+	Indicates the value in unsigned 16-bit format.
L	Indicates the value in signed 32-bit format.
L+	Indicates the value in unsigned 32-bit format.
RB	Indicates the value as 32-bit BCD float (SIMATIC).
RF	Indicates the value as 32-bit IEEE float.
RD	Indicates the value as 32-bit IEEE float without exponent.
SB	Indicates the value in 16-bit BCD format.
LB	Indicates the value in 32-bit BCD format.
SH	Indicates the value in 16-bit HEX format.
LH	Indicates the value in 32-bit HEX format.
ST	Indicates the number of registers as character string.





### Parameters for push\_key.fn

Parameter	Description	Example
KEY	Can assume the following values: A-Z 0-9 ACK LIST MAIN PREV BACKSPACE ENTER UP DOWN LEFT RIGHT	<pre>&lt;FORM ACTION="http://&lt;!--#exec cgi="/get_ipaddr.fn"--&gt;/push_key.fn" METHOD="POST"&gt; Key = &lt;SELECT NAME="Key"&gt; &lt;OPTION VALUE="ENTER"&gt;Enter &lt;OPTION VALUE="A"&gt;A &lt;OPTION VALUE="B"&gt;B &lt;OPTION VALUE="1"&gt;1 &lt;OPTION VALUE="2"&gt;2 &lt;OPTION VALUE="3"&gt;3 &lt;OPTION VALUE="UP"&gt;Up &lt;OPTION VALUE="DOWN"&gt;Down &lt;OPTION VALUE="LEFT"&gt;Left &lt;OPTION VALUE="RIGHT"&gt;Right &lt;OPTION VALUE="PREV"&gt;Prev &lt;/SELECT&gt; &lt;INPUT TYPE="submit" VALUE="Submit"&gt; &lt;P&gt; &lt;/FORM&gt;</pre>
F1 - F22	Can assume the following values: SET RESET TOGGLE	<pre>&lt;FORM ACTION="http://&lt;!--#exec cgi="/get_ipaddr.fn"--&gt;/push_key.fn" METHOD="POST"&gt; &lt;SELECT NAME="F2"&gt; &lt;OPTION VALUE="SET"&gt;Set &lt;OPTION VALUE="RESET"&gt;Reset &lt;OPTION VALUE="TOGGLE"&gt;Toggle &lt;/SELECT&gt; &lt;INPUT TYPE="submit" VALUE="Submit"&gt; &lt;/FORM&gt;</pre>

### Example of an HTML page with SSI and CGI scripts

```
<HTML>
<FORM ACTION="http://<!--#exec cgi="/get_ipaddr.fn"-->/ set_date.fn"
METHOD="POST">
Set date here (YY:MM:DD):
<INPUT SIZE=10
    MAXLENGTH=10
    NAME="YY:MM:DD"
    VALUE="<!--#exec cgi="/get_date.fn"-->">
<INPUT TYPE="submit" VALUE="Submit"> <P>
</FORM>
<FORM ACTION="http://<!--#exec cgi="/get_ipaddr.fn"-->/ set_time.fn"
METHOD="POST">
Set time here (HH:MM:SS):
<INPUT SIZE=10
    MAXLENGTH=10
    NAME="HH:MM:SS"
    VALUE="<!--#exec cgi="/get_time.fn"-->">
<INPUT TYPE="submit" VALUE="Submit"> <P>
</FORM>
<FORM ACTION="http://<!--#exec cgi="/get_ipaddr.fn"-->/ set_device.fn"
METHOD="POST">
D0 =
<INPUT SIZE=10
    MAXLENGTH=10
    NAME="D0"
    VALUE="<!--#exec cgi="/get_device.fn D0"-->">
<INPUT TYPE="submit" VALUE="Submit">
</FORM>
</HTML>
```

**Storing HTML files  
via FTP**

An FTP standard client, such as [DOP Tools] \ [DOP FTP Client], is used for transferring and saving HTML files to and on the terminal.

See section "FTP server" on page 233.

The files are stored in (transferred to) the HTML library in the terminal file system.

File names must be assigned in DOS format (8.3). The length of the file name is limited to eight characters. HTM is used as suffix.



The file `INDEX.HTM` must always exist.

**Recommendations and restrictions for network communication**

Optimal signal transfer is required for fast and efficient communication between terminals and controller in a terminal network (BDTP network). Read the section "Efficient communication" in chapter 7.1 and observe the requirements for optimizing the network function in the terminals. A maximum of 3000 signals can be transferred in a terminal network.

**Example 1**

A terminal network consists of three clients and a server. Each client can access 1000 signals. This means the server has to transfer 3000 signals to the individual clients. This is also the case if the address ranges for the signals in the clients are identical. This way the signal transfer capacity in the network is utilized optimally.

**Example 2**

The server should retrieve the addresses that were required by the clients. The server then requests the controller status and sends it to the relevant client.

**Example**

A terminal network (BDTP network) consists of a server and five clients. Each terminal contains 50 alarms with the same address. This means for the server that 50 addresses need to be requested by the controller. In addition, the server must send 50 alarms to the respective client (5 x 50). Consequently, the server must distribute 250 alarms in the network.



- Transparent mode via ETHERNET*
- The following prerequisites must be fulfilled before the [Transparent mode] via ETHERNET communication (TCP/IP protocol) function can be used:
- Driver and programming tools must support communication in transparent mode. (For more information, refer to the driver or controller manual.)
  - You will have to use a program for conversion from COM port to TCP/IP on the PC, if the programming software for the controller supports project transfer via TCP/IP. This program communicates with the controller in transparent mode via TCP/IP network.
- Pass-through mode via ETHERNET*
- A port for communication in pass-through mode can be activated and deactivated using the [DOP Connect] program (icon in the [DOP Tools] program group).
- Communication in transparent mode is possible if the drivers support this mode. See chapter 9.1 "Communication".
- The following prerequisite must be fulfilled before pass-through mode via ETHERNET communication (TCP/IP protocol) can be used:
- You will have to use a program for conversion from COM port to TCP/IP if the programming software for the controller supports project transfer via TCP/IP. This program communicates with the controller in transparent mode via TCP/IP network. (For more detailed information, refer to the driver or controller manual.)
- No protocol mode*
- The [No protocol mode] function, which is used when one or more terminals act as communication interface (see also chapter 9.1 "Communication"), is not recommended for large terminal networks (BDTP networks).
- A large network is a BDTP network with a large amount of signals between server and clients. Control registers and control signals are transferred when the terminal acts as communication interface. Registers and signals negatively influence communication speed and reduce network performance. See section "Efficient communication" in chapter 7.1.
- Signal packages*
- Optimal signal transfer is of great importance for fast and efficient communication between terminals and controller (e. g. in a network). Read the section "Efficient communication" in chapter 7.1 and observe the requirements for optimizing the network function in the terminals. These requirements apply to all stations in the terminal network. The refresh duration may increase if signals are not transferred in packages.



#### Alarm handling

The terminal network is a client / server network. The server contains data (e. g. alarm signals) that are requested by clients. A great number of different signals negatively influence the duration of communication between terminals and controllers in the network. The number of signals should therefore be limited. For further information, refer to chapter 7.1, section "Efficient communication".

The number of alarm signals in the network must not exceed the number of signals the server is capable of processing in the entire network. A server can process between 100 and 300 alarms depending on the application and the terminal. Consequently, a network must not comprise more than a total number of 100 and 300 alarms.


#### Index in the network client

In run mode, index addressing helps to specify the register from which an object should retrieve the displayed value. Index addressing cannot be used in terminals that act as BDTP clients. BDTP clients exclusively use the index register of the BDTP server.

However, the normal requirements for using index addressing apply if a terminal that acts as BDTP client also has a local controller.

## 9.4 Network services

You select the available services for the terminal in the network under [Setup] / [Network] / [Services]. Select the relevant function and click [Edit].



10805AEN

#### Project transfer server

Transfer of projects using TCP/IP. Click on Edit and enter the port number to be specified for a transfer. This value usually need not be changed.

#### BDTP

BDTP is a protocol that uses client/server communication. A client requests information and obtains this information from the server. The BDTP server can receive I/O requests from the BDTP clients. The terminal can be a server, a client, or both at the same time. A client can request data from maximal 16 servers. The IP addresses for the server are specified in the BDTP client. Each server can supply up to 20 clients with information.

Network communication via BDTP is used to connect two or more terminals with one or two controllers, or several terminals with two or more controllers at the same performance level. An example of network communication via BDTP is for production lines with one terminal at each work station.

If the BDTP server fails, the client will continue to use the physically existing system connection. The client does not perform a restart for establishing a connection to the server. If the server is active, BDTP communication will take place as before.



### **BDTP client**

For the BDTP client network service, IP addresses are defined for the BDTP server in the network from which the client will request information. Clicking on [Edit] opens the following dialog.

10986AEN

### **BDTP server port**

Enter the communication port to which the BDTP server or the network is connected. This value usually need not be changed.


### **Standard BDTP server**

You can specify a standard server which will be used by default. If no other entry is made for I/O, the signals will be requested from this server.



Data register

The values in the data register can be transferred between a client and various servers in the network. The first register in the register block of the client that is to be transferred to or from the specified server is defined under Data register. The register type must be the same for client and server.



54652AEN



### Control block

Control block specifies the first register in the control block of the client, which occupies a total of five registers.

Register	Content	Description
Ctrl. reg. 1	Command	Command register defined in the client.
		Available commands:
		0 No command
		1 Transfers the register values from the client to the server specified in control register 3.
		2 Transfers the register values from the server, which is specified in control register 3, to the client.
Ctrl. reg. 2	Result code	Result code register defined in the client.
		Available commands:
		0 Ready for new command
		1 OK
		2 Transfer error
Ctrl. reg. 3	Server index	Number of the server in the network with which the data is exchanged.
Ctrl. reg. 4	Index register	The value in the index register is added to the address of the register specified under Data register. If zero is entered, the register will start for the address specified under Data register.
Ctrl. reg. 5	Number of registers	Number of registers whose values are to be transferred from or to the specified server.

Transfer must take place as follows:

1. The result code register must be set to 0. If not, check whether the command register is set to 0.
2. Enter the command in the command register.
3. Wait for the ready signal or the error code in the result code register.
4. Set the command register to 0. The terminal will then set the result code register to 0.

### Synchronize clock with server

Specify whether you want the clock in the client to be synchronized with a certain server (terminal). Enter the number of the required server in the selection field for this purpose. If the clock in the client is changed locally, the new data will also be transferred to the server.

### BDTP server address

Enter the IP address for the server from which the client is to request data. The addresses are indexed in the order they are entered.

When programming the project, it is essential to specify the server from which the address is to be requested. Enter the text "Index signal of the server" in the address field of the object dialog fields.

For example, if you enter "2>D15" in the address field, the value for the object from register D15 on the server will be retrieved using index 2.

You can change the server index in a client project using the [BDTP station change] function.



If no controller is connected to the BDTP client (terminal), the inverter/PLC 1 and inverter/PLC 2 units must be dragged from the RS-232C / RS-422 / RS-485 interfaces to "Unused functions" in the [Peripheral configuration] dialog. Invoke this dialog from [Setup] / [Peripherals] from the dialog.

#### **BDTP server**

Manages requests from clients: supplies clients (terminals) with information after a request from a client (terminal). Click on Edit and enter the port. This value usually need not be changed.

Parameter	Description
Server port	Communication port for the BDTP server. Usually need not be changed.
Max. clients	Maximum number of BDTP clients (terminals) in the network.
Data register	The values in the data register can be transferred between a server and various clients in the network. The first register in the register block of the server that is to be transferred to or from the specified client is defined under Data register. The register type must be the same for client and server. Data transfer can only be controlled from the clients. For further information on data transfer, refer to section "BDTP client" on page 249.
Clock server	Specify whether you want all other clients in the network to be synchronized to the current server clock. See also section "BDTP client" on page 249.

#### **FTP server**

This function allows for transferring data from a PC to and from the terminal. The FTP server in the terminal supports data transfer in passive mode (PASV). The passive mode should be used if the terminal is not connected using PPP connection. This is necessary because it is not possible to determine in advance which components are connected between client and server, e. g. router based firewalls or gateways.

Using passive mode eliminates several errors. Web browsers use this mode as standard. Passive mode can also be used with PPP connections. National special characters in file names are not supported. The terminals use files without date.

For further information on the FTP server in the terminal, refer to chapter 9.3 "Network functions in the terminal".





To make the settings for this function, select the entry [FTP server] from [Setup] / [Network] / [Services] and click [Edit].

Parameter	Description
Control port number	The standard value is 21 and should not be changed.
Data port number	The standard value is 21 and should not be changed.
Request login	Here you specify whether the user requires to log in to be granted access to the FTP server (terminal). Make the user definition under [Setup] / [Network] / [Accounts]. See chapter 9.5 "Network accounts". If you do not activate this option, all users will have unlimited access right to the FTP server.
Pre login text	Text that appears before the login prompt pops up: e. g. "The terminal requires login. Enter the login data."
Post login text	Text that appears after the login prompt: e. g. "You are logged in."
Connection timeout (min)	Permitted idle time for the FTP connection before the FTP server (terminal) will disconnect the connection. The standard value is 10 minutes.

### SMTP client

This function allows for sending e-mails from the terminal. For using the SMTP client function, a mail server is required to which the message can be sent from the terminal. The receiver retrieves the mail message from the mail server. You can use the mail server of your Internet service provider or a local mail server. You can attach trend and recipe files to an e-mail. The attached files can only be read using DOP Tools. Up to a maximum of 20 messages can be sent simultaneously.

Under [Setup] / [Network] / [Services], select the entry [SMTP server], click [Edit] and make the following settings:

Parameter	Description
Server port	Connection port 25. Usually need not be changed.
Mail server	IP address for the mail server or alias name (DNS server) for the SMTP mail server. If you enter an alias name, you have to enter the IP address for the DNS server under [Setup] / [Network] / [TCP/IP connections].
My domain name	Name of the terminal or another domain (e-mail address) used for logging on to the SMTP server: e. g. the domain name in "mail@master.com" is "master.com".
My e-mail address	Enter your e-mail address. The recipient will see this name as sender. If possible, enter an actual e-mail address to which the mail server can send back error messages in case of an error.
Send via connection	Specify the TCP/IP connection to be used for sending the e-mail. Observe that TCP/IP connection 2 will only be available when TCP/IP connection 1 has been used.
Predefined recipients	Predefined list with maximal 16 recipients, e-mail addresses, to which the terminal will send messages. The maximum length for a recipient address is 60 characters.



#### *Sending alarms by e-mail*

Alarms can not only be printed but can also be sent by e-mail. You can transfer the entire alarm list by sending block 990 (see section "Sending reports by e-mail").

Each alarm can be linked to one or several e-mail addresses in the configuration of the STMP client. You can make a general setting for the status of alarms for being sent by e-mail under [Setup] / [Alarm settings]. See section "Alarm handling" on page 248.

No.	Signal	Alarm when	Alarm Text
1	M25	1	Tank No. 3 is empty
2	D44	>1500	Motor 1 is overloaded

10806AEN

Parameter	Description
Info block	If an info block is specified that is a text block, the info block will be included in the e-mail. See section "Alarm handling" on page 248.
Mail to address	Define the mail recipient. You can choose up to eight recipients from the predefined list in the [Setup STMP Client Service] dialog.



### Sending reports by e-mail

Text blocks can not only be printed but can also be sent by e-mail. Alarm block 990 can also be sent as e-mail.



Only text blocks can be sent. Alarm block 990 is the only system block that can be sent as e-mail. Trend and recipe files can be sent as attachment to the e-mail message. There are restrictions when using Unicode. For further information, refer to chapter 8.8 "Unicode".



10807AEN

Parameter	Description
Block name	The name of the text block will be sent as subject if you enter the name of a text block in this field.
Send mail signal	An e-mail will be sent when the specified digital signal is activated.
Completion signal	Digital signal that is output by the terminal after an e-mail has been sent. The signal is usually activated by the terminal. Selecting the [Reset] option will reset the signal when the e-mail was sent.
Mail to address	The e-mail address of the recipient is entered in this field. Clicking the [...] button enables you to select up to eight recipients from a list. The list with e-mail addresses is created under [Setup] / [Network] / [Services] in the [Create SMTP Client Service] dialog.
Append file	Enter the name of a trend or recipe file you want to attach to your mail. If a trend file and a recipe file have the same name, the trend file will be attached. The file name must not contain national special characters, such as B, Ä, Ö and Ü.



*Sending e-mail via system block*

A block jump to the [E-mail] system block (993) enables you to print and send messages in run mode.



Parameter	Description
Send e-mail to	Enter the recipient. You can type an address or select an entry from the global list. To display the global list, press the <LIST> key on terminals with keyboard, or the <MAIL> key on terminals with touchscreen.
Subject	Enter the subject of your message. The subject length is limited to 50 characters. The message text is limited to 10 lines with 50 characters each.



**Terminal controller**

Is used for changing from RUN to TRANSFER via TCP/IP. Click [Edit] and enter the port number to be specified for a transfer. The port number usually need not be changed. Activate the [User ID] option if user and password should be indicated prior to transfer. Users are defined under [Setup] / [Network] / [Accounts].

**Transparent mode**


Is used for communication in transparent/pass-through mode in the terminal network via ETHERNET (see also chapter 9.1 "Communication" and 9.3 "Network functions"). Click [Configuration Transparent Mode]. In this case, the unit must be connected via TCP/IP.

Parameter	Description
IP settings	Port number 6004 usually need not be changed. Select the required protocol: UDP or TCP.
Inverter / PLC-systems	Define whether you want the transparent / pass-through mode to apply to controller 1 or 2.
Mode	Select transparent or pass-through mode as communication type. Enter a time interval in seconds under [Timeout] after which the terminal will change from pass-through mode back to run mode if no pass-through communication took place.

**WWW server**

You can configure the web server in the terminal with this function. A www server is a program that uses client / server models and the Hypertext Transfer Protocol (HTTP) to transfer files that form web sites of Internet users (with computers with HTTP clients).

See also chapter 9.3 "Network functions in the terminal".



10809AEN



Parameter	Description
Account name	Defining an account name protects HTML pages in the terminal with passwords. Accounts are defined under [Setup] / [Network] / [Accounts].
Password	Enter a password. All HTML pages are protected with this account name and password. To protect an individual page with another account name and password, add the following code to the HTML header: <pre>&lt;HTML&gt;   &lt;HEAD&gt;     &lt;META name="superuser"<sup>1)</sup> content="12345"&gt;   &lt;/HEAD&gt;   Contains the remaining HTML code. &lt;/HTML&gt;</pre>


1) "superuser" stands for the account name and "12345" for the password.



The header must contain the above mentioned code. The *Name* and *Content* parameters must have an account name and a password.

### 9.5 Network accounts

Under [Setup] / [Network] / [Accounts], you can define who may access terminal services that require login. This function creates an authorization check. This means a user name and password are created for various users with access to different services in the network. National special characters are not permitted in account names and passwords.



10809AEN


According to the figure, the account with the name "Superuser" is authorized to access all network functions requiring login. The buttons enable you to update, append and delete accounts in the list.



Parameter	Description
Account name	Enter an account name.
Password	Enter a password for the account.

#### ***Access rights***

Parameter	Description
Serial connect	The user can establish a serial connection (PPP). This option should be activated.
Access terminal controller	Is used for changing from RUN to TRANSFER via TCP/IP. This option should be activated.
FTP Access	The user has read access on the FTP server (terminal).
FTP Write	The user has write access on the FTP server. This also requires FTP access.




## 10 Technical Data and Dimension Drawings

### 10.1 General technical data

#### Display


	DOP11A-10	DOP11A-20	DOP11A-30	DOP11A-40	DOP11A-50
Graphics resolution (pixels)	No graphics	240 x 64	320 x 240	320 x 240	640 x 480
Line x characters text	2 x 20	Graphic			
Active screen size, W x H	73.5 x 11.5 mm	127.2 x 33.9 mm	115.2 x 86.4 mm	115.2 x 86.4 mm	211.2 x 158.4 mm
Background lighting	50,000 h at an ambient temperature of +25 °C. LED.		50,000 h at an ambient temperature of +25 °C. Touchscreen. CFL.	50,000 h at an ambient temperature of +25 °C. CFL.	50,000 h at an ambient temperature of +25 °C. Touchscreen.
Contrast setting	Via slide rule; position: Upper right hand corner on terminal back.	Via system block			
Screen	LCD screen (liquid cristal), monochrome, 2 lines with 20 characters each, 5 mm character size	LCD screen (liquid cristal), 240 x 64 pixels, monochrome, 4 lines with 20 characters each or 8 lines with 40 characters each.	LCD screen (liquid cristal), 320 x 240 pixels, 256 colors (graphics and text)	LCD screen (liquid cristal), 320 x 240 pixels, 256 colors (graphics and text)	TFT screen, 640 x 480 pixels, 256 colors (graphics and text)





### Technical data

	DOP11A-10	DOP11A-20	DOP11A-30	DOP11A-40	DOP11A-50
Keyboard	<ul style="list-style-type: none"><li>Numeric keypad</li><li>Navigation keypad</li><li>Three function keys</li><li>No LEDs</li></ul>	<ul style="list-style-type: none"><li>Numeric keypad</li><li>Navigation keypad</li><li>8 function keys</li><li>16 LEDs (red / green)</li></ul>	Touch resistive	<ul style="list-style-type: none"><li>Numeric keypad</li><li>Navigation keypad</li><li>16 function keys</li><li>16 LEDs (red / green)</li></ul>	Touch resistive
Keyboard material / Material for unit face	Membrane keypad with polyester caps Overlay autotex F207 with back print 1 million operations	Membrane keypad with polyester caps Overlay autotex F207 with back print 1 million operations	Touchscreen Polyester on glass 1 million operations	Membrane keypad with polyester caps Overlay autotex F207 with back print 1 million operations	Touchscreen Polyester on glass 1 million operations
Graphical objects	No	Yes			
Real-time clock	±10 PPM + error display through ambient temperature and supply voltage. Max. total error display: 1 minute/month = 12 minutes/year. The real-time clock battery has a rating life of ten years.				
Supply voltage	DC 24 V (DC 20-30 V), 3-pole terminal contact CE				AC 100-240 V, 50/60 Hz, 3-pole terminal contact CE
	The voltage supply has to meet requirements for SELV according to IEC 950 or IEC 742. UL: Supply voltage according to guidelines for voltage supply class 2.				
Current consumption at operating voltage	Max. 200 mA	Without load: 300 mA Max. load: 450 mA	Max. 400 mA	Without load: 300 mA Max. load with expansion card: 550 mA	Max. 0.17 - 0.35A (AC 240 - 100 V)
Ambient temperature	0 to +50°C				
Storage temperature	-20 to +70°C				
Relative humidity	Max. 85 % (non-condensed)				
Dimensions W x H x D	142 x 90 x 3.5 mm	214 x 194 x 6 mm	200 x 150 x 5 mm	276 x 198 x 5.7 mm	290 x 247 x 6 mm
Installation depth	29 mm without sub D connector and 96.5 mm with sub D connector	69 mm without sub D connector and 110 mm with sub D connector	70 mm without sub D connector and 70 mm with sub D connector	87 mm without sub D connector and 110 mm with sub D connector	109 mm without sub D connector and 130 mm with sub D connector
Enclosure front	IP65, NEMA 4, NEMA 4X (indoor use only)				IP65, NEMA 4
Enclosure back	IP20				
Protection material back	Galvalume	Yellow-chromatized sheet metal			
Weight	Without sub D connector: 0.5 kg	Without sub D connector: 1.5 kg	Without sub D connector: 1.5 kg	Without sub D connector: 1.7 kg	Without sub D connector: 3.3 kg
Memory	Flash memory: 64 kB for application	Flash memory: 400 kB for application			Flash memory: 1600 kB for application
EMC tests on terminal	The terminal conforms with the essential protection requirements in article 4 of the EMC directive 89/336/EEC. Tested according to: EN 50081-1 (emission) and EN 50082-2 (interference immunity).				
UL approval	UL 508, UL 1604 (class I div 2)				
DNV approval	Approval by Det Norske Veritas Typgodkännande in classes temperature A, relative humidity B, vibration A, protection cover C (front cover only).				
Expansion slots	None	1 expansion slot	1 expansion slot	2 expansion slots	2 expansion slots



### Functions


	DOP11A-10	DOP11A-20	DOP11A-30	DOP11A-40	DOP11A-50
Alarm handling	No	Yes			
Intervals per time channel	4				
Recipe management	Yes				
Passthrough mode	Yes				
Dual protocol	Yes				
Web server	No	Yes, with ETHERNET option			
Printer function	Yes				

### Communication

	DOP11A-10	DOP11A-20	DOP11A-30	DOP11A-40	DOP11A-50
Serial interfaces	Separate interface for programming and inverter communication. <ul style="list-style-type: none"><li>• RS-232</li><li>• RS-485/RS-422</li></ul> Two interfaces can be used at the same time.	Separate interface for programming and inverter communication. <ul style="list-style-type: none"><li>• RS-232</li><li>• RS-422</li></ul> Two interfaces can be used at the same time.	Separate interface for programming and inverter communication. <ul style="list-style-type: none"><li>• RS-232</li><li>• RS-422</li><li>• RS-485</li></ul> Two interfaces can be used at the same time.	Separate interface for programming and inverter communication. <ul style="list-style-type: none"><li>• RS-232</li><li>• RS-422</li></ul> Two interfaces can be used at the same time.	Separate interface for programming and inverter communication. <ul style="list-style-type: none"><li>• RS-232</li><li>• RS-422</li></ul> Two interfaces can be used at the same time.
Fieldbus via option slot	No options	PROFIBUS DP or ETHERNET		<ul style="list-style-type: none"><li>• PROFIBUS DP and / or</li><li>• ETHERNET</li></ul>	<ul style="list-style-type: none"><li>• PROFIBUS DP and / or</li><li>• ETHERNET</li></ul>
Serial port RS-422	25-pin sub D connector, installed socket with standard retaining screws 4-40 UNC.				
Serial port RS-232	9-pin sub D connector, installed plug with standard retaining screws 4-40 UNC.				
Serial port RS-485	RS-422 and RS-485 are combined in 25-pin sub D connector. Installed socket with standard retaining screws 4-40 UNC.		4-pin contact, installed plug		

## 10.2 Pin assignment


**RS-232**

D-sub 9-pin plug	Termi- nal no.	Designation	Signal direction operator terminal ↔ XXX
	1	+5 V >200 mA <sup>1)</sup>	←
	2	TxD	→
	3	RxD	←
	5	0 V	
	7	CTS	←
	8	RTS	→
	9		


1) not connected

**RS-485**

For DOP11A-10 only.

D-sub 25-pin socket	Terminal no.	Designation	Signal direction operator terminal ↔ XXX
	2	Tx/Rx+	↔
	15	Tx/Rx-	↔
	6	Tx/Rx -/ 120 Ω <sup>1)</sup>	
	19	Tx/Rx+ <sup>1)</sup>	
	7,8	0 V	

1) Jumper between 6 and 19 active 120  $\Omega$  terminating resistor of RS-485 bus.




For DOP11A-30 only.

D-sub 9-pin plug	Termi- nal no.	Designation	Signal direction operator terminal ↔ XXX
	1	Tx / Rx+	↔
	2	Tx / Rx-	↔
	3	0 V	
	4	⏏	


### RS-422

D-sub 25-pin socket	Termi- nal no.	Designation	Signal direction operator terminal ↔ XXX
	2	+TxD	→
	15	-TxD	
	3	+RxD	←
	16	-RxD	
	4	+RTS	→
	17	-RTS	
	5	+CTS	←
	18	-CTS	
	20	1)	
	21	1)	
	7,8	0 V	
	14	+5 V <50 mA	→
	12,13, 24,25	2) +5 V >200 mA	←
	9	3) TxD	→
	10	3) RxD	←
	22	3) CTS	←
	23	3) RTS	→


- 1) Terminal no. 20 connected internally to terminal no. 21  
 2) For DOP11A-10 only:  
 3) Reserved




**PROFIBUS DP**  
(option card)


D-sub 9-pin socket	Termi- nal no.	Designation	Signal direction operator terminal ↔ XXX
	1		
	2		
	3	RxD/TxD-P	↔
	5	DGND	
	7		
	8	RxD/TxD-NS	↔
	9		

**ETHERNET**  
**10 Base T (option**  
**card)**

RJ45 socket	Termi- nal no.	Designation	Signal direction operator terminal ↔ XXX
	1	Tx+	→
	2	Tx-	→
	3	Rx+	←
	6	Rx-	←




### 10.3 DOP11A-10




**SEW**  
EURODRIVE

**DOP11A-10**


53454AXX




## 10.4 DOP11A-20



53455AXX




### 10.5 DOP11A-30




53458AXX







## 10.6 DOP11A-40



53459AXX



### 10.7 DOP11A-50



**SEW**  
EURODRIVE

**DOP11A-50**

53459AXX

## 11 Appendix

### 11.1 Membrane keypad

#### Autotex 2 resistance to solvents

##### Acceptable substances

The Autotex 2 material of the operator terminal can be exposed to the following substances according to DIN 42 115 part 2 for more than 24 hours without showing any noticeable changes:

- Ethanol
- Cyclohexanol
- Diacetone alcohol
- Glycol
- Isopropanol
- Glycerine
- Methanol
- Triacetin
- Dowanol DRM/PM
- Acetone
- Methyl ethyl ketone
- Dioxan
- Cyclohexanone
- Methylisobutylcetone
- Isophorone
- Ammonia <40%
- Caustic soda <40%
- Caustic potash <30%
- Alkaline carbonate
- Bicarbonate
- Potassium ferricyanide
- Acetonitrile
- Sodium bisulphate
- 1.1.1 Trichloroethane
- Ethyl acetate
- Diethyl ether
- n-butyl acetate
- Amyl acetate
- Ethylen glycol monobutyl ether
- Ether
- Sodium hypochloride <20%
- Hydrogen peroxide <25%
- Potassium carbonate
- Gasolin
- Formaldehyde 37% - 42%
- Ethanal
- Aliphatics
- Toluene
- Xylene
- Mineral spirit
- Formic acid <50%
- Acetic acid <50%
- Phosphoric acid <30%
- Hydrochloric acid <36%
- Nitric acid <10%
- Trichloroacetic acid <50%
- Sulfuric acid <10%
- Cutting oil
- Diesel oil
- Linseed oil
- Parrafin oil
- Blown castor oil
- Silicone oil
- White spirit
- Universal brake oil
- Decon
- Aviation gasoline
- Laundry detergent
- Fabric softener
- Ferrous (III) chloride
- Ferrous (II) chloride
- Dibutyl phthalate
- Diethyl phthalate
- Soda
- Fresh water
- Salt water
- Teepol

Autotex did not show any signs after being exposed to pure acetic acid for less than one hour according to DIN 42 115 part 2.



#### *Harmful substances*



The operator terminal may not get in contact with the following substances.

- Strong mineral acids
- Strong caustic solutions
- High pressure vapor with a temperature of more than 100°C
- Benzyl alcohol
- Dichloromethane

#### *Substances that do not change colors*

Autotext will not change colors when being exposed to the following substances for 24 hours at a temperature of 50°C:

- |                              |                         |                             |
|------------------------------|-------------------------|-----------------------------|
| • Top Job                    | • Grape juice           | • Ariel (laundry detergent) |
| • Ajax                       | • Jet Dry               | • Milk                      |
| • Persil (laundry detergent) | • Vim (cleansing agent) | • Gumption                  |
| • Coffee                     | • Wisk                  | • Domestos                  |
| • Fantastic                  | • Lenor                 | • Vortex                    |
| • Formula 409                | • Downey                | • Windex                    |

#### *Substances that may change colors*



Closer examination showed slight discolorations due to contact with the following substances:

- Tomato juice
- Ketchup
- Lemon juice
- Mustard

## 11.2 Downloading the system program

The operator terminal is delivered with a system program (operating system) stored in the terminal memory. You can replace the system program, e. g. to update it to a newer version. The following equipment is required to load the system program into the terminal:

- PC
- Connection cable between PC and operator terminal (PCS11A)
- PC program `SYSLOAD.EXE` (System loader, icon in the DOP Tools program group)
- File with new system program

Proceed as follows to download the system program:

1. Connect PC and operator terminal using the connection cable.
2. Start the PC program by selecting [Programs] / [Drive Operator Panels DOP] / [DOP Tools] / [DOP System Loader] from the startup menu.

No settings are required in the operator terminal.

You can define the communication port and the transfer speed under [Options] / [Comm Settings] in [DOP-Tools] / [DOP System Loader].



The checkbox for overwriting the controller driver must be activated when replacing the system program with an older version.

If downloading a new system program (\*.bin file) fails after you have clicked on [Send] in [DOP-Tools] / [DOP System Loader], the terminal will automatically enter sysload mode. You can retry to download the system program once the terminal has entered sysload mode.



## 12 Index

### A

Access..... 120, 160  
Accessories..... 20  
Activating the Java console..... 244  
Addressing of parameters and variables..... 62  
Alarm  
    *In run mode* ..... 188  
Alarm banner..... 143  
Alarm handling ..... 184, 252  
Alarm import..... 187  
Alarm library ALARMS ..... 239  
Alarm messages ..... 185  
Alarm settings ..... 186  
Alarms  
    *Alarm grouping* ..... 184  
    *Alarm message*..... 185  
    *Defining alarm groups* ..... 184  
    *Graphic alarm page*..... 190  
    *Handling* ..... 184  
    *Import* ..... 187  
    *Sending by e-mail*..... 258  
    *Settings*..... 186  
Alphanumeric keyboard ..... 157  
Alphanumeric keys..... 35  
Analog clock graphic object ..... 145  
Analog filling graphic objects..... 144  
Analog graphic objects..... 127  
Analog numeric object..... 132  
Analog numeric table graphic object..... 151  
Append recipe ..... 193  
Applet, signed ..... 243  
Application language..... 203  
Application languages in run mode..... 205  
Arrow keys ..... 36  
ASCII objects ..... 137

### B

Bar diagram graphic object ..... 133  
BDTP..... 252  
BDTP client ..... 253  
BDTP server..... 255, 256  
BDTP station change ..... 95  
Block ..... 56  
    *Create (using the Block Manager)*..... 73  
    *Define* ..... 74  
    *Defining the block header*..... 75  
    *Programming* ..... 80  
Block list ..... 99  
Block manager ..... 99, 115  
    *Settings*..... 115  
Boot error ..... 49  
Built-in function keys ..... 36

### C

Cable specification  
    *ETHERNET* ..... 29  
    *PROFIBUS* ..... 31  
    *RS-485*..... 26  
Calculate ..... 191  
Calculating technical units..... 118, 159  
Calculating the trend data size ..... 213  
CGI script ..... 247  
Change project settings ..... 72  
Changing operator terminal..... 72  
Changing the controller ..... 72  
Colors ..... 118  
Communication with MOVIDRIVE®  
and MOVITRAC® 07..... 59  
    *Addressing of parameters and variables* . 62  
    *Communication settings in the HMI-Builder*60  
    *Communication with inverters*  
        *connected via RS-485* ..... 64  
    *Indexed communication with inverters*  
        *connected via RS-485* ..... 65  
    *Serial connection between operator*  
        *terminal and inverter* ..... 59  
Communication with two controllers..... 220  
Communication, effective ..... 53  
Configuration mode (SETUP) ..... 39  
Connection of the basic unit ..... 23  
Connection PFE11A Ethernet option ..... 29  
Connection PFP11A PROFIBUS-DP option .. 30  
Connection RS-422 ..... 28  
Connection to a PC ..... 24  
Connection to SEW frequency inverter ..... 11  
Connection to Siemens S7 via  
    MPI & PCM11A ..... 31  
    Connection UWS11A ..... 28  
Connection, ETHERNET ..... 231  
Connection, serial ..... 59  
Contrast setting ..... 39  
Control..... 12  
Control codes for the printer..... 201  
Control, graphic..... 118  
Country settings ..... 107  
Create and transfer recipes  
with the controller program..... 194  
Create recipes on the terminal ..... 193  
Creating a project..... 52  
    *Blocks* ..... 56  
    *Effective communication*..... 53  
    *Menu structure*..... 54  
    *Programming a project* ..... 52  
    *Signal formats*..... 56

### D

Data exchange between controllers ..... 221



Date format .....	108
Defining printouts .....	200
Defining safety levels .....	196
Defining time channels .....	201
Delete recipes .....	194
Digital clock graphic object .....	146
Digital filling graphic object .....	130
Digital graphic objects .....	126
Digital symbol graphic object .....	129
Digital text graphic object .....	128
Dimension drawing .....	
<i>DOP11A-10</i> .....	270
<i>DOP11A-20</i> .....	271
<i>DOP11A-30</i> .....	272
<i>DOP11A-40</i> .....	273
<i>DOP11A-50</i> .....	274
Display .....	264
Display, graphic .....	118
Downloading the system program .....	277
Driver update .....	
<i>From disk</i> .....	71
Dynamic text objects .....	161
Dynamics .....	120

## E

Engineering units .....	118
Engineering units scaling .....	159
Error indication .....	49
Error messages .....	49
ETHERNET 10 Base T (option card) .....	269
ETHERNET connections .....	231
ETHERNET, network communication .....	230
Expansion cards .....	
<i>PFE11A for ETHERNET TCP/IP</i> .....	170
<i>PFP11A for PROFIBUS-DP</i> .....	175

## F

Font .....	119
Frequency inverter, connection .....	11
FTP server .....	237, 256
Function keys .....	210
<i>Built-in</i> .....	36
<i>Define</i> .....	78, 210
<i>Global</i> .....	210
<i>Jump to block</i> .....	213
<i>Local</i> .....	210
Functions, operator terminal .....	35

## G

General parameters .....	118, 159
Graphic block manager .....	81
<i>Create objects</i> .....	84
<i>Create tables</i> .....	87
<i>Cursor</i> .....	81
<i>Group objects</i> .....	87
<i>Keys</i> .....	81
<i>Mouse</i> .....	81

<i>Open</i> .....	81
<i>Position objects</i> .....	85
<i>Select several objects</i> .....	84
<i>Symbols</i> .....	88
<i>Toolbox</i> .....	83
Graphic display and control .....	118
Graphic object diagram .....	134
Graphic objects .....	125
<i>Alarm banner</i> .....	143
<i>Analog clock</i> .....	145
<i>Analog filling</i> .....	144
<i>Analog numeric</i> .....	132
<i>Analog numeric table</i> .....	151
<i>ASCII</i> .....	137
<i>Bar diagram</i> .....	133
<i>Diagram</i> .....	134
<i>Digital clock</i> .....	146
<i>Digital filling</i> .....	130
<i>Digital symbol</i> .....	129
<i>Digital text</i> .....	128
<i>Dynamic analog</i> .....	127
<i>Dynamic bitmap handling</i> .....	126
<i>Dynamic digital</i> .....	126
<i>Jump</i> .....	131
<i>Message</i> .....	150
<i>Multiple symbol</i> .....	147, 148
<i>Slider</i> .....	138
<i>Speedometer</i> .....	142
<i>Static / dynamic</i> .....	125
<i>Touch key</i> .....	149
<i>Trend</i> .....	139
<i>VU-meter</i> .....	136

## H

Harmful substances .....	276
HMI-Builder .....	
<i>Choose language</i> .....	68
<i>Communication settings</i> .....	60
<i>Creating a project</i> .....	68
<i>Description</i> .....	57
<i>Installation</i> .....	57
<i>Menu</i> .....	58
<i>Start</i> .....	68
<i>Status bar</i> .....	58
<i>System requirements</i> .....	57
<i>Updating drivers</i> .....	70
HTML library .....	239

## I

I/O browser .....	79
I/O change .....	94
I/O cross reference .....	95
Index addressing .....	178
Index in the network client .....	252
Initial operation .....	32
Input feedback .....	244
Installation .....	12, 22



<i>UL compliant</i> .....	23	<i>Object</i> .....	116
Installation, HMI-Builder.....	57	<i>Setup</i> .....	103
Installing drivers.....	70	<i>Symbol manager</i> .....	100
Introduction.....	9	<i>Toolbar</i> .....	101
Inverter		<i>Transfer</i> .....	117
<i>Communication via RS-485</i> .....	64	<i>View</i> .....	99
<i>Indexed communication via RS-485</i> .....	65	<i>Window</i> .....	117
<b>J</b>		Message graphic object.....	150
Joystick functions.....	41	Message library.....	182
Jump object.....	131	Modem	
<b>K</b>		<i>Connect</i> .....	227
Key combinations.....	36	<i>Settings</i> .....	168
Keyboard in the terminal.....	35	<i>Transfer</i> .....	167
<b>L</b>		Multi language functions.....	207
Language handling.....	202	Multiple symbol graphic object.....	147, 148
<i>Application</i> .....	202	<b>N</b>	
<i>Copy object</i> .....	205	Name list.....	100
<i>Cross reference</i> .....	205	Nameplate.....	14
<i>Language index</i> .....	205	Network communication.....	229
<i>Unicode</i> .....	205	<i>FTP server</i> .....	237
Language index.....	205	<i>Recommendations</i> .....	250
LEDs.....	209	<i>Restrictions</i> .....	250
<i>Define</i> .....	78	<i>Serial</i> .....	232
Library		<i>STMP client</i> .....	242
<i>ALARMS</i> .....	239	<i>Via ETHERNET</i> .....	230
<i>HTML</i> .....	239	Network services.....	252
<i>IMAGES</i> .....	241	No protocol mode.....	225, 251
<i>RECIPE</i> .....	239	<b>O</b>	
<i>Root library</i> .....	238	Operating display at unit start.....	48
<i>TRENDS</i> .....	240	Operating graphic blocks.....	153
Linking blocks with alarms.....	189	Operating modes (RUN and SETUP).....	38
List of errors.....	50	Operating text blocks.....	162
Login.....	197	Operation error.....	50
<b>M</b>		Operational environment.....	6
Macros.....	217	Option card	
<i>Activate</i> .....	219	<i>ETHERNET 10 Base T</i> .....	269
<i>Add</i> .....	217	<i>PROFIBUS DP</i> .....	269
<i>Edit</i> .....	219	Options.....	20
Maneuverable objects.....	153	Options, terminal.....	110
<i>Analog objects</i> .....	154	<b>P</b>	
<i>Digital objects</i> .....	154	Pass-through mode.....	224
<i>Select</i> .....	153	Pass-through mode via ETHERNET.....	251
Membrane keypad.....	275	Passwords.....	196
Menu		<i>Change during operation</i> .....	198
<i>Block list</i> .....	99	<i>Define</i> .....	197
<i>Block manager</i> .....	99, 115	<i>For project transfer</i> .....	197
<i>Edit</i> .....	98	<i>Multi-access</i> .....	197
<i>File</i> .....	97	Peripherals.....	111
<i>Functions</i> .....	102	Pin assignment.....	267
<i>Help</i> .....	117	<i>RS-232</i> .....	267
<i>I/O cross reference</i> .....	100	<i>RS-422</i> .....	268
<i>Layout</i> .....	116	<i>RS-485</i> .....	267
<i>Name list</i> .....	100	Print status.....	201
		Printer	





<i>Connection</i> .....	198	Scope of delivery .....	14
<i>Control codes</i> .....	201	Sending alarms by e-mail .....	258
<i>Settings</i> .....	200	Sending e-mail via system block .....	260
<i>Status</i> .....	201	Sending reports by e-mail .....	259
Printer connection .....	198	Serial connection .....	59
Printer settings .....	200	Serial network communication .....	232
Printing graphic blocks .....	199	Serial transfer .....	167
Printing projects .....	198	Service .....	51
Printing text blocks .....	199	Setting the real-time clock .....	40
PROFIBUS DP (option card) .....	269	Setting up a communication port .....	200
Programming .....	11, 52	Setting up the operator terminal .....	12
Programming software		Show terminal .....	78
<i>Choose language</i> .....	68	Signal formats .....	56
<i>Creating a project</i> .....	68	Signal packages .....	251
<i>Description</i> .....	57	Signed applet .....	243
<i>Installation</i> .....	57	Slider graphic objects .....	138
<i>Menu</i> .....	58	Speedometer graphic object .....	142
<i>Starting the HMI-Builder</i> .....	68	SSI script .....	245
<i>Status bar</i> .....	58	Startup .....	32
<i>Updating drivers</i> .....	70	Status display .....	12
Project		STMP client .....	242, 257
<i>Change settings</i> .....	72	Storing HTML files via FTP .....	250
<i>Creating</i> .....	68	Switch .....	38
<i>Print</i> .....	198	Symbol manager .....	91
<i>transfer</i> .....	44, 163	<i>Create</i> .....	92
Project transfer .....	44, 163	<i>Delete</i> .....	93
<i>Transfer settings</i> .....	164	<i>Duplicate</i> .....	92
<b>R</b>		<i>Edit</i> .....	92
Recipe directory .....	192	<i>Export</i> .....	91
<i>In run mode</i> .....	192	<i>Import</i> .....	91
Recipe handling		<i>More function</i> .....	92
<i>Append</i> .....	193	<i>Static symbol</i> .....	93
<i>Calculating recipe size</i> .....	191	Symbols	
<i>Create</i> .....	193	<i>Create</i> .....	88
<i>Delete</i> .....	194	System signals .....	103
<i>Per controller program</i> .....	194	<b>T</b>	
<i>Transfer</i> .....	193	TCP/IP transfer .....	167
Recipe library RECIPE .....	239	Technical data .....	264
Recipe management .....	190	<i>Communication</i> .....	266
Recipe settings .....	191	<i>display</i> .....	264
Recipe size .....	191	<i>Functions</i> .....	266
Repair .....	51	<i>General</i> .....	265
Reserved characters .....	36	Terminal applet .....	242
Resistance to solvents .....	275	Terminal controller .....	261
Return codes .....	50	Terminal font .....	206
Root library .....	238	Terminal mapping .....	242
RS-485		Terminal options .....	110
<i>Communication with inverters</i> .....	64	Text	
<i>Indexed communication with inverters</i> .....	65	<i>Digital text object</i> .....	128
RS-485 connection .....	25	Text block manager	
Run mode (RUN) .....	40	<i>Define</i> .....	90
<b>S</b>		<i>Keys</i> .....	89
Safety function .....	6	<i>Mouse</i> .....	89
Safety notes .....	5, 7	<i>Open</i> .....	89
Scaling .....	118	<i>Toolbox</i> .....	89
		Text objects, dynamic .....	161



Text-based display and control .....	159
Time control .....	201
Time format.....	108
Toolbar .....	101
Toolbox	
<i>Graphic block manager</i> .....	83
<i>Text block manager</i> .....	89
Touch key graphic object .....	149
Touchscreen .....	155
Transfer recipes to the controller .....	193
Transfer settings, projects.....	164
Transfer trend files .....	216
Transfer, modem.....	167
Transfer, serial .....	167
Transfer, TCP/IP .....	167
Transferring.....	163
Transparent mode.....	222, 261
Transparent mode via ETHERNET .....	251
Trend library TRENDS .....	240
Trends .....	213
<i>Calculating the trend data size</i> .....	213
<i>continuous values</i> .....	213
<i>Real-time trend</i> .....	214
<i>Trend files</i> .....	216
<i>Trend objects</i> .....	139, 214
Two drivers.....	220

## U

UL compliant installation .....	23
Unicode .....	206
<i>In the programming software</i> .....	206
<i>Limitations</i> .....	208
Unit design DOP11A-10.....	15
Unit design DOP11A-20.....	16
Unit design DOP11A-30.....	17
Unit design DOP11A-40.....	18
Unit design DOP11A-50.....	19
Unit designation .....	14
Updating drivers	
<i>From the Internet</i> .....	70
Use dynamic bitmaps.....	126
Use terminal as communication interface ....	225
User defined system language.....	204

## V

Voltage supply.....	23
VU-meter graphic objects.....	136

## W

Wait cursor .....	244
Warning instructions.....	5
Waste disposal.....	6
WWW server .....	245, 261



## Address List

Germany			
<b>Headquarters Production Sales</b>	<b>Bruchsal</b>	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal P.O. Box Postfach 3023 · D-76642 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 <a href="http://www.sew-eurodrive.de">http://www.sew-eurodrive.de</a> <a href="mailto:sew@sew-eurodrive.de">sew@sew-eurodrive.de</a>
<b>Service Competence Center</b>	<b>Central</b> Gear units / Motors	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf	Tel. +49 7251 75-1710 Fax +49 7251 75-1711 <a href="mailto:sc-mitte-gm@sew-eurodrive.de">sc-mitte-gm@sew-eurodrive.de</a>
	<b>Central</b> Electronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal	Tel. +49 7251 75-1780 Fax +49 7251 75-1769 <a href="mailto:sc-mitte-e@sew-eurodrive.de">sc-mitte-e@sew-eurodrive.de</a>
	<b>North</b>	SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 40-42 D-30823 Garbsen (near Hannover)	Tel. +49 5137 8798-30 Fax +49 5137 8798-55 <a href="mailto:sc-nord@sew-eurodrive.de">sc-nord@sew-eurodrive.de</a>
	<b>East</b>	SEW-EURODRIVE GmbH & Co KG Dänkritzer Weg 1 D-08393 Meerane (near Zwickau)	Tel. +49 3764 7606-0 Fax +49 3764 7606-30 <a href="mailto:sc-ost@sew-eurodrive.de">sc-ost@sew-eurodrive.de</a>
	<b>South</b>	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 D-85551 Kirchheim (near München)	Tel. +49 89 909552-10 Fax +49 89 909552-50 <a href="mailto:sc-sued@sew-eurodrive.de">sc-sued@sew-eurodrive.de</a>
	<b>West</b>	SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 D-40764 Langenfeld (near Düsseldorf)	Tel. +49 2173 8507-30 Fax +49 2173 8507-55 <a href="mailto:sc-west@sew-eurodrive.de">sc-west@sew-eurodrive.de</a>
	<b>Drive Service Hotline / 24 Hour Service</b>		+49 180 5 SEWHELP +49 180 5 7394357
	Additional addresses for service in Germany provided on request!		
France			
<b>Production Sales Service</b>	<b>Haguenau</b>	SEW-USOCOME 48-54, route de Soufflenheim B. P. 20185 F-67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 <a href="http://www.usocomme.com">http://www.usocomme.com</a> <a href="mailto:sew@usocomme.com">sew@usocomme.com</a>
<b>Assembly Sales Service</b>	<b>Bordeaux</b>	SEW-USOCOME Parc d'activités de Magellan 62, avenue de Magellan - B. P. 182 F-33607 Pessac Cedex	Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09
	<b>Lyon</b>	SEW-USOCOME Parc d'Affaires Roosevelt Rue Jacques Tati F-69120 Vaulx en Velin	Tel. +33 4 72 15 37 00 Fax +33 4 72 15 37 15
	<b>Paris</b>	SEW-USOCOME Zone industrielle 2, rue Denis Papin F-77390 Verneuil l'Etang	Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88
Additional addresses for service in France provided on request!			
Algeria			
<b>Sales</b>	<b>Alger</b>	Réducom 16, rue des Frères Zaghoun Bellevue El-Harrach 16200 Alger	Tel. +213 21 8222-84 Fax +213 21 8222-84
Argentina			
<b>Assembly Sales Service</b>	<b>Buenos Aires</b>	SEW EURODRIVE ARGENTINA S.A. Centro Industrial Garin, Lote 35 Ruta Panamericana Km 37,5 1619 Garin	Tel. +54 3327 4572-84 Fax +54 3327 4572-21 <a href="mailto:sewar@sew-eurodrive.com.ar">sewar@sew-eurodrive.com.ar</a>



## Address List

Australia			
Assembly Sales Service	Melbourne	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 <a href="http://www.sew-eurodrive.com.au">http://www.sew-eurodrive.com.au</a> <a href="mailto:enquires@sew-eurodrive.com.au">enquires@sew-eurodrive.com.au</a>
	Sydney	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. +61 2 9725-9900 Fax +61 2 9725-9905 <a href="mailto:enquires@sew-eurodrive.com.au">enquires@sew-eurodrive.com.au</a>
Austria			
Assembly Sales Service	Wien	SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Strasse 24 A-1230 Wien	Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 <a href="http://sew-eurodrive.at">http://sew-eurodrive.at</a> <a href="mailto:sew@sew-eurodrive.at">sew@sew-eurodrive.at</a>
Belgium			
Assembly Sales Service	Brüssel	SEW Caron-Vector S.A. Avenue Eiffel 5 B-1300 Wavre	Tel. +32 10 231-311 Fax +32 10 231-336 <a href="http://www.caron-vector.be">http://www.caron-vector.be</a> <a href="mailto:info@caron-vector.be">info@caron-vector.be</a>
Brazil			
Production Sales Service	Sao Paulo	SEW-EURODRIVE Brasil Ltda. Avenida Amâncio Gaiolli, 50 Caixa Postal: 201-07111-970 Guarulhos/SP - Cep.: 07251-250	Tel. +55 11 6489-9133 Fax +55 11 6480-3328 <a href="http://www.sew.com.br">http://www.sew.com.br</a> <a href="mailto:sew@sew.com.br">sew@sew.com.br</a>
	Additional addresses for service in Brazil provided on request!		
Bulgaria			
Sales	Sofia	BEVER-DRIVE GmbH Bogdanovetz Str.1 BG-1606 Sofia	Tel. +359 2 9532565 Fax +359 2 9549345 <a href="mailto:bever@fastbg.net">bever@fastbg.net</a>
Cameroon			
Sales	Douala	Electro-Services Rue Drouot Akwa B.P. 2024 Douala	Tel. +237 4322-99 Fax +237 4277-03
Canada			
Assembly Sales Service	Toronto	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, Ontario L6T3W1	Tel. +1 905 791-1553 Fax +1 905 791-2999 <a href="http://www.sew-eurodrive.ca">http://www.sew-eurodrive.ca</a> <a href="mailto:l.reynolds@sew-eurodrive.ca">l.reynolds@sew-eurodrive.ca</a>
	Vancouver	SEW-EURODRIVE CO. OF CANADA LTD. 7188 Honeyman Street Delta. B.C. V4G 1 E2	Tel. +1 604 946-5535 Fax +1 604 946-2513 <a href="mailto:b.wake@sew-eurodrive.ca">b.wake@sew-eurodrive.ca</a>
	Montreal	SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger Street LaSalle, Quebec H8N 2V9	Tel. +1 514 367-1124 Fax +1 514 367-3677 <a href="mailto:a.peluso@sew-eurodrive.ca">a.peluso@sew-eurodrive.ca</a>
Additional addresses for service in Canada provided on request!			
Chile			
Assembly Sales Service	Santiago de Chile	SEW-EURODRIVE CHILE LTDA. Las Encinas 1295 Parque Industrial Valle Grande LAMP RCH-Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile	Tel. +56 2 75770-00 Fax +56 2 75770-01 <a href="mailto:ventas@sew-eurodrive.cl">ventas@sew-eurodrive.cl</a>
China			
Production Assembly Sales Service	Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 46, 7th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25322611 <a href="mailto:gm-tianjin@sew-eurodrive.cn">gm-tianjin@sew-eurodrive.cn</a> <a href="http://www.sew.com.cn">http://www.sew.com.cn</a>



<b>China</b>			
<b>Assembly Sales Service</b>	<b>Suzhou</b>	SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021 P. R. China	Tel. +86 512 62581781 Fax +86 512 62581783 suzhou@sew.com.cn
<b>Colombia</b>			
<b>Assembly Sales Service</b>	<b>Bogotá</b>	SEW-EURODRIVE COLOMBIA LTDA. Calle 22 No. 132-60 Bodega 6, Manzana B Santafé de Bogotá	Tel. +57 1 54750-50 Fax +57 1 54750-44 sewcol@andinet.com
<b>Croatia</b>			
<b>Sales Service</b>	<b>Zagreb</b>	KOMPEKS d. o. o. PIT Erdödy 4 II HR 10 000 Zagreb	Tel. +385 1 4613-158 Fax +385 1 4613-158 kompeks@net.hr
<b>Czech Republic</b>			
<b>Sales</b>	<b>Praha</b>	SEW-EURODRIVE CZ S.R.O. Business Centrum Praha Luná 591 CZ-16000 Praha 6 - Vokovice	Tel. +420 220121236 Fax +420 220121237 <a href="http://www.sew-eurodrive.cz">http://www.sew-eurodrive.cz</a> sew@sew-eurodrive.cz
<b>Denmark</b>			
<b>Assembly Sales Service</b>	<b>Kopenhagen</b>	SEW-EURODRIVEA/S Geminivej 28-30, P.O. Box 100 DK-2670 Greve	Tel. +45 43 9585-00 Fax +45 43 9585-09 <a href="http://www.sew-eurodrive.dk">http://www.sew-eurodrive.dk</a> sew@sew-eurodrive.dk
<b>Estonia</b>			
<b>Sales</b>	<b>Tallin</b>	ALAS-KUUL AS Paldiski mnt.125 EE 0006 Tallin	Tel. +372 6593230 Fax +372 6593231 veiko.soots@alas-kuul.ee
<b>Finland</b>			
<b>Assembly Sales Service</b>	<b>Lahti</b>	SEW-EURODRIVE OY Vesimäentie 4 FIN-15860 Hollola 2	Tel. +358 201 589-300 Fax +358 3 780-6211 <a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a> sew@sew.fi
<b>Gabon</b>			
<b>Sales</b>	<b>Libreville</b>	Electro-Services B.P. 1889 Libreville	Tel. +241 7340-11 Fax +241 7340-12
<b>Great Britain</b>			
<b>Assembly Sales Service</b>	<b>Normanton</b>	SEW-EURODRIVE Ltd. Beckbridge Industrial Estate P.O. Box No.1 GB-Normanton, West- Yorkshire WF6 1QR	Tel. +44 1924 893-855 Fax +44 1924 893-702 <a href="http://www.sew-eurodrive.co.uk">http://www.sew-eurodrive.co.uk</a> info@sew-eurodrive.co.uk
<b>Greece</b>			
<b>Sales Service</b>	<b>Athen</b>	Christ. Boznos & Son S.A. 12, Mavromichali Street P.O. Box 80136, GR-18545 Piraeus	Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 <a href="http://www.boznos.gr">http://www.boznos.gr</a> info@boznos.gr
<b>Hong Kong</b>			
<b>Assembly Sales Service</b>	<b>Hong Kong</b>	SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong	Tel. +852 2 7960477 + 79604654 Fax +852 2 7959129 sew@sewhk.com



## Address List

Hungary			
<b>Sales Service</b>	<b>Budapest</b>	SEW-EURODRIVE Kft. H-1037 Budapest Kunigunda u. 18	Tel. +36 1 437 06-58 Fax +36 1 437 06-50 office@sew-eurodrive.hu
India			
<b>Assembly Sales Service</b>	<b>Baroda</b>	SEW-EURODRIVE India Pvt. Ltd. Plot No. 4, Gidc Por Ramangamdi · Baroda - 391 243 Gujarat	Tel. +91 265 2831086 Fax +91 265 2831087 mdoffice@seweurodriveindia.com
<b>Technical Offices</b>	<b>Bangalore</b>	SEW-EURODRIVE India Private Limited 308, Prestige Centre Point 7, Edward Road Bangalore	Tel. +91 80 22266565 Fax +91 80 22266569 salesbang@seweurodriveinindia.com
	<b>Mumbai</b>	SEW-EURODRIVE India Private Limited 312 A, 3rd Floor, Acme Plaza Andheri Kurla Road, Andheri (E) Mumbai	Tel. +91 22 28348440 Fax +91 22 28217858 salesmumbai@seweurodriveindia.com
Ireland			
<b>Sales Service</b>	<b>Dublin</b>	Alpertons Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11	Tel. +353 1 830-6277 Fax +353 1 830-6458
Israel			
<b>Sales</b>	<b>Tel-Aviv</b>	Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon	Tel. +972 3 5599511 Fax +972 3 5599512 lirazhandasa@barak-online.net
Italy			
<b>Assembly Sales Service</b>	<b>Milano</b>	SEW-EURODRIVE di R. Blicke & Co.s.a.s. Via Bernini,14 I-20020 Solaro (Milano)	Tel. +39 2 96 9801 Fax +39 2 96 799781 sewit@sew-eurodrive.it
Ivory Coast			
<b>Sales</b>	<b>Abidjan</b>	SICA Ste industrielle et commerciale pour l'Afrique 165, Bld de Marseille B.P. 2323, Abidjan 08	Tel. +225 2579-44 Fax +225 2584-36
Japan			
<b>Assembly Sales Service</b>	<b>Toyoda-cho</b>	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Toyoda-cho, Iwata gun Shizuoka prefecture, 438-0818	Tel. +81 538 373811 Fax +81 538 373814 sewjapan@sew-eurodrive.co.jp
Korea			
<b>Assembly Sales Service</b>	<b>Ansan-City</b>	SEW-EURODRIVE KOREA CO., LTD. B 601-4, Banweol Industrial Estate Unit 1048-4, Shingil-Dong Ansan 425-120	Tel. +82 31 492-8051 Fax +82 31 492-8056 master@sew-korea.co.kr
Latvia			
<b>Sales</b>	<b>Riga</b>	SIA Alas-Kuul Katlakalna 11C LV-1073 Riga	Tel. +371 7139386 Fax +371 7139386 info@alas-kuul.ee
Lebanon			
<b>Sales</b>	<b>Beirut</b>	Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut	Tel. +961 1 4947-86 +961 1 4982-72 +961 3 2745-39 Fax +961 1 4949-71 gacar@beirut.com



<b>Lithuania</b>			
<b>Sales</b>	<b>Alytus</b>	UAB Irseva Merkines g. 2A LT-62252 Alytus	Tel. +370 315 79204 Fax +370 315 56175 info@irseva.lt www.sew-eurodrive.lt
<b>Luxembourg</b>			
<b>Assembly Sales Service</b>	<b>Brüssel</b>	CARON-VECTOR S.A. Avenue Eiffel 5 B-1300 Wavre	Tel. +32 10 231-311 Fax +32 10 231-336 http://www.caron-vector.be info@caron-vector.be
<b>Malaysia</b>			
<b>Assembly Sales Service</b>	<b>Johore</b>	SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia	Tel. +60 7 3549409 Fax +60 7 3541404 kchtan@pd.jaring.my
<b>Mexico</b>			
<b>Assembly Sales Service</b>	<b>Queretaro</b>	SEW-EURODRIVE, Sales and Distribution, S. A. de C. V. Privada Tequisquiapan No. 102 Parque Ind. Queretaro C. P. 76220 Queretaro, Mexico	Tel. +52 442 1030-300 Fax +52 442 1030-301 scmexico@seweurodrive.com.mx
<b>Morocco</b>			
<b>Sales</b>	<b>Casablanca</b>	S. R. M. Société de Réalisations Mécaniques 5, rue Emir Abdelkader 05 Casablanca	Tel. +212 2 6186-69 + 6186-70 + 6186-71 Fax +212 2 6215-88 srm@marocnet.net.ma
<b>Netherlands</b>			
<b>Assembly Sales Service</b>	<b>Rotterdam</b>	VECTOR Aandrijftechniek B.V. Industrieweg 175 NL-3044 AS Rotterdam Postbus 10085 NL-3004 AB Rotterdam	Tel. +31 10 4463-700 Fax +31 10 4155-552 http://www.vector.nu info@vector.nu
<b>New Zealand</b>			
<b>Assembly Sales Service</b>	<b>Auckland</b>	SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. +64 9 2745627 Fax +64 9 2740165 sales@sew-eurodrive.co.nz
	<b>Christchurch</b>	SEW-EURODRIVE NEW ZEALAND LTD. 10 Settlers Crescent, Ferrymead Christchurch	Tel. +64 3 384-6251 Fax +64 3 384-6455 sales@sew-eurodrive.co.nz
<b>Norway</b>			
<b>Assembly Sales Service</b>	<b>Moss</b>	SEW-EURODRIVE A/S Solgaard skog 71 N-1599 Moss	Tel. +47 69 241-020 Fax +47 69 241-040 sew@sew-eurodrive.no
<b>Peru</b>			
<b>Assembly Sales Service</b>	<b>Lima</b>	SEW DEL PERU MOTORES REDUCTORES S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima	Tel. +51 1 3495280 Fax +51 1 3493002 sewperu@sew-eurodrive.com.pe
<b>Poland</b>			
<b>Assembly Sales Service</b>	<b>Lodz</b>	SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 PL-92-518 Lodz	Tel. +48 42 67710-90 Fax +48 42 67710-99 http://www.sew-eurodrive.pl sew@sew-eurodrive.pl




## Address List


Portugal			
Assembly Sales Service	Coimbra	SEW-EURODRIVE, LDA. Apartado 15 P-3050-901 Mealhada	Tel. +351 231 20 9670 Fax +351 231 20 3685 <a href="http://www.sew-eurodrive.pt">http://www.sew-eurodrive.pt</a> <a href="mailto:infosew@sew-eurodrive.pt">infosew@sew-eurodrive.pt</a>
Romania			
Sales Service	Bucuresti	Sialco Trading SRL str. Madrid nr.4 011785 Bucuresti	Tel. +40 21 230-1328 Fax +40 21 230-7170 <a href="mailto:sialco@sialco.ro">sialco@sialco.ro</a>
Russia			
Sales	St. Petersburg	ZAO SEW-EURODRIVE P.O. Box 263 RUS-195220 St. Petersburg	Tel. +7 812 5357142 +812 5350430 Fax +7 812 5352287 <a href="http://www.sew-eurodrive.ru">http://www.sew-eurodrive.ru</a> <a href="mailto:sew@sew-eurodrive.ru">sew@sew-eurodrive.ru</a>
Senegal			
Sales	Dakar	SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar	Tel. +221 849 47-70 Fax +221 849 47-71 <a href="mailto:senemeca@sentoo.sn">senemeca@sentoo.sn</a>
Serbia and Montenegro			
Sales	Beograd	DIPAR d.o.o. Kajmakcalanska 54 SCG-11000 Beograd	Tel. +381 11 3088677 / +381 11 3088678 Fax +381 11 3809380 <a href="mailto:dipar@yubc.net">dipar@yubc.net</a>
Singapore			
Assembly Sales Service	Singapore	SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644	Tel. +65 68621701 Fax +65 68612827 <a href="mailto:sewsingapore@sew-eurodrive.com">sewsingapore@sew-eurodrive.com</a>
Slovakia			
Sales	Sereď	SEW-Eurodrive SK s.r.o. Trnavská 920 SK-926 01 Sereď	Tel. +421 31 7891311 Fax +421 31 7891312 <a href="mailto:sew@sew-eurodrive.sk">sew@sew-eurodrive.sk</a>
Slovenia			
Sales Service	Celje	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 SLO – 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 <a href="mailto:pakman@siol.net">pakman@siol.net</a>
South Africa			
Assembly Sales Service	Johannesburg	SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 494-3104 <a href="mailto:dross@sew.co.za">dross@sew.co.za</a>
	Capetown	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442 Cape Town	Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 <a href="mailto:dswanepoel@sew.co.za">dswanepoel@sew.co.za</a>
	Durban	SEW-EURODRIVE (PROPRIETARY) LIMITED 2 Monaceo Place Pinetown Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 700-3451 Fax +27 31 700-3847 <a href="mailto:dtait@sew.co.za">dtait@sew.co.za</a>





<b>Spain</b>			
<b>Assembly Sales Service</b>	<b>Bilbao</b>	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 E-48170 Zamudio (Vizcaya)	Tel. +34 9 4431 84-70 Fax +34 9 4431 84-71 sew.spain@sew-eurodrive.es
<b>Sweden</b>			
<b>Assembly Sales Service</b>	<b>Jönköping</b>	SEW-EURODRIVE AB Gnejsvägen 6-8 S-55303 Jönköping Box 3100 S-55003 Jönköping	Tel. +46 36 3442-00 Fax +46 36 3442-80 http://www.sew-eurodrive.se info@sew-eurodrive.se
<b>Switzerland</b>			
<b>Assembly Sales Service</b>	<b>Basel</b>	Alfred Imhof A.G. Jurastrasse 10 CH-4142 Münchenstein bei Basel	Tel. +41 61 41717-17 Fax +41 61 41717-00 http://www.imhof-sew.ch info@imhof-sew.ch
<b>Thailand</b>			
<b>Assembly Sales Service</b>	<b>Chon Buri</b>	SEW-EURODRIVE (Thailand) Ltd. Bangpakong Industrial Park 2 700/456, Moo.7, Tambol Donhuaroh Muang District Chon Buri 20000	Tel. +66 38 454281 Fax +66 38 454288 sewthailand@sew-eurodrive.co.th
<b>Tunisia</b>			
<b>Sales</b>	<b>Tunis</b>	T. M.S. Technic Marketing Service 7, rue Ibn El Heithem Z.I. SMMT 2014 Mégrine Erriadh	Tel. +216 1 4340-64 + 1 4320-29 Fax +216 1 4329-76
<b>Turkey</b>			
<b>Assembly Sales Service</b>	<b>Istanbul</b>	SEW-EURODRIVE Hareket Sistemleri Sirketi Bagdat Cad. Koruma Cikmazi No. 3 TR-34846 Maltepe ISTANBUL	Tel. +90 216 4419163 + 216 4419164 + 216 3838014 Fax +90 216 3055867 sew@sew-eurodrive.com.tr
<b>USA</b>			
<b>Production Assembly Sales Service</b>	<b>Greenville</b>	SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365	Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Manuf. +1 864 439-9948 Fax Ass. +1 864 439-0566 Telex 805 550 http://www.seweurodrive.com cslyman@seweurodrive.com
<b>Assembly Sales Service</b>	<b>San Francisco</b>	SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, California 94544-7101	Tel. +1 510 487-3560 Fax +1 510 487-6381 cshayward@seweurodrive.com
	<b>Philadelphia/PA</b>	SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. +1 856 467-2277 Fax +1 856 845-3179 csbridgeport@seweurodrive.com
	<b>Dayton</b>	SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. +1 937 335-0036 Fax +1 937 440-3799 cstroy@seweurodrive.com
	<b>Dallas</b>	SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237	Tel. +1 214 330-4824 Fax +1 214 330-4724 csdallas@seweurodrive.com
Additional addresses for service in the USA provided on request!			
<b>Venezuela</b>			
<b>Assembly Sales Service</b>	<b>Valencia</b>	SEW-EURODRIVE Venezuela S.A. Av. Norte Sur No. 3, Galpon 84-319 Zona Industrial Municipal Norte Valencia, Estado Carabobo	Tel. +58 241 832-9804 Fax +58 241 838-6275 sewventas@cantv.net sewfinanzas@cantv.net





## How we're driving the world

With people who think fast and develop the future with you.



With a worldwide service network that is always close at hand.



With drives and controls that automatically improve your productivity.



With comprehensive knowledge in virtually every branch of industry today.



With uncompromising quality that reduces the cost and complexity of daily operations.



With a global presence that offers responsive and reliable solutions. Anywhere.

With innovative technology that solves tomorrow's problems today.



**SEW-EURODRIVE**  
Driving the world

With online information and software updates, via the Internet, available around the clock.



**SEW**  
**EURODRIVE**

SEW-EURODRIVE GmbH & Co KG  
P.O. Box 3023 · D-76642 Bruchsal / Germany  
Phone +49 7251 75-0 · Fax +49 7251 75-1970  
sew@sew-eurodrive.com

→ [www.sew-eurodrive.com](http://www.sew-eurodrive.com)