



ICS465

Weighing terminals Compact scales



METTLER TOLEDO Service

Congratulations on choosing the quality and precision of METTLER TOLEDO. Proper use according to these instructions and regular calibration and maintenance by our factory-trained service team ensure dependable and accurate operation to protect your investment. Contact us about a ServiceXXL agreement tailored to your needs and budget.

We invite you to register your product at

www.mt.com/productregistration

so we can contact you about enhancements, updates and important notifications concerning your METTLER TOLEDO product.

Contents

1	Introduction.....	5
1.1	Safety instructions	5
1.2	Presentation.....	6
1.3	Commissioning	14
2	Operation.....	18
2.1	Switching on and off	18
2.2	Simple weighing.....	18
2.3	Switching units.....	18
2.4	Zeroing / Zero point correction	19
2.5	Weighing with tare.....	19
2.6	Displaying information	21
2.7	Printing results	21
2.8	Average (dynamic) weighing.....	22
2.9	Working with identifications	23
2.10	Working in a higher resolution	23
2.11	Working with a prompt.....	24
2.12	Calling up alibi log file.....	27
2.13	Switching scales.....	27
2.14	Cleaning.....	28
2.15	Verification test.....	28
3	Counting.....	29
3.1	Counting parts into a container	29
3.2	Counting parts out of a container	29
3.3	Determining the parts in a full container.....	30
3.4	Counting with a known average piece weight	30
3.5	Counting with variable reference quantity	30
3.6	Counting with reference weight check	30
3.7	Reference optimisation	31
3.8	Counting with automatic reference determination	31
3.9	Counting with two scales.....	32
3.10	Counting by calling up an article from the database	33
4	Checkweighing	34
4.1	Specifying target values.....	34
4.2	Checkweighing procedure.....	37
4.3	Checkweighing during subtractive weighing	39
4.4	Checkweighing with "Quick start"	39
4.5	Checkweighing to zero	40
4.6	Terminating Checkweighing	41

5	Totalisation	42
5.1	Starting totalisation	42
5.2	Totalising manually	42
5.3	Automatic totalising	43
5.4	Deleting items from the sum	43
5.5	Terminating totalising	43
6	Settings in the menu.....	44
6.1	Operating the menu	44
6.2	Scale menu block	47
6.3	Application menu block	51
6.4	Terminal menu block.....	59
6.5	Communication menu block	63
6.6	Maintenance menu block.....	72
7	Event and error messages.....	74
7.1	Error conditions	74
7.2	Errors and warnings.....	75
7.3	Smart weighing counter / spanner icon	76
7.4	Service information	76
8	Technical data and accessories.....	77
8.1	Technical data weighing terminal	77
8.2	Technical data weighing platforms	79
8.3	Dimensional drawings	81
8.4	Accessories.....	82
9	Appendix	84
9.1	Notice for verified instruments in EC countries	84
9.2	Tables of Geo Code values.....	84
9.3	Disposal	86
9.4	Protocol printouts	87
9.5	Index.....	88

1 Introduction

1.1 Safety instructions



General

- ▲ Do not use the device in a hazardous environment. Special devices are available in our range of products for hazardous environments.
- ▲ The safety of the device cannot be ensured if it is not operated in accordance with these operating instructions.
- ▲ Only authorised personnel may open the device.



Devices with protection level IP65

Devices with protection level IP65 are dust-tight and protected from water jets according to EN 60529. They are suitable for use in dusty environment and brief contact with liquids.

- ▲ Ensure that the device is dried off again after coming into contact with liquid.
- ▲ Do not use the device in environments with a risk of corrosion.
- ▲ Do not flood the device or submerge it in liquid.



Devices with built-in power supply unit

- ▲ Ensure that the power socket outlet for the device is earthed and easily accessible, so that it can be de-energised rapidly in emergencies.
- ▲ Ensure that the supply voltage at the installation site lies within the range of 100 V to 240 V.
- ▲ Check the power cable regularly for damage. If it is damaged, immediately disconnect the device from the power supply unit.



Devices with built-in storage battery

- ▲ Only use storage batteries from the manufacturer.
- ▲ Do not use the battery charger in humid or dusty rooms or below 0 °C (32 °F) ambient temperature.
- ▲ After the storage battery has been charged, the cover cap of the charging socket at the device must be closed.




Compact scales

- ▲ Avoid falling loads, shock loads as well as impacts from the side.

1.2

Presentation

1.2.1



Weighing terminals

There are two versions of the ICS465 weighing terminal:

ICS465a with **analog** scale interface:
to connect analog weighing platforms

ICS465d with **digital** scale interface SICSpro, which is based on RS422:
to connect METTLER TOLEDO weighing platforms with digital scale interface SICSpro, e.g., PBD 655

1.2.2

Compact scales




A compact scale consists of a weighing terminal with digital scale interface SICSpro and a weighing platform which are fixed together.

Depending on the connected weighing platform there are two basic versions of the ICS465 compact scales:

ICS465d-.../f ICS465 compact scale with strain gauge load cell

ICS465k-.../f ICS465 compact scale with MonoBloc® load cell

The weighing platforms are available in three different sizes as shown below.

ICS465d-...XS/f ICS465k-...XS/f ICS465k-...XS/DR/f	ICS465d-...SM/f ICS465k-...SM/f ICS465k-...SM/DR/f	ICS465d-...LA/f ICS465k-...LA/f ICS465k-...LA/DR/f
		
extra small weighing platform	small weighing platform	large weighing platform

Naming

The complete name of a compact scale also indicates the type, size and capacity of the connected weighing platform. E.g., ICS465k-6SM/DR/M/f stands for

ICS465k ICS465 terminal, weighing platform with MonoBloc® load cell

6 weighing capacity in kg

SM size of the weighing platform

DR if present: Delta Range weighing platform

M if present: weighing platform verified by the manufacturer

/f mechanical design: fixed connection

1.2.3 Options

Interfaces

Default equipment ICS465a / ICS465d weighing terminals

- 1 serial interface RS232
- 1 analog scale interface resp. digital scale interface SICSpro

ICS465d.../f / ICS465k.../f compact scales

- 1 serial interface RS232
- 1 digital scale interface SICSpro

One additional interface is possible.

- RS232 (usable as data interface or SICS scale)
- RS422/485 (usable as data interface or scale interface SICSpro)
- USB Device
- USB Host
- Ethernet
- WLAN
- Digital I/O
- Analog scale

Weighing platform resolutions for compact scales

	Default	Optional
ICS465d-.../f	1 x 6,000 d, non-approved	1 x 30,000 d, non-approved 1 x 60,000 d, non-approved 1 x 6,000 d, approved, e = d
ICS465k-.../f	up to 1 x 610,000 d, non-approved	up to 1 x 61,000 d, approved, e = 10d


Further options

- Exchangeable storage battery (IP54)
- Built-in storage battery (IP65)
- Alibi memory

1.2.4

Display

To meet your special requirements different display layouts are available in the Terminal menu.

Straight weighing display**Default layout**

- 1 Metrological data – for details see following table
- 2 Weight value with star, sign and stability monitor – for details see following table
- 3 Spanner icon: service needed – for details see Event and error messages
- 4 Battery symbol
- 5 Net/Gross
- 6 Unit
- 7 Soft keys (factory setting, page 1)
- 8 Auxiliary data line – the contents is defined in the menu; here: bargraph
- 9 Symbol and info line – for details see following table

Weight values in 3-line mode**Bargraph**

The device offers a bargraph indicating the scale capacity available.



The bargraph indicates roughly which part of the scale capacity is already occupied and what capacity is still available.

In the example, approx. 3/4 of the scale capacity is occupied, although the applied net weight isn't really high. The reason therefore could be a high tare weight.

Metrological data line



The metrological data are stored in the weighing platform. The weighing terminal only serves as indicator.

In the metrological data line the following information is displayed:

Symbol	Information	Remark
	Accuracy classes	Displayed only if the scale is approved according to the Weights and Measures guidelines
W1 , W2 , W3	Weighing range information	For multi range devices only, displayed only if the scale is approved according to the Weights and Measures guidelines
Max , cap	Maximum capacity	–
Min	Minimum capacity	Displayed only if the scale is approved according to the OIML Weights and Measures guidelines
e =	Approved resolution	OIML: Displayed only if the scale is approved NTEP: Displayed only if the scale is approved and d is different from e
d =	Display resolution	Please note for approved scales: OIML: Displayed only if d is different from e NTEP: Displayed always
Approved scale	Approved weighing device	Metrology display disabled, Weights and Measures data must be indicated on a label near the weight display






Weight value

The weight value can be marked with the following symbols:

Symbol	Information	Remark
*	Calculated weight value	E.g., for average weighing results
–	Sign	For negative weight values
○	Stability monitor	For unstable weight values
1.2343 kg	Non-approved last digit with $e > d$	For approved scales only The example shows the weight value for a scale with $e = 1 \text{ g}$ and $d = 0.1 \text{ g}$ The last, smaller digit is not approved

Symbols and info line

In the symbols and info line the following information can be displayed:

Symbol	Information	Remark
←→ 1	Weighing range	For multi range or multi interval scales only
△ ⁺ △	Scale number	–
	Weight below minimum weight	MinWeigh must be activated in the menu
	Average weighing	Average must be activated in the menu
	Automatic taring	Auto Tare must be activated in the menu
	Automatic clearing of the tare weight	A-Clear Tare must be activated in the menu
↓0	Checkweighing to zero	To zero must be assigned to a soft key in the menu
>0<	Center of zero indication	Availability depending on local Weights and Measures regulations
	Automatic APW optimisation	APW optimisation must be set to Auto
Σ	Totalisation	–

1.2.5

Keyboard









Key	Name	Function in the operating mode	Function in the menu
	Power	<ul style="list-style-type: none"> Switching on and off Cancel editing 	<ul style="list-style-type: none"> Cancel editing Exit menu
	Clear	<ul style="list-style-type: none"> Clear tare Leave info page Leave counting 	<ul style="list-style-type: none"> Clear value Clear digit
	Switch	<ul style="list-style-type: none"> Switch over weight unit 	<ul style="list-style-type: none"> Re-edit
	Zero	<ul style="list-style-type: none"> Set scale to zero Clear tare 	–
	Tare	<ul style="list-style-type: none"> Tare scale Clear tare 	–
	Info	<ul style="list-style-type: none"> Activate info screen Proceed to next info line / info page Freeze and release startup screen 	–
	Transfer	<ul style="list-style-type: none"> Transfer data to a printer or computer 	<ul style="list-style-type: none"> Confirm entry / selection

1.2.6

Soft keys

To meet your specific application requirements, ICS465 offers 16 soft keys which can be configured in the `Terminal` menu. The soft keys are divided into four lines (pages).

Factory setting














Page 1					
	Reference n here: 10 pieces	APW	Average weighing	Checkweighing	Scroll to page 2
Page 2	Σ		Alibi		
	Totalising		Alibi memory		Scroll to page 3


Page 3, Page 4 Pages 3 and 4 are free for customer configuration.
When scrolling from page 4, page 1 is displayed again.

Operating soft keys

→ Press the key below the desired function.

Soft key options

Symbol	Menu setting	Function
	Zero	
	Tare	
x 10	High resolution	Show the weight value with 10 times higher resolution
	Average weighing	Start average weighing
ID1, ID2, ID3	ID1, ID2, ID3	Enter identifications
Prompt	Prompt	Starting a predefined workflow. The user will be guided step by step.
Alibi	Alibi memory	Calling up the optional alibi memory
	Switch scale	
	Ref n	Determine the average piece weight
	APW	Enter the average piece weight
	APW optimisation	Reference weight optimisation
	Weight/count	Switch between weight display and display of pieces
	ToZero	Checkweighing to zero
Σ	Totalising	
	Checkweighing	
	Save article	Save the current article parameters in the database
	Recall article	Recall parameters from the database
	Display layout	Switch between default weight display and 3-line mode

1.2.7**Connections**


- 1** AC power supply or battery charging
- 2** Standard interface COM1 (RS232)
- 3** Optional interface COM2 incl. digital scale interface SICSpro and SICS scale
- 4** Weighing platform connection SCALE 2, to connect analog weighing platforms only
- 5** (Digital) weighing platform connection SCALE 1


The SCALE connections for analog weighing platforms are without plug, but with cable exit.

1.3**Commissioning****1.3.1****Selecting the location**

The correct location is crucial to the accuracy of the weighing results.

- Select a stable, vibration-free and, if possible, a horizontal location for the weighing platform.
The ground must be able to safely bear the weight of the fully loaded weighing platform.
- Observe the following environmental conditions:
 - No direct sunlight
 - No strong drafts
 - No excessive temperature fluctuations



1.3.2**Levelling the weighing platform**

Only weighing platforms that have been levelled precisely horizontally provide accurate weighing results. Weights and Measures approved weighing platforms have a spirit level to simplify levelling.

→ Turn the adjustable feet of the weighing platform until the spirit level's air bubble is inside the inner circle.

Levelling of compact scales

On compact scales levelling can be done in an easier way.

1. Turn the compact scale upside down.
2. Unscrew the plastic screw in the middle of the terminal front side far enough that it does support the terminal.
3. Screw in the 2 adjustable feet on the side facing the terminal.
4. Turn over the compact scale into its normal position.
5. Level the compact scale by turning the other 2 adjustable feet of the weighing platform until the spirit level's air bubble is inside the inner circle.

1.3.3**Weighing platform connection****Analog weighing platforms**

→ Call the METTLER TOLEDO service technician to connect an analog weighing platform to the ICS465a weighing terminal.

Weighing platforms with digital scale interface SICSpro

→ Connect the weighing platform connector to the ICS465d weighing terminal.



- If you have ordered an approved weighing system consisting of an ICS465d weighing terminal and an approved PBD... weighing platform, the approval was done in the factory.
- Due to the new digital scale interface SICSpro, you can disconnect the weighing platform from the weighing terminal of an approved weighing system without violating the approval.
 - If another weighing platform is connected to the weighing terminal, the system is not approved.
 - If the weighing platform of the approved system is connected again, the approval is valid again.
- If you have connected a non-approved weighing platform and want to approve the system, call the METTLER TOLEDO service technician.

1.3.4

Power supply connection**CAUTION****Risk of electric shock!**

- ▲ Before connecting the power supply, check whether the voltage value printed on the rating plate corresponds to your local system voltage.
- ▲ Do not under any circumstances connect the device if the voltage value on the rating plate deviates from the local system voltage.
- ▲ Make sure the weighing platform has reached room temperature before switching on the power supply.

→ Plug the power plug into the power socket.
After it has been connected, the device runs a self-test. The device is ready to operate when zero appears on the display.

1.3.5

Handling of the storage battery

Note the following when operating a device with a built-in storage battery:



- The operating life depends on the intensity of use, the configuration and the connected scale. For details see the technical data.
- The battery symbol shows the current state of charge of the storage battery.
 - One segment corresponds with approx. 25 % capacity.
 - If the symbol flashes, the storage battery has to be charged.
 - During charging the segments are "running" until the battery is fully charged and all segments light up continuously.
- The charging time of the storage battery amounts to approx. 6 hours.
The storage battery is protected against overcharging.
- The storage battery has a service life of approx. 2 years or 500 to 1,000 charging/discharging cycles.

**CAUTION****No success in charging the storage battery due to low temperatures!**


- ▲ Do not charge the battery if the battery temperature is below 0 °C (32 °F). Charging is not possible in this temperature range.
- ▲ Do not operate the battery charger outside its temperature range of 0 °C to 40 °C (32 °F to 104 °F).

Recommended use of the storage battery

The characteristics mentioned above are only valid if the following recommendations are observed:

- Change the battery as soon as the warning message "Low battery" appears and the battery symbol starts flashing. When the message appears you still have enough time (at least 10 minutes) to complete your current task.
- For optimum battery performance operate the device with built-in storage battery at an ambient temperature in the range of 10 °C to 30 °C (50 °F to 86 °F). This applies to discharging as well as charging the battery.
- If you plan to put the scale out of operation for a longer period, charge the battery completely.
- Even if you do not use the instrument, charge the battery at least every 3 months to avoid deep discharge.
- On devices with removable battery, remove the battery prior to long term storage.

Changing battery



1. Unlock the battery by moving the slider to the outside and remove the discharged battery.
2. Insert the fully charged battery and secure it by moving the slider to the inside.



With optional IP65 protection, the battery is not accessible from the outside. Please call the METTLER TOLEDO service technician.

2 Operation

2.1 Switching on and off

2.1.1 Switching on/off

Switching on → Press .

For a few seconds the device shows a start-up screen with device name, software version, serial number of the weighing terminal and the Geo value (not for MonoBloc® weighing platforms).




- You can freeze the start-up screen by pressing **i**.
- When you start a compact scale, the metrology line shows whether it is approved or not. If you have ordered an approved compact scale, approval has been done in the factory already.
- When user management is active, you are asked to select your name and enter the corresponding password.


Switching off → Press .

Before the display goes out, **-OFF-** appears briefly.

2.1.2 Resetting


→ Press and hold  for approx. 5 seconds.
The device is reset and will operate with the last saved settings.

2.2 Simple weighing

1. Place weighing sample on the scale.
2. Wait until the stability monitor  goes out.
3. Read the weighing result.

2.3 Switching units

If an additional second weight unit is configured in the menu, it is possible to switch back and forth between the two weight units.

→ Press .

The weight value is displayed in the second unit.



Possible units are g, kg, oz, lb, lb-oz, t and PCS in piece counting.

2.4 Zeroing / Zero point correction

Zeroing corrects the influence of slight changes on the load plate or minor deviations from the zero point.

- Manual**
1. Unload scale.
 2. Press **→0←**.
Zero appears in the display.

Automatic In case of non-verified scales, the automatic zero point correction can be deactivated in the menu or the zero range can be changed. Approved scales are set fixed to 0.5 d. By default, the zero point of the scale is automatically corrected when the scale is unloaded.



- The zero function is only available within a limited weighing range.
- After zeroing the scale, the whole weighing range is still available.
- A successful zeroing will always delete a tare weight.

2.5 Weighing with tare


2.5.1 Taring

- Place the empty container on the scale and press **→T←**.
The zero display and the symbol **NET** appear.
The tare weight remains stored until it is cleared.

2.5.2 Clearing the tare

- Press **C**.
The symbol **NET** goes out, the gross weight appears in the display.




If the symbol  is displayed, i.e., the **A-Clear Tare** function is activated in the menu under **Scale -> Tare**, the tare weight is automatically cleared as soon as the scale is unloaded.

2.5.3 Automatic clearing of the tare

A tare weight is automatically cleared when the scale is unloaded.


Prerequisite

- ✓ The symbol  is displayed, i.e., the tare function **A-Clear Tare** is activated in the **Scale** menu.

2.5.4**Automatic taring**

If you place a weight on an empty scale, the scale tares automatically and the symbol **NET** is displayed.

Prerequisite

- ✓ The symbol  is displayed, i.e., the tare function `Auto Tare` is activated in the `Scale` menu.



The weight to be tared automatically, e.g., packaging material, must be heavier than 9 display steps of the scale.

2.5.5**Chain tare**

With this function it is possible to tare several times if, e.g., cardboard is placed between individual layers in a container.

Prerequisite

- ✓ The tare function `Chain tare` is activated in the `Scale` menu.

1. Place the first container or packaging material on the scale and press **→T←**.
The packaging weight is automatically saved as the tare weight, the zero display and the symbol **NET** appear.
2. Weigh the weighing sample and read/print out the result.
3. Place the second container or packaging material on the scale and press **→T←** again.
The total weight on the scale is saved as the new tare weight. The zero display appears.
4. Weigh the weighing sample in the second container and read/print the result.
5. Repeat steps 3 and 4 for other containers.

2.5.6**Tare preset**

If you know the weight of your containers, you can enter the tare weight numerically. Thus you do not have to tare the empty container.

1. Enter the known tare weight and press **→T←** to confirm.
The weight display shows the negative tare weight and the symbol **NET** appears.
2. Place the full container on the weighing platform.
The net weight is displayed.



- The entered tare weight is valid until a new tare weight is entered or the tare weight is cleared.
- The tare weight can be entered via barcode or SICS command as well.

2.6 Displaying information

Up to 5 different items for display can be configured in the menu for the info key. Depending on the configuration in the `Terminal` menu, the following data can be assigned in a free order, e.g.,

- Date & Time
- Weight values
- Identifications
- Device information
- Serial numbers and software versions

On the second and third info page, system and contact information can be displayed.


1. Press **i**.
The (first) info page is displayed.
2. Press **i** again.
The next info screen is displayed.
3. To leave the info screens, press **C**.



An info screen is displayed until **i** is pressed again or **C** is pressed.

2.7 Printing results


If a printer or computer is connected, weighing results and other information can be printed or transferred to a computer.

- Press .
- The defined data is printed or transferred to the computer.



The printout content can be defined in the `Templates` menu.

2.8 Average (dynamic) weighing

With the average weighing function, it is possible to weigh restless weighing samples such as living animals. If this function is activated,  is displayed in the info line.

With average weighing, the scale calculates the mean value from weighing operations within a certain time interval. The time interval for calculation can be set in the Application menu.

Start via soft key (factory setting)

✓ Weighing sample heavier than 9 scale divisions.

1. Place the weighing sample on the scale.
2. Press the soft key  to start average weighing.

During average weighing, stars appear in the display, and the average result will be displayed with the symbol *.

3. Unload the scale to be able to start a new average weighing operation.

Start via hard key

✓ Application -> Average -> Mode -> Print key (factory setting), Info key or Switch key is selected in the menu.

✓ Weighing sample heavier than 9 scale divisions.

1. Place the weighing sample on the scale.
2. Press the key defined in the menu to start average weighing.

During average weighing, stars appear in the display, and the average result will be displayed with the symbol *.

3. Unload the scale to be able to perform a new average weighing operation.

With automatic start

✓ Application -> Average -> Mode -> Auto is selected in the menu.

✓ Weighing sample heavier than 9 scale divisions.

1. Place the weighing sample on the scale.
Average weighing starts automatically.

During average weighing, stars appear in the display, and the average result will be displayed with the symbol *.


2. Unload the scale to be able to perform a new average weighing operation.

2.9 Working with identifications

Weighing series can be assigned 3 identification numbers ID1, ID2 and ID3 with up to 40 characters that are also printed out in the protocols. If for example a customer number and an article number are assigned, it can be clearly seen in the protocol which article was weighed for which customer.

Direct entry

✓ At least one of the soft keys ID1, ID2 or ID3 is activated in the Terminal menu.

1. Press the desired soft key ID1, ID2 or ID3.
The last entered ID is displayed.
 2. Enter the ID and confirm with .
- The entered ID is assigned to the following weighings until the ID is changed.

Barcode use (for one identification only)

- ✓ ID1, ID2 or ID3 is selected as destination for external input in the Communication menu.
- ✓ To display the identification, in the Terminal menu ID1, ID2 or ID3 is activated for an auxiliary line.

Using SICS command set (up to three identifications)

- ✓ To display the identification(s), in the Terminal menu ID1, ID2 and/or ID3 is activated for the auxiliary line.

2.10 Working in a higher resolution

The weight value can be displayed in a higher resolution continuously or when called.

Prerequisite

✓ Soft key `x10 Display` is activated in the Terminal menu.

→ Press soft key **x10**.

The weight value is displayed in at least 10x higher resolution and is marked with the symbol *****.

The higher resolution is displayed until the soft key **x10** is displayed again.



With verified weighing platforms, the weight value only appears in a higher resolution as long as the soft key **x10** is pressed.

2.11 Working with a prompt

ICS465 offers prompts for often used workflows. The weighing terminal will then lead you from step to step.

In the `Application` menu one of the following prompts can be activated:

- Tare/Sample
- Sample/Tare
- Hands free
- Multi tare
- Additive tare


During prompting no other soft keys are available.

2.11.1 Tare/Sample


This prompt will guide you through piece counting with first taring and then determining the average piece weight.

1. Press the soft key **Prompt**.

In the soft key line the following is displayed:



2. Load the tare weight and confirm with the soft key below the symbol.
The soft key line changes.



3. Put on the indicated number of reference parts and confirm with the soft key below the symbol.

The display unit changes to PCS and the soft key line changes.



4. Put on the weighing samples and read the number of pieces.
5. To leave piece counting press the soft key **C**.
"Cleared" is displayed briefly.



If a printer is connected, each individual result can be printed out by pressing .

2.11.2

Sample/Tare

This prompt will guide you through piece counting with first determining the average piece weight and then taring.


1. Press the soft key **Prompt**.

In the soft key line the following is displayed:



2. Put on the indicated number of reference parts and confirm with the soft key below the symbol.

The display unit changes to PCS and the soft key line changes.




3. Load the tare weight and confirm with the soft key below the symbol.
"0 PCS" is displayed and the soft key line changes.



4. Put on the weighing samples and read the number of pieces.
5. To leave piece counting press the soft key **C**.
"Cleared" is displayed briefly.



If a printer is connected, each individual result can be printed out by pressing .

2.11.3

Hands free

This prompt will guide you through piece counting without pressing a key.

1. Press the soft key **Prompt**.

In the soft key line the following instruction is displayed:

"Put on weight and wait for Auto tare."

2. Put on the tare weight.

When the weight is stable, an automatic taring is carried out.

In the soft key line the next instruction is displayed:

"Load ... reference parts and wait for Auto ref n."

3. Load the indicated number of reference parts.

The weight unit changes to PCS and the following soft key line is displayed:



4. Put on the weighing samples and read the number of pieces.
5. To leave piece counting press the soft key **C**.
"Cleared" is displayed briefly.

2.11.4

Multi tare

This prompt will guide you through taring a bundle of containers with the same known tare weight.

1. Press the soft key **Prompt**.
The number of containers (n) is highlighted.

2. Enter the number of containers and confirm entry with the soft key **OK**.
The tare value of a single container is highlighted.
3. Enter the known tare weight of a single container and confirm entry with the soft key **OK**.
When all entries are made, the weight display is shown.
E.g., with a bundle 6 containers of 0.4 kg each, a PT value of 2.4 kg is displayed for the whole bundle.
4. Weigh the bundles.
The net weight of the bundle is displayed without extra taring.
5. To leave prompting press **C**.
"Cleared" is displayed briefly.

2.11.5

Additive tare

This prompt will guide you through taring e.g., a pallet with containers on it with known tare weights.

1. Press the soft key **Prompt**.
The following screen is displayed:

#	Tare Value	Unit
1	1.00	kg
2	1.00	kg

2. Enter the known tare weights and confirm each entry with the soft key **OK**.
 - Use the soft key **↓** to proceed to the next tare weight. When there is no more tare weight entered, the marking switches to the first tare weight.
 - Use the soft key **↶** to delete a tare weight.
3. When all tare weights are entered, press the soft key **OK** to finish the entry.
The total of all tare weights is displayed as pretare value indicated with PT.
4. Weigh the pallets or similar.
The net weight of the pallet is displayed without extra taring.
5. To leave prompting press **C**.
"Cleared" is displayed briefly.

2.12 Calling up alibi log file

If requested by national regulations, the optional Alibi memory is available to trace all weighing activities on the scale.

The alibi log file stores all weighings with the mandatory data. In addition you can store one more item, either device name, device location or article number (Application -> Memory -> Custom field).

1. Press the soft key **Alibi**.

The alibi records of the last 5 weighing operations are displayed.

*000028	Date:	06/10/11	Gross:	19.51 kg
000027	Time:	14:14:06	Tare:	0.00 kg
000026	ID1:	ID0		
000025				
000024				



The weighing data of the data record with the highlighted number are displayed.

2. Use the soft keys **↓/↑** to scroll the list. Soft key **End** leads you to the last weighing.
3. Press the soft key **Esc** to leave the Alibi memory.

2.13 Switching scales

Prerequisite

- ✓ Two scales are connected to the weighing terminal.
- ✓ The soft key `Switch scale` is activated in the `Terminal` menu.

- Press the soft key   to switch the active scale.

The current active scale is displayed in the symbol and info line on the top of the display.

2.14**Cleaning****Risk of electric shock**

- ▲ Before cleaning, unplug the power plug in order to disconnect the terminal from the power supply.
- ▲ Cover open connectors with protective caps.
- Clean the protective cover separately. The protective cover is dishwasher-safe.
- Take off the load plate and remove any dirt and foreign substances which may have collected underneath. Do not use any hard objects to do so.
- Do not disassemble the weighing device.
- Remove any possibly remaining detergent by rinsing with clear water.
- Observe all the existing regulations on cleaning intervals and permissible cleaning agents.

Cleaning of other weighing platforms than described in this user manual

- Make sure to observe the cleaning instructions for the connected weighing platform. The weighing platform may not be designed for the environments and cleaning procedures described above.

2.15**Verification test**

The weighing instrument is verified if

- the accuracy class is displayed in the metrological line,
- the approval readability is shown with "e = readability",
- it bears an official verification mark, e.g., the green M sticker (OIML),
- the validity is not expired.

The weighing instrument is also verified if

- the metrological line shows "Approved scale",
- labels with the metrological data are placed near the weight display,
- the securing seal is not tampered with,
- it bears an official verification mark, e.g., the green M sticker (OIML),
- the validity is not expired.



The period of validity is country-specific. It is in the responsibility of the owner to renew verification in due time.

Strain gauge weighing platforms

Strain gauge weighing platforms use a Geo Code to compensate gravitational influence. The manufacturer of the weighing instrument uses a defined Geo Code value for verification.

- Check if the Geo Code in the instrument corresponds with the Geo Code value defined for your location.


The Geo Code value is displayed when you switch on the instrument.

The Geo Code for your location is shown in the Appendix.




- Call the METTLER TOLEDO service technician if the Geo Code values do not match.

3 Counting


3.1 Counting parts into a container

1. Place the empty container on the scale and press $\rightarrow T \leftarrow$.
The container is tared and the zero display appears.
2. Place the number of reference parts on the scale as indicated on the soft key  and press the soft key.
The scale determines the average piece weight and then shows the number of reference pieces.
3. Add more parts to the container until the required number of pieces is reached.
4. When piece counting is completed, press **C** to clear the reference.
The scale is ready for the next weighing or counting.




- The average piece weight remains saved until **C** is pressed or a new average piece weight is determined.
- With  or soft key  /  you can switch between the number of pieces and the weighing units preset.
- The average piece weight (APW), i.e., the weight of an individual reference unit, can be displayed on the info page or in the auxiliary line.
- If in the menu *Auto clear APW* is set to *On*, the average piece weight is automatically cleared after each counting operation.
- The achieved counting accuracy can be displayed in the auxiliary lines.

3.2 Counting parts out of a container


1. Place the full container on the scale and press $\rightarrow T \leftarrow$.
The container is tared and the zero display appears.
2. Remove the number of reference parts on the scale as indicated on the soft key  and press the soft key.
The scale determines the average piece weight and then shows the number of reference pieces removed, together with a minus sign.
3. Remove more parts to the container until the required number of pieces is reached.
4. When piece counting is completed, press **C** to clear the reference.
The scale is ready for the next weighing or counting.

3.3 Determining the parts in a full container

When you know the tare weight of the container, the number of parts in the container can be determined.

1. Enter the known tare weight and press **→T←** to confirm.
The weight display shows the negative tare weight and the symbol **NET** appears.
2. Place the number of reference parts on the scale as indicated on the soft key  and press the soft key.
The scale determines the average piece weight and then shows the number of reference pieces.
3. Place the full container on the weighing platform.
The number of pieces in the container is displayed.

3.4 Counting with a known average piece weight


- Enter the known average piece weight and press the soft key .
The scale changes the unit to PCS.

The rest of the counting procedure is as described before.

3.5 Counting with variable reference quantity

Prerequisite

- ✓ In the `Application` menu, `Fixed ref. size` is set to `Off`.

1. Place any number of reference parts on the scale.
2. Enter the number of reference parts and press the soft key .
The scale determines the average piece weight and then shows the number of pieces.

The rest of the counting procedure is as described before.

3.6 Counting with reference weight check

The reference weight check ensures that the reference weight is high enough to lead to a good counting result.

Prerequisite

- ✓ In the `Application` menu, `Ref. weight check` is set to `On`.

1. Determine the average piece weight as described before.
If the average piece weight is not sufficient, `Add x PCS` appears.
2. Add the displayed number of pieces.
The average piece weight is determined again with the larger reference quantity.


The rest of the counting procedure is as described before.


3.7 Reference optimisation

The greater the reference quantity, the more accurately the scale determines the number of pieces.

3.7.1 Automatic reference optimisation

Prerequisite

✓ In the `Application` menu, APW optimisation is set to `Auto`, the symbol  appears in the display.

1. Place the indicated number of reference parts on the scale and press the soft key .
2. Place additional reference parts on the scale, max. the same number as for the first determination of the average piece weight.



The scale automatically optimises the average piece weight with the larger number of reference parts.

The rest of the counting procedure is as described before.

3.7.2 Manual reference optimisation

Prerequisite

- ✓ In the `Application` menu, APW optimisation is set to `Soft key`.
- ✓ In the `Terminal` menu, the soft key APW optimisation is activated.

1. Place the indicated number of reference parts on the scale and press the soft key .
2. Place additional reference parts on the scale, max. the same number as for the first determination of the average piece weight and press soft key .

The scale automatically optimises the average piece weight with the larger number of reference parts.

The rest of the counting procedure is as described before.

3.8 Counting with automatic reference determination

Prerequisite

✓ In the `Application` menu, `Autosampling` is set to `On`.

→ Place the indicated number of reference parts on the scale.

The scale automatically determines the average piece weight and then shows the quantity.

The rest of the counting procedure is as described before.



Pressing **C** the last average piece weight is cleared and the current weight is set as the new reference weight.

3.9 Counting with two scales

The ICS465 can handle a weighing system with 2 scales.

There are two possibilities for counting with a scale system:

- Counting with **reference scale** and **bulk scale**
e.g., a high precision scale for determining the reference and a floor scale to count large quantities
- Counting with **auxiliary scales**
e.g., a high precision scale for counting small parts and a floor scale for counting bigger parts.

3.9.1 Counting with reference and bulk scale

Prerequisite

- ✓ In the `Application` menu one scale is configured as `Reference` scale for determining the average piece weight and the other scale is configured as `Bulk` scale for counting large numbers of pieces.

1. Make sure that the reference scale is the currently active scale.
2. On the reference scale determine the average piece weight as described before. After determining the average piece weight the scale is switched automatically.
3. Place the empty container on the bulk scale and press **→T←**.
The container is tared and the zero display appears.
4. Add the parts to the container until the required number of pieces is reached.

3.9.2 Counting with auxiliary scales

Prerequisite

- ✓ In the `Application` menu at least one scale of the system is configured as `Auxiliary` scale.
- ✓ In the `Terminal` menu the soft key `Switch scale` is activated.

1. Make sure that the selected scale is suitable for the product to be counted.
2. Carry out counting as described before.




When changing the product to be counted, always check which of the auxiliary scales is the most suitable. If necessary, change the scale.

3.10 Counting by calling up an article from the database

3.10.1 Storing an article in the database

Prerequisite

✓ The soft key `Save article` is activated in the `Terminal` menu.

1. Determine the reference weight as described before.
2. Press the soft key .
A new screen is displayed to enter an article.
3. Enter the article and confirm with the soft key **OK**.
"Record stored" is displayed briefly. The article is stored.




- If in the `Description` field is activated in the `Application` menu, you are asked to enter an article description as well.
- When you always use the same container, the tare weight can be saved with the article. Just tare the container before determining the reference.
- If the selected article already exists the message "Article already exists – Overwrite article?" is displayed.

3.10.2 Recalling an article from the database

Prerequisite



✓ The soft key `Recall article` is activated in the `Terminal` menu.

1. Press the soft key .
The database opens. The article data of the highlighted record number are displayed.

Database			
002	Article :	852	Tol Type : Absolute
003	Desc. :	456	T- : 0 PCS
004	Tare :	0.00 kg	T : 0 PCS
*005	APW :	0.22 kg	T+ : 0 PCS
006			

Esc ↑ ↓ OK ▶▶▶

For a counting article the fields in the frame are significant.

2. Use the arrow keys to navigate through the database records. On the second soft key page  and  are available to scroll a page up or down.
3. Confirm the selected data record with the soft key **OK**.
"Record loaded" is displayed briefly. The weight display changes to unit PCS.

4 Checkweighing

The device offers Checkweighing functions. The respective settings in the menu are described in the `Application` menu section.

The corresponding coloured background lighting allows rapid detection of the states "too light" (factory setting: red), "good" (factory setting: green) and "too heavy" (factory setting: yellow). The colours can be modified in the menu.

Prerequisite

✓ The soft key `Checkweighing` is activated in the `Terminal` menu.

4.1 Specifying target values

Different entries are required at the beginning of Checkweighing / Checkcounting, depending on the tolerance type setting.

Tolerance type "Absolute"

A low and a high weight value must be entered. These weights and all weights within this range are treated as being within tolerance.



Tolerance type "Relative"

Target weight (Target) as well as lower tolerance (Tol-) and upper tolerance (Tol+) have to be specified. The tolerances are displayed as relative deviations from the target weight.

Tolerance type "Percent"

Target weight (Target) as well as lower tolerance (Tol-) and upper tolerance (Tol+) have to be specified. At Checkweighing the weight value is represented as a percentage of the target weight. The target weight value is 100 % or 0 % at Checkweighing to zero.



4.1.1**Weighing in target values**

1. Press the soft key .
The current Checkweighing parameters are displayed.
2. Check the tolerance type.
3. To change the tolerance type press the soft key .
4. Confirm the tolerance type with the soft key **OK**.
5. Load the requested weight and confirm with the soft key **OK**.
The next weight is highlighted.
6. Repeat step 5 until "New target set!" is displayed.
The coloured Checkweighing display appears, the scale is ready for Checkweighing.



- If tolerance default values have been set in the menu, only the target has to be specified with tolerance types "Relative" and "Percent".
- The upper tolerance value has to be greater than or equal to the lower one (High \geq Low) or, respectively, the target weight has to be greater than or equal to the lower tolerance value and smaller than or equal the upper tolerance (Tol+ \geq Target \geq Tol-).

4.1.2**Entering known target values**

1. Press the soft key .
The current Checkweighing parameters are displayed.
2. Check the tolerance type.
3. To change the tolerance type press the soft key .
4. Confirm the tolerance type with the soft key **OK**.
5. Enter the requested weight value and confirm with the soft key **OK**.
The next weight is highlighted.
6. Repeat step 5 until "New target set!" is displayed.
The coloured Checkweighing display appears, the scale is ready for Checkweighing.




- If tolerance values have been set in the menu, only the target has to be specified with tolerance types "Relative" and "Percent".
- The upper tolerance value has to be greater than the lower one (High $>$ Low) or, respectively, the target weight has to be greater than the lower tolerance value (Tol+ $>$ Target $>$ Tol-).

4.1.3 Specifying target number of pieces

Prerequisite

- ✓ At least one of the counting soft keys `Ref n` or `APW` is activated in the `Terminal` menu.

Determining the piece weight

- ➔ Apply the indicated number of reference parts and press the soft key . The number of reference parts is displayed.



- For alternate procedures to determine the average piece weight refer to the Counting section.
- When using the unit PCS, the tolerance type Percent is not available.


Determining target number of pieces

- ➔ Proceed as described in the section "Weighing in target values" or "Entering known target values". The display unit is PCS.

4.1.4 Storing an article in the database

Prerequisite

- ✓ The soft key `Save article` is activated in the `Terminal` menu.

1. Determine the target as described before.
2. Press the soft key . A new screen is displayed to enter an article.
3. Enter the article and confirm with the soft key **OK**. "Record stored" is displayed briefly. The article is stored.




- If in the `Description field` is activated in the `Application` menu, you are asked to enter an article description as well.
- When you always use the same container, the tare weight can be saved with the article. Just tare the container before determining the reference.
- If the selected article already exists the message "Article already exists – Overwrite article?" is displayed.

4.1.5 Recalling an article from the database

Prerequisite





✓ The soft key `Recall article` is activated in the `Terminal` menu.

1. Press the soft key .

The database opens. The article data of the highlighted record number are displayed.

Database				
001	Article :	1000	Tol Type :	Relative
*002	Desc. :	987654321	T- :	0.05 kg
003	Tare :	0.00 kg	T :	2.00 kg
004	APW :	0.00 kg	T+ :	0.10 kg
005				
Esc	↑	↓	OK	▶▶▶

For checkweighing articles the fields in the frame are significant.

2. Use the arrow keys to navigate through the database records. On the second soft key page   and   are available to scroll a page up or down.
3. Conform the selected data record with the soft key **OK**.
"Record loaded" is displayed briefly. The coloured checkweighing display appears.




4.2 Checkweighing procedure

The device facilitates Checkweighing and Checkcounting through different coloured background lighting for the states "too light" (factory setting: red), "good" (factory setting: green) and "too heavy" (factory setting: yellow).

1. Specify the target values as described above.
2. Place the checkweighing material on the scale.
Depending on the applied weight the colour of the background lighting changes. Weight information is displayed in accordance with the display setting and the Checkweighing settings.

With factory settings for display type and colours, the following is displayed for "too light", "good", "too heavy":

Display for Checkweighing and tolerance type "Absolute"



Display for Checkweighing and tolerance type "Relative"



Display for Checkweighing and tolerance type "Percent"



4.3 Checkweighing during subtractive weighing


Assistance through the coloured background and the graphical weighing aid is also possible during subtractive weighing and subtractive counting.

Procedure

1. Specify target values as described above.
The target value is indicated with a negative sign.
2. Place a full container on the weighing platform and tare it.
3. Remove as much from the weighing sample as required for the display to change to the state "good" (factory setting = green).
4. Tare the unit again.
The scale is ready for the next removal.

Display for subtractive Checkweighing

With factory settings for display type and colours the following is displayed for "too light", "good", "too heavy":



4.4 Checkweighing with "Quick start"

If default values for the tolerances are used with tolerance types "Relative" or "Percent", Checkweighing can be started by pressing just one key.

Prerequisites

- ✓ The setting `On` is selected in the menu under `Application -> Over/Under -> Default Values`.
- ✓ Tolerance values are defined under `Application -> Over/Under -> Default Values`.
- ✓ The selected tolerance type matches the entered default values.

Procedure

- ➔ Place the target weight or target amount on the scale and press the soft key `←✓→`.
The applied weight or the applied amount is stored as the target weight or target amount respectively. The display changes to the state "good" (factory setting = green).
Checkweighing is activated.

4.5 Checkweighing to zero

The weight value or the number of pieces can also be represented as the difference to the target weight.

Prerequisites

- ✓ For Checkweighing to zero, tolerance types "Relative" or "Percent" are selected
For Checkcounting to zero, tolerance type "Relative" is selected
- ✓ The soft key `To zero` is activated in the `Terminal` menu, the symbol $\downarrow 0$ is displayed in the symbols and info line
- ✓ Display layout "Colour mode" or "3-line mode" selected in the `Terminal` menu

Procedure

1. Specify the target values as described above.
2. Press the soft key $\downarrow 0$.
The target is displayed with a minus sign.
3. Place the checkweighing material on the scale.
Depending on the applied weight or the applied amount the colour of the background lighting changes.
The display value is displayed in accordance with the tolerance type setting.
The target value is 0 (kg or PCS) or 0.00 %.

Display at Checkweighing to zero

With display type "Colour mode" and default colours the following is displayed for "too light", "good", "too heavy":



Terminating Checkweighing to zero

- Press soft key $\downarrow 0$ again.
The symbol $\downarrow 0$ in the info line disappears, the net weight is displayed.

4.6 Terminating Checkweighing

With clearing the Checkweighing parameters

- Press **C**.
"Cleared" appears in the display.
The target values are cleared and the straight weighing display appears.
The device operates in straight weighing mode.

With keeping the Checkweighing parameters

- Press the soft key **ESC**.
The straight weighing display appears, the Checkweighing parameters are kept.
The device operates in straight weighing mode.
- To reactivate the Checkweighing parameters, press the soft key **←✓→**.
The last entered Checkweighing parameters are displayed.

5 Totalisation

5.1 Starting totalisation

→ Press the soft key Σ .

The following soft keys for totalising are displayed:

Esc	+		↺	-
Leave totalising without clearing the sum	Add item to the sum		Undo totalisation	Add item to the sum with subtractive weighing

5.2 Totalising manually

Totalising

1. Load the first sample and press the soft key **+**.
Total Net, Total Gross and number of items are displayed.
2. Unload the scale.
3. Load the next sample and press the soft key **+** again.
The totals are updated.
4. Unload the scale.
5. Repeat steps 3 and 4 for further items.
6. To finish totalising, press **C**.
The total is cleared.



Piece counting results and Checkweighing results can be totalised the same way, but they cannot be mixed up in a total.

Totalising in subtractive weighing

1. Load the full container and press **→T←**.
The full container is tared.
2. Remove the first portion from the container and press the soft key **—**.
Total Net, Total Gross and number of items are displayed.
3. Press **→T←**.
4. Remove the next portion and press the soft key **—** again.
The total is updated.
5. Repeat steps 3 and 4 for further portions.
6. To finish totalising, press **C**.
The total is cleared.



Piece counting results and Checkweighing results can be totalised the same way, but they cannot be mixed up in a total.

5.3 Automatic totalising

Prerequisites

- ✓ Auto print is activated in the Communication menu or in the Application
- > Over/Under menu (for Checkweighing only).

Totalising

1. Load the first sample.
The total is displayed in the auxiliary lines.
2. Unload the scale.
3. Load the next sample.
The total is updated.
4. Unload the scale.
5. Repeat steps 3 and 4 for further items.
6. To finish totalising, press **C**.
The total is cleared.



Piece counting results and Checkweighing results can be totalised the same way, but they cannot be mixed up in a total.

5.4 Deleting items from the sum

- Press the soft key .
- The last weighing is deleted from the sum.

5.5 Terminating totalising

With clearing the total → Press **C**.
"Cleared" appears in the display.
The total is cleared and the straight weighing display appears.
The device operates in straight weighing mode.

With keeping the total → Press the soft key **ESC**.
The straight weighing display appears, the total is kept.
The device operates in straight weighing mode.

- To continue totalising, press the soft key Σ .
The last total is displayed.

6 Settings in the menu

In the menu, settings can be changed and functions can be activated. This enables adaptation to individual weighing requirements.

The menu consists of the following 5 main blocks containing various submenus on several levels.



Scale	see section 6.2
Application	see section 6.3
Terminal	see section 6.4
Communication	see section 6.5
Maintenance	see section 6.6

6.1 Operating the menu

6.1.1 Calling up the menu and entering the password



The menu differentiates between 2 operating levels: Operator and Supervisor. The Supervisor level can be protected by a password. When the device is delivered, both levels are accessible without a password.

Operator menu

1. Press  and keep it pressed until `Enter code` appears.
2. Press  again.


The menu item `Terminal` is displayed. Only parts of the submenu `Device are` accessible.

Supervisor menu

1. Press  and keep it pressed until `Enter code` appears.
2. Enter the password and confirm with .

The first menu item `Scale` is highlighted.




No supervisor password has been defined when the device is first delivered. Therefore, confirm the password inquiry with  when you call up the menu for the first time.

If a password has still not been entered after a few seconds, the scale returns to the weighing mode.

Emergency password for Supervisor access to the menu


If a password has been issued for Supervisor access to the menu and you have forgotten it, you can still enter the menu:

→ Press **→0←** 3 times and confirm with .

6.1.2

Display presentation in the menu

Menu items are displayed together with their context.



- 1 Menu items; the selected menu item is highlighted
- 2 Scroll flag, like the scroll bar of your PC
- 3 Sub-menu items
- 4 Menu info line, i.e., menu path of the current menu item
- 5 Soft key line: use the soft keys below to navigate the menu as indicated


Exiting the menu

1. Press **ESC**.
"Save settings ?" is displayed.
2. Press **OK**.
The menu changes are saved and the terminal returns to the weighing mode.
– or –
→ Press **ESC** for further menu settings.
– or –
→ Press **NO** to discard changes and return to the weighing mode.


6.1.3 Selecting and setting parameters in the menu

Example: Setting of the average weighing mode to automatic


1. In the menu start screen use **↓** to select (highlight) the `Application` menu.
The submenus are displayed in the middle column.




2. Press **➡** to enter the `Application` menu.




3. Press **↓** and then press **➡** to open the `Avg. weighing` submenu.
The current setting of the highlighted menu item is displayed in the right column.



4. Press **➡** to enter the `Mode` submenu.
The possible settings of the selected menu item are displayed on the right side.



5. Press **↑** to select (highlight) `Auto` and confirm selection with **OK**.
The setting of the average weighing mode has changed.



If all the settings of a menu item cannot be displayed on one page (e.g., all the info items), just use **↓** to proceed to the hidden items.

6.2 Scale menu block



When entering the SCALE menu block, an overview of the connected scales is displayed:
If SCALE 2 is a SICS scale, no more settings are available.

6.2.1 Overview

Factory settings are printed in **bold** in the following overview.

After selecting the Scale 1 or Scale 2, the following menu is available:

Level 1	Level 2	Level 3	Level 4
Identifica- tion	Scale location		
	Scale ident.		
Linear. & Calib.	Linearisation		
	Calibration		
	Auto print calib.	On, Off	
Disp. unit & res.	Display unit 1	g, kg , oz, lb, lb-oz, t	
	Display unit 2	g, kg, oz, lb, lb-oz, t	
	Disp. resolution	Off, ...	
	Unit roll	On, Off	
Zero	AZM	Off, 0.5d , 1d, 2d, 5d, 10d	
Tare	Auto tare	On, Off	
	Chain tare	On , Off	
	Auto clear tare	On, Off	
Restart	On, Off		
Filter	Vibration	Low, Medium , High	
	Process	Universal , Dosing	
	Stability	Fast, Standard , Precise	
MinWeigh	Function	On, Off	
FACT *	Temperature	Off, 1K, 2K, 3K	
	Time	Time 1, Time 2, Time 3	
	Days	Monday, ... Sunday	Off , On
Reset	Perform reset ?		


* for MonoBloc® load cells only

6.2.2 Scale 1 / Scale 2 → Identification


Scale location	Entering the scale location, e.g., floor and room
Scale ident.	Entering the scale identification, e.g., inventory number
Note	<ul style="list-style-type: none"> Scale location and scale identification can be displayed in the auxiliary or info lines or printed out. Scale location and scale identification can consist of up to 12 characters (0 ... 9 and decimal point)

6.2.3 Scale 1 / Scale 2 → Linearization & Calibration

This menu item is not available for verified scales.

Last calibration	Shows the date of the last calibration.
Autoprint calib.	When set to <code>On</code> , a protocol is printed out automatically for each calibration process.
Perform calib. ----- blinking Preload blinking xx kg blinking	<ol style="list-style-type: none"> Unload the scale. Apply preload and confirm with OK. If necessary, change the calibration weight value displayed using ↓ / ↑. Apply the indicated calibration weight on the weighing platform and confirm with OK. <code>Passed</code> is displayed briefly.
Note	In order to achieve a particularly high precision, calibrate under full load. The calibration process can be aborted using  .

6.2.4 Scale 1 / Scale 2 → Display units & resolution

Display unit 1	Selecting weighing unit 1
Display unit 2	Selecting weighing unit 2, different from unit 1
Display resolution	Selecting readability (resolution), the possible settings depend on the connected scale. When set to <code>OFF</code> , only the default resolution of the weighing platform is available.
Unit roll	When unit roll is switched on, the weight value can be displayed in all available units with  .
Notes	<ul style="list-style-type: none"> In case of verified scales, individual sub-items of the <code>Display/Units & Resolution</code> menu item may not be available or only to a limited extent, depending on the respective country. On dual-range/dual interval scales, resolutions marked with !<->! 1/2 are divided up into 2 weighing ranges/intervals, e.g., 2 x 3000 d.

6.2.5 Scale 1 / Scale 2 -> Zero – Automatic zero update

AZM	On verified scales, this menu item does not appear. Switching on/off automatic zero update and selecting zeroing range.
------------	--

6.2.6 Scale 1 / Scale 2 -> Tare – Tare function

Auto tare On, Off	Configuring automatic taring Switching automatic taring on/off When a load is placed on the scale and the gross weight exceeds 9 d, the weight is tared automatically.
Chain tare	Switching on/off chain tare
Auto clear tare On, Off	Configuring automatic clearing of the tare weight Switching automatic clearing of the tare weight on/off When the load is removed and the weight drops below 9 d, the tare weight is cleared automatically

6.2.7 Scale 1 / Scale 2 -> Restart – Automatic saving of zero point and tare value


Restart	When the Restart function is activated, the last zero point and the tare value are saved. After switching off/on or after a power interruption, the device continues to work with the saved zero point and tare value.
----------------	---

6.2.8 Scale 1 / Scale 2 -> Filter – Adaptation of the ambient conditions and the weighing type

Vibration Low Medium High	Adaptation to ambient conditions <ul style="list-style-type: none"> • Very steady and stable environment. The scale works very rapidly, but is very sensitive to external influences. • Normal environment. The scale operates at medium speed. • Restless environment. The scale works more slowly, but is insensitive to external influences.
Process Universal Dosing	Adaptation to the weighing process <ul style="list-style-type: none"> • Universal setting for all weighing samples and normal weighing goods. • Dispensing liquid or powdery weighing samples.
Stability Fast Standard Precise	Adjusting the stability detector <ul style="list-style-type: none"> • The scale operates very fast. • The scale operates at medium speed. • The scale operates with the greatest possible reproducibility. <p>The slower the scale works, the greater the reproducibility of the weighing results.</p>

6.2.9 Scale 1 / Scale 2 → MinWeigh – Minimum weighing-in quantity

Before you can use this function, the METTLER TOLEDO service technician has to determine and enter a minimum weight value.

Function On/Off	MinWeigh function Switching MinWeigh function on/off When set to On and if the weight on the scale drops below the stored minimum weight,  will appear in the symbols and info line and the display colour will change.
Display colours	Setting the display colour for weight values below the stored minimum weight.

6.2.10 Scale 1 / Scale 2 → FACT – automatic temperature-dependent adjustment

This menu item appears only on scales with an internal calibration weight.

Temperature Off 1K, 2K, 3K	Setting the temperature difference for automatic adjustment. Switching off automatic adjustment in the case of a temperature difference. Automatic adjustment in case of the selected temperature change.
Time Time 1 ... Time 3	Setting up to 3 times per day for the automatic adjustment. Entering the times for the automatic adjustment (hours, minutes in 24 h format). If you do not want 3 times per day, just set all the times to the same value.
Days Monday ... Sunday	Setting the days of the week for the automatic adjustment. On all days which are set to On, the automatic adjustment will be performed.

6.2.11 Scale 1 / Scale 2 → Reset – Resetting scale settings to factory settings

Perform reset ?	Confirmation inquiry • Reset the scale settings to factory settings with OK .
------------------------	---


6.3 Application menu block

Factory settings are printed in **bold** in the following overview.

6.3.1 Application -> Straight weighing

Printout	Defining printer and template in the straight weighing application
COM1 ... COM2	Selecting the COM port for the desired printer. E.g., COM1 for printout to a PC and the optional COM2 for printout on an office (ASCII) printer
Off	No printout on this COM port
Standard	Printout with the standard template on the selected printer
Template 1 ... Template 5	Assigning a customer template to the selected printer
Note	Templates can be defined under <code>Communication -> Define templates</code>

6.3.2 Application -> Average weighing



Mode	Selecting mode for determining the average weight for an unstable load (dynamic weighing)
Auto	Calculating average weight with automatic start of the weighing cycle
Print key Info key Switch key Soft key	Calculating average weight with manual start of the weighing cycle via the selected key. 
Printout	Defining printer and template in the average weighing application
	See "Straight weighing"

6.3.3 Application -> Counting

Overview

Level 1	Level 2	Level 3
Fixed ref. Size	Off, On	
Reference size		
Ref weight check	Off, On	
	0 % ... 30 %	
APW optimisation	Off, Auto, Soft key	
Autosampling	Off, On	
Auto clear APW	Off, On	
Counting system	Scale 1	Bulk, Reference, Aux., Off
	Scale 2	
Printout	see "Straight Weighing"	

Description

Fixed ref. size	Selecting the reference size
Off	Variable reference size, i.e., any number of parts can be used as reference size
On	Determining the average piece weight is only possible with the default reference size
Reference size	Define a default reference size, e.g., 12 PCS. The reference size is displayed in the corresponding soft key .
Ref Weight	Monitoring the minimum reference weight
Ref wt check	Activating/deactivating the reference weight check function
Off	No monitoring of the minimum reference weight
On	Monitoring the minimum reference weight. When the minimum reference weight drops below the set tolerance value, the display colour changes and a message is displayed which asks you to add more reference parts.
Ref wt value	Only displayed if Ref wt check is set to On.
1 % ... 30 %	Setting the factor for the reference weight check. The higher the factor, the smaller the required minimum reference weight. Factory setting: 20 %
APW optimisation	Optimisation of the average piece weight.
Off	No optimisation of the average piece weight
Auto	Automatic optimisation of the average piece weight
Soft key	Manual optimisation of the average piece weight with soft key  ✓.

Autosampling	Automatic determination of the average piece weight
On	After taring, the average piece weight is determined with the next weight placed on the scale and the displayed reference size.
Off	No automatic determination of the average piece weight
Auto clear APW	Automatic clearing of the average piece weight
On	When the load is taken off the scale after a counting operation, the average piece weight is automatically cleared. The next counting operation begins with determining the average piece weight again.
Off	The average piece weight must be cleared manually with C .
Counting system	Configuring a system of several scales for counting
Scale 1, Scale 2	Selecting the scale to assign a function in the counting system. Only the scales connected are displayed.
Bulk	The selected scale serves as bulk scale to count/measure quantities. Another scale of the system must then be set to <i>Reference</i> .
Reference	The selected scale serves as reference scale to determine the average piece/unit weight. Another scale of the system must then be set to <i>Bulk</i> .
Aux.	The selected scale can be used for determining the average piece/unit weight as well as for counting/measuring.
Off	The selected scale is not part of a counting system.
Printout	Defining printer and template in the counting application
	See "Straight weighing"

6.3.4 Application -> Checkweighing

Overview

Level 1	Level 2	Level 3
Tolerance type	Off , Absolute, Relative, Percent	
Default values	Act. deft. values	Off , On
	Rel. weight	Tol -, Tol +
	Per. weight	Tol -, Tol +
	Rel. pieces	Tol -, Tol +
Output	Thresh % of tol-	
	Beeper	Off , Within Tolerances, Outside Tolerances
	Beeper mode	Continuous, Stable
	Autoprint	Off , Within Tolerances, Outside Tolerances
Display mode & Colours	Stealth mode	On, Off
	Good range	White, Green, Red, Yellow, Blue, Brown, Violet, Orange
	Under range	
	Over range	
	Below threshold	
Printout	see "Straight Weighing"	

Description

Tolerance type	Specifying which parameters have to be entered for Checkweighing/Filling
Off	No tolerance type predefined, it can be set individually when entering Checkweighing/Filling parameters.
Absolute	A low and a high weight value must be entered. These weights and all weights within this range are treated as being within tolerance.
Relative	The target weight has to be entered as an absolute weight, upper and lower tolerances as deviations in weight from the target weight.
Percent	The target weight has to be entered as an absolute weight, upper and lower tolerances as deviations in percent from the target weight. This setting is not available for counting.

Default values	Storing default tolerance values
	If you always use the same tolerances for Checkweighing, you can store these tolerances and thus avoid entering tolerances all the time.
Act. deflt. values Off On	Activating usage of default tolerance values. Default tolerance values not used Default tolerance values used
Rel. weight	Entering the default values for Tolerance – and Tolerance +.
Per. weight	Entering the default percentages for Tolerance – and Tolerance +.
Rel. pieces	Entering the default values for Tolerance – and Tolerance + in pieces.
Output	Setting output options
Thresh % of tol-	When Thresh % of tol- is reached, the coloured display will change from the "Below threshold" colour to the "Tolerance –" colour. This feature can be used to show the "Tolerance –" colour when you are already near the target or if you need an additional setpoint for I/O control. This setpoint is available on the optional digital I/O interface as well. Possible settings 0 ... 100 % (of the "Tolerance –" value) Factory setting 12 %
Beeper Off Within tolerances Outside tolerances	Setting the beeper for Checkweighing No beeper A short beep will sound when a weight value within the tolerance values is reached A short beep will sound when a weight value outside the tolerance values is reached
Beeper mode Continuous Stable	Defining how the beeper will act Beeping on every change in weight within the selected range Beeping only when a stable weight value within the selected range is recognised
Autoprint Off Within tolerances Outside tolerances	Setting the automatic printout No automatic printout Automatic printout when a stable weight value within the tolerance values is reached Automatic printout when a stable weight value outside the tolerance values is reached

Display mode & colours	Setting the weight display in the Checkweighing application
Stealth mode	This menu item is not available if the scale is approved.
Off	Weight display
On	No weight display, only the coloured display for "too light", "good" and "too heavy".
Good range	Selecting the colour to indicate a weight value within tolerances Factory setting: green
Under range	Selecting the colour to indicate a weight value below "Tolerance –" Factory setting: red
Over range	Selecting the colour to indicate a weight value above "Tolerance +" Factory setting: red
Below threshold	Selecting the colour to indicate a weight value below "Threshold as % of Tol –" Factory setting: white
Possible colours	White, Green, Red, Yellow, Blue, Brown, Violet, Orange
Printout	Defining printer and template in the Checkweighing application
	See "Straight weighing"

6.3.5 Application -> Totalising

Overview

Level 1	Level 2	Level 3	Level 4
Mode	Mode	Manual , Auto +, Auto -	
	Zero return	Off , On	
Printout	Lot print	COM1, COM2	Off, Standard, Template 1 ... Template 10
	Final print		
	Summary print		

Description

Mode	Configuring totalising
Mode	
Manual	Items must be totalised manually with the soft key +
Auto +	Stable weight values will be totalised automatically
Auto -	Automatic totalisation of stable weight values in subtractive weighing
Zero return	Reaching a stable zero point between two items
On	All load must first be removed from the scale before totalisation of the next item is possible
Off	No load removal requested between two items
Printout	Configuring printouts
Lot print	Printout for each individual item
Final print	Printout of the total at the end of totalising
Summary print	Additional printout of the individual items and the total after completion of totalisation.
COM1, COM2	Selecting the printer interface for the lot printout
Off	No automatic printout
Standard	Automatic printout using the standard template which is predefined in the factory.
Template 1 ...	Automatic printout using the selected template
Template 10	

6.3.6 Application -> Memory

Custom field	<p>Selecting information to be stored with the alibi data record in the additional custom field</p> <p>Select from the following: Off, Scale SNo., Terminal model, Terminal location, ID1 ... ID3, APW, Quantity, Terminal SNo., Temperature (for MonoBloc® load cells only)</p>
---------------------	--

6.3.7 Application -> Database

Description field	
On	Each data record has an additional field to enter e.g., an article name
Off	No field for entering a description.
Delete record	Select a data record to be deleted.
Delete all	Delete all data records. A safety prompt is displayed.
Print all	Print all data records.

6.3.8 Application -> Prompting

Mode	Configuring start of the prompting
Automatic	Prompting always active, no other functions available
Soft key	Start by a soft key
Apps	Selecting the workflow which shall be supported by the prompt
Off	No workflow
Tare/Sample	Reference determination: First tare, then add reference parts
Sample/Tare	Reference determination: First weigh reference parts, then tare
Handsfree	Counting without a keystroke
Multi tare	Taring of several containers with the same tare weight
Additive tare	Adding the known tare weight of different containers

6.3.9 Application -> Reset – Resetting application settings to factory settings

Perform reset ?	<p>Confirmation inquiry</p> <ul style="list-style-type: none"> Reset the application settings to factory settings with OK.
------------------------	--

6.4 Terminal menu block

The Terminal menu block consists of the following main subblocks, which are described in detail in the following.

- Device
- Access

Factory settings are printed in **bold** in the following overview.

6.4.1 Terminal -> Device – General device settings


Overview

Level 1	Level 2	Level 3	Level 4	Level 5
Region	Laguage	English , Deutsch, Français, Italiano, Español, Chinese, ...		
	Date format	MM/DD/YY, MM/DD/YYYY, MMM/DD/YYYY, DD/MM/YY, DD/MMM/YYYY, YY/MM/DD, YYYY/MMM/DD, YYYY/MM/DD, DD/MM/YYYY		
	Set date	Set year		
		Set month		
		Set day		
	Time format	24:MM, 12:MM tt, 24:MM:SS , 12:MM:SS tt		
Set time	Set hour			
	Set minutes			
Sleep / Power off	Off , 1 minute, 3 minutes, 5 minutes, 15 minutes, 30 minutes			
Identifica-tion	Terminal location			
	Terminal identification			
Display	Display layout	Default , 3-lines mode, Colour mode		
	Brightness	1 ... 10		
	Weight hold	0 s ... 10 s		
	Default color	Yellow, light blue, dark blue, red, purple, green, orange, light green, pink, white		
	Auxiliary line	Not used, Date & Time , Gross, Net, Tare, High resolution (not available for approved scales), ID1, ID2, ID3, Name of active scale, Target, Tolerance+, Tolerance-, Article description, Deviation to target, APW, Reference count, Quantity, Article, Total net, Total gross, Total PCS, n, Bargraph, Temperature (for MonoBloc® load cells only)		


Level 1	Level 2	Level 3	Level 4	Level 5	
Keyboard	Hard keys	Power, Clear, Switch, Info, Transfer, Numeric keys	On, Off		
	Soft key	Soft key 1-1 ... Soft key 4-4	Not used, Zero, Tare, High Resolution, Average weighing, ID1, ID2, ID3, Prompt, Alibi Memory, Switch scale, Ref N, APW, APW optimisation, Weight count, To zero, Totalising, Checkweighing, Save article, Recall article, Display layout		
	Info key	Page 1	Item 1 ... Item 5	Not used, Date & Time, Gross, Net, Tare, ID1, ID2, ID3, Terminal Identification, Terminal Location, Terminal Model, SNR Terminal, SNR Scale, Firmware Vers., Target, Tol-, Tol+, Dev. to target, APW, Quantity, Record number, Total net, Total gross, Total PCS, n, HighRes, Temperature (for MonoBloc® load cells only), Alibi no, MinWeigh, Scale model, Scale location, Scale identification	
			Page 2 & 3	Info page 2	Off, System info , Contact info
				Info page 3	Off , System info, Contact info
		Beeper	On, Off		
Timeout	Mode	Off, Rental, Screensaver			
	Days				
Reset	Perform reset?				







Description

Region	Country specific settings
Language	Selecting the language of the operator interface. We will expand the available languages continuously.
Date format	Selecting the date format
Set date	Entering the year in the selected format Entering the month in the selected format Entering the day in the selected format
Set year	
Set month	
Set day	
Time format	Selecting the time format
Set time	Entering the hour in the selected format Entering the minutes
Set hour	
Set minutes	

Sleep (Operator access)	Setting the sleep mode
Off 1 minute ... 30 minutes	This menu item only appears on devices in mains operation . When sleep is activated, the device switches off display and backlighting after the time period set when not in use and gross weight is 0. Display and backlighting are switched on again by pressing a key or if the weight changes.
Power off (Operator access)	Setting the power off mode
Off 1 minute ... 30 minutes	This menu item only appears on devices in battery operation . When power off is activated, the device switches itself off automatically after the time period set when not in use. After this, it must be switched on again using  .

Identification	Setting terminal identification data
Terminal location	Entering the terminal location, e.g., floor and room
Terminal ident.	Entering the terminal identification, e.g., inventory number
Note	<ul style="list-style-type: none"> Terminal location and terminal identification can be displayed in the auxiliary or info lines or printed out. Terminal location and terminal identification can consist of up to 12 characters (0 ... 9 and decimal point)

Display	Setting the display according to your specific task
Display Layout	Selecting the presentation of the weight value.
Brightness (Operator access)	Setting the brightness of the display. This menu item is accessible with Operator access rights.
Weight hold	Setting how long the weighing result is frozen in the display after the transfer key  has been pressed or auto print was generated.
Default colour	Setting the default colour for straight weighing.
Auxiliary line	Selecting the contents of the auxiliary display line.

Keyboard	Setting the keyboard according to your specific task
Hard keys	Locking/unlocking keys. Possible keys Power (), Clear (), Switch / Toggle (), Info (), Transfer (), Numeric keys
Soft keys Soft key 1-1 ... Soft key 4-4	Assigning a function to the selected key. 1. Select the soft key number 2. Assign function
Info key Page 1 Page 2, Page 3	Configuring the items to be displayed using the info key () On the first page of the info key up to 9 information items on the weighing process can be configured. 1. Select item number 2. Assign information On pages 2 and 3 system and contact information will be displayed. In case of a problem, here you will find your contact data and the system information the service technician will ask for. System information is set by the manufacturer, contact information is set by your sales representative.
Beeper	When set to On, each keystroke will be confirmed by a short beep.

Time out	Setting the behaviour when no action takes place on the terminal
Mode Off Rental Screensaver	Setting the time out mode. No time out setting. The scale can be used for a set time interval, e.g., when the scale is rented for a special event like a fair or a market. When there is no action on the scale for the set time, the display will show the screensaver.
Days	Entering the number of days the scale will be active in rental mode.

6.4.2 Terminal -> Access – Password for Supervisor menu access

Supervisor	Password for Supervisor menu access
Password	Enter password for Supervisor menu access.
Retype Password	Repeat the password entry.
Note	The password can consist of up to 6 characters.

6.4.3 Terminal -> Reset

Perform reset ?	Confirmation inquiry
	<ul style="list-style-type: none"> Reset the terminal settings to factory settings with OK.

6.5 Communication menu block



For detailed information on interface protocols and commands refer to the SICS Reference manual.

The Communication menu block consists of the following subblocks:

Overview	Showing the interfaces installed.
COM1	Parameter settings for the standard RS232 interface COM1.
COM2	Parameter settings for the optional second interface COM2.
Define templates	Defining templates to be assigned to the application specific printouts

The interfaces identify themselves. Therefore only those menu settings appear which are relevant for the individual interface.

If no optional interface is installed, the COM2 menu will not appear.

6.5.1 Communication menu blocks for serial interfaces

Possible settings for serial interfaces

		COM1	COM2					
		RS232	RS232	RS422 / RS485	Ethernet	WLAN	USB Device	USB Host
Mode	Print Auto print Continuous (Dialog) *	✓	✓	✓	✓	✓	✓	–
	Dialog *	Factory setting						
	External input	✓	✓	✓	✓	✓	–	✓
	Toledo cont.-weight Toledo cont.-count Second display Digitol B Digitol G	✓	✓	✓	✓	✓	✓	✓
Printer		✓	✓	✓	✓	✓	–	✓
External input		✓	✓	✓	✓	✓	–	✓
Parameter	Baud (factory setting)	9600	9600	9600	–	–	–	–
	Parity (factory setting)	8 none	8 none	8 none	–	–	–	–
	Handshake	✓	✓	✓	–	–	–	–
	Checksum	✓	✓	✓	✓	✓	–	✓
	STX	✓	✓	✓	✓	✓	–	–
	RS Type Net Address Load resistor	–	–	✓	–	–	–	–
	DHCP IP address Subnet mask Gateway	–	–	–	✓	✓	–	–
TCP settings		–	–	–	✓	✓	–	–
Wireless settings		–	–	–	–	✓	–	–

* for more information see Reference manual "MT-SICS for ICS4xx/ICS6xx"

Overview RS232 menu block (COM1 / COM2)

Level 1	Level 2	Level 3	Level 4
Mode	Print, Auto print, Continuous (Dialog), Dialog , External input, Toledo Cont.-weight, Toledo Cont.-count, Second display		
	Digitol B, Digitol G	Net Gross Tare	On, Off
Printer	Type	ASCII printer , Label printer	
	ACII Format	Line format	Multiple , Single, Fixed
		Line length	1 ... 24 ... 100
		Separator	. , : ; - _ / \ Space
		Expanded	On, Off
		Add line feed	0 ... 9
External input	Preamble length		
	Data length		
	Postamble length		
	Termination char.	CR, LF, EOT, ...	
	Destination	Off , Tare preset, ID1 ... ID3	
Parameter	Baud	300, 600, ... 9600 , ... 115200 baud	
	Parity	7 none, 8 none , 7 odd, 8 odd, 7 even, 8 even	
	Handshake	Off , Xon - Xoff	
	Checksum	Off , On	
Reset RS232	Perform Reset ?		

Overview RS422 / RS485 menu block (COM2)

Level 1	Level 2	Level 3
Mode	see RS232	
Printer		
External input		
Parameter	Baud	300, 600, ... 9600 , ... 115200 baud
	Parity	7 none, 8 none , 7 odd, 8 odd, 7 even, 8 even
	Handshake	Off , Xon - Xoff
	RS-Type	RS422 , RS485
	Net address	0 ... 31
	Checksum	Off , On
	Load resistor	Off , On
Reset RS4xx	Perform Reset ?	

Overview Ethernet menu block (COM2)

Level 1	Level 2	Level 3
Mode	see RS232	
Printer		
External input		
Parameter	DHCP	Off , On
	Local IP	
	Subnet mask	
	Gateway	
	Checksum	Off , On
	TCP Mode	TCP Mode
Local Port		
Remote IP		
Remote Port		
Connect Timeout		
Disconnect Timeout		
Reset Ethernet	Perform Reset ?	

Overview WLAN menu block (COM2)

Level 1	Level 2	Level 3
Mode	see RS232	
Printer		
External input		
Parameter	see Ethernet	
TCP Mode	see Ethernet	
Wireless setting	SSID	Enter SSID
	Encryption	Off, WEP, WPA
	WEP settings	64 Bit, 128 Bit
	WEP key	Key 1, Key 2, Key 3, Key 4
	WPA settings	WPA-TKIP, WPA2-AES
	Password	Enter password
Status	Display the current status, e.g., connection status, signal strength.	
Reset WLAN	Perform Reset ?	


Overview USB Device and USB Host menu blocks (COM2)

Level 1	Level 2	Level 3	Level 4
Mode	Continuous (Dialog), Dialog , External input *, Toledo Cont.-weight, Toledo Cont.-count, Second display		
	Digitol B, Digitol G	Net Gross Tare	On, Off
Printer *	see RS232		
External input *			
Parameter *	Checksum	Off , On	
Reset USB	Perform Reset ?		

*USB Host only

6.5.2 Description of the communication menu blocks for serial interfaces

Communication → COMx → Mode – Operating mode of the serial interface

Print	Manual data output to the printer with 
Auto print	Automatic output of stable results to the printer (e.g., for series weighing operations)
Continuous (Dialog)	Ongoing output of all weight values via the interface
Dialog	Bi-directional communication via MT-SICS commands, control of the device via PC
External input	Input other than via terminal keypad. What the input is used for is defined in the <i>Destination</i> menu block
Toledo Cont.-weight	TOLEDO Continuous mode
Toledo Cont.-count	TOLEDO Continuous mode with counting results
Second display	On the selected interface port a second display is installed
Digital B, Digital G	Digital compatible format. The gross weight is either identified by "B". Digital compatible format. The gross weight is either identified by "G".
Net, Gross, Tare	Selecting the weight values to be transferred.
Note	Printing conditions for <i>Auto print</i> and <i>Demand m auto</i> : <ul style="list-style-type: none"> • The weight must be heavier than 9 display increments. • A weight change of at least 9 display increments is required to initiate the next printout.

Communication → COMx → Printer – Settings for protocol printout

Type	Selecting printer type
ASCII printer Label printer	Note If Label printer is selected, the transmitted data does not include the name of the variable, e.g., date, gross, ID1, but the value and, if appropriate, the unit as a separate line. This allows the label printer to fill its template with the required data.
ASCII Format	Selecting formats for the protocol printout
Line format	Selecting line format:
Multiple	Multiple lines
Single	Single line
Fixed	Fixed (Records output in single lines; every record includes the number of characters that was defined under <i>Line length</i>)
Line length	Setting line length This item is only displayed for the line formats <i>Multiple</i> and <i>Fixed</i>
Separator	Selecting the separator This item is only displayed for the line format <i>Single</i>
Add line feed	Adding line feeds

Communication -> COMx -> External input – Configuring barcode input

Preamble length	The barcode may contain additional data ahead of the relevant data (preamble) and behind (postamble). → Enter the number of characters of preamble, (relevant) data and postamble
Data length	
Postamble length	
Termination char.	Selecting the termination character which is used by the connected barcode scanner
Destination	Selecting the item to be entered via barcode scanner

Communication -> COMx -> Parameter – Communication parameters

Not all parameters are available on all serial interfaces. Refer to the overviews of the interfaces to check which parameters are available.

Baud	Selecting baud rate
Parity	Selecting parity
Handshake	Selecting handshake
Checksum	Activating/deactivating checksum byte
STX	Activating/deactivating STX If STX is enabled, the STX signal (0x02) is sent at the beginning of each output string that is sent via the interface.
RS Type	Selecting type of the optional RS422/RS485 interface
Net Address	Assigning network address
Load resistor	To avoid reflexions on a network, we recommend to make a defined termination. For this purpose the load resistor within the terminal can be used. When set to "On", a resistor of approx. 100 Ω between the signal lines is enabled
DHCP	If DHCP is set to "On", the device will receive the IP address automatically. Then IP address, Subnet mask and Gateway are read-only fields
Local IP	Displaying/entering the local IP address
Subnet mask	Displaying/entering subnet mask
Gateway	Displaying/entering gateway address

6.5.3 Communication menu block für digital I/Os

Overview Digital I/O menu block (COM2)

Level 1	Level 2	Level 3
Input	Input pin 1 ... Input pin 4	Off, Zero, Tare, Transfer, Switch, Clear, Info, Target, Softkey 1-1 ... 4-5, Total +, Total -, Start
Output	Ready, Stable, Tare, Zero, < Min weigh, >= Min weigh, Underload, Overload, <= Setpoint 1, > Setpoint 1, <= Setpoint 2, > Setpoint 2, Good range, < Tolerance -, > Tolerance +, Good range, Star	Off , Output pin 1 ... Output pin 4
Setpoints	Setpoint 1, Setpoint 2	
Output mode	Continuous, Stable	

Configuring inputs

1. Select an input pin.
2. Assign an input signal to the selected input pin.

Configuring outputs

1. Select an output signal.
2. Assign an output pin.

Configuring setpoints

- Enter values for the setpoints.

Setting output mode

Continuous Digital outputs are updated continuously

Stable Digital outputs are updated only when the weight is stable

6.5.4 Communication – Define templates

Level 1	Level 2	Level 3
Template 1 ... Template 5	Line 1 ... Line 30	Not used, Header *, Date, Time, Gross, Net, Tare, High resolution, ID1, ID2, ID3, Terminal ID, Terminal location, SNR Terminal, SNR Scale, Star line, New line, Form feed, Target, Tolerance -, Tolerance +, Tol. type, Description field, Deviation, Weight position, Average PW, Reference count, Quantity, Article, Article description

* The content of these items has to be entered via SICS command.

Configuring templates

1. Select a template.
2. Select a line.
3. Assign an item.


6.6 Maintenance menu block

6.6.1 Overview

Level 1	Level 2	Level 3	Level 4
Scale test	Scale 1 Scale 2	Internal test	Perform test?
		External test	Perform test?
		Conf. ext. test	Test weight
	Weight name		
	Auto print	On, Off	
Keyboard test	Perform test?		
Display test	Perform test?		
Serial No.	SNR scale		
	SNR terminal		
Print setup	Print menu settings?		
Reset all	Perform reset?		




6.6.2 Description

Scale test	Testing the selected scale
Internal test Perform test?	For scales with an internal test weight → Press OK to start the test. The deviation of test weight value and actually weighed value is displayed.
External test Perform test?	For scales without an internal test weight 1. Press OK to start the test. Preload is displayed. 2. If applicable, load the preload, and press OK . The test weight is blinking. 3. Load the requested test weight and press OK . The deviation of test weight value and actually weighed value is displayed.
Conf. ext. test Test weight Weight name Tolerance	Configuring the external test weight Setting the test weight value Entering the test weight name Setting the test tolerance
Auto print	When set to On, a protocol is printed for each scale test.

Keyboard test	Testing the keyboard
Perform test?	<ol style="list-style-type: none"> 1. Press OK to start the keyboard test. 2. Press the keys in the displayed order. If the key works, the device switches to the next key. The keyboard test is terminated by pressing .
Display Test	Testing the display
Perform test?	<ol style="list-style-type: none"> 1. Press OK to start the display test. A checkerboard pattern is displayed. 2. Press any key to invert the checkerboard pattern. 3. Press any key to show the coloured display. 4. Repeat pressing a key until "Perform test?" is displayed again. <p>The display is working properly if all fields are displayed without missing pixels.</p>
Serial number	Displaying serial numbers
SNo. scale	Displaying the serial number of the connected weighing platform.
SNo. terminal	Displaying the serial number of the weighing terminal.
Print Setup	Printout of a list of all menu settings
Print menu settings	→ Press OK to start the printout.
Reset All	Reset all settings to factory settings
Perform reset ?	<p>Confirmation inquiry</p> <ul style="list-style-type: none"> • Reset all settings to factory settings with OK.

7 Event and error messages


7.1 Error conditions

Error	Cause	Remedy
Display dark	• Backlighting set too dark	→ Set backlighting brighter.
	• No mains voltage	→ Check mains.
	• Unit switched off	→ Switch on unit.
	• Mains cable not plugged in	→ Plug in mains cable.
	• Brief fault	→ Switch device off and on again.
Weight display unstable	• Restless installation location	→ Adjust vibration adapter.
	• Draft	→ Avoid draft.
	• Restless weighing sample	→ Dynamic weighing.
	• Contact between weighing pan and/or weighing sample and surroundings	→ Remedy contact.
	• Mains fault	→ Check mains.
Incorrect weight display	• Incorrect zeroing	→ Unload scale, set to zero and repeat weighing operation.
	• Incorrect tare value	→ Clear tare.
	• Contact between weighing pan and/or weighing sample and surroundings	→ Remedy contact.
	• Weighing platform tilted	→ Level weighing platform.
	• Load plate not on the scale • Weighing range not reached	→ Place load plate on the scale. → Set to zero.
	• Weighing range exceeded	→ Unload scale. → Reduce preload.
	• Result not yet stable	→ If necessary, adjust vibration adapter.
"Attention: Approval invalid" alternating with metrological data	• Approval was tampered with	→ Call METTLER TOLEDO service technician.

7.2 Errors and warnings

7.2.1 Error messages


Error messages contain the following information:



7.2.2 Warnings

Warnings are displayed briefly and then disappear automatically.

Example



7.3


Smart weighing counter / spanner icon


This weighing instrument features several control functions to monitor the condition of the device.

The METTLER TOLEDO service technician can setup and enable these functions.

This helps the user and the METTLER TOLEDO service technician to determine how the device is treated and what measures are needed to keep it in a good shape.

If the control functions triggers an alert, a message is shown.

You can confirm the message and continue to work with the weighing instrument. The spanner icon  lights up.



In case of an alert we strongly recommend calling the METTLER TOLEDO service technician

- to replace parts which are at the end of lifetime,
- to correct wrong settings,
- to educate operators about proper handling,
- to perform routine service work,
- to reset the alert.

The control functions monitor the following conditions:

- number of weighings
- number of overloads
- maximum weight
- zero commands and zero failures
- battery charging cycles
- power-on time
- date for the next service inspection

7.4

Service information

In case you need the METTLER TOLEDO service technician, you can read the necessary system and contact information from the device.

1. Press **I** twice.
System information data are displayed.
2. Press **I** again.
Your contact data are displayed.

8 Technical data and accessories

8.1 Technical data weighing terminal

Housing	<ul style="list-style-type: none"> Aluminium diecast
Display	<ul style="list-style-type: none"> LCD liquid crystal graphical display, with backlighting
Keyboard	<ul style="list-style-type: none"> Tactile-touch membrane keypad (PET) Scratch-resistant labelling
Protection type	<ul style="list-style-type: none"> With power supply connection IP65 With built-in storage battery IP65 With exchangeable battery IP54 Weighing platform IP54 / IP65 (option, not for XS)
Net weight	<ul style="list-style-type: none"> Weighing terminal 2.0 kg / 4.4 lb
Mains connection	<ul style="list-style-type: none"> Direct connection to power supply (supply voltage fluctuation not exceeding $\pm 10\%$ of the rated voltage) Rated voltage 100 ... 240 VAC / 50 ... 60 Hz / 300 mA Power cord approx. 2.5 m / 8.2 ft
Storage battery operation	<ul style="list-style-type: none"> Supply of device: 12 V \equiv / 2.5 A If the supply voltage is interrupted, the device automatically switches over to storage battery operation
9-28 VDC power supply	<ul style="list-style-type: none"> Rated voltage: 9 ... 28 V \equiv / max. 2.5 A Power cord approx. 5 m / 16 ft, open ends
Battery charger	<ul style="list-style-type: none"> Ambient conditions: 0 ... 40 °C / 32 ... 104 °F, dry environment
Ambient conditions	<ul style="list-style-type: none"> Application indoor use only Altitude up to 2,000 m Temperature range Class III -10 ... 40 °C / 14 ... 104 °F Temperature range Class II 10 ... 30 °C / 50 ... 86 °F Overvoltage category II Pollution degree 2 Humidity: Max. rel. humidity 85 % for temperatures up to 40 °C
Interfaces	<ul style="list-style-type: none"> 1 interface RS232 and 1 scale interface integrated 1 additional optional communication interface possible
W & M approvals	<ul style="list-style-type: none"> OIML Class II, III, IIII NTEP Class II, III

Applications

- Weighing
- Average weighing
- Counting
- Checkweighing
- Totalising
- Database
- Prompting
- Alibi Memory

Operating life with storage battery

The operating life during storage battery operation varies depending on the intensity of use, the configuration and the connected scale.

The following approximate values apply with standard RS232 interface and the brightness set to 5.

Weighing platform	Conditions	Duration
With strain gauge weighing platform, e.g., ICS465a-...SM/f	WLAN, continuous operation	8 h
	USB host, continuous operation	13 h
With MonoBloc® weighing platform, e.g., ICS465k-...SM/f	WLAN, continuous operation	7 h
	USB host, continuous operation	11 h

Analog scale interface

Impedance	• $\geq 80 \Omega$
Excitation	• 3.3 V
Sensitivity	• 2 to 3 mV/V
Max. resolution	• 7500 e (OIML) • 300,000 d (non approvable)
Min. verification interval	• 0.5 $\mu\text{V}/e$

8.2 Technical data weighing platforms

8.2.1 Strain gauge weighing platforms

ICS465d-.../f compact scales use a weighing platform with strain gauge load cell.

- Approved resolution of 1 x 6,000 e (OIML, NTEP)
- Non-approved resolutions up to 60,000 d

ICS465d-.../f	3SM	6SM	15LA	35LA
Capacity	3 kg	6 kg	15 kg	35 kg
	6 lb	12 lb	30 lb	70 lb
Readability				
Standard resolution: 6,000 d	0.5 g	1 g	2 g	5 g
	0.001 lb	0.002 lb	0.005 lb	0.01 lb
Optional resolution: 30,000 d	0.1 g	0.2 g	0.5 g	1 g
	0.0002 lb	0.0005 lb	0.001 lb	0.002 lb
Optional resolution: 60,000 d	0.05 g	0.1 g	0.2 g	0.5 g
	0.0001 lb	0.0002 lb	0.0005 lb	0.001 lb
Approved resolution: 6,000 e	0.5 g	1 g	2 g	5 g e
	0.001 lb	0.002 lb	0.005 lb	0.01 lb
Repeatability (sd)	0.05 g	0.1 g	0.2 g	0.5 g
	0.0001 lb	0.0002 lb	0.0005 lb	0.001 lb
Linearity	0.1 g	0.2 g	0.5 g	1 g
	0.0002 lb	0.0005 lb	0.001 lb	0.002 lb
Weight	5.5 kg	5.5 kg	7.7 kg	7.7 kg
	12.1 lb	12.1 lb	17.0 lb	17.0 lb

8.2.2 Monoblock weighing platforms

ICS465k-.../f and **ICS465k-.../DR/f** compact scales use a weighing platform with MonoBloc® load cell.


- Approved resolution of up to 61,000 e (OIML, NTEP)
- Non-approved resolutions up to 610,000 d
- FACT function (Fully Automatic Calibration Technology) calibrates the scale according to temperature changes thus increasing weighing accuracy
- **ICS465k-.../DR/f** provide a range with higher resolution.

ICS465k-.../f	0.6XS	3XS	6XS	6SM	15LA7	35LA
Capacity	0.6 kg	3 kg	6 kg	6 kg	15 kg	35 kg
	1.2 lb	6 lb	12 lb	12 lb	30 lb	70 lb
Readability						
Standard resolution	0.001 g	0.01 g	0.01 g	0.1 g	0.1 g	0.1 g
	0.000002 lb	0.00002 lb	0.00002 lb	0.0002 lb	0.0002 lb	0.0002 lb
Approved resolution	0.01 g	0.1 g	0.1 g	1 g	1 g	1 g
	0.00002 lb	0.0002 lb	0.0002 lb	0.002 lb	0.002 lb	0.002 lb
Repeatability (sd)	0.001 g	0.01 g	0.01 g	0.1 g	0.1 g	0.1 g
	0.00002 lb	0.00002 lb	0.00002 lb	0.0002 lb	0.0002 lb	0.0002 lb
Linearity	0.002 g	0.02 g	0.02 g	0.2 g	0.2 g	0.3 g
	0.000005 lb	0.00005 lb	0.00005 lb	0.0005 lb	0.0005 lb	0.0005 lb
Weight	5.7 kg	5.7 kg	5.7 kg	5.7 kg	9.0 kg	9.0 kg
	12.6 lb	12.6 lb	12.6 lb	12.6 lb	19.8 lb	19.8 lb

ICS465k-.../DR/f	0.6XS	3XS	6XS	6SM	15LA	35LA
Capacity	0.12 kg / 0.6 kg	0.6 kg / 3 kg	1.2 kg / 6 kg	1.2 kg / 6 kg	3 kg / 15 kg	7 kg / 35 kg
Readability						
Standard resolution	0.001 g / 0.01 g	0.01 g / 0.1 g	0.01 g / 0.1 g	0.1 g / 1 g	0.1 g / 1 g	0.1 g / 1 g
Approved resolution	0.01 g / 0.1 g	0.1 g / 1 g	0.1 g / 1 g	1 g / 10 g	1 g / 10 g	1 g / 10 g
Repeatability (sd)	0.001 g	0.01 g	0.01 g	0.1 g	0.1 g	0.1 g
Linearity	0.002 g	0.02 g	0.02 g	0.2 g	0.2 g	0.3 g
Weight	5.7 kg	5.7 kg	5.7 kg	5.7 kg	9.0 kg	9.0 kg


8.3 Dimensional drawings

8.3.1 Weighing terminal




8.3.2 Compact scales

Compact scale with **XS** or **SM** weighing platform



Compact scale with **LA** weighing platform










8.4

Accessories

Accessories	Order no.
Printer RS-P25/02	11 124 310
Printer USB-P25/02	11 124 311
Printer RS-P26/02	11 124 313
Printer RS-P28/02	11 124 314
Protective cover for the weighing terminal, set of 5 pieces	30 032 638
Auxiliary display AD-RS-M7	12 122 381
Power supply 9-28 V (conversion kit)	22 023 504
Charging station	30 035 339
Battery pack	30 032 647
Windshield for ...XS weighing platforms	72 262 929
Wall bracket	30 032 637
Support for wheeled bench stand	22 023 460
Column for PBA330, PBA655, PBD655 (requires wall bracket 30 032 637)	
Height 330 mm / 13 ft	72 198 699
Height 660 mm / 26 ft	72 198 700
Floor stand, height 1000 mm / 3,3 ft	
Painted steel	22 023 451
Stainless steel	22 023 503
Relaybox 4, for Digital I/O	22 011 967
Power supply for Relaybox 4	00 505 544
Cables	Order no.
Cable M12 USB Female Type A, USB host	
0.2 m / 0.7 ft,	22 017 604
3 m / 10 ft	22 017 608
Cable M12 USB Male Type A, USB device, 3 m / 10 ft	22 018 967
Cable M12 RS232 Female Sub D 9 pin (crossed; used for PC)	22 017 601
Cable M12 RS232 Male Sub D 9 pin (not crossed; used for SICS scale)	22 017 602
Cable M12 RS422/485, open ends	22 017 603
Cable M12 Digital I/O, open ends	22 018 969
Cable M12 Ethernet RJ45	
5 m / 16 ft,	22 017 610
20 m / 66 ft	22 017 614
Cable for auxiliary display AD-RS-M7	30 041 060

Assignment of the interface connections

	Digital I/O	RS232	RS422	RS485	USB Device USB Host	Ethernet	Power
Socket							
Pin 1	In 0	CTS	TxD+	T/RxD+	+5 V	TD+	+12 V
Pin 2	In 1	TxD	TxD-	T/RxD-	D-	RD+	+12 V
Pin 3	In 2	RTS	RxD+	-	GND	TD-	GND
Pin 4	In 3	RxD	+12 V	+12 V	D+	RD-	GND
Pin 5	In_GND	+12 V	GND	GND			
Pin 6	Out 0	+5 V	RxD-	-			
Pin 7	Out 1	-					
Pin 8	Out 2	GND					
Pin 9	Out 3						
Pin 10	Out_GND						
Pin 11	+12 V						
Pin 12	GND						

9 Appendix

9.1 Notice for verified instruments in EC countries



Weighing instruments verified at the place of manufacture bear the preceding mark on the packing label and a green "M" sticker on the descriptive plate. They may be set to work immediately.



Weighing instruments which are verified in two steps have no green "M" on the descriptive plate and bear the preceding identification mark on the packing label. The second step of the verification must be carried out by the approved METTLER TOLEDO service or Weights and Measures authorities. Please contact your METTLER TOLEDO organisation. The first step of the verification has been carried out at the manufacturing plant.

If national regulations in individual countries limit the period of validity of the verification, the operator of such a weighing instrument is himself responsible for its timely re-verification.

9.2 Tables of Geo Code values

For weighing instruments verified at the manufacturer's, the Geo Code value indicates the country or geographical zone for which the instrument is verified. The Geo Code value set in the instrument (e.g. "Geo 18") appears briefly after switching on.

Table "Geo Code values 3000e" shows the Geo Code values for European countries.

Table "Geo Code values 6000e/7500e" shows the Geo Code values for different gravitation zones.

9.2.1 Geo Code values 3000e, OIML Class III (European Countries)

Country	Geographical latitude	Geo Code value
Austria	46°22' – 49°01'	18
Belgium	49°30' – 51°30'	21
Bulgaria	41°41' – 44°13'	16
Croatia	42°24' – 46°32'	18
Czechia	48°34' – 51°03'	20
Denmark	54°34' – 57°45'	23
Estonia	57°30' – 59°40'	24
Finland	59°48' – 64°00'	25*
	64°00' – 70°05'	26
France	41°20' – 45°00'	17
	45°00' – 51°00'	19*
Germany	47°00' – 55°00'	20
Greece	34°48' – 41°45'	15
Hungary	45°45' – 48°35'	19
Iceland	63°17' – 67°09'	26
Ireland	51°05' – 55°05'	22
Italy	35°47' – 47°05'	17
Latvia	55°30' – 58°04'	23

Country	Geographical latitude	Geo Code value
Liechtenstein	47°03' – 47°14'	18
Lithuania	53°54' – 56°24'	22
Luxemburg	49°27' – 50°11'	20
Netherlands	50°46' – 53°32'	21
Norway	57°57' – 64°00'	24*
	64°00' – 71°11'	26
Poland	49°00' – 54°30'	21
Portugal	36°58' – 42°10'	15
Romania	43°37' – 48°15'	18
Slovakia	47°44' – 49°46'	19
Slovenia	45°26' – 46°35'	18
Spain	36°00' – 43°47'	15
Sweden	55°20' – 62°00'	24*
	62°00' – 69°04'	26
Switzerland	45°49' – 47°49'	18
Turkey	35°51' – 42°06'	16
United Kingdom	49°00' – 55°00'	21*
	55°00' – 62°00'	23

* factory setting

9.2.2

Geo Code values 6000e/75000e OIML Class III (Height ≤ 1000 m)

Geographical latitude	Geo Code value	Geographical latitude	Geo Code value
00°00' – 12°44'	18	43°26' – 47°51'	18
05°46' – 17°10'	21	45°38' – 50°06'	22
12°44' – 20°45'	16	47°51' – 52°22'	20
17°10' – 23°54'	18	50°06' – 54°41'	21
20°45' – 26°45'	20	52°22' – 57°04'	24*, 26
23°54' – 29°25'	23	54°41' – 59°32'	21
26°45' – 31°56'	24	57°04' – 62°09'	15
29°25' – 34°21'	25*, 26	59°32' – 64°55'	18
31°56' – 36°41'	17, 19*	62°09' – 67°57'	19
34°21' – 38°58'	20	64°55' – 71°21'	18
36°41' – 41°12'	15	67°57' – 75°24'	15
38°58' – 43°26'	19	71°21' – 80°56'	24*, 26
41°12' – 45°38'	26	75°24' – 90°00'	18

* factory setting

9.3



Disposal

In conformance with the European Directive 2002/96 EC on Waste Electrical and Electronic Equipment (WEEE), this device may not be disposed of with domestic waste. This also applies to countries outside the EU, according to their specific requirements.

Please dispose of this product in accordance with local regulations at the collecting point specified for electrical and electronic equipment.

If you have any questions, please contact the responsible authority or the distributor from which you purchased this device.

Should this device be passed on to other parties (for private or professional use), the content of this regulation must also be related.

Thank you for your contribution to environmental protection.

9.4 Protocol printouts

P25 printouts, in English

Straight weighing – standard template

Gross	255 g	Gross/net/tare weights
Net	94 g	
Tare	161 g	

Starline

Average weighing with header and identification data

METTLER TOLEDO		Header
Tel. +49 7431 140		
Germany		
Date	07/05/2012	Date/time
Time	17:26:56	
ID1	Company ABC	Identifications
ID2	ID1	
ID3	ID2	
Dev.Id	456	
Average G	236 g	Average weighing result

Piece counting with header and identification

METTLER TOLEDO		Header
Tel. +49 7431 140		
Germany		
Date	07/05/2012	Date/time
Time	17:35:39	
ID1	Company ABC	Identifications
ID2	ID1	
ID3	ID2	
Dev.Id	456	
Gross	756 g	Gross/tare/net weights
Tare	161 g	
Net	595 g	
APW	9 g	Reference weight data
Ref Cnt	10 PCS	Counting result
Quantity	63 PCS	

Checkweighing

Date	05/02/2002	Date/time
Time	06:39:33	
Terminal model	DeviceNam	Identification
Gross	5.000 kg	Gross weight
Target	4.800 kg	Checkweighing info
High	5.100 kg	
Low	4.500 kg	
Deviation	0.200 kg	

9.5 Index

A		E		P	
Accessories	82	Environment	77	Power supply	16, 77
Average weighing	22	Errors	74	Printing	21
		Error conditions	74	Printout examples	87
B		Error messages	75	Prompting	58
Battery		External input	69	Additive tare	26
Changing	17	G		Hands free	25
Handling	16	Geo value	28, 84	Multi tare	26
Specification	77			Sample/Tare	25
				Tare/Sample	24
C		I		S	
Checkweighing	34	Identifications	23, 61	Safety instructions	5, 28
Checkcounting	36	Info key	11, 21, 62	Service information	21, 76
Display	37	Interface assignment	83	SICS	
Quick start	39	Interface settings	63	Command set	63
Subtractive weighing	39	Digital I/O	70	Identifications	23
Tolerance types	34	Ethernet	66	Tare preset	20
To zero	40	RS232	65	Simple weighing	18
Commissioning	14	RS422 / RS485	66	Smart weighing counter	76
Compact scales	6	USB	67	Soft keys	12
Counting	29, 52	WLAN	67	Spanner icon	8, 76
Autosampling	31, 53	K		Switching on and off	18
Auxiliary scale	32, 53	Keyboard	11		
Bulk scale	32, 53	M		T	
Reference optimisation	31, 52	Menu		Tare	
Reference scale	32, 53	Application	51	Automatic clearing	19
Reference weight		Communication	63	Automatic taring	20, 49
check	30, 52	Operation	44	Chain tare	20
D		Password	44	Tare preset	20
Database	33, 37	Scale	47	Taring	19
Dimensions	81	Terminal	59	Technical data	77
Display		Messages	74	Templates	51, 71
Auxiliary line	8, 62	MinWeigh	50	Test	
Checkweighing	8	Mode		Display	73
Metrological data	9	Dialog mode	68	Keyboard	73
Symbols and info line	10	Digital	68	Scale	72
Weight display	10	External input	68	Verification	28
Disposal	86	Print mode	68	Totalising	42
Dynamic weighing	22, 51	Second display	68		
		Toledo Continuous	68		

V

Verified instruments in EC
countries..... 84

W

Warnings 75

Z

Zero

Automatic zero update..... 49

Zeroing 19

Zero point correction..... 19

**To protect your METTLER TOLEDO
product's future:**

METTLER TOLEDO Service XXL assures
the quality, measuring accuracy and
preservation of value of all METTLER
TOLEDO products for years to come.

Please send for full details about our
attractive terms of service.
Thank you.

www.mt.com/service

For more information

Mettler-Toledo (Albstadt) GmbH

D-72458 Albstadt
Tel. +49 7431-14 0
Fax +49 7431-14 232

Subject to technical changes
© 04/2012 Mettler-Toledo (Albstadt) GmbH
Printed in Germany
Order number 22023406A



* 2 2 0 2 3 4 0 6 A *