



Hardware User Manual

EA9-USER-M



VICPAS

WARNING M

Thank you for purchasing automation equipment from Automationdirect.com[®], doing business as, AutomationDirect. We want your new automation equipment to operate safely. Anyone who installs or uses this equipment should read this publication (and any other relevant publications) before installing or operating the equipment.

To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and usually change with time. It is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation is in compliance with the latest revision of these codes.

At a minimum, you should follow all applicable sections of the National Fire Code, National Electrical Code, and the codes of the National Electrical Manufacturer's Association (NEMA). There may be local regulatory or government offices that can also help determine which codes and standards are necessary for safe installation and operation.

Equipment damage or serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.

Our products are not fault-tolerant and are not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of the product could lead directly to death, personal injury, or severe physical or environmental damage ("High Risk Activities"). **AutomationDirect** specifically disclaims any expressed or implied warranty of fitness for High Risk Activities.

For additional warranty and safety information, see the Terms and Conditions section of our catalog. If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please call us at 770-844-4200.

This publication is based on information that was available at the time it was printed. At **AutomationDirect** we constantly strive to improve our products and services, so we reserve the right to make changes to the products and/or publications at any time without notice and without any obligation. This publication may also discuss features that may not be available in certain revisions of the product.

Trademarks

This publication may contain references to products produced and/or offered by other companies. The product and company names may be trademarked and are the sole property of their respective owners. **AutomationDirect** disclaims any proprietary interest in the marks and names of others.

Copyright 2021, Automationdirect.com[®] Incorporated All Rights Reserved

No part of this manual shall be copied, reproduced, or transmitted in any way without the prior, written consent of Automationdirect.com[®] Incorporated. AutomationDirect retains the exclusive rights to all information included in this document.



N ADVERTENCIA N

Gracias por comprar equipo de automatización de **Automationdirect.com**[®]. Deseamos que su nuevo equipo de automatización opere de manera segura. Cualquier persona que instale o use este equipo debe leer esta publicación (y cualquier otra publicación pertinente) antes de instalar u operar el equipo.

Para reducir al mínimo el riesgo debido a problemas de seguridad, debe seguir todos los códigos de seguridad locales o nacionales aplicables que regulan la instalación y operación de su equipo. Estos códigos varian de área en área y usualmente cambian con el tiempo. Es su responsabilidad determinar cuales códigos deben ser seguidos y verificar que el equipo, instalación y operación estén en cumplimiento con la revisión mas reciente de estos códigos.

Como mínimo, debe seguir las secciones aplicables del Código Nacional de Incendio, Código Nacional Eléctrico, y los códigos de (NEMA) la Asociación Nacional de Fabricantes Eléctricos de USA. Puede haber oficinas de normas locales o del gobierno que pueden ayudar a determinar cuales códigos y normas son necesarios para una instalación y operación segura.

Si no se siguen todos los códigos y normas aplicables, puede resultar en daños al equipo o lesiones serias a personas. No garantizamos los productos descritos en esta publicación para ser adecuados para su aplicación en particular, ni asumimos ninguna responsabilidad por el diseño de su producto, la instalación u operación.

Nuestros productos no son tolerantes a fallas y no han sido diseñados, fabricados o intencionados para uso o reventa como equipo de control en línea en ambientes peligrosos que requieren una ejecución sin fallas, tales como operación en instalaciones nucleares, sistemas de navegación aérea, o de comunicación, control de tráfico aéreo, máquinas de soporte de vida o sistemas de armamentos en las cuales la falla del producto puede resultar directamente en muerte, heridas personales, o daños físicos o ambientales severos ("Actividades de Alto Riesgo"). **Automationdirect.com** específicamente rechaza cualquier garantía ya sea expresada o implicada para actividades de alto riesgo. Para

información adicional acerca de garantía e información de seguridad, vea la sección de Términos y Condiciones de nuestro catálogo. Si tiene alguna pregunta sobre instalación u operación de este equipo, o si necesita información adicional, por favor llámenos al número 770-844-4200 en Estados Unidos. Esta publicación está basada en la información disponible al momento de impresión. En **Automationdirect.com** nos esforzamos constantemente para mejorar nuestros productos y servicios, así que nos reservamos el derecho de hacer cambios al producto y/o a las publicaciones en cualquier momento sin notificación y sin ninguna obligación. Esta publicación también puede discutir características que no estén disponibles en ciertas revisiones del producto.

Marcas Registradas

Esta publicación puede contener referencias a productos producidos y/u ofrecidos por otras compañías. Los nombres de las compañías y productos pueden tener marcas registradas y son propiedad única de sus respectivos dueños. Automationdirect.com, renuncia cualquier interés propietario en las marcas y nombres de otros.

PROPIEDAD LITERARIA 2021, AUTOMATIONDIRECT.COM[®] INCORPORATED Todos los derechos reservados

No se permite copiar, reproducir, o transmitir de ninguna forma ninguna parte de este manual sin previo consentimiento por escrito de **Automationdirect.com**[®] **Incorprated. Automationdirect.com** retiene los derechos exclusivos a toda la información incluida en este documento. Los usuarios de este equipo pueden copiar este documento solamente para instalar, configurar y mantener el equipo correspondiente. También las instituciones de enseñanza pueden usar este manual para propósitos educativos.

VICPAS

AVERTISSEMENT 🗡

Nous vous remercions d'avoir acheté l'équipement d'automatisation de **Automationdirect.com**[®], en faisant des affaires comme, **AutomationDirect**. Nous tenons à ce que votre nouvel équipement d'automatisation fonctionne en toute sécurité. Toute personne qui installe ou utilise cet équipement doit lire la présente publication (et toutes les autres publications pertinentes) avant de l'installer ou de l'utiliser.

Afin de réduire au minimum le risque d'éventuels problèmes de sécurité, vous devez respecter tous les codes locaux et nationaux applicables régissant l'installation et le fonctionnement de votre équipement. Ces codes diffèrent d'une région à l'autre et, habituellement, évoluent au fil du temps. Il vous incombe de déterminer les codes à respecter et de vous assurer que l'équipement, l'installation et le fonctionnement sont conformes aux exigences de la version la plus récente de ces codes.

Vous devez, à tout le moins, respecter toutes les sections applicables du Code national de prévention des incendies, du Code national de l'électricité et des codes de la National Electrical Manufacturer's Association (NEMA). Des organismes de réglementation ou des services gouvernementaux locaux peuvent également vous aider à déterminer les codes ainsi que les normes à respecter pour assurer une installation et un fonctionnement sûrs.

L'omission de respecter la totalité des codes et des normes applicables peut entraîner des dommages à l'équipement ou causer de graves blessures au personnel. Nous ne garantissons pas que les produits décrits dans cette publication conviennent à votre application particulière et nous n'assumons aucune responsabilité à l'égard de la conception, de l'installation ou du fonctionnement de votre produit.

Nos produits ne sont pas insensibles aux défaillances et ne sont ni conçus ni fabriqués pour l'utilisation ou la revente en tant qu'équipement de commande en ligne dans des environnements dangereux nécessitant une sécurité absolue, par exemple, l'exploitation d'installations nucléaires, les systèmes de navigation aérienne ou de communication, le contrôle de la circulation aérienne, les équipements de survie ou les systèmes d'armes, pour lesquels la défaillance du produit peut provoquer la mort, des blessures corporelles ou de graves dommages matériels ou environnementaux («activités à risque élevé»). La société **AutomationDirect** nie toute garantie expresse ou implicite d'aptitude à l'emploi en ce qui a trait aux activités à risque élevé.

Pour des renseignements additionnels touchant la garantie et la sécurité, veuillez consulter la section Modalités et conditions de notre documentation. Si vous avez des questions au sujet de l'installation ou du fonctionnement de cet équipement, ou encore si vous avez besoin de renseignements supplémentaires, n'hésitez pas à nous téléphoner au 770-844-4200.

Cette publication s'appuie sur l'information qui était disponible au moment de l'impression. À la société AutomationDirect, nous nous efforçons constamment d'améliorer nos produits et services. C'est pourquoi nous nous réservons le droit d'apporter des modifications aux produits ou aux publications en tout temps, sans préavis ni quelque obligation que ce soit. La présente publication peut aussi porter sur des caractéristiques susceptibles de ne pas être offertes dans certaines versions révisées du produit.

Marques de commerce

La présente publication peut contenir des références à des produits fabriqués ou offerts par d'autres entreprises. Les désignations des produits et des entreprises peuvent être des marques de commerce et appartiennent exclusivement à leurs propriétaires respectifs. **AutomationDirect** nie tout intérêt dans les autres marques et désignations.

Copyright 2021, Automationdirect.com® Incorporated Tous droits réservés

Nulle partie de ce manuel ne doit être copiée, reproduite ou transmise de quelque façon que ce soit sans le consentement préalable écrit de la société **Automationdirect.com**[®] **Incorporated. AutomationDirect** conserve les droits exclusifs à l'égard de tous les renseignements contenus dans le présent document.







HARDWARE USER MANUAL

Please include the Manual Number and the Manual Issue, both shown below, when communicating with Technical Support regarding this publication.

Manual Number:	EA9-USER-M
Issue:	1st Edition Revision P
Issue Date:	08/21

Publication History		
Issue Date Description of Changes		
First Edition	03/14	Original
1st Ed. Rev. A	10/14	Minor Revisions
1st Ed. Rev. B	01/15	Revised PLC communication and drivers, minor revisions
1st Ed. Rev. C	03/16	Added Recovery Tool and No System Found to Troubleshooting, minor revisions
1st Ed. Rev. D	12/16	Added EA9-T7CL(-R). Added Appendix C, minor revisions
1st Ed. Rev. E	11/17	Added EA9-T10WCL and EA9-T15CL-R. Minor revisions
1st Ed. Rev. F	02/18	Revised Memory Device Formatting table
1st Ed. Rev. G	08/18	Corrected DH485-CBL description
1st Ed. Rev. H	08/19	Added Micro-800 series. Minor revisions
1st Ed. Rev. J	09/19	Minor Revisions
1st Ed. Rev. K	01/20	Added S7-1500
1st Ed. Rev. L	04/20	Minor Revisions
1st Ed. Rev. M	06/20	Revised Appendix C
1st Ed. Rev. N	07/20	Revised Hazardous location information
1st Ed. Rev. P	08/21	Updated cable photos





TABLE OF CONTENTS

Chapter 1: Getting Started

Introduction	1-2
The Purpose of this Manual	1-2
Supplemental Manuals	1-2
Technical Support	1-2
Conventions Used	1-3
Key Topics for Each Chapter	1-3
Product Overview	1-4
Quick Start Steps	1-5
Step 1 – Unpack and Inspect	1-5
Step 2 – Install Optional Hardware Accessories	1-6
Step 3 – Become Familiar with Available Communication Ports	1-7
Step 4 – Install the Programming Software and Develop a Project	1-8
Step 5 – Connect Touch Panel to Computer	1-9
Step 6 – Provide Power to the Touch Panel	1-10
Step 7 – Access the Touch Panel Setup Screens	1-12
Step 8 – Choose Touch Panel to Device Cables	1-13
Step 9 – Connect Touch Panel to PLC	1-16

Chapter 2: Specifications

Available Models	2-4
Model Specifications	2-5
Specifications common to all models	2-6
6-inch Models	2-7
7-inch Models	2-8
8-inch and 10-inch Models	2-9
12-inch and 15-inch Models	2-10

VICPAS Ile of Contents

EA9-T6CL-R, EA9-T6CL	
Dimensions, Inches [mm]	
Ports and Memory Expansion	
EA9-T7CL-R, EA9-T7CL	2-13
Dimensions, Inches [mm]	2-13
Ports and Memory Expansion	2-14
EA9-T8CL	
Dimensions, Inches [mm]	2-15
Ports and Memory Expansion	
EA9-T10CL	2-17
Dimensions, Inches [mm]	2-17
EA9-T10WCL	
Dimensions, Inches [mm]	
Ports and Memory Expansion	2-19
EA9-T12CL	
Dimensions, Inches [mm]	
Ports and Memory Expansion	
EA9-T15CL-R, EA9-T15CL	
Dimensions, Inches [mm]	
Ports and Memory Expansion	
Mounting Clearances	2-25
EA9-T15CL-R, EA9-T15CL Derating	
Communications Ports	
Handling External Memory Devices	
Writing to External Memory Devices	
Memory Device Formatting	
Minimizing Data Errors	
Monitoring Available Memory	
File Name Limitations	
Power Loss Retention	
Chemical Compatibility	



iii

Chapter 3: Accessories

Accessories Overview	3-2
AC/DC Power Adapter	
AC/DC Power Adapter Dimensions	3-5
AC/DC Power Adapter Installation	
EA-ECOM Ethernet Communication Module	3-7
D-SUB 15-pin to Terminal Block Adapters	3-8
Non-glare Screen Covers	
Clear Screen Overlay Installation	
SD Card	3-11
USB FLASH Drive	3-11

Chapter 4: Installation and Wiring

Safety Guidelines	
Introduction	
UL Requirements	4-4
EA9-T6CL-R, EA9-T6CL, EA9-T7CL-R and EA9-T7CL Cutout Dimensions	4-5
EA9-T8CL and EA9-T10WCL Cutout Dimensions	4-6
EA9-T12CL Cutout Dimensions	4-8
EA9-T15CL-R and EA9-T15CL Cutout Dimensions	
Mounting Clearances	4-10
EA9-T15CL-R, EA9-T15CL Derating	4-11
Wiring Guidelines	4-12
Agency Approvals	4-12
Providing Power to the Touch Panel	4-13
C-more LED Status Indicators	4-14

Chapter 5: System Setup Screens

Introduction	5-2
Accessing the System Setup Screens (no project loaded)	5-3
Accessing the System Setup Screens (with project loaded)	5-4
System Setup Screens – Enable Password in Software	5-6
System Setup Screens Flowchart	5-12
Main Menu	5-13
Information Menu	5-14
Setting Menu	5-18
Test Menu	5-25
Memory Menu	5-34

Chapter 6: PLC Communications

Introduction	6-2
DirectLOGIC PLCs Password Protection	6-2
PLC Protocols	6-3
PLC Communication Cables & Wiring Diagrams	6-5
AutomationDirect PLCs RS-232C Serial	6-7
AutomationDirect PLCs RS-422A/RS-485A	6-10
DirectLOGIC Universal Isolated Network Adapter, p/n FA-ISOCON:	6-16
DirectLOGIC Universal Converter, p/n F2-UNICON:	6-17
RS-422A/RS-485A Multi-Drop Wiring Diagram Examples	6-18
Allen-Bradley	6-22
GE	6-27
GE VersaMax Micro	6-27
Mitsubishi	6-28
Omron	6-30
Modicon Modbus RS-232	6-31
Modicon Micro Series	6-31
Modicon Modbus with RJ45	6-31
Siemens	6-32

Chapter 7: Maintenance

Check Operating Environment7-2Check Operating Voltage7-2Check Status Indicators7-2Check Status Indicators7-2Check Physical Conditions7-3Run Tests under System Setup Screens7-3Check Memory Usage7-4Check/Adjust Display Brightness7-4Check Error Log7-4Adjust Touch Panel.7-4Cleaning the Display Screen7-5Check Project Functionality7-6Checks from C-more Programming Software7-7	Project Backup	
Check Operating Voltage7-2Check Status Indicators7-2Check Physical Conditions7-3Run Tests under System Setup Screens7-3Check Memory Usage7-4Check/Adjust Display Brightness7-4Check Error Log7-4Adjust Touch Panel7-4Cleaning the Display Screen7-5Check Project Functionality7-6Checks from C-more Programming Software7-7	Check Operating Environment	7-2
Check Status Indicators7-2Check Physical Conditions7-3Run Tests under System Setup Screens7-3Check Memory Usage7-4Check/Adjust Display Brightness7-4Check Error Log7-4Adjust Touch Panel7-4Cleaning the Display Screen7-5Check Project Functionality7-6Checks from C-more Programming Software7-7	Check Operating Voltage	7-2
Check Physical Conditions7-3Run Tests under System Setup Screens7-3Check Memory Usage7-4Check/Adjust Display Brightness7-4Check Error Log7-4Adjust Touch Panel7-4Cleaning the Display Screen7-5Check Project Functionality7-6Checks from C-more Programming Software7-7	Check Status Indicators	7-2
Run Tests under System Setup Screens.7-3Check Memory Usage7-4Check/Adjust Display Brightness.7-4Check Error Log7-4Adjust Touch Panel.7-4Cleaning the Display Screen7-5Check Project Functionality7-6Checks from C-more Programming Software7-7	Check Physical Conditions	7-3
Check Memory Usage7-4Check/Adjust Display Brightness7-4Check Error Log7-4Adjust Touch Panel.7-4Cleaning the Display Screen7-5Check Project Functionality7-6Checks from C-more Programming Software7-7	Run Tests under System Setup Screens	
Check/Adjust Display Brightness.7-4Check Error Log7-4Adjust Touch Panel.7-4Cleaning the Display Screen.7-5Check Project Functionality7-6Checks from C-more Programming Software7-7	Check Memory Usage	7-4
Check Error Log 7-4 Adjust Touch Panel. 7-4 Cleaning the Display Screen 7-5 Check Project Functionality 7-6 Checks from C-more 7-6 Notes: 7-7	Check/Adjust Display Brightness	7-4
Adjust Touch Panel	Check Error Log	7-4
Cleaning the Display Screen	Adjust Touch Panel	7-4
Check Project Functionality	Cleaning the Display Screen	7-5
Checks from C - <i>more</i> Programming Software	Check Project Functionality	7-6
Notes:	Checks from C-more Programming Software	7-6
	Notes:	

Chapter 8: Troubleshooting

Common Problems
Troubleshooting Flow Chart
Touch Panel does not Power up
Display is Blank
Display is Dim
No User Program
Firmware Recovery Tool
No System Found
No Communications between Panel and PC (Personal Computer) via USB
USB Driver Troubleshooting
No Communications between Panel and PC (Personal Computer) via Ethernet 8-14
No Communications between Panel and PLC
IP Address in System Setup Screens displays 0.0.0.0
Difficulty Connecting to the Panel over the Internet (Web server and Remote Access
features)
PLC Protocol Error Codes
Touch Panel Runtime Errors
Panel Constantly Displays "Initializing" when Powering up
Data not Logging Problems

Electrical Noise Problems

Chapter 9: Replacement Parts

Replacement Parts Overview	9-2
Panel Mounting Clip Replacements – EA9-BRK	9-3
Logo Label Replacement Insert - EA9-LBL	9-4
3-wire Communications Terminal Block – EA9-3TB	9-5
DC Panel Power Connector Replacement – EA-DC-CON	9-5
AC Power Adapter Connector Replacement– EA-AC-CON	9-6
Panel Gasket Replacements – EA9-xx-GSK	9-7
Gasket Replacement Installation Instructions:	9-7

Appendix A: Panel and PLC Error Code Tables

Introduction	A-2
C-more Touch Panel Error Code Table	A-3
Direct LOGIC – Panel Error Code PLC-499 Explanation	A-5
Direct LOGIC K-Sequence Protocol – PLC Error Code Table	A-5
Direct LOGIC Direct NET Protocol – PLC Error Codes	A-5
Modbus Protocols Error Code P499 Explanation	A-6
AutomationDirect CLICK	A-6
AutomationDirect DirectLOGIC - Modbus (Koyo)	A-6
Modicon Modbus RTU	A-6
Entivity Modbus RTU	A-6
Direct LOGIC ECOM Protocol – PLC Error Codes	A-6
Productivity Error Code P499	A-7
AutomationDirect Do-More Error Codes	A-8
Allen-Bradley – Panel Error Code PLC-499 Explanation	A-9
Allen-Bradley DF1 & DH485 Protocols – PLC Error Code Tables	A-10
Allen-Bradley EtherNet/IP Protocol –	
Panel Error Code PLC-496, 497 and 498 Explanation	A-12



Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, CompactLogix, & FlexLogix	A-13
Allen-Bradley – Micro800 Serial and EtherNet/IP Tag Based PLC Error Code Tab	les
Allen-Bradley - EtherNet /IP Protocol - PLC Error Code Tables	Α-17 Δ_21
Generic EtherNet IP Protocol – PLC Error Codes	A-26
GE 90-30 – Panel Error Code PLC-499 Explanation	A-27
GE 90-30 SNPX Protocol – PLC Error Code Tables	A-28
Mitsubishi FX Protocol – PLC Error Codes	A-37
Omron – Panel Error Code PLC-499 Explanation	A-37
Omron Host Link Protocol – PLC Error Code Table	A-38
Omron FINS Protocol – PLC Error Code Table	A-39
Omron – Panel Error Code P495 Explanation	A-42
Omron CS/CJ FINS Ethernet Protocol – PLC Error Code Table	A-43
Siemens – Panel Error Code P499 Explanation	A-44
Siemens PPI Protocol – PLC Error Code Table	A-45
Siemens ISO over TCP Protocol – PLC Error Code Table	A-46

Appendix B: Touch Panel Runtime Errors

Introduction	B-2
Runtime Errors	В-З
Log File Naming	B-4

Appendix C: Security Considerations for Control Systems Networks

Security Considerations for Control Systems NetworksC-2	2
---	---





GETTING STARTED



In This Chapter...

Introduction	1-2
The Purpose of this Manual	1-2
Supplemental Manuals	1-2
Technical Support	1-2
Conventions Used	1-3
Key Topics for Each Chapter	1-3
Product Overview	1-4
Quick Start Steps	1-5
Step 1 – Unpack and Inspect	1-5
Step 2 – Install Optional Hardware Accessories	1-6
Step 3 – Become Familiar with Available Communication Ports	1-7
Step 4 – Install the Programming Software and Develop a Project	1-8
Step 5 – Connect Touch Panel to Computer	1-9
Step 6 – Provide Power to the Touch Panel	1-10
Step 7 – Access the Touch Panel Setup Screens	1-12
Step 8 – Choose Touch Panel to Device Cables	1-13
Step 9 – Connect Touch Panel to PLC	1-16

CHAPTER

Introduction

The Purpose of this Manual

Thank you for purchasing our *C-more*® Touch Panel family of products. This manual describes AutomationDirect.com's *C-more* Touch Panels, their specifications, included components, available accessories and provides you with important information for installation, connectivity and setup. The manual shows you how install, wire and use the products. It also helps you understand how to interface the panels to other devices in a control system.

This user manual contains important information for personnel who will install the touch panels and accessories, and for the personnel who will be programming the panel. If you understand control systems that make use of operating interfaces such as the *C-more* touch panels, our user manuals will provide all the information you need to get, and keep your system up and running.

Supplemental Manuals

If you are familiar with industrial control type devices, you may be able to get up and running with just the aide of the Quick Start Guide that is included with each touch panel. You can also refer to the On-line help that is available in the *C-more* programming software for more information about programming the panel.

Technical Support

We strive to make our manuals the best in the industry. We rely on your feedback to let us know if we are reaching our goal. If you cannot find the solution to your particular application, or, if for any reason you need technical assistance, please call us at:

770-844-4200

Our technical support group will work with you to answer your questions. They are available Monday through Friday from 9:00 A.M. to 6:00 P.M. Eastern Time. We also encourage you to visit our web site where you can find technical and non-technical information about our products and our company.

http://c-more.automationdirect.com



Conventions Used

Á	<u>,,,,,,,</u>
/	=
/	=
-	

When you see the "notepad" icon in the left-hand margin, the paragraph to its immediate right will be a special note. The word NOTE: in boldface will mark the beginning of the text.



When you see the "exclamation mark" icon in the left-hand margin, the paragraph to its immediate right will be a warning. This information could prevent injury, loss of property, or even death (in extreme cases). The word Warning: in boldface will mark the beginning of the text.

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

Key Topics for Each Chapter

The beginning of each chapter will list the key topics that can be found in that chapter.



Product Overview

Some of the features designed into the product to provide excellent hardware and software are listed below.

- Analog touch screen (no touch cell boundaries). The touchscreen is designed to respond to a single touch. If it is touched at multiple points at the same time, an unexpected object may be activated.
- Plenty of memory and methods to get data in/out of the panel
- · Overlapping active devices on the touch screen
- 65,536 colors for enhanced graphics
- Screen resolutions up to 1024 X 768 pixel
- HDMI Video Output on 12-inch and 15-inch models.
- Built-in FTP client/server, E-mail client, and Web server
- Audio output port stereo, requires amplifier and speaker(s) (full feature units only)
- User configurable LED on the front of the panel
- · Built-in project simulation; test on PC while developing
- Ethernet 10/100Base-T communications (not available on EA9-T6CL-R)
- 15 pin serial port with RS-232, RS422/485
- 3-wire terminal block RS-485 port and RJ12 RS-232 port (full feature units only)
- Programming via USB or Ethernet (Ethernet not available on EA9-T6CL-R)
- Optional AC/DC power adapter (EA-AC)
- Animation of bitmaps and objects
- Thousands of built-in symbols and Windows fonts
- PID face plate, trending, alarming and a recipe database
- Event Manager to trigger actions based on assigned state changes, schedules, PLC tag names, etc. setup in a database environment. The event can also trigger a sound byte, initiate a screen capture, send a data file (FTP), send an E-mail, etc.
- Trend Data logging
- Internet Remote Access
- Customizable label on the front of the panel

Quick Start Steps

VICPAS

Step 1 – Unpack and Inspect

- a.) Unpack the *C-more* Touch Panel from its shipping carton. Included in the carton are the following:
 - *C-more* Touch Panel
 - cutout template
 - mounting clips
 - DC power connector
 - gasket
 - logo label
 - Quick Start Guide



*Not included with EA9-T7CL-R and EA9-T7CL.

Shipping Carton Contents

Optional Accessories



EA9-USER-M Hardware User Manual, 1st Ed. Rev. P





Step 2 – Install Optional Hardware Accessories





Step 3 - Become Familiar with Available Communication Ports

▲ Note: Device is only available on touch panels EA9-T12CL, EA9-T15CL and EA9-T15CL-R.



NOTE: See Chapter 2: Specifications and Chapter 6: PLC Communications for additional details on the available communication ports, protocols and cables.

Step 4 – Install the Programming Software and Develop a Project

Download the latest version of the *C-more* Programming Software, p/n EA9-PGMSW, from the Automationdirect website. Alternately, if the *C-more* Programming Software CD is available, you may install from the software CD. Refer to the AutomationDirect website for current minimum system requirements for installation.

For software download installation, follow the screen prompts to download and install the *C-more* Programming Software.

For CD installation, insert the supplied CD into the PC's CD drive and navigate to the CD drive location on the PC. Double-click on *EA_Setup.exe* and follow the instructions. If you need assistance during the software installation, call the AutomationDirect Technical Support team @ 770-844-4200.



NOTES: Regarding Ethernet access to a C-more panel.

If you intend to take advantage of the methods of remote access to the panel, including the web server, PC remote access, FTP, iOS or Android app, you need to consider the security exposure in order to minimize the risks to your process and your C-more panel.

Security measures may include password protection, changing the ports exposed on your network, including a VPN in your network, and other methods. Security should always be carefully evaluated for each installation. Refer to Appendix C - Security Considerations for Control Systems Networks.





Step 5 – Connect Touch Panel to Computer

- **Connect** a USB Programming Cable, such as p/n USB-CBL-AB15, from a USB type A port on the PC to the USB type B programming port on the *C-more* touch panel
- or connect the *C-more* touch panel and PC together either directly or via an Ethernet switch, and CAT5 Ethernet cables (full feature panels only)



Step 6 – Provide Power to the Touch Panel

- **Connect** a **dedicated** 12-24 VDC Class 2 power supply to the DC connector on the rear of the *C-more* touch panel, include wiring the ground terminal to a proper equipment ground
- or install a *C-more* AC/DC Power Adapter, EA-AC, to the rear of the touch panel and connect an AC voltage source of 100-240 VAC, 50/60Hertz, to its AC connector (see note below)
- **then** turn on the power **source** and check the LED status indicators on the front and rear of the *C-more* touch panel for proper indication (see next page)



NOTE: A dedicated power supply is recommended. If the power supply also feeds inductive loads such as solenoids or relays, the transients caused by these loads can affect the operation of the panel or damage panel components.



NOTE: The AC/DC Power Adapter, EA-AC, is for **C-more** touch panels only. The adapter is powered from a 100-240 VAC, 50/60 Hertz power source. The adapter provides 24 VDC @ 1.5 A. Power Fault features help protect data on an SD memory card during power failures.



Warning: Use 60 / 75°C copper conductors only.

MOLE EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Step 6 – Provide Power to the Touch Panel (cont'd) *C-more* LED Status Indicators



Step 7 – Access the Touch Panel Setup Screens

- Access the Main Menu of the touch panel System Setup Screens by pressing the extreme upper left corner of the panel display area for three (3) seconds as shown below.
- Adjust the time and date for the panel by pressing the Setting button on the Main Menu, then press the Adjust Clock button on the Setting screen.
- Use the right pointing arrows for the time or date display to select the unit to change. Use the up and down arrows to increment or decrement the value for the selected unit.
- Press OK when done to accept the changes to the time and date in the touch panel or press Cancel to exit the Adjust Clock setup screen without making any changes.
- Press the Main Menu button on the Setting screen and then the Exit button on the Main Menu screen to return to the application screen.



Step 8 - Choose Touch Panel to Device Cables

The table below shows the PLCs, controllers and protocols supported by the EA9-RHMI. Ensure your controller and protocol are supported.

PLC Protocol Table					
Model			Protocols		
	Droductivity	Carico	Productivity Serial		
	Productivity	Series	Productivity Ethernet		
	Do-more		Do-more Serial		
	(BRX)	dii	Do-more Ethernet		
	CLICK		Modbus (CLICK addressing)		
			Modbus TCP (CLICK addressing)		
		all	K-Sequence		
			Direct NET		
	DL03/DL00		Modbus (Koyo addressing)		
		H0-ECOM/H0-ECOM100	Direct LOGIC Ethernet		
	DL105	all	K-Sequence		
		D2-230	K-Sequence		
		D2 240	K-Sequence		
		D2-240	Direct NET		
			K-Sequence		
	DL205	D2-250/D2-250-1/D2-260/D2-262	Direct NET		
			Modbus (Koyo addressing)		
		D2-240/D2-250-1/D2-260	Direct NET		
		Using DCM	Modbus (Koyo addressing)		
		H2-ECOM/H2-ECOM100	Direct LOGIC Ethernet		
AutomotionDiroot	DL305	D3-330/330P (Requires the use of a Data Communications Unit)	Direct NET		
AutomationDirect		D3-340	Direct NET		
			K-Sequence		
		D3-350	Direct NET		
			Modbus (Koyo addressing)		
		D2 250 DCM	Direct NET		
			Modbus (Koyo addressing)		
		D4 420	K-Sequence		
			Direct NET		
		D4-440	K-Sequence		
			Direct NET		
	DI 405		K-Sequence		
	DL40J	D4-450/D4-454	Direct NET		
			Modbus (Koyo addressing)		
			Direct NET		
			Modbus (Koyo addressing)		
		H4-ECOM/H4-ECOM100	Direct LOGIC Ethernet		
	H2-WinPLC (Think & Do) Live V5.2 or later and Studio any version		Think & Do Modbus RTU (serial port)		
	H2-WinPLC (Think & Do) Live V5.5.1 or later and Studio V7.2.1 or later	Think & Do Modbus TCP/IP (Ethernet port)		
	GS Drives		GS Drives Serial		
			GS Drives TCP/IP (GS-EDRV)		
	SOLO Temp	erature Controllers (models with serial communications)	SOLO Temperature Controller		



Step 8 - Choose Touch Panel to Device Cables (cont'd)

PLC Protocol Table (cont'd)				
Model		Protocols		
	MicroLogix 1000, 1100, 1200, 1400, 1500, SLC 5-01/02/03	DH485/AIC/AIC+		
	MicroLogix 1000, 1100, 1200, 1400 and 1500			
	SLC 5-03/04/05	DF1 Half Duplex; DF1 Full Duplex		
	ControlLogix™, CompactLogix™, FlexLogix™			
	PLC-5	DF1 Full Duplex		
	ControlLogix, CompactLogix, FlexLogix - Tag Based	DF1 Half Duplex; DF1 Full Duplex		
	ControlLogix, CompactLogix, FlexLogix - Generic I/O Messaging	EtherNet/IP Server		
Allen-Bradley	ControlLogix, CompactLogix, FlexLogix - Tag Based			
	MicroLogix 1100, 1400 and SLC 5/05, via native Ethernet port	EtherNet/IP Client		
	MicroLogix 1000, 1100, 1200, 1400, 1500, SLC 5-03/04/05, all via ENI adapter			
		Modbus RTU		
	Micro 800 Series	Modbus TCP		
		DF1 Full Duplex		
	Micro 800 Series - Tag Based	EtherNet/IP Client		
Modbus RTU	Modbus RTU devices	Modbus RTU		
Modbus TCP/IP	Modbus TCP/IP devices	Modbus TCP/IP		
05	90/30, 90/70, Micro 90, VersaMax Micro	SNPX		
UE	90/30, Rx3i	SRTP Ethernet		
	FX Series	FX Direct		
Mitoubiobi	Q02, Q02H, Q06H, Q12H, Q25H	Q CPU		
INITSUDISIII	Q, QnA Serial	QnA Serial		
	Q, QnA Ethernet	QnA Ethernet		
	984 CPU, Quantum 113 CPU, AEG Modicon Micro Series 110 CPU: 311-xx, 411-xx, 512-xx, 612-xx	Modbus RTU		
Modicon		Modbus RTU		
	Uther devices using Modicon Modbus addressing	TUModbus TCP/IP		
Omron	C200 Adapter, C500	Host Link		
	CJ1/CS1 Serial			
	CJ1/CS1 Ethernet			
	S7-200 CPU, RS-485 Serial	PPI		
Siemens	S7-200 CPU, S7-300 CPU, S7-400, S7-1200, S7-1500 CPU Ethernet	Ethernet ISO over TCP		



Step 8 – Choose Touch Panel to Device Cables (cont'd)

Available cables to connect from PLC to C-more serial Port 1

To use Serial communication through Port 1 of a *C-more* panel, consult the chart below for the proper cable. See Chapter 6: PLC Communications for wiring diagrams of additional user contructed cables.

Purchased Cable Description	Cable Part Number
AutomationDirect Productivity Series, Do-more, CLICK, Direct LOGIC PLC RJ-12 port, DL05, DL06, DL105, DL205, D3-350, D4-450 & H2-WINPLC (RS-232C)	EA-2CBL
Direct LOGIC (VGA Style) 15-pin port DL06, D2-250 (250-1), D2-260 (RS-232C)	EA-2CBL-1
DirectLOGIC PLC RJ-11 port, D3-340 (RS-232C)	EA-3CBL
<i>Direct</i> LOGIC DL405 PLC 15-pin D-sub port, DL405 (RS-232C)	EA-4CBL-1
DirectLOGIC PLC 25-pin D-sub port, DL405, D3-350, DL305 DCU and all DCM's (RS-232C)	EA-4CBL-2
Allen-Bradley MicroLogix 1000, 1100, 1200, 1400, 1500 (RS-232C)	EA-MLOGIX-CBL
Allen-Bradley SLC 5-03/04/05, ControlLogix, CompactLogix, FlexLogix DF1 port (RS-232C)	EA-SLC-232-CBL
Allen-Bradley PLC-5 DF1 port (RS-232C)	EA-PLC5-232-CBL
Allen-Bradley SLC 5-01/02/03, PLC5 DH485 port	EA-DH485-CBL
GE 90/30, 90/70, Micro 90, VersaMax Micro 15-pin D-sub port (RS-422A)	EA-90-30-CBL
MITSUBISHI FX Series 25-pin port (RS-422A)	EA-MITSU-CBL
MITSUBISHI FX Series 8-pin mini-DIN (RS-422A)	EA-MITSU-CBL-1
OMRON Host Link (C200 Adapter, C500) (RS-232C)	EA-OMRON-CBL



NOTE: The above list of pre-made communications cables may be purchased. See **Chapter 6: PLC Communications** for wiring diagrams of additional user constructed cables. Chapter 6 also includes wiring diagrams for the pre-made cables.



1-15

C-more.

Step 9 – Connect Touch Panel to PLC

- Connect the serial communications cable between the *C-more* touch panel and the PLC
- or connect the *C-more* touch panel and PLC together either directly or via an Ethernet switch, and CAT5 Ethernet cables (full feature panels only)

For further information on setting up communications between a *C-more* panel and a PLC, see the *C-more* programming help file topic *CM129: Creating a New Project*.





SPECIFICATIONS



In This Chapter... Available Models......2-4 Specifications common to all models2-6 8-inch and 10-inch Models2-9 12-inch and 15-inch Models2-10 Dimensions, Inches [mm]......2-11 Ports and Memory Expansion......2-12 Dimensions, Inches [mm]......2-13 Ports and Memory Expansion......2-14 Dimensions, Inches [mm]......2-15 Dimensions, Inches [mm]......2-17 Dimensions, Inches [mm]......2-18 Ports and Memory Expansion......2-19



SPECIFICATIONS



CHAPTER



This page intentionally left blank

Available Models

The *C-more*® Operator Interface is the next generation of touch panel brought to you by AutomationDirect. It has been designed to display and interchange graphical data from a PLC by merely viewing or touching the screen.

The *C-more* Touch Panel is available in a variety of models to suit your application. Refer to the following tables for a list of part numbers, descriptions and options available.

Part Number	Description	Project Memory	SD Card Option	USB Device	Ethernet	HDMI Video Out
EA9-T6CL-R	<i>C-more</i> EA9 series touch screen HMI, 6in color TFT LCD, 320 x 240 pixel, QVGA, LED backlight, supports (1) serial and (2) USB ports and (1) memory card slot.	26 MB	1 slot	Yes	No	No
EA9-T6CL	C-more EA9 series touch screen HMI, 6in color TFT LCD, 320 x 240 pixel, QVGA, LED backlight, supports (3) serial, (1) Ethernet and (2) USB ports, (1) memory card slot and (1) audio line out.	26 MB	1 slot	Yes	Yes	No
EA9-T7CL-R	<i>C-more</i> EA9 series touch screen HMI, 7in color TFT LCD, widescreen, 800 x 480 pixel, WVGA, LED backlight, supports (1) serial, (1) Ethernet and (2) USB ports and (1) memory card slot.	26 MB	1 slot	Yes	Yes	No
EA9-T7CL	C-more EA9 series touch screen HMI, 7in color TFT LCD, widescreen, 800 x 480 pixel, WVGA, LED backlight, supports (3) serial, (1) Ethernet and (2) USB ports, (1) memory card slot and (1) audio line out.	26 MB	1 slot	Yes	Yes	No
EA9-T8CL	C-more EA9 series touch screen HMI, 8in color TFT LCD, 800 x 600 pixel, SVGA, LED backlight, supports (3) serial, (1) Ethernet and (2) USB ports, (1) memory card slot and (1) audio line out.	26 MB	1 slot	Yes	Yes	No
EA9-T10CL	C-more EA9 series touch screen HMI, 10in color TFT LCD, 800 x 600 pixel, SVGA, LED backlight, supports (3) serial, (1) Ethernet and (2) USB ports, (1) memory card slot and (1) audio line out.	26 MB	1 slot	Yes	Yes	No
EA9-T10WCL	C-more EA9 series touch screen HMI, 10in color TFT LCD, widescreen, 1024 x 600 pixel, WSVGA, LED backlight, supports (3) serial, (1) Ethernet and (2) USB ports, (1) memory card slot and (1) audio line out.	26 MB	1 slot	Yes	Yes	No
EA9-T12CL	C-more EA9 series touch screen HMI, 12in color TFT LCD, 800 x 600 pixel, SVGA, LED backlight, supports (3) serial, (1) Ethernet and (2) USB ports, (2) memory card slots, (1) HDMI video out and (1) audio line out.	82 MB	2 slots	Yes	Yes	Yes
EA9-T15CL-R	C-more EA9 series touch screen HMI, 15in color TFT LCD, 1024 x 768 pixel, XGA, LED backlight, supports (1) serial, (1) Ethernet port and (2) USB ports and (2) memory card slots.	82 MB	2 slots	Yes	Yes	No
EA9-T15CL	C-more EA9 series touch screen HMI, 15in color TFT LCD, 1024 x 768 pixel, XGA, LED backlight, supports (3) serial, (1) Ethernet and (2) USB ports, (2) memory card slots, (1) HDMI video out and (1) audio line out.	82 MB	2 slots	Yes	Yes	Yes


Model Specifications

The following specification tables are separated into these groups:

- Specifications common to all models
- 6" & 7" Reduced and Full Feature Models, EA9-T6CL-R, EA9-T6CL, EA9-T7CL-R and EA9-T7CL
- 8" & 10" Full Feature Models, EA9-T8CL, EA9-T10CL and EA9-T10WCL
- 12" & 15" Reduced and Full Feature Models, EA9-T12CL, EA9-T15CL-R and EA9-T15CL

Specification tables begin on the next page.

2

Specifications common to all models

Model Specification	All Models	
Operating Temperature	0 to 50 °C (32 to 122 °F); Maximum surrounding air temperature rating: 50 °C (122 °F) IEC 60068-2-14 (Test Nb, Thermal Shock)	
Altitude	Up to 2000m (6562 ft)	
Storage Temperature	-20 to +60 °C (-4 to +140 °F) IEC 60068-2-1 (Test Ab, Cold) IEC 60068-2-2 (Test Bb, Dry Heat) IEC 60068-2-14 (Test Na, Thermal Shock)	
Humidity	5–95% RH (non-condensing)	
Environment	For use in Pollution Degree 2 environment, no corrosive gases permitted	
Noise Immunity	(EN61131-2) EN61000-4-2 (ESD), EN61000-4-3 (RFI) EN61000-4-4 (FTB) EN61000-4-5 (Serge) EN61000-4-6 (Conducted) EN61000-4-8 (Power frequency magnetic field immunity) (Local Test) RFI, (145MHz, 440Mhz 10W @ 10cm) Impulse 1000V @ 1µs pulse	
Withstand Voltage	1000 VAC, 1 min. (FG to Power supply)	
Insulation Resistance	> 10M ohm @ 500V DC (FG to Power supply)	
Vibration	IEC60068-2-6 (Test Fc)	
Shock	IEC60068-2-27 (Test Ea)	
Emission	EN55011 Class A (Radiated RF emission)	
Enclosure	NEMA 250 type 4/4X indoor use only UL50 type 4X indoor use only IP-65 indoor use only (When mounted correctly)	
Backlight Average Lifetime*	50,000 hours @ 25 °C	
Touch Panel Type**	Four-wire analog resistive	
Supply Power	10.2-26.4VDC Class2 or SELV (Safety Extra-Low Voltage) Circuit or Limited Energy Circuit (LEC) or use the AC/DC Power Adapter, EA-AC, to power the touch panel from a 100-240 VAC, 50/60 Hz power source. Reverse Polarity Protected	



* **NOTE:** The backlight average lifetime is defined as the average usage time it takes before the brightness becomes 50% of the initial brightness. The lifetime of the backlight depends on the ambient temperature. The lifetime will decrease under low or high temperature usage.



** **NOTE:** The Touchscreen is designed to respond to a single touch. If it is touched at multiple points at the same time, an unexpected object may be activated.

6-inch Models

Model Specification	6" TFT color w/ base features	6" TFT color w/ full features	
Part Number	EA9-T6CL-R	EA9-T6CL	
Display Actual Size and Type	5.7" TF	T color	
Display Viewing Area	4.54" » [115.2 mm	k 3.40" x 86.4 mm]	
Weight	1.56 lb (710g)	1.59 lb (720g)	
Screen Pixel	320 x 24	0 (QVGA)	
Display Brightness	280 nit	ts (typ)	
LCD Panel Dot Pitch	0.18 mm >	k 0.18 mm	
Color Scale	65,	536	
Project Memory	26	MB	
Number of Screens	Up to 999 screens – lim	nited by project memory	
Realtime Clock	Realtime Clock Built into panel, backed up for 3 24 h	0 days at 25°C after power has been applied for ours	
Calendar - Month / Day / Year	Yes - monthly deviation 60 sec at 25°C		
Serial Port 1	15-pin D-sub female -	RS2342C, RS-422/485	
Serial Port 2	N/A	3-wire terminal block - RS-485	
Serial Port 3	N/A	RJ-12 modular jack - RS-232C	
USB Port - Type B	USB 2.0 High speed (480 Mbps) Type B - Download/Program Max cable length - 15 ft.		
USB Port - Type A	USB 2.0 High speed (480 Mbps) Type A - for USB device options Max cable length - 15ft Bus Power – Less than 200mA at 5VDC		
Ethernet Port	N/A	Ethernet Port Ethernet 10/100 Base-T, auto MDI/MDI-X	
Audio Line Out	N/A	3.5 mm mini jack: 3-pin – requires amplifier and speaker(s), Full Scale Output: 1.0 Vrms	
Mic In (future)	N/A 3.5 mm mini jack: 2pin, Input: 100 mVrm Impedance: <10k0hms		
SD Card Slot	1 slot. Supports max 2 GB (SD,) max 32 GB (SDHC)		
HDMI Video Out	N/A		
Power Consumption	16.0W 1.30A @ 12 VDC 0.66A @ 24 VDC		
Internal Fuse (non-replaceable)	4A		
Agency Approvals	UL61010 (E157382), CE (EN6113 CUL Canadian C22.2	I-2) Class 1, Div 2, Groups A, B, C, , RoHS (2011/65/EU)	

7-inch Models

Model Specification	7" TFT color w/ base features	7" TFT color w/ full features	
Part Number	EA9-T7CL-R	EA9-T7CL	
Display Actual Size and Type	7.0" TF	T color	
Display Viewing Area	6.0" x [152.4 mm	3.60" x 91.4 mm]	
Weight	1.46 lb (660g)	1.48 lb (670g)	
Screen Pixel	800 x 480) (WVGA)	
Display Brightness	350 nit	s (typ)	
LCD Panel Dot Pitch	0.19 mm >	< 0.19 mm	
Color Scale	65,	536	
Project Memory	26	MB	
Number of Screens	Up to 999 screens – lim	ited by project memory	
Realtime Clock	Realtime Clock Built into panel, backed up for 3 24 h	0 days at 25°C after power has been applied for ours	
Calendar - Month / Day / Year	Yes - monthly deviation 60 sec at 25°C		
Serial Port 1	15-pin D-sub female - RS2342C, RS-422/485		
Serial Port 2	N/A	3-wire terminal block - RS-485	
Serial Port 3	N/A	RJ-12 modular jack - RS-232C	
USB Port - Type B	USB 2.0 High speed (480 Mbps) Type B - Download/Program Max cable length - 15 ft.		
USB Port - Type A	USB 2.0 High speed (480 Mbps) Type A - for USB device options Max cable length - 15ft Bus Power – Less than 200mA at 5VDC		
Ethernet Port	Ethernet Port Ethernet 10/100 Base-T, auto MDI/MDI-X		
Audio Line Out	N/A	3.5 mm mini jack: 3-pin – requires amplifier and speaker(s), Full Scale Output: 1.0 Vrms	
Mic In (future)	N/A	3.5 mm mini jack: 2pin, Input: 100 mVrms, Impedance: <10kOhms	
SD Card Slot	1 slot. Supports max 2 GB (SD,) max 32 GB (SDHC)		
HDMI Video Out	N/A		
Power Consumption	16.0W 1.30A @ 12 VDC 0.66A @ 24 VDC		
Internal Fuse (non-replaceable)	4A		
Agency Approvals	UL61010 (E157382), CE (EN61131-2), CUL Canadian C22.2, RoHS (2011/65/EU)		

8-inch and 10-inch Models

Model Specification	8" TFT color w/ full features	10" TFT color w/ full features	10" TFT color widescreen w/ full features
Part Number	EA9-T8CL	EA9-T10CL	EA9-T10WCL
Display Actual Size and Type	8.4" TFT color	10.4" TFT color	10.1" TFT color wide
Display Viewing Area	6.71" x 5.03" [170.4 mm x127.8mm]	8.31" x 6.24" [211.2 mm x 158.4 mm]	8.769" x 4.932" [222.72 mm x 125.28 mm]
Weight	2.93 lb (1330g)	4.19 lb (1900g)	2.43 lb (1100g)
Screen Pixel	800 x 60	D (SVGA)	1024 x 600 (WSVGA)
Display Brightness	310 nits (typ)	280 nits (typ)	240 nits (typ)
LCD Panel Dot Pitch	0.213 mm x 0.213 mm	0.264 mm x 0.264 mm	0.218 mm x 0.209 mm
Color Scale		65,536 colors	
Project Memory		26 MB	
Number of Screens	Up to 9	99 screens – limited by project	memory
Realtime Clock	Realtime Clock	Built into panel, backed up for	30 days at 25°C
Calendar - Month / Day / Year	Yes - monthly deviation 60 sec (Reference)		
Serial Port 1	15-pin D-sub female - RS2342C, RS-422/485		
Serial Port 2	3-wire terminal block - RS-485		
Serial Port 3	RJ-12 modular jack - RS-232C		
USB Port - Type B	USB 2.0 High speed (480 Mbps) Type B - Download/Program Max cable length - 15 ft.		
USB Port - Type A	USB 2.0 High speed (480 Mbps) Type A - for USB device options Max cable length - 15ft Bus Power – Less than 200mA at 5VDC		
Ethernet Port	Ethernet Port Ethernet 10/100 Base-T, auto MDI/MDI-X		
Audio Line Out	3.5 mm mini jack – requires amplifier and speaker(s)		
Mic In (future)	3.5 mm mini jack		
SD Card Slot	1 slot. Supports max 2 GB (SD,) max 32 GB (SDHC)		
HDMI Video Out	N/A		
Power Consumption	18. 1.50A @ 0.75A @	0W 12 VDC 24 VDC	17.0W 1.42A @ 12 VDC 0.71A @ 24 VDC
Internal Fuse (non-replaceable)	6.3A		
Agency Approvals	UL508 (E157382), CE (EN61131-2), CUL Canadian C22.2, RoHS (2011/65/EU)		

2

12-inch and 15-inch Models

Model Specification	12" TFT color w/ full features	15" TFT color w/ base features	15" TFT color w/ full features	
Part Number	EA9-T12CL	EA9-T15CL-R	EA9-T15CL	
Display Actual Size and Type	12.1" TFT color	15.	0" TFT color	
Display Viewing Area	9.69" x 7.26" [246.0 mm x 184.5 mm]	11 [304.1 r	.97" x 8.98" nm x 228.0 mm]	
Weight	4.85 lb (2200g)	6.46 lb (2930g)	6.50 lb (2950g)	
Screen Pixel	800 x 600 (SVGA)	1024	4 x 768 (XGA)	
Display Brightness		280 nits (typ)		
LCD Panel Dot Pitch	0.3075 mm x 0.3075 mm	0.297 r	nm x 0.297 mm	
Color Scale		65,536 colors		
Project Memory		82 MB		
Number of Screens	Up to 999	screens – limited by proje	ct memory	
Realtime Clock	Realtime Clock Bu	ilt into panel, backed up fo	or 30 days at 25°C	
Calendar - Month / Day / Year	Yes - monthly deviation 60 sec (Reference)			
Serial PLC Interface Port 1	15-pin D-	sub female - RS2342C, RS	S-422/485	
Serial PLC Interface Port 2	3-wire terminal block - RS-485	N/A	3-wire terminal block - RS-485	
Serial PLC Interface Port 3	RJ-12 modular jack - RS-232C	N/A	RJ-12 modular jack - RS-232C	
USB Port - Type B	USB 2.0 High speed (480 Mbps) Type B - Download/Program Max cable length - 15 ft.			
USB Port - Type A	USB 2.0 High speed (480 Mbps) Type A - for USB device options Max cable length - 15ft Bus Power – Less than 200mA at 5VDC			
Ethernet Port	Ethernet Port I	Ethernet 10/100 Base-T, au	uto MDI/MDI-X	
Audio Line Out	3.5 mm mini jack – requires amplifier and speaker(s)	N/A	3.5 mm mini jack – requires amplifier and speaker(s)	
Mic In (future)	3.5 mm mini jack	N/A	3.5 mm mini jack	
SD Card Slot	2 slots. Supports max 2 GB (SD), max 32 GB (SDHC)			
HDMI Video Out	HDMI Type A Port	N/A	HDMI Type A Port	
HDMI Supported Resolution	800 x 600 (SVGA)	N/A	1024 x 768 (XGA)	
Power Consumption	21.0W 1.75A @ 12 VDC 0.88A @ 24 VDC	29.0W 2.40A @ 12 VDC 1.20A @ 24 VDC		
Internal Fuse (non-replaceable)	6.3A			
Agency Approvals	UL508 (E157382), CE (EN61131-2), CUL Canadian C22.2, RoHS (2011/65/EU)			

2

EA9-T6CL-R, EA9-T6CL

Dimensions, Inches [mm]

All the necessary mounting hardware is provided with the touch panel. Use the four mounting clips and screws to secure the touch panel to the cabinet or enclosure surface.

A template for marking the cutout dimensions on the mounting surface is provided in the box.





-more

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



2-12 Cincre[®] EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



EA9-T7CL-R, EA9-T7CL

Dimensions, Inches [mm]

All the necessary mounting hardware is provided with the touch panel. Use the four mounting clips and screws to secure the touch panel to the cabinet or enclosure surface.

A template for marking the cutout dimensions on the mounting surface is provided in the box.





← PRODUCT LABEL

USB

DEVICE

aaaaaahaaaad

ETHERNET

PC/PLC

AUTO LINE

OUT

0000000000

רי

PLC SERIAL COMMUNICATIONS PORT 1



EA9-T8CL

Dimensions, Inches [mm]

All the necessary mounting hardware is provided with the touch panel. Use the four mounting clips and screws to secure the touch panel to the cabinet or enclosure surface.

A template for marking the cutout dimensions on the mounting surface is provided in the box.





EA9-USER-M Hardware User Manual, 1st Ed. Rev. P





EA9-T10CL

Dimensions, Inches [mm]

All the necessary mounting hardware is provided with the touch panel. Use the eight mounting clips and screws to secure the touch panel to the cabinet or enclosure surface.

A template for marking the cutout dimensions on the mounting surface is provided in the box.





EA9-T10WCL

Dimensions, Inches [mm]

All the necessary mounting hardware is provided with the touch panel. Use the eight mounting clips and screws to secure the touch panel to the cabinet or enclosure surface.

A template for marking the cutout dimensions on the mounting surface is provided in the box.



10" Wide,

15"

[0.45 - 0.55 Nm]

92 - 106 oz-in

[0.65 - 0.75 Nm]

Metal

[1 – 5 mm]

0.039 - 0.20 inch

[1 – 5 mm]

MOUNTING CLIP

SCREW TORQUE

Ports and Memory Expansion







EA9-T12CL

Dimensions, Inches [mm]

All the necessary mounting hardware is provided with the touch panel. Use the eight mounting clips and screws to secure the touch panel to the cabinet or enclosure surface.

A template for marking the cutout dimensions on the mounting surface is provided in the box.



2-20

15"



Ports and Memory Expansion



EA9-T15CL-R, EA9-T15CL

Dimensions, Inches [mm]

All the necessary mounting hardware is provided with the touch panel. Use the eight mounting clips and screws to secure the touch panel to the cabinet or enclosure surface.

A template is provided for marking the cutout dimensions on the mounting surface.



and Mounting Clip Screw Torque

	Touch Panel Size	Enclosure Thickness Range	Mounting Clip Screw Torque	Material
BRACKET	6", 7", 8", 10" & 12"	0.039 - 0.20 inch [1 – 5 mm]	63 - 77 oz-in [0.45 - 0.55 Nm]	Metal
V MOUNTING CLIP SCREW TORQUE	10" Wide, 15"	0.039 - 0.20 inch [1 – 5 mm]	92 - 106 oz-in [0.65 - 0.75 Nm]	Metal

2-22



Ports and Memory Expansion



EA9-T15CL



2-24 Cimore EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Mounting Clearances

The following drawing shows the mounting clearances for the *C-more* touch panel. There should be a minimum of 4 inches of space between all sides of the panel and the nearest object or obstruction and at least 1.72 inches between the rear of the panel and the nearest object or obstruction.



EA9-T15CL-R, EA9-T15CL Derating

If EA9-T15CL-R and EA9-T15CL are mounted off the vertical plane facing upward, the temperature shall be derated as shown below. Other panels may be mounted at any angle without derating consideration.





Communications Ports

Ethernet Port

The Ethernet port can be used several ways: for programming the panel (downloading a project), for PLC communication, and for the advanced features, such as sending e-mail, web server, FTP access, and allowing users to access and control the panel remotely.

The Ethernet connector is an RJ-45 Module jack.



NOTE: EA9-T6CL-R does not include an Ethernet port and does not have these capabilities.

Refer to http://c-more.automationdirect.com for the latest driver information.

USB Type B Port

Program *C-more* via the USB programming port. It's fast and easy, with no baud rate settings, parity, or stop bits to worry about. We stock standard USB cables for your convenience, such as part no. USB-CBL-AB15. The USB type B port can be used to upload or download projects to and from a PC (personnel computer).

USB Type A Port

The USB type A port is a standard feature for all models and can be used to connect various USB 2.0 HID (Human Input Device) devices to the panel, such as:

- USB pen drives, (ADC p/n USB-FLASH)
- USB keyboards
- USB barcode scanners
- USB card scanners

C-more can log data to the USB pen drive as well as restore projects to the panel from the pen drive. You can also back up project files and panel firmware.



NOTE: Output current is less than 200mA @ 5VDC.

Sound Interface (Audio Line Out)

When attached to an amplifier and speaker(s), *C-more* can play warning sounds, or pre-recorded messages such as: "conveyor is jammed". Various "Objects" in the *C-more* programming software support sounds. *C-more* supports WAV type files. Sound files are stored in the sound library.

Audio WAV File Specifications

The *C-more* Audio Line Out port supports the following WAV file specifications:

Audio Format (codec): PCM

Audio Sample Rate: 44.1 kHz

Channels: 2 (stereo)

Audio Sample Size: 16-bit



Serial Communication Ports

Port 1

Connect to your serial controller network via Port 1. Port 1 is a 15-pin port that supports RS-232 and RS-422/485.

Port 2

Connect your RS-485 network via Port 2. Port 2 is provided with a 3-wire removable terminal block.

Port 3

Connect to your RS-232C device via Port 3. Port 3 is an RJ12 connection



NOTE: EA9-T6CL-R, EA9-T7CL-R and EA9-T15CL-R do not include Serial Ports 2 and 3.

HDMI Port Video Out

EA9-T12CL and EA9-T15CL include an HDMI Type A port to provide video output to a projector or monitor.

Model	Supported Resolution
EA9-T12CL	SVGA 800 x 600 pixel
EA9-T15CL	XGA 1024 x 768 pixel
Output	Video Data - Same Screen as Panel
Sound Pass Through	Does not support Mic sound Pass Through

User Defined LED

The user defined LED on the panel front bezel can be controlled from the project to illuminate red, green or orange. It can also be configured to blink these colors. Refer to the online help file provided with the programming software for details.



Handling External Memory Devices

Writing to External Memory Devices

Different types of numeric and text data from the *C-more* touch panel can be stored on an SD card or a USB memory device. Numeric data from Line Trend Graph and PID Faceplate Trend Graph objects may be stored. Text data from Lookup Text and Multi-state Text objects can also be stored.

Up to 16 objects may be configured in the C-more programming software to log data. Along with the 16 object limit, available storage on the external memory device is subject to the memory capacity of the SD card or USB memory device. One log file is created in a 24 hour period for each object. Additionally logging data is initially stored in the buffer in the panel MRAM and data is written to the external memory device:

- when 2kB of data is cached,
- when 20 records have been stored,
- periodically, once every 1 minute,
- when one of the "SYS Copy LogTo %device%" or "SYS %device% Eject" tags is turned on.
- when there is an email or FTP action
- when the System Screen is called
- when the panel date is changed

Memory Device Formatting

Memory Devices should be formatted according to the following guidelines to insure best performance and integrity of logged data.

Item		Capacity	Supported Resolution	Supported
		up to 2GB	FAT	Yes
USB Memory Device		4GB to 32GB	FAT 32	Yes
		64GB or larger	exFAT	Yes
	Туре			
SD Cord	SD	up to 2GB	FAT	Yes
SD Caru	SDHC	4GB to 32GB	FAT 32	Yes
	SDXC		exFAT	No

SD cards must be formatted using the SD formatter provided by the SD Association at www.sdcard.org using the standard allocation unit size for best performance.



Minimizing Data Errors

To minimize data errors when logging data to external memory, consider the following:

- Do not turn off power to the *C-more* touch panel while the external memory device is being accessed. The optional EA-AC power adapter is designed to protect external memory devices from damage during power failure.
- Do not remove any external memory device with the device is being accessed by the *C-more* panel.

The following internal tags should be used to monitor, access and safely remove external memory devices:

SYS SD1 WriteStatus SYS SD2 WriteStatus SYS USB WriteStatus SYS Copy LogToSD1 SYS Copy LogToSD2 SYS Copy LogToUSB SYS SD1 Eject SYS SD2 Eject SYS USB Eject SYS SD1 ReadyToUse SYS SD2 ReadyToUse SYS USB ReadyToUse

- Be sure to backup the memory device at regular intervals.
- If you suspect the memory device is bad, you may want to use a PC to re-format the device, or use a known good memory device.
- The number of times the memory device can be written to is limited. Consequently, logging frequently will may shorten the service life of the memory device. Using slower sample rates will increase the life of the device.

Monitoring Available Memory

Each external memory device can be monitored and events can be configured to alert the user when available memory is approaching the maximum capacity of the external memory device. The following internal tags allow external memory devices data to be monitored:

SYS SD1 TotalMemory SYS SD1 FreeMemory SYS SD1 UsedMemory SYS SD2 TotalMemory SYS SD2 FreeMemory SYS USB TotalMemory SYS USB FreeMemory SYS USB FreeMemory SYS USB UsedMemory

Refer to the *C-more* programming software online help files for additional information on system tags and managing data logging devices.

2-31

VICPAS File Name Limitations

There is a limit of 999 file names with the same first four characters. Internal file names are restricted by the DOS 8-character-dot-3-character limit. Therefore trend log files are identified internally by the first four characters of the object name plus tilde plus a three digit number.

Examples are:

TREND GRAPH EAST CHILLER TEMP_130925.txt is saved internally as TREN-001.txt TREND GRAPH WEST CHILLER TEMP_130925.txt is saved internally as TREN-002.txt

As new log files are created in each 24 hour period, these files count against the maximum of 999 files. If multiple graph objects appear on one screen, the files will be identified internally by the first Two Characters of the screen name plus the first Two Characters of the object name plus tilde plus three digit number.

To maximize storage capabilities on external memory devices use screen names that have unique characters in the first four digits and object names that are unique in the first two characters.



NOTE: When the 999 filename limit is reached, the oldest files will automatically be deleted and logging will continue.

Power Loss Retention

When a power loss is detected, the panel will attempt to complete all data logging operations safely.

The power retention while using a DC power is not long enough to complete writes to an SD Card or USB device. An Uninterruptable Power Supply (UPS) should be considered.

Power Loss Detection (at 25°C)		
Power Supply	Detect Loss	
DC (Panel only)	8.9 VDC	
EA-AC	67VAC (6 - 10 inch) 70VAC (12 - 15 inch)	

Chemical Compatibility

The *C-more* touch panels comprise three different materials that may be exposed to outside elements: a gasket, a screen sheet and a bezel.

- Gasket material is silicone.
- Screen sheets are PET.
- Panel bezels are ABS plastic.



Accessories



Accessories Overview



Part Numher	Description
	AC/DC power adapter 24 V/DC For use with C more EA7 and EA0 series touch papels
LA-AU	AC/DC power adapter, 24 VDC. For use with C-more LA7 and LA9 series touch panels.
EA-6-COV2	Screen protector, non-glare, 6in. Package of 3. For use with C-more and C-more Micro 6in panels.
EA-7-COV2	Screen protector, non-glare, 7in. Package of 3. For use with C-more 7in panels.
EA-8-COV2	Screen protector, non-glare, 8in. Package of 3. For use with C-more and C-more Micro 8in panels.
EA-10-COV2	Screen protector, non-glare, 10in. Package of 3. For use with C-more EA9-T10CL and C-more Micro EA3- T10CL HMIs.
EA-10W-COV2	Screen protector, non-glare, 10in. Package of 3. For use with C-more EA9-T10WCL widescreen HMI.
EA-12-COV2	Screen protector, non-glare, 12in. Package of 3. For use with C-more 12in panels.
EA-15-COV2	Screen protector, non-glare, 15in. Package of 3. For use with C-more 15in panels.
EA-SD-CARD	SD memory card, 2GB, industrial.
USB-FLASH	SanDisk USB Flash drive, 32GB.
EA-COMCON-3*	DSUB port adapter, 15-pin male to 6-pole RS-422/485 terminal block, right angle cable entry. For use with C-more Micro EA1 series 4in and 6in HMIs, C-more Micro EA3 series 3in, 4in, and 6in HMIs, C-more EA9 6in and 7in HMIs.
	EA-COMCON-3 is low profile and fits EA9-T6CL-R, EA9-T6CL, EA9-T7CL and EA9-T7CL-R
LA-CONICON-SA	EA-COMCON-3A is straight and fits EA-T8CL, EA9-T10CL, EA9-T12CL and EA9-T15CL
*Note: EA-COMCON-3	is low profile and fits EA9-T6CL-R, EA9-T6CL, EA9-T7CL and EA9-T7CL-R
EA-COMCON-3A is stra	aight and fits EA-T8CL, EA9-T10CL, EA9-T12CL and EA9-T15CL



AC/DC Power Adapter

The optional *C-more* AC/DC Power Adapter can be used to power the *C-more* touch panels from a 100-240 VAC, 50/60 Hertz, voltage source. The adapter provides 24 VDC @ 1.5 A to the touch panel's DC power connector and can be conveniently secured to the touch panel with two captive screws. The adapter provides a power loss signal to the touch panel that causes the touch panel to stop writing data to SD memory devices providing a controlled shutdown for increased data logging reliability.



Tightening Torque		
Power supply cable torque	71 - 85 oz-in (0.5 - 0.6 Nm)	
Power connector mounting torque	71 - 85 oz-in (0.5 - 0.6 Nm)	
Mounting flange screw torque	57 - 71 oz-in (0.4 - 0.5 Nm)	



Warning: Use 60 / 75°C copper conductors only.

A	C/DC Power Adapter Specifications
Part Number	EA-AC
Input Voltage & frequency	100-240 VAC; 50/60 Hertz
Operating Temperature Range	0 °C to 50 °C [32 to 122 °F] Maximum surrounding temperature rating, 50 °C
Storage Temperature Range	-20 to 60 °C [-4 to 140 °F]
Operating & Storage Humidity	10-85% RH (non-condensing)
Noise Immunity	1000 VAC p-p (Pulse width 1 μs, rise time: 1 ns) With proper ground connection on AC terminal block.
Hi-pot	1000 VAC, 1 minute With proper ground connection on AC terminal block.
Insulation Resistance	500 VDC, 10 M ohm or above With proper ground connection on AC terminal block.
Vibration	Compliant with IEC61131-2
Shock	Pulse shape: Sine half wave, Peak acceleration: 147 m/s2 (15 G), X, Y, Z: 3 directions, 2 times each
Thermal Protection	140 °C [284 °F], with autorecovery
Short Circuit Protection	85 VAC: 2.6 A, 100 VAC: 2.8 A, 264 VAC: 3.9 A
Static Electricity Discharge Resistance	Compliant with IEC61000-4-2, Contact: 4 kV, Air: 8 kV
Agency Approvals	UL508, UL Recognized, cUL, CE, EMC EN61132-2
Environment	For use in pollution degree 2 environment
Grounding	Ground resistance: less than 100 ohm
Weight	6.13 oz. [175 g]
Removable AC Power Connector	EA-AC-CON or DECA Switchlab MC101-508-03G Secure with (2) captive M2.5 screws, torque to 70 oz-in [0.5 Nm]
Output Current	Maximum 1.5 A
Inrush Current	For 100 VAC: 15 A, 3 ms or less For 240 VAC: 20 A, 3 ms or less
Recommended AC Supply Fuse	3.0 A time delay, ADC p/n MDL3
Power Supply Cable Torque	71 - 85 oz-in (0.5 - 0.6 Nm)
Mounting to Touch Panel	Secure with (2) spring loaded captive M3-20 screws, torque to 50 oz-in [0.35 Nm]



NOTE: Logic within the EA-AC will turn off the backlight instantly when a power failure is detected to allow the CPU to run longer. The backlight turns on automatically when the power returns to the **C-more** operating voltage.

3





Panel Depth with AC/DC Power Adapter Installed



AC/DC Power Adapter Installation



WARNING: This procedure should only be performed by qualified personnel who are experienced in working with electronic equipment. Take the necessary steps to prevent damage that may be caused by static electricity discharge. Disconnect input power to the touch panel before proceeding.



Preparation: Place the touch panel face down on a lint-free soft surface to prevent scratching the display screen if not already installed in a control cabinet. Remove the DC power connector if it is installed.



Secure the AC/DC Power Adapter to the touch panel by tightening the two (2) spring loaded captive M3-20 screws to a torque of 50 oz-in [0.35 Nm].



Insert the AC/DC power adapter into the touch panel's 5-position DC power connector.



Plug the wired 3-pin AC Power Connector into its mating connector on the adapter and secure in place by tightening the two (2) captive M2.5 screws to a torque of 70 oz-in [0.5 Nm].

3



EA-ECOM Ethernet Communication Module

The EA-ECOM Ethernet Communication module plugs into the expansion port on the rear of the EA3 series 6, 8, and 10-inch *C-more* Micro panels to allow Ethernet communications for programming and PLC communications at a speed of 10/100 Mbps.





EA9-USER-M Hardware User Manual, 1st Ed. Rev. P 🔍

-more

D-SUB 15-pin to Terminal Block Adapters

These adapters are plugged into the 15-pin serial port on the rear of the panels to allow wire terminal connections for RS-422/485 PLC communication cable. The wiring of both adapters is the same.

EA-COMCON-3 is used with EA9-T6CL-R, EA9-T6CL, EA9-T7CL-R and EA9-T7CL. EA-COMCON-3 is UL Recognized.

EA-COMCON-3A is NOT UL Recognized or Listed. It is used with EA9-T8CL, EA9-T10CL, EA9-T12CL, EA9-T15CL-R and EA9-T15CL



EA-COMCON-3A



3-8


3

Non-glare Screen Covers

Non -glare PET screen covers are protective overlays used to protect the touch screen and help reduce glare from external light sources. (pk of 3)

Part No. EA-6-COV2, EA-7-COV2, EA-8-COV2, EA-10-COV2, EA-10W-COV2, EA-12-COV2 & EA-15-COV2





Non-glare Screen Covers Dimensions - inches [mm]						
Part Number A		В	C	D		
EA-6-COV2	4.91 [124.8]	3.80 [96.4]				
EA-7-COV2	6.40 [162.6]	4.00 [101.5]				
EA-8-COV2	7.32 [185.8]	5.44 [138.2]				
EA-10-COV2	8.91 [226.2]	6.61 [168.0]	0.197 [5.0]	0.157 [4.0]		
EA-10W-COV2	9.23 [234.5]	5.38 [136.7]				
EA-12-COV2	10.26 [260.6]	7.64 [194.1]				
EA-15-COV2	12.56 [319.1]	9.37 [238.1]				

-more

Non-glare Screen Covers (cont'd)

Clear Screen Overlay Installation Step 1



Check to be sure that the proper size non-glare screen cover is being used on the subject touch panel. Notice that the outer perimeter of the screen cover has an adhesive band. The adhesive band will be located on the outside edge of the touch panel's white frame bordering the touch area when installed.



Align the screen cover over the touch panel's white frame, then start on one side and gently lay the cover over the entire touch area.





Start in one corner and peel the screen cover from the backing.





Smooth out the screen cover and press all around the outside perimeter to secure the cover in place. The screen cover can be removed by lifting up on the small tab and gently pulling the cover away form the touch panel's surface.





NOTE: The protective cover ships with a thin protective sheet on the face of the cover that needs to be carefully removed. If your panel is not clear, the protective sheet may not have been removed.





SD Card

SD memory card for non-volatile storage, 2GB industrial grade. 85° C maximum operating temperature makes it suitable for data logging in industrial applications. Recommended for *C-more* EA9 series. The EA-SD-CARD utilizes SLC technology so it is the fastest option for writing and storing data. If logged data is saved to external memory, AutomationDirect recommends using an EA-SD-CARD.

EA-SD-CARD



/	333333
	=
	\equiv
-	

NOTE: SLC Flash memory utilized by EA-SD-CARD has the advantage of being the most accurate flash memory type when reading and writing data. SLC flash has the longest lifespan of flash types and can operate in a broader temperature range than other types.

EA-SD-CARD with SLC Flash memory is recommended for industrial workloads that require heavy read/write cycles.

USB FLASH Drive

USB-FLASH sold by AutomationDirect has been tested with *C-more* HMIs and is Hi-Speed USB 2.0 certified. The EA-SD-CARD is the best option for logging data, but the USB-FLASH is a high quality flash drive perfect for transferring log files, capturing screens, backing up and restoring projects and storing images for the Image Viewer object.

USB-FLASH









INSTALLATION AND WIRING



In This Chapter	
Safety Guidelines	4-2
Introduction	4-3
UL Requirements	4-4
EA9-T6CL-R, EA9-T6CL, EA9-T7CL-R and EA9-T7CL Cutout Dimensions	4-5
EA9-T8CL and EA9-T10WCL Cutout Dimensions	4-6
EA9-T12CL Cutout Dimensions	4-8
EA9-T15CL-R and EA9-T15CL Cutout Dimensions	4-9
Mounting Clearances	4-10
EA9-T15CL-R, EA9-T15CL Derating	4-11
Wiring Guidelines	4-12
Agency Approvals	4-12
Providing Power to the Touch Panel	4-13
C-more LED Status Indicators	4-14

Safety Guidelines

NOTE: Products with CE marks perform their required functions safely and adhere to relevant standards as specified by CE directives provided they are used according to their intended purpose and that the instructions in this manual are adhered to. The protection provided by the equipment may be impaired if this equipment is used in a manner not specified in this manual. A listing of our international affiliates is available on our Web site: http://www. automationdirect.com



WARNING: Providing a safe operating environment for personnel and equipment is your responsibility and should be your primary goal during system planning and installation. Automation systems can fail and may result in situations that can cause serious injury to personnel or damage to equipment. Do not rely on the automation system alone to provide a safe operating environment. You should use external electromechanical devices, such as relays or limit switches, that are independent of the PLC application to provide protection for any part of the system that may cause personal injury or damage. Every automation application is different, so there may be special requirements for your particular application. Make sure you follow all national, state, and local government requirements for the proper installation and use of your equipment.

Plan for Safety

The best way to provide a safe operating environment is to make personnel and equipment safety part of the planning process. You should examine every aspect of the system to determine which areas are critical to operator or machine safety. If you are not familiar with control system installation practices, or your company does not have established installation guidelines, you should obtain additional information from the following sources.

 NEMA — The National Electrical Manufacturers Association, located in Washington, D.C. publishes many different documents that discuss standards for industrial control systems. You can order these publications directly from NEMA. Some of these include:

ICS 1, General Standards for Industrial Control and Systems

ICS 3, Industrial Systems

ICS 6, Enclosures for Industrial Control Systems

- NEC The National Electrical Code provides regulations concerning the installation and use of various types of electrical equipment. Copies of the NEC Handbook can often be obtained from your local electrical equipment distributor or your local library.
- Local and State Agencies many local governments and state governments have additional requirements above and beyond those described in the NEC Handbook. Check with your local Electrical Inspector or Fire Marshall office for information.



Introduction

The installation and wiring of the *C-more*® touch panels requires selecting an appropriate location for the touch panel, laying out the cutout dimensions on the surface of the control cabinet that the panel will be mounted through, securing the touch panel with the provided mounting clips, tightening the screws to the appropriate torque rating to assure the gasket is sealing correctly, and finally connecting the appropriate power source to the touch panel.



NOTE: Each **C-more** touch panel is provided with a cutout template to make marking the proper cutout size on the surface of the control cabinet that the panel will be mounted through a simple task.

This chapter covers the proper mounting of the touch panel and connecting power. Once power is applied to the touch panel, the user will want to read Chapter 5 on the System Setup Screens in order to set the internal time and date for the panel, become familiar with the touch panel test features, and check memory options.

Mounting Clips - EA9-BRK



UL Requirements

UL Satisfaction Ratings					
Model Number	Input Ratings				
EA9-T6CL-R					
EA9-T6CL					
EA9-T7CL-R	12 - 24 VDC, Class 2, SELV of LEC, Maximum 16.0W				
EA9-T7CL					
EA9-T8CL	12 - 24 VDC, Class 2, SELV or LEC, Maximum 18.0W				
EA9-T10WCL	12 - 24 VDC, Class 2, SELV or LEC, Maximum 17.0W				
EA9-T10CL	12 - 24 VDC, Class 2, SELV or LEC, Maximum 18.0W				
EA9-T12CL	12 - 24 VDC, Class 2, SELV or LEC, Maximum 21.0W				
EA9-T15CL-R	12 24 VDC Class 2 SELV or LEC Maximum 20 0W				
EA9-T15CL	12 - 24 VDG, Glass 2, SELV OF LEG, MidxIIIIdH 29.0W				
Terminal connecting w	ire size 12 - 24 AWG				
Connecting torque 71	- 85 oz-in (5 - 7 lbf-in) (0.5 - 0.6 Nm)				
Maximum surrounding	air temperature rating, 50°C				
For use in Pollution De	gree 2 environment				
All interface ports are i	ntended to be directly connected to an isolated secondary circuit				
For use on a flat surfac	ce of a type 4X Indoor Use Only enclosure				

Class 1, Div 2, Groups A, B, C Hazardous Location Installation Requirements

Models EA9-T6CL-R and EA9-T6CL Only

Hazardous Location Installation Requirements

SUITABLE FOR USE IN CLASS I, DIVISION 2, GROUPS A, B, C AND D HAZARDOUS LOCATIONS, OR NONHAZARDOUS LOCATIONS ONLY.

WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS.

WARNING - EXPLOSION HAZARD - SUBSTITUTION OF ANY COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2.

DEVICES SHALL BE INSTALLED INTO AN ENCLOSURE THAT UTILIZES A TOOL REMOVABLE DOOR/COVER.



EA9-T6CL-R, EA9-T6CL, EA9-T7CL-R and EA9-T7CL Cutout Dimensions

The *C-more* 6" and 7" touch panels are mounted into a cutout through the control cabinet and secured with four (4) mounting clips. The mounting clips are provided with the touch panel. The mounting clips will insert into a series of slots around the rear perimeter of the touch panel. Each clip has a tab that will mate to a slot. The screw of each mounting clip needs to be tightened to the torque rating shown in the table below so that the gasket is compressed to form the proper seal between the panel and cabinet surface.

INCHES [MM]





EA9-T8CL and EA9-T10WCL Cutout Dimensions

The *C-more* EA9-T8CL and EA9-T10WCL touch panels will mount into the same cutout and are mounted into the cutout through the control cabinet and secured with four (4) mounting clips. The mounting clips are provided with the touch panel. The mounting clips will insert into a series of slots around the rear perimeter of the touch panel. Each clip has a tab that will mate to a slot. The screw of each mounting clip needs to be tightened to the torque rating shown in the table below so that the gasket is compressed to form the proper seal between the panel and cabinet surface.

INCHES [MM]





4-6



EA9-T10CL Cutout Dimensions

The *C-more* 10" touch panels are mounted into a cutout through the control cabinet and secured with eight (8) mounting clips. The mounting clips are provided with the touch panel. The mounting clips will insert into a series of slots around the rear perimeter of the touch panel. Each clip has a tab that will mate to a slot. The screw of each mounting clip needs to be tightened to the torque rating shown in the table below so that the gasket is compressed to form the proper seal between the panel and cabinet surface.



ev. P Comore

EA9-T12CL Cutout Dimensions

The *C*-more 12" touch panels are mounted into a cutout through the control cabinet and secured with eight (8) mounting clips. The mounting clips are provided with the touch panel. The mounting clips will insert into a series of slots around the rear perimeter of the touch panel. Each clip has a tab that will mate to a slot. The screw of each mounting clip needs to be tightened to the torque rating shown in the table below so that the gasket is compressed to form the proper seal between the panel and cabinet surface.



-8



SCREW TORQUE



EA9-T15CL-R and EA9-T15CL Cutout Dimensions

The *C-more* 15" touch panels are mounted into a cutout through the control cabinet and secured with eight (8) mounting clips. The mounting clips are provided with the touch panel. The mounting clips will insert into a series of slots around the rear perimeter of the touch panel. Each clip has a tab that will mate to a slot. The screw of each mounting clip needs to be tightened to the torque rating shown in the table below so that the gasket is compressed to form the proper seal between the panel and cabinet surface.



EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

more

Mounting Clearances

The following drawing shows the mounting clearances for the *C-more* touch panel. There should be a minimum of 4 inches of space between all sides of the panel and the nearest object or obstruction and at least 1.72 inches between the rear of the panel and the nearest object or obstruction.



4-10 Cimure EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



EA9-T15CL-R, EA9-T15CL Derating

If EA9-T15CL-R and EA9-T15CL are mounted off the vertical plane facing upward, the temperature shall be derated as shown below. Other panels may be mounted at any angle without derating consideration.



Wiring Guidelines



WARNING: To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and it is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation are in compliance with the latest revision of these codes.

Equipment damage or serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.

If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please call technical support at 1-800-633-0405 or 770-844-4200. This publication is based on information that was available at the time it was printed. At Automationdirect.com® we constantly strive to improve our products and services, so we reserve the right to make changes to the products and/or publications at any time without notice and without obligation. This publication may also discuss features that may not be available in certain revisions of the product.

Agency Approvals

Some applications require agency approvals for particular components. The *C-more* touch panel agency approvals are listed below:

- UL (Underwriters' Laboratories, Inc.)
- CUL (Canadian Underwriters' Laboratories, Inc.)
- CE (European Economic Union)



Wiring Guidelines (cont'd)

Providing Power to the Touch Panel

- **Connect** a **dedicated** 12-24 VDC Class 2 power supply to the DC connector on the rear of the *C-more* touch panel, include wiring the ground terminal to a proper equipment ground
- or install a *C-more* AC/DC Power Adapter, EA-AC, to the rear of the touch panel and connect an AC voltage source of 100-240 VAC, 50/60Hertz, to its AC connector (see note below)
- then turn on the power **source** and check the LED status indicators on the front and rear of the *C-more* touch panel for proper indication (see next page)



NOTE: A dedicated power supply is recommended. If the power supply also feeds inductive loads such as solenoids or relays, the transients caused by these loads can affect the operation of the panel or damage panel components.

	 l
/	
-	

NOTE: The AC/DC Power Adapter, EA-AC, is for **C-more** touch panels only. The adapter is powered from a 100-240 VAC, 50/60 Hertz power source. The adapter provides 24 VDC (a) 1.5 A. Power Fault features help protect data on an SD memory card during power failures.





Warning: Use 60 / 75°C copper conductors only.

C-more LED Status Indicators



(.....)¢

B

Rear View

On

Off

Comm. is active

No communication



System Setup Screens

In This Chapter...

•	
Introduction	5-2
Accessing the System Setup Screens (no project loaded)	5-3
Accessing the System Setup Screens (with project loaded)	5-4
System Setup Screens – Enable Password in Software	5-6
System Setup Screens Flowchart	5-12
Main Menu	5-13
Information Menu	5-14
Setting Menu	5-18
Test Menu	5-25
Memory Menu	5-34

CHAPTER

5

Introduction

The *C-more* touch panels include a series of built-in System Setup Screens that allow the user to view detailed information about the panel; adjust certain features; configure communications; test various functions of the touch panel; backup & restore firmware, recipe, log and project memory; clear memory and reset all values and conditions back to the original factory defaults.

The four Main Menu selections are:

Information

Inform	ation
6)

The information tabs display details about the touch panel model; the panel's name; version information for the hardware, boot loader and firmware; clock source, and beeper status. Other tabs display details on the panel's internal memory and the status of any external memory

devices. Communication port details are available in this area, as well as an error log to help in trouble-shooting the system

Setting



This is the area for 1.) making adjustments to the internal clock, 2.) adjusting the brightness of the display, 3.) setting the IP address 4.) adjusting (calibrating) the touch panel, 4.) enabling or disabling the internal beep, and 5.) enabling or disabling a mouse pointer.

Test Menu



From this sub menu, the user can 1.) test the touch panel, 2.) test the display, 3.) test the user LED 4.) test the communication ports, and 5.) test both the internal beeper or the audio line output, if a speaker with an amplifier is connected. A WAV sound file is system provided for the

audio line output test.

Memory



Select the Memory menu item to either backup or restore your project, log data, recipe data and/or system memory. Selections can be made to backup to optional SD card memory or USB pen drive memory. The menu selections also give the user the ability to clear the memory, and

there is also a selection to reset all of the touch panel settings back to the original factory defaults.



Accessing the System Setup Screens (no project loaded)

To access the Main Menu of the touch panel System Setup Screens prior to downloading a project, press the extreme upper left corner of the panel display area for 3 seconds as shown below. The Main Menu will then be displayed.



Accessing the System Setup Screens (with project loaded)

To access the Main Menu of the touch panel System Setup Screens with a project loaded into memory, press the upper left corner of the panel display area for 3 seconds as shown below.



If no system screen password is enabled, the following WARNING dialog box will appear on the touch screen.:

System	n Screen Called
Activating Sys Par Do you	stem Screen will stop the nel Run Mode. want to continue?
ОК	Cancel

- Pressing OK will display the system setup screen. See the WARNING below!
- Pressing Cancel will take you back to the project screen.
- Communications with the PLC is active while the Warning is displayed.
- The dialog box will close if no action is taken for 60 seconds.
- The dialog box will not display if the touch panel does not have a project loaded.
- The dialog box will display after a valid password is entered if the System Screen password is enabled.



WARNING: Pressing OK at this point will STOP the PLC driver and therefore all communications between the touch panel and PLC will cease. It is strongly recommended that the password system tag "SYS SYSTEMSCREENPW" be enabled to add a safeguard step in accessing the system setup screens. See the next section for an overview for setting the System Tags in the Event Manager Database.



System Setup Screens

The OK button in the Warning dialog box will bring up the Main Menu as shown below. You can then proceed to the other system setup screens.



Password Protecting System Screen Access



NOTE: If the password system tag **SYS SYSTEMSCREENPW** is enabled, the Enter Security Code keypad shown below will open. The procedure to enable the **SYS SYSTEMSCREENPW** is detailed below. Entering the correct password will display the Panel Run Mode warning dialog described previously. PLC communications continue while the keypad is displayed. The keypad will timeout after 60 seconds.

Enter Security Code					
7	8				
4	5				
1	1 2 3		Enter		
-	0	CL	Cancel		

5-5

System Setup Screens – Enable Password in Software

Under the *C-more* Programming Software's Navigation window, select the Function tab, then double click on "Alarm Action" to display the Event Manager Database shown below:



5



System Setup Screens - Enable Password (cont'd)



The Event Add dialog box will be displayed as shown.

Click on the **Tag Name:** pull down menu and select the internal **System Bit On** (**SYS BIT ON**) tag as shown. This will force the tag event type to be continuously active.



System Setup Screens – Enable Password (cont'd)

Use the **Eve**nt Name: text box to document the event as "System Screen PW" for record keeping This is optional.

In the Action box, click once on the displayed 01-Alarm under the Sequence List: so that 01-Alarm is highlighted. Then click the **Delete Action** button to remove the **01-Alarm**.





System Setup Screens - Enable Password (cont'd)

In the Action box, click on the Add Action... button. This will bring up the Add Action dialog box as shown below:



Click on the **Command:** pull down list in the **Add Command** box, select **Tag** from the list, then click **OK**.



EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

-more[.]

System Setup Screens – Enable Password (cont'd)

A 01-Tag	action item	will then	be added	to the Sec	juence List.
----------	-------------	-----------	----------	------------	--------------

ventNo 🖊 🖣 1 ventType	► H		
Tag 💌 Event Name System Screen Pw	Tag Name: SYS BIT ON Event State	OFF	
)		-	01-Tao
Action Sequence List: ☑ 01-Tag	Tag Name:		-
Acton Sequence List:	Too Nane: Wite Side O ON OFF	Volue Volue Data Type:	

Click on the **Tag Name:** pull down list down arrow in the **Action** box's **Tag** tab, select **SYS SYSTEMSCREENPW** from the list, and click **OK**.







System Setup Screens – Enable Password (cont'd)

Enter a numeric value into the **Value:** box, such as "777". This value becomes the Password code to access the System Setup Screen's **Main Menu**.



Click the **Apply** button in the Event Add dialog box and then the Close button to return to the Event Manager Database. You now will see that the first event in the database is for the System Screen Password and it is enabled.

Event							
Event No.	Event Name	Event Type	Alarm	Tag	Tag Copy	Sound	
1	System Scre	Tag		Yes			

System Setup Screens Flowchart



5-12 Cimure EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Main Menu



The **Main Menu** system setup screen is the top layer in the menu structure.

5

Touch Screen Calibration

While the **Main Menu** system setup screen is being displayed, the extreme upper left corner of the touch panel can be pressed for 3 seconds to access the **Touch Screen Calibration** display. This feature is used if the touch panel data becomes corrupted and touching the **Main Menu** buttons does not work. It allows a shortcut to the touch panel calibration screen





Information Menu

Information - General tab

	Inform	mation	
General	Memory	Ethernet	Erro
Panel Type	:EA9-T10C	L	
Panel Name	:EA9-T10C	L-00224A	
Version			
Hardware	:0800		
	:00-00-00-0	0-00-00-00-00	
Boot Loader	: 0800		
Firmware			
-0S	: Ver.0.99 Ji	I 18 2013 at 07:0	3 33
-Runtime	: V4.81 Test	15	
-System Screen	: V4.81 Test	15	<u> </u>
Clock	: Internal	(6	: \
Веер	Enable		
STATES IN		0	Main N

The **General** tab under the Information menu provides detailed information of the *C-more* touch panel.

ltem No.	Function	Description	Comments
1	Panel Type	EA9-T6CL-R EA9-T6CL EA9-T7CL-R EA9-T7CL EA9-T7CL EA9-T10CL EA9-T10WCL EA9-T12CL EA9-T15CL-R EA9-T15CL-R EA9-T15CL	Model Number
2	Panel Name	The panel name is configured in the programming software and saved with a project.	The default panel name is the model number plus the lower three bytes of the panel MAC address, ie EA9- T8CL-0022C4.
3	Version	The version identifications provide information on the components and firmware in the panel	Files reside in the <i>C-more</i> touch panel's memory.
4	Clock	Internal/External clock selection.	Configured in the <i>C-more</i> Programming Software.
5	Beep	Status of the internal beeper.	Configurable in the Setting Menu – Beeper shown on page 5-23 or in the <i>C-more</i> Programming Software.
6	Main Menu	Press to return to the Main Menu screen.	Main Menu shown on previous page.

Information General Memory Ethernet Error Total Usage Free SDRAM 108 MB 60 MB 48 MB MRAM 512 KB 6 KB 506 KB Built-in Flash 81 MB 9 MB 72 MB Main Menu Resource Manito

Information - Memory tab

1. **Memory components** - Status of each memory component - SDRAM, MRAM and Built-in Flash are internal memory components. When external memory devices are installed in the panel they will be included in this list : SD1, SD2 (12 and 15 inch panels only) and USB.

	Inform	mation	
General	Memory	Ethernet	Error
	Total	Usade	Eree
SDR Error List			OK × 9MB
MRA			δKB
Built-			₿MB
SD1			₫ GB
SD2			R CB
USB			INB
Cieco	Pateur	PatroBisin	Close
105			
Resource Mo	nitor		Main Menu

- 2. **Resource Monitor** this troubleshooting tool displays CPU and panel internal memory usage. When enabled, the Resource Monitor will display on the panel screen WHILE THE PROJECT IS RUNNING that is, after you click Main Menu then click Exit) - the Resource Monitor also allows access to the Error Tab WITHOUT STOPPING COMMUNICATIONS WITH THE PLC
- 3. Main Menu Press to return to the Main Menu screen Main Menu shown previously

Information - Ethernet tab

General Memory Ethernet Error Ethernet (Link: Online) MAC Address :00:D0:7C:00:22:4A Address :01:D1:7C:00:22:4A Address Type :Static : : : : : IP Address : 01:10:155 :		Inform	ation	
Ethernet (Link: Online) MAC Address : 00:D0:7C:00:22:4A Address Type : Static IP Address : 10:11:0.155 Subnet Mask : 255:255:0.0 Default Gateway : 0:0:0 DNS Server : Automatically	General	Memory	Ethernet	Error
MAC Address : 00:D0:7C:00:22:4A Address Type : Static IP Address : 10:11:0.155 Subnet Mask : 255:255:0 0 Default Gateway : 0:0:0 DNS Server : Automatically	Ethernet (Link: O	nline)		
Address Type : Static IP Address : 10.110.155 Subnet Mask : 255.255.00 Default Gateway : 0.0.0 DNS Server : Automatically	MAC Address	:00:D0:7C:00):22:4A	
IP Address : 10.11.0.155 Subnet Mask : 255.255.0.0 Default Gateway : 0.0.0.0 DNS Server : Automatically	Address Type	Static		
Subnet Mask : 255.255.0.0 Default Gateway : 0.0.0 DNS Server : Automatically	IP Address	: 10.11.0.155		
Default Gateway: 0.0.0.0 DNS Server : Automatically	Subnet Mask	: 255.255.0.0		
DNS Server : Automatically	Default Gateway	0.0.00		
	DNS Server	: Automatically	1	
				_
			(
				Z)
(2)				\sim
2				Main M

ltem No.	Function	Description	Comment
1	Ethernet (Link: Online)	Ethernet Settings: MAC Address: 00 D0 7C XX XX XX Address Type: DHCP/Static IP Address: Subnet Mask: Default Gateway: DNS: 1.) Automatically 2.) Use Designated Address Note: N/A - not available on reduced featured models (-R)	Configurable in the Setting Menu – IP Address Setting shown on in this section or in the <i>C-more</i> Programming Software.
2	Main Menu	Press to return to the Main Menu screen.	



Error Message Format:

Item No.	Function	Description	Comment		
Order of error message functions: Error Number, Date, Time, Error Port, Device Name, Error Type, PLC Device, Access Bytes, Error Message					
1	Date	Format: MM/DD/YY	Date error occurred.		
2	Time	Format: HH/MM/SS	Time error occurred.		
3	Error Port	PLC Serial Communications Port: Ethernet:			
4	Device Name	The name of the device reporting the error.	Device names are configured in the programming software, Panel Manager		
5	Error Type	RD: Read WT: Write			
6	PLC Address	The assigned address of the PLC that caused the error.			
7	Access Bytes	The number of access bytes.			
8	Error Message	The error message is the same as the message displayed in the upper left of the <i>C-more</i> touch panel's display.	A list of Error Massages is shown in Appendix A		

Error Message navigation buttons:

ltem No.	Function	Description	Comment
1	Clear	Press to clear all error messages. This button is grayed out when there are no error messages to display.	Errors are also cleared with firmware is updated on the panel. Errors are not cleared on power cycle or project transfer.
2	Page Down	Press to go to to the next page. This button is grayed out when there is no error messages on the next page.	
3	Page Up	Press to go to the previous page. This button is grayed out when there is no error messages on the previous page.	
4	Main Menu	Press to return to the Main Menu screen.	

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Setting Menu



The **Setting Menu** is used to adjust the time & date, adjust the contrast or brightness of the display, enter the IP address settings, adjust (calibrate) the touch screen, enable or disable the internal beep and turn on and off the mouse cursor.

ltem No.	Function	Description	Comments
1	Adjust Clock	Press to go to the Adjust Clock screen.	
2	Adjust Display	Press to go to the Adjust Display screen.	
3	IP Address	Press to go to the IP Address screen	The IP Address can also be set from the programming software or by the project.
4	Adjust Touch Panel	Press to go to the Adjust Touch Panel screen.	
5	Веер	Press to go to the Beep screen.	
6	Mouse	Press to go to the Mouse screen.	
7	Main Menu	Press to return to the Main Menu screen.	
Setting – Adjust Clock

Time

13:58:43

Adjust Clock

Function

Date

OK

88-16-2813

5

Cancel

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

	é

5-19

Comments

cycle thru the following settings.	
1.) No Selection to Hours	
2.) Hours to Minutes	
3.) Minutes to Seconds	
4.) Seconds back to Hours	
Date: Each press of the Select button will	

Description

Time: Each press of the Select button will

1	Select	 No Selection to Hours Hours to Minutes Minutes to Seconds Seconds back to Hours Date: Each press of the Select button will cycle thru the following settings. Month to Day Day to Year Year back to Month 	
2	Up	Press to increment the value by "1" with each press.	
3	Down	Press to decrement the value by "1" with each press.	
4	ОК	Press to accept the changes.	
5	Cancel	Press to return to the Setting Menu screen without accepting the changes.	



Item No.

NOTE: The function buttons used to adjust the clock settings on the panel's setup screen are disabled if an External clock source is selected in the C-more programming software. The choice of an internal or external clock source is available by selecting Clock Source in the C-more programming software under the Main Menu drop down function Setup.



NOTE: The panel's clock can also be adjusted from the **C-more** programming software. The **Adjust Clock** function can be accessed in the software by selecting Adjust Clock under the Main Menu drop down function Panel or selecting Adjust Clock under the Panel tab in the software's Navigation window.



Setting – Adjust Display



ltem No.	Function	Description	Comments
1	Setting	Use the Up and Down arrows to change the brightness.	
2	Color Sample	Displays a sample of how colors will appear with the new setting.	
3	Contrast Sample	Displays a sample of contrast with the new setting	
4	ОК	Press to accept the changes.	
5	Cancel	Press to return to the Setting Menu screen without accepting the changes.	



Setting – Adjust Touch Panel

This procedure is used to calibrate the touch screen to ensure accuracy of the touch areas. There are five points on the touch screen that the calibration is based around. The adjustment relies on very narrow areas for the calibration points.



NOTE: The panel will display the **Adjust Touch Panel** window on power up until the calibration procedure is completed.



ltem No.	Function	Description	Comment
1	Start Calibration	Press to begin the touch screen calibration	
2	Cancel	Press to return to the Setting Menu screen.	
3	Points 3a thru 3e	The touch screen calibration crosshairs will appear individually in the order of point 3a thru 3e respectively as each proceeding crosshair is pressed.	If the touched co-ordinate point is too far off from normal, then the procedure will return to Point 3a.



Setting – Beep



This system setup screen function is used to enable or disable the touch panel's internal beep function.

ltem No.	Function	Description	Comments
1	Enable Beep	Check to enable the internal beep.	
2	ОК	Press to accept the changes.	
3	Cancel	Press to return to the Setting Menu screen without accepting the changes.	



NOTE: The project settings in the **C-more** programming software **Panel Manager** will override the touch panel's internal setting upon initial download.



Setting - Mouse

Mou	5e		_
Show Mouse cursor			
O Dn			
• Off			
		DK Canc	el

This system setup screen function is used to enable/ disable the arrow mouse cursor on the panel screen. It may be valuable to display the mouse cursor, for example, when an external USB keyboard is connected to the panel..



NOTE: The project settings in the **C-more** programming software **Panel Manager** will override the touch panel's internal setting upon initial download.

Setting – IP Address Setting



ltem No.	Function	Description	Comment
1	DHCP	"DHCP" is enabled as the default when this system setup screen is first selected. All of the other selections on this screen are dimmed when "DHCP" is selected and are not available.	
2	IP Address	The "Use the following IP Address" setting is selected when its radio button is pressed. Use the numerical keypad to assign the IP address.	Note: If an Ethernet cable is not connected to the touch panel from an active Ethernet device, then the IP Address will show as 0.0.0.0.
3	IP Address Subnet Mask Default Gateway	Select the field that needs to be assigned by touching the entry value and use the keypad to enter the desired address.	Each field can be independently assigned.
4	Keypad	The keypad is used to enter the Address: Use the numeric keys to enter the address, e.g: 192.168.10.1 "CL" = Clear value entered	
5	ОК	Press to accept the changes and return to the Setting Menu screen.	
6	Cancel	Press to return to the Setting Menu screen without accepting the changes.	



NOTE: The project settings in the **C-more** programming software **Panel Manager** will override the touch panel's internal setting upon initial download.



Test Menu



The **Test Menu** gives the user the ability to test the operation of the touch screen, test the LCD display, test the various communication ports, and also test the internal beeper and the audio line out through an user supplied amplified (stereo) speaker(s).

ltem No.	Function	Description	Comments
1	Test Touch Panel	Press to go to the Test Touch Panel screen.	
2	Test Display	Press to go to the Test Display screen.	
3	Test User LED	Tests the user configurable LED on the front of the panel. Refer to the online help file for details on the configuration of this LED.	
4	Test Communication Port	Press to go to the Test Communication Port screen.	
5	Test Beep/Sound	Press to go to the Test Beep/Sound screen.	
6	Main Menu	Press to return to the Main Menu screen.	

5-25

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

Test Touch Panel 1 2 Carcel Carcel		Using this to operation of determined Testing: If an area of be inoperative while in to mode. The in that area black when is defective Setting - Ad	Using this test, normal or unusual operation of the analog touch panel can be determined. Testing: If an area of the touch screen is suspected to be inoperable, touch that area of the screen while in the Test Touch Panel screen mode. The screen pixels should turn black in that area. If the screen pixels do not turn black when touched, then the touch screen is defective or needs to be calibrated. See Setting - Adjust Touch Screen	
ltem No.	Function	Description	Comments	
1	Touch area	Touch to turn on pixels on the screen.	Both the title bar (Test Touch Panel) and Cancel button can be drawn across to test the touch operation.	
2	Cancel	Press to return to the Test Menu screen.		



NOTE: The Touchscreen is designed to respond to a single touch. If it is touched at multiple points at the same time, an unexpected object may be activated.



Test Menu – Test Display

There are two different test patterns that may be run on the display to allow the user to check for display screen defects. If the screen is not touched within 3 seconds of **Test Pattern 1** being displayed, then **Test Pattern 2** will be displayed until the screen is touched, otherwise **Test Pattern 1** will remain until cancelled.

Test Pattern 1 displays a test pattern of 16 grayscale graduations and RGB colors.



Test Pattern 2 will follow the pattern as shown in the following chart with the color wiping across the screen in the direction indicated by the arrows, then repeats:



Item No.	Function	Description	Comments
1	Touch the Test Display screen.	Press the screen anywhere except the Cancel button and the shown Test Pattern 1 remains.	If the Test Display screen is not touched, then in three seconds the display will move to Test Pattern 2 .
2	Cancel (Test Pattern 1)	Press to return to the Test Menu screen.	
3	Touch Anywhere (Test Pattern 2)	Touch the sceen anywhere during Test Pattern 2 and return to the Test Menu screen.	

Test Results: If any pixels on the screen do not appear the same color as the surrounding pixels, the screen may be defective. A single pixel gone bad is relatively common. Surrounding pixels going bad over time is another indication the screen may be defective.

Test Menu – Test Communication Ports: Serial Ports



The following test can be used to check the operation of the serial communication ports, with the use of a loop back connector and can also check the serial communications to any connected and configured PLC.

Item No.	Function	Description	Comments
1	Loop Back Test	The loop back test checks the hardware components of the selected port for proper operation.	The loop back test may be performed on Serial Port 1 or Serial Port 3. Each tab shows diagrams to assist the user in building the loop back connector
2	PLC Enquiry Test	This function allows the ability to select any PLC that that may be connected to the touch panel via a serial connection and checks to see if the communications are working correctly.	The PLC must be configured for the selected port in the C-more programming software Panel Manager and transferred tot he panel before attempting the PLC Enquiry test.
3	Cancel	Press to return to the Test Menu screen.	



5-28 Cincle EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Test Menu - PLC Serial Comm Port - Loop Back Test

Test Results

- 1.) Bytes Sent: The number of bytes sent after a test is started.
- 2.) Receive Counts: The number of bytes which are received after the test is started.
- 3.) Error Counts: The number of bytes which have not been received after the test is started.
- 4.) RTS/CTS Test: Pass/Fail

RTS is turned on and if CTS receives the signal then the test shows "Pass", otherwise the test shows "Fail".



]

NOTE: The test will continue to run until the Cancel button is pressed. If there are any error counts, check the loop back connector.

	Test Co	nn. Port	
	Serial : Lo	op Back Test	
COM3 Port	Butes	Receive	Error
TXD/RXD	Sent	Counts	Counts
Test	8	8	0
RTS/CTS			
Test	Pass		
			Cancel

5

Test Menu - PLC Enquiry Test: Serial Connection

PLC Enguny Test
Select PLC:

This function allows the ability to select any PLC that may be connected to the touch panel through the selected serial comm. port connection and checks to see if the communications are working correctly.

Á	<u>, , , , , , , , , , , , , , , , , , , </u>
	\equiv
L	=
-	_

NOTE: The communications protocol for the PLC being selected must be configured the same as the **C-more** touch panel. The touch panel's PLC serial communications are configured using the **C-more** Programming Software's Panel Manager.

PLC Enquiry Test

Four test packets are sent to the selected PLC. The test result with return either Pass or Fail.



Test Menu – Test Communication Ports: Ethernet



The following test feature can be used to check the operation of the Ethernet communication port by indicating if an Ethernet link has been established or not, and can also check the status of the Ethernet communications to any connected PLC.

Base featured models (-R) do not include an Ethernet port, therefore this check is not displayed.



NOTE: The communications protocol for the PLC being selected must be configured the same as the **C-more** touch panel. The touch panel's PLC serial communications are configured using the **C-more** Programming Software's Panel Manager.

ltem No.	Function	Description	Comments
1	Ethernet Connected	This area displays information to whether an Ethernet link has been established for the touch panel's Ethernet comm port or not. Displays panel's IP address and shows whether it is static or assigned by a DHCP server.	
2	PLC Enquiry Test	This function allows the ability to select any PLC configured in the project that may be connected to the touch panel via an Ethernet connection and checks to see if the communications are working correctly.	The PLC must be configured for the selected port in the C-more programming software Panel Manager and transferred to the panel before attempting the PLC Enquiry test.
3	Cancel	Press to return to the Test Menu screen.	

Example of displayed message when the touch panel's Ethernet port is not connected. Note that the address resets to 0.0.0.0 even if it has previously been entered.







5

Test Menu – PLC Enquiry Test: Ethernet Connection



This function allows the ability to select any PLC configured in the project that may be connected to the touch panel through an Ethernet port connection and checks to see if the communications are working correctly.



NOTE: The communications protocol for the PLC being selected must be configured the same as the **C-more** touch panel. The touch panel's PLC serial communications are configured using the **C-more** Programming Software's Panel Manager.

PLC Enquiry Test

Following are the steps that the Ethernet PLC Enquiry Test performs:

- 1.) Ping the network 4 times for the PLC selected.
- 2.) Four of the test read packets are sent to the selected PLC.

The test result will either be Pass or Fail. However, if the result of pinging the network shows an error, the test is stopped.

Test Conn. Port Ethernet : PLC Enquiry Test Selected PLC : H0-ECOM Ping Test Data1:Reply from PLC:bytes=32 time=1ms TTL=128 Data2:Request timed out Data3:Request timed out Data4:Request timed out Data4:Request timed out Data1:Test Fail. Data2:Test Fail. Data4:Test Fail. Data4:Test Fail.

5-32 Cimere EA9-USER-M Hardware User Manual, 1st Ed. Rev. P





Test Menu - Test Beep/Sound

The internal Beeper can be tested from this system setup screen whether the Beeper is enabled or disabled. After the **Beep Test** button is pressed and released, the Beeper will sound for 500 msec.



The **Speaker Test** function requires that a speaker(s) with an amplifier (can be stereo) be connected to the Audio Line Out stereo jack on the rear of the touch panel.

After the **Speaker Test** button is pressed then released, a system provided Test.WAV file will play once.



WARNING: Hearing damage may occur if the volume on the user supplied external amplified speaker is set too high.



Memory Menu



The user's project, Firmware and OS, log and recipes files can be backed up to or restored from an SD memory card (SD Card Slot 1 or SD Card Slot 2), or a USB memory device. From this menu the user can also clear the project log files. The user also has the ability to clear the memory within the *C-more* touch panel.

ltem No.	Function	Description	Comments
1	Backup	Backup project, Firmware and OS, log & recipe files to the following memory devices: USB port - Type A: USB pen drive SD Card Slot1 (All panels): SD card SD Card Slot2 (12-inch & 15-inch): SD Card	Any USB 2.0 pen drive. SD formats SD and SDHC are supported. Capacity up to 32 GB. The backup data files are created and copied to a folder on the memory device named "EA_Memory Copy." The project file is named StartupStorage.eas9 "Log" and "Recipe" folders with the appropriate data files are also created on the memory device.
2	Restore	Restore project, Firmware and OS, log & recipe files to the internal memory from one of the following memory devices: USB port - Type A: USB pen drive SD Card Slot1 (All panels): SD card SD Card Slot2 (12-inch & 15-inch): SD Card	A folder on the memory device named "EA_Memory Copy" must exist containing a file named "StartupStorage. eas9". The project data file is stored in this file, and if the system data file was backed up, it also will be stored in this file. Any backed up log or recipe data files will be located under the appropriate "Log" or "Recipe" folders.
3	Clear Memory	Clear selected data files from the memory of the following internal memory or external memory devices: Built-in FLASH Memory USB port - Type A: USB pen drive SD Card Slot1 (All panels): SD card SD Card Slot2 (12-inch & 15-inch): SD Card	Can only clear project, log and recipe data files of the Built-in FLASH memory. Can clear entire contents or individual data files of external memory devices.
4	Reset to Factory Default	The touch panel's internal memory is set to the original factory defaults.	Clears all project memory.
5	Main Menu	Press to return to the Main Menu screen.	

NOTE: The Project is RESTORED to the panel from an external memory device. A project can be TRANSFERRED to and SD card or USB memory from the programming software to be RESTORED to a panel that is not connected to the programming software. This file has the .eas9 extension NOT the .eap9 extension of a projects SAVED from the software.



Project Executed from SD Card Slot 1

If the Project Storage/Boot Location is set to Auto or SD1 in the *C-more* software Panel Manager, and an SD memory card is located in the SD Card Slot 1 at the time a project is transferred to the panel, the project will be stored on the SD card, and the Internal Project Memory will be cleared.

If Slot 1 contains an SD memory card with a project and the touch panel's power is cycled, then the project file stored on the SD card is loaded into the touch panel's internal memory and executed. Any project in the internal FLASH memory is cleared.



WARNING: During power up with an SD memory card plugged into an SD card slot, do not remove the memory card from the slot. Damage to the SD memory card and possibly the touch panel may result.



WARNING: After a firmware update, the project files which are located in either the touch panel's internal FLASH memory or an SD memory card plugged into an SD card slot are cleared. The programming software will need to be used to Transfer the project file back into the panel. If you wish to retain the project on the SD memory card, power down the panel and remove the SD card before performing a firmware upgrade.

Increasing Project Memory Size using an SD memory card:

If a project is transferred to the panel with an SD memory card in SD slot 1, the Font and Recipe data files are not included in the 26 MB (82MB for 12" and 15" models) project size. Therefore using an SD memory card can allow a project to be loaded that is larger than 26MB IF the excessive size is caused by Fonts and/or Recipe Sheets.

Memory – Backup



The Memory - Backup selection allows you to backup the panel's **Project**, **Log** files, **Recipe** files or even the **Firmware** files to either an SD memory card or **USB** pen drive. The available memory devices will be displayed with their total and free memory.

If the device is not available, it will be grayed out. The **Next** button is grayed out until a device is selected.

The **Cancel** button can be pressed at any time to return to the **Memory Menu** screen.

	Backup
Step-1: Select backup devi	ice
	USB Total : 488 MB Free : 0 KB
SD1 Total: 8 GB Free: 8 GB	SD2 Total N/A Free N/A
	Next >> Cancel

This is an example of selecting a USB memory device to write the backed up files to.

The selected device is highlighted. Pressing again deselects it.

Even if there is only one available memory device, it still needs to be highlighted in order to go to the next step.

Press the Next button to continue to Step 2.

Please read the explanation for the availability of SD1 under different conditions that follow:

Memory – Backup (cont'd)

SD Card Slot1 Availability Explanation:



SD1 may be unavailable (grayed out) if there is no card in SD Slot 1 or the card in SD slot 1 has the project currently running on the panel stored on it. The project will exist on SD1 if the SD card was installed in SD1 when the project was TRANSFERRED to the panel by the *C-more* programming software.

	Backup
Step-1 : Select backup dev	ice
	USB Total: 488 MB Free: 10 KB
SD1 Total:8 GB Free:8 GB	SD2 Total ISA Free INKA
	Next>> Cancel

If the panel is powered up or rebooted with an SD card inserted into SD1 Slot, then the SD1 button's Total and Free memory will be displayed.

5-37

5

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

Memory - Backup (cont'd)



NOTE: The following definitions are for the various file types that can be backed up:

Project data – consists of the actual developed project data that is created in the **C-more** programming software and includes all functionality, objects, screens, tag names, labels, comments, graphics, etc. Included in backup file name StartupStorage.eas9.

Recipe data – consists of all the data values and labels that have been created for the various recipe sheets. Includes all recipe sheets loaded to the panel. Only recipe sheets used in the project are loaded to the panel. **Firmware** – consists of the operating system, firmware and run time files. Included in backup file name StartupStorage.eas9.

Log data - consists of the Alarm Log, Message Log and Trend Data Logging files.

Select the data file(s) to be backed up by pressing the appropriate data file button. The selection will be highlighted.

Backup		
Step-2 : Select Data Area to E	Backup	
Project Total : 507 KB	Recipe Total 0 KB	
Log Total : 5 MB	Firmware Total: 17 MB	
	<< Prev. Next >> Cancel	

Pressing the highlighted data file button again will turn it off.

The Next >> button will stay grayed out until at least one data file is selected.

Any file type not available will be grayed out.

The Next >> button is now enabled.

Pressing Cancel will return to the previous menu.

Press the Next button to continue.



NOTE: In the case of the **Project** and **Firmware** files, these can be **Restored** later to another panel. **Recipe** files can be edited externally from the panel and then **Restored** to the panel. The **Log** files are for viewing purposes only.

See **Memory** - **Restore** later in this chapter for instructions on Restoring the Project, Firmware and or Recipe files to a Panel.



Memory – Backup (cont'd)

Backup Data Files Naming and Organization

The following graphic shows how the various data files are organized on the memory device when doing a **Backup** and also the file naming convention that is used when viewed in Windows® Explorer on a PC.





Memory – Backup (cont'd)

Backup		
Step-3 : Panel to USB		
Panel	USB	
Total : 17 MB	Total : 488 MB	
Project : 2 MB	Used : 624 KB	
Firmware : 15 MB	Free : 487 MB	
<< Prev.	OK Cancel	

The next system setup screen allows the verification of the data file selections. When the OK button is pressed, the backup begins.

The user can return to the previous screen by pressing the << Prev button.



This message is displayed during the **Backup** copying process. Press the **Cancel** button to abort the backup.

The following text is shown in the copying progress message box:

Copy to USB Memory:

"Please do not Power Off and Remove USB"

Copy to SD1 or SD2: "Please do not Power Off and Remove SD"



WARNING: During the copying process do not power off the touch panel or remove the memory device.



This message is displayed to indicate the **Backup** is complete. Press the **OK** button to return to the previous menu selection.

Memory - Backup (cont'd)



Warning Messages

If the destination does not have enough space to store the selected memory size, then the message shown here will be displayed. Press the **OK** button to clear the warning message.

The warning message will read "Not enough Memory Space in %Device%".

%Device% will show either "SD1", "SD2", or "USB".



This warning message will be displayed if the backup Memory device fails or is removed during the backup. Press the OK button to clear the warning message.

The warning message will read "Backup Failed. "%Device% cannot be found".

%Device% will show either "SD1", "SD2", or "USB".

Refer to **Chapter 8: Troubleshooting** for additional help.

Васкив			
Step-3	Step-3 : Panel to USB		
Sys	stem Screen		
Backup Failed.			
OK			
	Cancel		

For any other reason the backup fails, then this warning message will be displayed. Press the **OK** button to clear the warning message.

The warning message will read "Backup Failed".

Refer to **Chapter 8: Troubleshooting** for additional help.

5 - 41

Memory - Restore



The Memory - Restore function is used to:

1.) **Restore** a project previously backed up on an SD card or USB pen drive memory device to the same panel. See **Memory - Backup** previously in this chapter.

2.) Copy a project from one panel to another panel using a memory device to physically transport the data files.

3.) **Restore** a project into the panel that was transferred to an "External Memory Device" using the *C-more* Programming Software.

4.) **Restore Recipe Sheet(s)** previously backed up to a memory device or copied to the memory device using a PC.

The available memory devices will be displayed showing the total and free available memory for that device. If the device is not available, it will be grayed out. The **Next** button is grayed out until a device is selected.

The **Cancel** button can be pressed at any time to return to the **Memory Menu** screen.

This is an example of a USB memory device selected to be the source for restoring the data file(s).

The selected device is highlighted. Pressing again deselects it.

Even if there is only one available memory device, it needs to be highlighted in order to go to the next step.

Press the **Next** button to continue to Step 2.

	000000
1	
1	
L	

NOTE: If you have a memory device inserted into the proper port on the touch panel, but it doesn't show up as highlighted in Step 1 of the **Backup** setup screen, then try a different device to determine if the memory device is defective or if there is a possible problem with the memory device connection. It may not be compatible with the panel. Some USB pen drives are not USB 2.0 compatible and will not work with **C-more** touch panels. Some USB pen drives may take several minutes before they are recognized by the panel. SD cards must be formatted using the SD formatter provided by **SDcard.org**



Please read the explanation for the availability of SD1 under different conditions as shown on this page and the next.

SD1 Availability Explanation:



SD1 may be unavailable (grayed out) if there is no card in SD Slot 1 or the card in SD slot 1 has the project currently running on the panel stored on it.

The project will exist on SD1 if the SD card was installed in SD1 when the project was TRANSFERRED to the panel by the *C-more* programming software.



If the panel is powered up or rebooted with an SD card inserted into SD1 Slot, then the SD1 button's Total and Free memory will be displayed.



NOTE: The following definitions are for the various file types that can be restored:

Project data – consists of the actual developed project data that is created in the **C-more** programming software and includes all functionality, objects, screens, tag names, labels, comments, graphics, etc. Included in backup file name StartupStorage.eas9.

Recipe data – consists of all the data values and labels that have been created for the various recipe sheets. Includes all recipe sheets loaded to the panel. Only recipe sheets used in the project are loaded to the panel. **Firmware** – consists of the operating system, firmware and run time files. Included in backup file name StartupStorage.eas9.

Log data - consists of the Alarm Log, Message Log and Trend Data Logging files.

Restore		
Step-2 : Select Data Area to Restore		
Project Recipe Total : 172 KB Total : 1 KB		
Log Total : 268 KB	System Total : 16 MB	
< Prev.	Next >> Cancel	

Select the data file(s) to be restored by pressing the appropriate data file button. The selection will be highlighted. The data file can be either the **Project**, **Firmware** and/or **Recipe files**. The selected data is restored to the internal built-in memory if there is no SD card inserted into the SD1 slot.

Pressing the highlighted data file again will turn it off.

The **Next** >> button will stay grayed out until at least one data file is selected.

Any file type not available will be grayed out.

Restore		This is an example of a file selected to restore
Step-2 : Select Data Area to Restore		This is an example of a file selected to restore.
1▶2▶3		The selected file is highlighted
Project	Recipe	
IULAI . IIZ KD		The Next >> button is now enabled.
Log Total : 268 KB	System Total : 16 MB	Pressing Cancel will return to the previous menu.
< Prev.	Next >> Cancel	Press the Next button to continue.



NOTE: The following definitions are for the various file types that can be restored: **Project data** – consists of the actual developed project data that is created in the **C-more** programming software

and includes all functionality, objects, screens, tag names, labels, comments, graphics, etc. Included in backup file name StartupStorage.eas9.

Recipe data – consists of all the data values and labels that have been created for the various recipe sheets. Includes all recipe sheets loaded to the panel. Only recipe sheets used in the project are loaded to the panel. **Firmware** – consists of the operating system, firmware and run time files. Included in backup file name StartupStorage.eas9.

Log data - consists of the Alarm Log, Message Log and Trend Data Logging files.



 Restore

 Ster-3 : USB to Panel

 1
 2
 3

 System Screen
 3

 Tot
 The restore was completed.

 OK
 OK

 <</td>
 OK

 OK
 Cancel

This message is displayed to indicate the **Restore** is complete. Press the **OK** button to return to the previous menu selection.

5

Restore Ster-3 : USB to Panel I I System Screen Tot Not enough Memory Space in System Memory. OK OK Cancel

Restore Ster-3 : USB to Panel System Screen Restore Failed. USB cannot be found. OK OK Cancel



Warning Messages:

If the system memory does not have enough space to restore the selected memory size, then the message shown here will be displayed. Press the **OK** button to clear the warning message.

The warning message will read "Not enough Memory Space in System Memory".

The Project size must be less than 10 MByte for 6"-10" panels and less than 40 MByte for 12" & 15" panels.

This warning message will be displayed if the restore Memory device fails or is removed during the backup. Press the **OK** button to clear the warning message.

The warning message will read "Restore Failed. "%Device% cannot be found".

%Device% will show show "SD1", "SD2", or "USB".

Try using a different device with known good data in the same connector or using the device that is causing the error in a different connector.

For any other reason the restore fails, then this warning message will be displayed. Press the **OK** button to clear the warning message.

5-46

Memory – Clear Memory

Clear Memory			
Step-1 : Select Device to Clea	ar		
Built-in Memory Total 81 MB Free , 72 MB	USB Total : 488 MB Free : 0 KB		
SD1 Total & GE Free : 8 GB	SD2 Total::N/A Free : N/A		
	Next >> Cancel		

This function is used to clear individually selected data files, or all data files, within the panel's **Built-in Memory**, or any installed memory device such as a USB pen drive or an SD card.

Select the memory device to clear. If the device is not available, it will be grayed out.

The Next button is grayed out until a device is selected.

Clear Memory		
Step-1 : Select Device to Clea	ar	
Built-in Memory Total : 77 MB Free : 69 MB	USB Total: 488 MB Free : 481 MB	
SD1 Total: 15 GB Free : 15 GB	SD2 Total INA Free INA	
	Next >> Cancel	

The selected device is highlighted. Pressing again deselects it.

When there are more than two available backup devices, the one selected will be highlighted. If another is selected, then the highlight will change to the last one pressed. Only one device can be selected at a time.

Press the **Next** button to continue.

5-47

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

Memory - Clear Memory (cont'd)

Clear Memory				
Step–2 : Select Data Area to Erase				
Project Total : 0 KB	Recipe Total : 0 KB			
Log Total : 0 KB	Clear All Total:70 MB			
<< Prev.	Next >> Cancel			

Select the data file(s) to be cleared.

This is an example of an SD card or USB memory that was selected in **Clear Memory - Step-1**.

The selected file will be highlighted. Pressing again deselects it.

The **Next** >> button will stay grayed out until file(s) are selected.

Selecting **Clear All** will erase all files located on the memory device.

This is an example of **USB Memory** that was selected in **Clear Memory - Step-1**.

Notice the ability to select either the **Project** file, **Log** files, **Recipe** files, or the **System** files.



NOTE: Firmware files cannot be cleared from internal memory.





Clear Memory
Step-3 : Clear USB
System Screen
USB cleared.
<u> </u>
<< Prev. OK Cancel

The following message is displayed when the clearing process is complete:

"%Device% cleared"

%Device% will show either "SD1", "SD2", or "USB".

Press the **OK** button to return to the **Memory Menu** screen.

5

Memory - Clear Memory (cont'd)



5-50

NOTE: If Clear All is selected, all files will be erased from the memory device, even those not related to the **C-more** touch panel.



The data file(s)selected to clear are verified. If the data file is good, then the OK button can be pressed to start the clear procedure.

If there is a problem with the data file, the **OK** button will remain grayed out and the user can return to the previous screen by pressing the << Prev button.

Press the **OK** button to continue.

The warning message shown here will be displayed to give the user the opportunity to decide if they want to proceed or not.

Press the **OK** button to continue.

The **Clear All** process will start with a warning message as seen in the first example and continue until a message saying the device is cleared or a warning message as shown on the next page will appear.



Memory - Clear Memory (cont'd)



The warning message shown here will be displayed if the clearing process fails.

"Clear Failed".

Press the **OK** button to return to the **Clear Memory** screen and try again.

If the selected memory still fails to clear, then refer to **Chapter 8: Troubleshooting** for additional help.



Memory – Reset to Factory Default



After pressing the **Reset to Factory Default** button from the **Memory Menu**, the message box shown will be displayed.

Resetting to the Factory Defaults produces the following actions:

- 1.) The touch screen calibration is reset to the Factory Defaults.
- 2.) The project file is cleared.
- 3.) The log, recipe & WAV files are cleared.
- 4.) The IP address is set to DHCP.



WARNING: As a precaution, it is recommended to create a backup file to an SD card or USB storage device using the Memory Backup function before resetting to factory defaults.



The message shown here is displayed once the **Factory Default** values have been stored into the system memory.

Press OK to continue.

After pressing **OK**, the touch panel will reboot and startup on the **Touch Screen Calibration** procedure as shown here.

The following note is also shown on the calibration screens to remind the user that the **Project File** has been cleared, there's no communications with the PLC, and the calibration procedure most be performed in order to ready the panel to download a project:

Note: The panel will not communicate or run its project in this mode.

Also, the *C-more* **Programming Software** will not connect to the panel in this situation.



PLC COMMUNICATIONS

In This Chapter... AutomationDirect PLCs RS-422A/RS-485A......6-10 DirectLOGIC Universal Isolated Network Adapter, p/n FA-ISOCON:6-16 RS-422A/RS-485A Multi-Drop Wiring Diagram Examples6-18 Modicon Modbus RS-232.....6-31 Modicon Modbus with RI45......6-31 Siemens 6-32

CHAPTER

Introduction

The *C-more* family of touch panels is capable of communicating with a wide variety of Programmable Logic Controllers. *C-more* is capable of communicating over RS232, RS422 and RS485 serial networks as well as Ethernet networks. It communicates with all AutomationDirect PLC's utilizing various protocols. *C-more* also communicates with other brands of PLCs by their different protocols. The table on the next page lists all of the various PLCs and protocols that can be configured. The page after the protocol table lists the various serial communication cables that are available to purchase. The rest of this chapter is devoted to showing the pin to pin connections of all the available cables plus wiring diagrams that the user can refer to in order to construct their own cables, along with wiring diagrams of cables that are not available for purchase. To simplify RS422/RS485 wiring schemes, we have included wiring diagrams showing connections for available terminal connectors such as our ZIPLink Communication Adapter Module, p/n ZL-CMA15, used for example with our DL-06 and D2-260 PLCs.

If you have difficulty determining whether the particular PLC and/or protocol you are using will work with the *C-more* series of touch panels, please contact our technical support group at 770-844-4200

DirectLOGIC PLCs Password Protection

NOTE: Many **Direct**Logic PLCs support multi-level password protection of the ladder program. This allows password protection while not locking the communication port to an operator interface. The multilevel password can be invoked by creating a password with an upper case "A" followed by seven numeric characters (e.g. A1234567). Please refer to the specific PLC user manual for further details.




PLC Protocols

		PLC Protocol Table		
Model			Protocols	
	Productivity Series		Productivity Serial	
	Productivity	Series	Productivity Ethernet	
	Do-more	all	Do-more Serial	
	(BRX)		Do-more Ethernet	
			Modbus (CLICK addressing)	
	ULIUK		Modbus TCP (CLICK addressing)	
		all	K-Sequence	
			Direct NET	
	DL05/DL06		Modbus (Koyo addressing)	
		H0-ECOM/H0-ECOM100	Direct LOGIC Ethernet	
	DL105	all	K-Sequence	
		D2-230	K-Sequence	
		D0.040	K-Sequence	
		D2-240	Direct NET	
			K-Sequence	
	DL205	D2-250/D2-250-1/D2-260/D2-262	Direct NET	
			Modbus (Koyo addressing)	
		D2-240/D2-250-1/D2-260	Direct NET	
		Using DCM	Modbus (Kovo addressing)	
		H2-ECOM/H2-ECOM100	Direct LOGIC Ethernet	
	D3-330/330P (Requires the use of a Data Communications Unit) Direct NET	Direct NET		
AutomationDirect		D3-340	Direct NET	
			K-Sequence	
	DL305	D3-350	Direct NET	
			Modbus (Koyo addressing)	
			DirectNET	
		D3-350 DCM	Modbus (Koyo addressing)	
		D.4.400	K-Sequence	
		104-430	Direct NET	
		D4.440	K-Sequence	
		04-440	Direct NET	
			K-Sequence	
	DL405	D4-450/D4-454	Direct NET	
			Modbus (Koyo addressing)	
			Direct NET	
			Modbus (Koyo addressing)	
		H4-ECOM/H4-ECOM100	Direct LOGIC Ethernet	
H2-WinPL(Think & Do) Live V5.2 or later and Studio any version	Think & Do Modbus RTU (serial port)	
	H2-WinPLC (Think & Do) Live V5.5.1 or later and Studio V7.2.1 or later		Think & Do Modbus TCP/IP (Ethernet port)	
			GS Drives Serial	
	GO Drives		GS Drives TCP/IP (GS-EDRV)	
	SOLO Temp	erature Controllers (models with serial communications)	SOLO Temperature Controller	

PLC Protocols

	PLC Protocol Table (cont'd)		
Model		Protocols	
	MicroLogix 1000, 1100, 1200, 1400, 1500, SLC 5-01/02/03	DH485/AIC/AIC+	
	MicroLogix 1000, 1100, 1200, 1400 and 1500		
	SLC 5-03/04/05	DF1 Half Duplex; DF1 Full Duplex	
	ControlLogix™, CompactLogix™, FlexLogix™	-	
	PLC-5	DF1 Full Duplex	
	ControlLogix, CompactLogix, FlexLogix - Tag Based	DF1 Half Duplex; DF1 Full Duplex	
	ControlLogix, CompactLogix, FlexLogix - Generic I/O Messaging	EtherNet/IP Server	
Allen-Bradley	ControlLogix, CompactLogix, FlexLogix - Tag Based		
	MicroLogix 1100, 1400 and SLC 5/05, via native Ethernet port	EtherNet/IP Client	
	MicroLogix 1000, 1100, 1200, 1400, 1500, SLC 5-03/04/05, all via ENI adapter		
	Non 200 Contra	Modbus RTU	
		Modbus TCP	
	Micro 800 Series - Tag Based	DF1 Full Duplex	
		EtherNet/IP Client	
Modbus RTU	Modbus RTU devices	Modbus RTU	
Modbus TCP/IP	Modbus TCP/IP devices	Modbus TCP/IP	
CE.	90/30, 90/70, Micro 90, VersaMax Micro	SNPX	
GE	90/30, Rx3i	SRTP Ethernet	
	FX Series	FX Direct	
Mitouhichi	Q02, Q02H, Q06H, Q12H, Q25H	Q CPU	
WIIISUDISIII	Q, QnA Serial	QnA Serial	
	Q, QnA Ethernet QnA Ether	QnA Ethernet	
	984 CPU, Quantum 113 CPU, AEG Modicon Micro Series 110 CPU: 311-xx, 411-xx, 512-xx, 612-xx	Modbus RTU	
Modicon	CON Other devices using Modicon Modbus addressing	Modbus RTU	
		TUModbus TCP/IP	
Omron	C200 Adapter, C500	Host Link	
	CJ1/CS1 Serial	FINS	
	CJ1/CS1 Ethernet		
	S7-200 CPU, RS-485 Serial	РРІ	
Siemens	S7-200 CPU, S7-300 CPU, S7-400, S7-1200, S7-1500 CPU Ethernet	Ethernet ISO over TCP	



PLC Communication Cables & Wiring Diagrams

Cable Description	Cable Part No.	Cable Description Cable
Cables used with 15-pin RS-232/422/4	85 serial Port1	Cables used with P I12 PS 222 serial Part No.
AutomationDirect Productivity Series, Do-more, CLICK, <i>Direct</i> LOGIC PLC RJ-12 port, DL05, DL06, DL105, DL205, D3-350, D4-450 & H2-WinPLC (RS-232C) 3m (9.8 ft) cable length	EA-2CBL	AutomationDirect Productivity Series, Do-more, CLICK, <i>Direct</i> LOGIC PLC RJ-12 port, DL05, DL06, DL105, DL205, D3-350, D4-450 & H2-WinPLC (RS-232C)
<i>Direct</i> LOGIČ (VGA Style) 15-pin port, DL06, D2-250 (250-1), D2-260 (RS-232C) <u>3m (9.8 ft) cable length</u>	EA-2CBL-1	3.66m (12tt) cable length <i>Direct</i> LOGIC (VGA Style) 15-pin port, DL06, D2-250 (250-1), D2-260 (RS-232C). FA-15HD
Direct LOGIC PLC RJ-11 port, D3-340 (RS-232C) 3m (9.8 ft) cable length	EA-3CBL	Direct LOGIC PLC 15-pin D-sub port,
<i>Direct</i> LOGIC DL405 PLC 15-pin D-sub port, DL405 (RS-232C) 3m (9.8 ft) cable length	EA-4CBL-1	Use with DO-CBL cable.
Direct LOGIC PLC 25-pin D-sub port, DL405, D3-350, DL305 DCU and all DCM's (RS-232C) 3m (9.8 ft) cable length	EA-4CBL-2	Direct LOGIC PLC RJ-11 port, D3-340 OP-3CBL-1 (RS-232C) 2m (6.56 ft) cable length OP-3CBL-1
Allen-Bradley MicroLogix 1000, 1100, 1200, 1400 & 1500 (RS-232C) 3m (9.8 ft) cable length	EA-MLOGIX-CBL	
Allen-Bradley SLC 5-03/04/05, ControlLogix, CompactLogix, FlexLogix DF1 port (RS-232C)	EA-SLC-232-CBL	
Allen-Bradley PLC-5 DF1 port (RS-232C) 3m (9.8 ft) cable length	EA-PLC5-232-CBL	
Allen-Bradley SLC 5-01/02/03, PLC5 DH485 port 3m (9.8 ft) cable length	EA-DH485-CBL	
GE 90/30, 90/70, Micro 90, Versamax Micro (Port2) 15-pin D-sub port (RS-422A) 3m (9.8 ft) cable length	EA-90-30-CBL	
MITSUBISHI FX Series 25-pin port (RS-422A) 3m (9.8 ft) cable length	EA-MITSU-CBL	
MITSUBISHI FX Series 8-pin mini-DIN (RS-422A) 3m (9.8 ft) cable length	EA-MITSU-CBL-1	
OMRON Host Link (C200 Adapter, C500) (RS-232C) 3m (9.8 ft) cable length	EA-OMRON-CBL	
Port1		*Port2
$ \begin{array}{c} 8 \\ 0 \\ 15 \\ 9 \end{array} $ D-Sub on rear	15-pin female of touch panel	+ RS-485 Serial - Communications Logic Ground
Pin Signal 1 0V 2 N.C. 3 RXD 4 TXD 5 +5V 6 0V		RJ12 RS-232 Serial Communications

INULE: All cables for connections at Port 2 are user constructed. Refer to the specifications of the connected device port to construct the cable properly. The connector for Port2, EA9-3TB, is included with your **C-more** panel.

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

Cables from AutomationDirect (cont'd)



6-6 Cimore EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



PLC Communication Cables & Wiring Diagrams (cont'd)

The following series of wiring diagrams show the connectors and wiring details for the communication cables that are used between the *C-more* touch panels and various PLC controllers. Part numbers are included with the **pre-made cables** that can be purchased from *AutomationDirect*. The information presented will allow the user to construct their own cables if so desired.

AutomationDirect PLCs RS-232C Serial







6

AutomationDirect PLCs RS-232C Serial (cont'd)



6-8 Cimore: EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



AutomationDirect PLCs RS-232C Serial (cont'd)





DO-CBL



OP-3CBL-1

-more



EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

AutomationDirect PLCs RS-422A/RS-485A

When using the RS-422A/RS-485A capabilities of the *C-more* 15-pin PLC communications Port1, the termination resistor is placed between the **RXD–** and **RXD+** terminals on the PLC side of the connection between the touch panel and PLC. The Termination Resistor value is based on the characteristic impedance of the cable being used. To enable the built-in 120 Ohm Termination Resistor, jumper pin **13** to pin **9** (**RXD+**) on the *C-more* 15-pin PLC communications Port1.



NOTE: The RS-422 wiring diagrams shown above are not for multi-drop networks involving connecting more than one PLC to a panel. Refer to the multi-drop wiring diagram examples later in this chapter if more than one PLC will be connected to a panel.

6-10

MOFE^{*} EA9-USER-M Hardware User Manual, 1st Ed. Rev. P







User Constructed



NOTE: The RS-422 wiring diagrams shown above are not for multi-drop networks involving connecting more than one PLC to a panel. Refer to the multi-drop wiring diagram examples later in this chapter if more than one PLC will be connected to a panel.







NOTE: The RS-485 wiring diagram shown above is not for multi-drop networks involving connecting more than one PLC to a panel. Refer to the multi-drop wiring diagram examples later in this chapter if more than one PLC will be connected to a panel.

6-12 Cincre[®] EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



User Constructed







NOTE: The RS-422 and RS-485 wiring diagrams shown above are not for multi-drop networks involving connecting more than one PLC to a panel. Refer to the multi-drop wiring diagram examples later in this chapter if more than one PLC will be connected to a panel.



* NOTE: EA-COMCON-3 will install only on EA9-T6CL, EA9-T6CL-R, EA9-T7CL and EA9-T7CL-R panels

User Constructed



PLC will be connected to a panel.



* NOTE: EA-COMCON-3 will install only on EA9-T6CL, EA9-T6CL-R, EA9-T7CL and EA9-T7CL-R panels





User Constructed





NOTE: The RS-485 wiring diagram shown above is not for multi-drop networks involving connecting more than one PLC to a panel. Refer to the multi-drop wiring diagram examples later in this chapter if more than one PLC will be connected to a panel.

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P Cimple 6-15



6-16 Cmore EA9-USER-M Hardware User Manual, 1st Ed. Rev. P





6-17

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P





Typical RS-422 Multi-Drop Wiring Diagram

using DirectLogic pin numbers to illustrate



RS-422A/RS-485A Multi-Drop Wiring Diagram Examples (cont'd)



EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Notes: 1. We recommend Belden 9842 shielded cable or equivalent. 2. Wiring Diagram for this example, ZL-CMA15(L)



* Termination resistors required at both ends of the network to match the impedance of the cable (between 100 and 500 ohms).

Typical RS-485 Multi-Drop Wiring Diagram

using DirectLogic pin numbers to illustrate



RS-422A/RS-485A Multi-Drop Wiring Diagram Examples (cont'd)

DL06 and DL205 used for illustration purposes



Notes: 1. We recommend Belden 9842 shielded cable or equivalent. 2. Wiring Diagram for this example, ZL-CMA15(L)



Typical RS-485 Multi-Drop Wiring Diagram (cont-d) using DirectLogic pin numbers to illustrate

*Termination resistors required at both ends of the network receive data signals to match the impedance of the cable (between 100 and 500 ohms). Jumper pin 13 to 9 on the *C-more* touch panel 15-pin connector to place the 1200 internal resistor into the network. If the cable impedance is different, then use an external resistor matched to the cable impedance.

6-21

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

Allen-Bradley

EA-MLOGIX-CBL



MOLE EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

6-22





6 - 23

_more



6-24 Cimore EA9-USER-M Hardware User Manual, 1st Ed. Rev. P







User Constructed





GE

EA-90-30-CBL



GE VersaMax Micro

To C-more Touch GE VersaMax Micro Port 1 To PLC Panel PLC Port **RS-232C** RJ45 Port 1 RJ45 8-pin 15-pin Phone Plug D-sub 1 = RTS Wiring Diagram (8P8C) (male) 2 = CTS 8 = do not use 15 = do not use _____ TXD ← RXD 7 = do not use 3 = RXD 14 = do not use 000000000 115 4 = TXD 6 = donot use 13 = do not use RXD 5 = Logic GND 5 = DCD 12 = do not use GND < 8 6 = DTR 4 = do not use 11 = do not use 3 = RXD (232C) 7 = +5V 10 = do not use shield nt 2 = TXD (232C) ٠ 8 = GND 9 = do not use 87654321 1 = Frame GND Note: Use the above wiring diagram to make your own cable. We recommend using 22 AWG shielded cable.

User Constructed

6-27

6

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P Cimore

Mitsubishi



6-28

MDFP^{*} EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Mitsubishi (cont'd)

User Constructed



Omron

EA-OMRON-CBL



User Constructed



User Constructed



IDFE® EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Modicon Modbus RS-232





Modicon Micro Series

User Constructed



Modicon Modbus with RJ45

User Constructed

-more



6-31

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

Siemens





MAINTENANCE



In This Chapter...

Project Backup	7-2
Check Operating Environment	7-2
Check Operating Voltage	7-2
Check Status Indicators	7-2
Check Physical Conditions	7-3
Run Tests under System Setup Screens	7-3
Check Memory Usage	7-4
Check/Adjust Display Brightness	7-4
Check Error Log	7-4
Adjust Touch Panel	7-4
Cleaning the Display Screen	7-5
Check Project Functionality	7-6
Checks from C-more Programming Software	7-6
Notes:	7-7

Maintenance



Although the C-more touch panels require very little maintenance, setting up a routine maintenance schedule will ensure the longevity of the product in your application.

The following are some suggestions of items to include in a preventive maintenance list or schedule. Most of these items should be scheduled quarterly or semi-annually.

Project Backup

• During routine preventive maintenance is a good time to make sure that there is an up-todate backup of the application project. Although the C-more touch panel has the ability to upload the complete project from a panel through the programming software, insurance is warranted just in case the worse case scenario happens and the entire touch panel is destroyed.

Check Operating Environment

- Make sure the touch panel is operating in the proper temperature range: 0 to 50 $^{\circ}$ C (32 to 122 $^{\circ}$ F).
- Make sure the touch panel is operating within the specified humidity range: (5 95% RH, non-condensing).
- Make sure the operating environment is free of corrosive gasses.



Check Operating Voltage

• Check the input voltage that is powering the touch panel to make sure it is within the appropriate range.



DC: 12 - 24 VDC

AC: If the panel is being powered from an AC/DC Power Adapter, EA-AC, then the acceptable input voltage range to the adapter is 100-240 VAC, 50/60 Hertz.

Check Status Indicators

• During routine maintenance is a good time to take a quick look at the status indicators on the front and rear of the touch panel. The Power LED (PWR) indicator should be on and there should be activity on the TxD and RxD LED indicators when connected serially to a PLC or control device. Check the status of the CPU LED and compare it to the chart shown in the illustration below. Any indication of the CPU LED other than a solid green shows there is a possible problem, and the condition needs to be corrected.



DFP® EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

VICPAS HMI Parts Center

Check Physical Conditions

- Make sure that harmful chemicals are not being used around the panel. Look for any deterioration of the touch panel's bezel and front display area.
- Check the mounting gasket to make sure it is sealing properly and Replace the mounting gasket if there are any signs of deterioration, or if there is any evidence that moisture/liquids have penetrated to the inside of the enclosure where the panel is mounted. Information on a replacement gaskets can be found in **Chapter 9: Replacement Parts.**
- Check to make sure that none of the cooling vents around the inside section of the touch panel are clogged with dust or debris. Also make sure that there is clearance around the touch panel as shown in **Chapter 4: Installation and Wiring.**

Run Tests under System Setup Screens

• Use the touch panel's System Setup Screens to test the touch screen, display, communication ports, beeper and audio output (only with external amplifier and speaker(s) connected). See **Chapter 5: System Setup Screens** for additional details for the **Test Menu.**

Test Touch Panel - allows the user to check the analog touch function of the screen by drawing free hand lines and shapes across the entire touch area. The display will retain the lines where the screen has been touched until the **Cancel** button is pressed.

Test Display - used to test the display and color rendition. A test pattern will first show both the primary colors and a gray scale. If the touch screen is not pressed within a few seconds, the display will go into alternating color sweeps across the screen until the panel is pressed again. If the screen is pressed when the test pattern first appears, it will stay in this mode until the **Cancel** button is pressed.

Test Comm. Port - used to test the functionality of the 15-pin PLC communication serial port, the 3-wire terminal block RS-485 port, the RJ12 RS-232 port and the Ethernet port. A loop-back connector can be fabricated and used on the serial ports to test the RS-232 or RS-422/485 communications for the TxD and RxD signals and also the RTS and CTS signals if applicable. The **Test Comm. Port** setup screens and **Chapter 5** show pin-outs for the RS-232 and RS-422/485 loop-back connectors. The Ethernet connection can also be tested for communications if it is at least connected to an Ethernet switch. If the touch panel is connected to a PLC, then an inquiry test can also be done to test the communications between the panel and the PLC. Press the Cancel button when finished to return to the **Test Menu** screen.

Test Beep/Sound - used to test the touch panel's internal beeper and also test the audio line output port with an external amplifier and speaker(s) connected. Testing the audio output is done by playing an included internal WAV file. Press the **Cancel** button when finished to return to the **Test Menu** screen.







Check Memory Usage

- A good time to check and record the touch panel's memory usage for future reference is during a routine maintenance schedule. The various memory devices being used by the panel are listed under the tab. This includes internal memory as well as any external memory device such as a USB pen drive or SD card memory. If no external memory device is inserted, it will not show up on the list.
- The memory usage can be viewed by use of the panel's **System Setup Screen's Main Menu**, and then selecting the **Information** button then the **Memory** tab. See **Chapter 5**: **System Setup Screens** for additional details on using the **Memory** tab.

Check/Adjust Display Brightness

• Is is good practice to occasionally check the display brightness or contrast and adjust as required. This is done by using the **Setting Menu** in the **System Setup Screens**. See **Chapter 5**: **System Setup Screens** for additional details.







Ĩ.	Touch Screen Calibration	1
+	Calibrate the Youch Screen by touching the center of the cookheis + with your finger or a injust.	T
	+	
T		Ē.
+		+

Check Error Log

Another good practice is to review the touch panel's Error Log. The log can be viewed by use of the panel's System Setup Screen's Main Menu, and then selecting the Information button. Look under the Error tab. See Chapter 5: System Setup Screens for additional details on using the Error tab, Appendix A: PLC Protocol Error Codes for a list of the error codes as they relate to the specific PLC that is being used with a description of the error, and Appendix B: Touch Panel Runtime Errors for a list of errors that may occur when the panel is in operation.

Adjust Touch Panel

• It is recommended that a regularly scheduled maintenance program include **adjusting** the touch panel. The adjustment calibrates the touch area of the panel. The procedure should also be done anytime that it seems the touch area being pressed for an object is out of position by a small amount. The procedure is done by using the **Setting Menu** in the **System Setup Screens** and then selecting the **Adjust Touch Panel** button. See **Chapter 5: System Setup Screens** for additional details.

Cleaning the Display Screen

- The display screen should be cleaned periodically by wiping it with a lint free damp cloth using a mild soap solution. Dry the surface when finished with a lint free cloth. Do not clean with ammonia based products which are solvents and will damage the face of the panel.
- The longevity of the display can be increased by the use of a non-glare screen protector, p/n EA-XX-COV2, where XX = touch panel screen size, 6, 7, 8, 10, 12, or 15. See Chapter 3: Accessories for additional information on the screen protectors.



EA-6-COV2

• To prevent damage to the display screen, avoid touching the screen with sharp objects, striking the screen with a hard object, the use of abrasives near the screen, or using excessive force when pressing the touch screen.

Check Project Functionality

- During routine maintenance is a good time to check the functionality of your application, making sure that various areas on different screens do what they were designed to do. An outline or specification for the application is a useful tool for testing the various aspects of your application. As a starting point, you may want to run through all the screens to make sure they are accessible.
- If there are any trouble-shooting procedures built into the touch panel application, now is a good time to also check these aids.

Checks from C-more Programming Software

- If you have a PC available with the *C-more* programming software, EA9-PGMSW, installed, and the PC is connected to the touch panel, there are checks you can make to the status of the touch panel by using the **Panel Information...** feature located under the **Main Menu** heading **Panel**. This includes the following:
 - Connected panel details
 - Memory availability and usage
 - Revisions

General Information	Memory			
Type: EA9-T8CL	Select a Memory MRAM	MRAM		
Display: 8.4" TFT Color Type: 64K Recolution: 800x600 Power Voltage: 0K	 Built-in FLASH SD1 SD2 USB 	0 % Total: Used: Free:	512 КВ 5 КВ 506 КВ	100 % 524,288 Byte 5,122 Byte 519,166 Byte
Revision Hardware: 0800 Boot Loader: 0800 Firmware: OS: Ver.0.99 Runtime: V4.81 System Screen: V4.81				

• Other functions that can be accessed from the programming software directly to the touch panel include: **DisplayScreen**, **Reboot**, **AdjustClock**, **MemoryClear**, and **Update Firmware**. Additional information for these functions can be found in the *C-more* programming software online help file.


Notes:

 <u> </u>
 <u> </u>
 <u> </u>
 <u>.</u>
 <u> </u>
 <u> </u>
 <u> </u>

7





TROUBLESHOOTING



In This Chapter...

Common Problems 8.7
I roubleshooting Flow Chart
Touch Panel does not Power up8-4
Display is Blank8-5
Display is Dim8-6
No User Program8-7
Firmware Recovery Tool
No System Found
No Communications between Panel and PC (Personal Computer) via USB8-10
USB Driver Troubleshooting8-12
No Communications between Panel and PC (Personal Computer) via Ethernet8-14
No Communications between Panel and PLC8-18
IP Address in System Setup Screens displays 0.0.0.08-21
Difficulty Connecting to the Panel over the Internet (Web server and Remote Access
features)
PLC Protocol Error Codes8-23
Touch Panel Runtime Errors8-24
Panel Constantly Displays "Initializing" when Powering up
Data not Logging Problems8-25
Electrical Noise Problems8-26



The following topics are some of the more likely problems that may be encountered during the installation and operation of your C-more touch panel. We have made some suggestions on what to check in order to correct the problem. Please start with the troubleshooting flow chart that covers the more common problems encountered by other users.

Common Problems

The troubleshooting flow chart shown on the following page is based on the more common problems fielded by our technical support team. If you are having problems, please start with the flow chart, follow the suggestions listed, and if you still need help, call our tech support team @ 770-844-4200. In addition to having ready the information suggested in the flow chart, please have the following available:

- C-more touch panel part number including serial number with date code. Why is this
 information important? The various sizes of the touch panel use different processors and
 memory sizes, and therefore can have different types of problems within the particular
 panel size.
- 2) Programming software version that you are currently using. For example: Version 5.20. Having the software version number will allow our tech support team member to assess whether there are similar problems that have been reported when using the same version of the software. The programming software version can be found by clicking on "About C-more Programming Software..." selection under the Help pull down menu in the software. Also, it is always a good practice to visit the Software/Firmware Downloads area under the Tech Support section of the *AutomationDirect* website and check to see if you are using the latest version of the programming software. If you aren't using the latest software version, we suggest that you upgrade to see if this resolves your problem.

NOTE: The **"About C-more Programming Software...**" dialog box will show a Firmware version. This is the current firmware version that is included with the programming software and does not reflect what firmware is actually loaded on your **C-more** touch panel. See the following for details on how to check the firmware version.

3) Firmware version of the *C-more* touch panel. For example: V5.20. The firmware version can be checked by using the **System Setup Screens**, going to the **Information** menu under the **Main Menu**, and looking under the **General** tab for **Firmware: -Runtime**. The firmware version can also be checked by using the programming software, while connected to the panel, and clicking on the **Panel Information** selection under the Panel pull down menu. As with the programming software version, it is important for our tech support associates to know which firmware version you are using so they can check on any known problems. As with the programming software, we strongly suggest that the firmware be updated to the latest version. Check for the latest version and download from the **Software/Firmware Downloads** area of the *AutomationDirect* website.

It is also helpful to have a copy of your project file for our tech support associates to use in troubleshooting a problem, so please be prepared to forward a copy of your project if it is requested.





Touch Panel does not Power up

- Check the status indicators on the front of the panel to see if the Power LED (Green) indicator is on. Refer to the diagram below. If the Power LED (Green) indicator is on and the panel was observed showing "Initializing..." during power up, but the display is now blank, go to the next troubleshooting tip, Display is Blank.
- 2.) If the Power LED (Green) indicator is off and the panel is being powered with a 12 or 24 VDC power source, use a voltmeter to check the incoming DC voltage level. If the incoming DC voltage is zero, check any fusing that may be in the circuit. If the fuse is open, determine cause and replace. If the DC voltage level is out of range, the DC power source needs to be corrected or replaced.
- 3.) If the Power LED (Green) indicator is off and the panel is being powered with an AC/DC Power Adapter, EA-AC, use a voltmeter to check the incoming AC power. The AC voltage to the AC/DC Power Adapter should be in the range of 100 to 240 VAC, 50/60 Hertz. If the incoming AC voltage is zero, check any fusing that may be in the circuit. If the fuse is open, determine cause and replace. If proper AC voltage is present on the AC/DC Power Adapter, but the Power LED (Green) indicator is off, replace the AC/DC Power Adapter, EA-AC.



VICPAS

Display is Blank

- 1.) Touch the screen to make sure the panel is not in the Screen Saver mode.
 - The Screen Saver will be turned off and the panel screen will display:
 - If a PLC Address is configured to control the Screen Saver and changes from On to Off.
 - When the panel touchscreen is touched.
 - When the screen is clicked by Remote Access.
 - When the **Alarm Event** of the **Event Manager** occurs. (Only when the **Display** setting of the **Alarm Event** is checked).
 - When there is a screen change by the PLC.
 - When an Error such as a Communication Error occurs.
- 2.) If the panel is not in **Screen Saver** mode, check the status indicators on the rear of the panel.



- Make sure the CPU status LED (Green, Orange, Red) is a steady Green.
- If the **CPU** status **LED** is **blinking Green**, then the supply voltage is below 12 VDC, or below 100 VAC when using the optional *C-more* AC/DC Power Adapter, EA-AC. The backlight will turn off immediately to extend the power retention period. The panel will continue to run and the LCD display may be slightly visible. This may be seen as the display being dim, so it is advisable to check the incoming voltage.
- A **blinking Orange CPU** status LED indicates that the operating system could not be found. Reload the firmware to the touch panel. If this does not resolve the problem, the panel must be replaced.

Display is Blank continued on next page.

3.) There is always the remote possibility that a project has been transferred to the touch panel that includes a screen that uses a black background and has no objects placed on the screen. To check for this possibility, access the Main Menu of the touch panel System Setup Screens by pressing the extreme upper left corner of the panel display area for three (3) seconds as shown below. If the System Setup Screen's Main Menu is displayed, then most likely an empty black background screen is being displayed.



Display is Dim

1.) Check the brightness setting found under the System Setup Screens. See **Chapter 5:** System Setup Screens for additional information.



2.) Backlights will lose some luminance over time causing the display to slightly dim. The backlight average lifetime is rated at 50,000 hours and is defined as the average usage time it takes before the brightness becomes 50% of the initial brightness. The lifetime of the backlight depends on the ambient temperature; the lifetime decreases in low or high temperatures. To improve the backlight life, use the **Start Screen Saver** function that is available in the **C-more** Programming Software in the Panel Manager dialog box.

Display is Dim continued on next page.

- The Screen Saver will be turned off and the panel screen will display:
 - If a PLC Address is configured to control the Screen Saver and changes from On to Off.
 - When the panel touchscreen is touched.
 - When the screen is clicked by Remote.
 - When the **Alarm Event** of the **Event Manager** occurs. (Only when the **Display** setting of the **Alarm Event** is checked).
 - When there is a screen change by the PLC.
 - When an Error such as a Communication Error occurs.
- 3.) Another condition that may make the display appear dim is to view the touch panel in direct sunlight or in a location where direct light is reflected onto the display. The *C-more* touch panel displays have **Display Brightness** ratings of 280 to 310 cd/m2 (NITS), depending on the particular model. The higher the cd/m2 (NITS) rating, the more visible the display will be under bright lighting conditions.



NOTE: The C-more panel is not rated for direct sunlight.

No User Program

C	
:	NO USER PROGRAM

If a connected display is displaying the message "No User Program" after it has powered up, then either:

- the built-in Flash memory does not contain a recognized project, or
- an SD memory card is plugged into the SD1 slot, the project is set to boot from SD1 and there is no project on the SD memory card. Turn the power off, remove the SD memory card and turn the power back on.

Keep in mind that on power up, the HMI will read the project into the SDRAM memory from the location designated in the **Project Storage/Boot Location** setting in the in the *C-more* Software. This will either be the Built-in Flash memory or an SD memory card in the SD1 slot. If the location designated has no project, the upon power up or reboot NO USER PROGRAM will be displayed even if a project resides in the other location.

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Firmware Recovery Tool

If the panel power is interrupted during a firmware update, the firmware and/or operating system in the panel may become corrupt. The panel may be recoverable using a recovery utility that installs when the *C-more* Programming Software is installed. If the firmware is corrupt, but the operating system is still intact, the screen below will open when power is reapplied to the panel. This is called Safe Mode



Press the Information button and the Information Screen shown below will display. Notice that the runtime version is blank.

-	Information							
General	Memory	Fonts	Error					
Model	: unki	nown						
Panel Name	: Pane	11						
Version	- 1002							
Boot Loader	1001							
Firmware								
-OS	: Nov1	8 2008 at 14:	27:50					
-System Sch	en V2.2	3						
Clock	: Interi	nal						
Battery	: OK							
Beep	: Enab	le f	Main Manuel					
		100 M	Main Menu					

To recover, start the firmware update again making sure that there is a constant clean power supply.





No System Found

If the operating system is corrupt, the screen will display No System Found.



To recover the panel's Operating System:

- 1. Connect the Panel to your PC with the USB programming cable. (Any standard USB printer cable will also work.)
- 2. Close the C-more Programming Software.
- 3. Cycle the power on the panel.
- 4. From the Windows Start Menu select:

Start Menu > AutomationDirect > C-more EA9 Series Recovery Tool

The window shown below will open.





NOTE: If the USB lcon is blinking and the USB light is Red, this indicates that there is a communication problem to the panel. Check that the USB cable is properly connected and make sure there is communication to the panel.

5. Select Start and the Operating System will be loaded to the panel.

No Communications between Panel and PC (Personal Computer) via USB

The *C-more* touch panel is programmed using the *C-more* Programming Software, EA9-PGMSW. The developed project is transferred from the PC to the touch panel by either a USB or an Ethernet connection between the two. (Ethernet available on full feature units only.)

If using USB, then a USB type AB programming cable, such as p/n USB-CBL-AB15, should be used to make a connection between the panel's USB Port, Type B and a USB port on the PC. The *C-more* Programming Software will install a USB driver on the PC during the software installation.



If the USB connection to the panel is recognized by the PC, you will hear the Windows device-recognized-sound when the powered panel is connected to the PC. The driver will appear in the Windows Device Manager under Network adapters as **C-more EA9**..

🛃 Device Manager	<u>121</u> 8	
File Action View Help		
⊨ ⇒ 📰 🗾 🎫 💭		
> 🛄 Computer		
> 🚽 ControlVault Device		
> 👝 Disk drives		
🔉 🔙 Display adapters		
> 🙀 Human Interface Devices		
🔉 🏣 Intel(R) Dynamic Platform and Thermal Framework		
🔉 🚍 Keyboards		
> 🧾 Memory technology devices		
> II Mice and other pointing devices		
> 🥅 Monitors		
🗸 🚰 Network adapters		
Bluetooth Device (Personal Area Network)		
Bluetooth Device (RFCOMM Protocol TDI)		
C-more EA9		





No Communications between Panel and PC (Personal Computer) via USB (cont'd)

The *C-more* software will then identify the USB connection with a green indicator.



This Communication indicator appears on the Panel tab in the Navigation window and in the Project Transfer or Read from Panel windows.

USB Driver Troubleshooting

Check the USB driver using Windows Device Manager:

With the *C-more* panel connected to the PC, on the PC, open **Control Panel--> System** -->Hardware tab --> Device manager. Next expand "Network adapters". *r*:

I he	C-more	driver	15	named	C	-more	EA9	as	shown	bel	ow

🛃 Device Manager	<u>18-18</u>	×
File Action View Help		
> 🛄 Computer		 *
> 🛃 ControlVault Device		
> 🔜 Disk drives		
> 🔙 Display adapters		
> 🙀 Human Interface Devices		
> to Intel(R) Dynamic Platform and Thermal Framework		
> 🥅 Keyboards		
> 🧱 Memory technology devices		
> III Mice and other pointing devices		
> 🤜 Monitors		
🗸 🚰 Network adapters		
Bluetooth Device (Personal Area Network)		
Bluetooth Device (RFCOMM Protocol TDI)		
🗁 C-more EA9		4

If the *C-more* programming software Communication Config dialog USB indicator is red, and the driver does not appear in Device Manager,

- 1) Unplug both end of the cable and replug them in.
- 2) If that does not establish communication, plug into a different USB port on the PC.
- 3) If there are any USB hubs or other devices being used, temporarily eliminate them to see if this solves the problem.
- 4) Reinstall the C-more HMI USB driver.





USB Driver Troubleshooting (cont'd)

The *C-more* USB driver installation utility is bundled with the *C-more* software installation files. If you have a *C-more* software CD, the file is in the root, called **EA9USBDriver.exe**.

If you downloaded the software, when you extracted the files, the **EA9USBDriver.exe** was extracted to the location you chose. First, close the C-more software and disconnect the USB cable from the PC. Then, browse to **EA9USBDriver.exe** and run it.

Plug the USB cable into the PC and the C-more panel.

The Found New Hardware Wizard will prompt you to search for the driver. Select "No not this time", click Next. Select "Install the Software automatically (Recommended)" click **Next**. Click **Continue Anyway** in the Windows Logo warning popup. Click **Finish**.

Open the project in the *C-more* software. The Communication Config (and Transfer Project) USB indicator should be green.

No Communications between Panel and PC (Personal Computer) via Ethernet

When using an **Ethernet** connection to communicate between the touch panel and the PC and the communications does not seem to be working, the first area to check is the Ethernet status indicators located next to the **10/100 Base-T Ethernet Port** on the rear of the panel. The **Link Status LED** must be displaying a steady or blinking green.



If using **Ethernet**, there are two basic ways to make the connection. You can use an **Ethernet** cable to make a direct connection between the touch panel and PC or use an **Ethernet** cable from the touch panel to a switch and then to the PC.



Use the *C-more* programming software to check the status of the **Ethernet** communications. From the **Navigation** window, select the **Panel** tab. At the bottom of the **Panel** tab is the **Communication Config** dialog box. Select the **Browse** button. If the connection is working the panel will be listed in the online link list. Select the panel and then select OK. If the **Ethernet** communications to the panel is working, then there should be a "green" indicator next to the **Ethernet** selection. There should also be an **IP Address** shown in the browse box below the **Ethernet** selection. If the **Ethernet** radio button is "red", then you will need to check your **Ethernet** cables and connections or **Browse** for the panel.





No Communications between Panel and PC (Personal Computer) (cont'd)

There can also be a conflict with another Ethernet connection that may be using the same **IP Address**. You may want to check the setup both in the touch panel and also in your PC. As a starting point, it is best to start with an assigned IP Address and Subnet mask, mainly to eliminate IP addressing conflicts. Use the *C-more* programming software and open the **Touch Panel Network** dialog box under the **Main Menu's Setup** drop down menu. Click on the **Ethernet Port** tab to display the dialog box used to set up the touch panel's **Ethernet** port.

Another cause of an Ethernet communications problem that may be encountered, is the touch panel doesn't show up in the node list, which can be caused by the PC having a firewall.

The figure below shows the **Touch Panel Network** dialog box with the **Ethernet** port tab opened. The **Save settings to Project** check box is checked and we are using the **Use the following IP Address** selection by checking its radio button. The subnet (192.168.100.X) and the subnet mask (255.255.255.0) must be the same for both the panel and the PC. See the *C-more* programming software on-line help for additional details regarding the **Touch Panel Network**.

Touch Panel	Network					
General Ethernet F	Cot DNS FTP Service	Email Client Web t om DHCP IP Address	Server			
	IP Address: Subnet Mask: Delault Gateway:	192.168.100.4 255.255.255.0			the example s	nown here, the
				si a	subnet is 192.10 ubnet mask is 2 and both need to for all the Ethe connected t	68.100.X, the 55.255.255.0, be the same rnet devices together.
				ОК	Cancel	Help

IP	Addres	s sett	ing			_
O DHCP						
Use the following IP i	Address					
IP Address :	10	. 1	1 .	0.	155	
Subnet Mask :	255	. 25	55 . 2	255 .	0	
Default Gateway ;	0	. () .	Ο.	0	
	1	2	3	4	5	CL
	6	7	8	9	0	+
			-		-1	
			-	OK		ancel

The **IP** Address assigned to the touch panel can also be checked or edited by using the system setup screens built into the touch panel. See **Chapter 5: System Setup Screens** for additional information.

The figure to the left shows a different example of the panel's **System Setup Screens' Ethernet Port** dialog box for configuring the **Ethernet** port. Again, make sure the subnet (10.11.0.x) and subnet mask (255.255.255.0) is the same for both the panel and the PC.

8 - 15

No Communications between Panel and PC (Personal Computer) (cont'd)

Another option for accessing the **IP Address** assigned to the touch panel is to use the *C-more* Programming Software. Open the **Navigation** window's **Panel** tab and click on the **Browse** button under the **Communication** window at the bottom. This will open the **Ethernet Connection Setup** window. The **Online Link List** tab will show all of the connected panels. If none are shown, try clicking the **Browse Network** button to search for attached devices. Double click on the **Panel Name** you want to access and this will bring up the Change IP Address window. In this window changes can be made to the panel's name, IP address, subnet mask, and default gateway.

Navigation ×	Ethernet Conne	ction Setup		
	Select Link			
Panel Information	Online Link List Offline	Link List		
Display Screen	Panel Name	IP Address	Panel Type	MAC Address
Adjust Clock Memory Clear Opdate Firmware	Matts_E7C Jim AUDITORIUM Lobby	192.168.10.165 192.168.11.166 192.168.16.18 192.168.20.45	EA7-T8C EA7-S6C EA7-T10C EA7-T15C	00:D0:7C:01:28 00:D0:7C:01:00 00:D0:7C:01:02 00:D0:7C:01:12
	<			
	Change IP Addres Browse Network	Note To physi Press the	cally verify the selected Pa "Blink Screen" button	nel. Bink Screen Cancel Help
	Ch	ange IP Address		
		Panel Name: Lobby		
		Ethernet Card: Etherne	Port	
		Panel Type: EA7-T15	iC	
		MAC Address: 00:D0:7	D:01:10:0E	
/		O Obtain Address From DHC	P	
		 Use the following IP Addre 	\$\$	
Communication		IP Address: 192	. 168 . 20 . 45	
<u> </u>		Subnet Mask: 255	255 . 255 . 0	
OUSB ● ● Ethemet ●		Default Gateway: 192	. 168 . 20 . 1	
Browse		0	Cancel Help	

8-16

No Communications between Panel and PC (Personal Computer) (cont'd)

Check the **IP** Address setting of the PC by opening the Windows operating system's **Control Panel** and then selecting the **Network Connections** utility. Click on **Properties**, scroll down to **Internet Protocol (TCP/IP)** and click **Properties**. The **Internet Protocol (TCP/IP) Properties** dialog box will open. Again, make sure the **Subnet Mask** is set the same for both the panel and the PC and also make sure that the **IP** Addresses do not conflict.

🕹 Local Area Connec	tion Status 🛛 🕐 🔀	1 838388 1	NOTE: If a DHCP Server is being used to obtain
General Support		1/=	the IP Address for the PC, there are ways to
Connection			identify the IP Address. For example, if using
Chable	Connected	_	Windows XP, open a Command Prompt (Run
Duration:	11 days 07:24:13		> CMD) and type IPCONFIG /ALL. A list of all
Speed	10 Gbps		Ethernet assignments for the PC will be shown.
Speed.	1.0 0000		
		→ Lo	cal Area Connection Prope ? 🔀
27, 2000		Gener	al Authentication Advanced
Activity	-	Con	nect using.
Sent —	Received	田淵	Intel(R) PR0/1000 MT Network Con
Packets: 6,759,794	7,493,282	This	connection uses the following items:
			WLink NetBIOS
			The Internet Protocol (TCP/IP)
Properties Disable		<	
			Install Uninstall Properties
	Close	- De	escription
		Т	ransmission Control Protocol/Internet Protocol. The default
		W	ide area network protocol that provides communication
		G	
Internet Brotocol (T	CD/ID) Deposition	🗌 S	how icon in notification area when connected
internet Protocor (1	criir) riopercies 🔛 🚺	V N	lotify me when this connection has limited or no connectivity
General			
You can get IP settings assigned a this capability. Otherwise, you need	utomatically if your network supports d to ask your network administrator for	<u></u>	
the appropriate IP settings.			OK Cancel
🔵 🛛 btain an IP address automat	ticaly	<u>k</u>	
- O Use the following IP address:			
IP address:	192.168.100.2		
Subnet mezic	255.255.255.0		
Detank dateway:			
C Obran DNS server address a	utomotically		
Use the following DNS server	addiesses:		
Preferred DNS server:			
Alternate DNS server.			
	Advanced		
	OK Cancel		

No Communications between Panel and PLC

The communications between the *C-more* touch panel and designated PLC or controlling device can be accomplished by either a serial connection or by an **Ethernet** connection to the panel's **10/100 Base-T Ethernet Port**. (Ethernet available on full feature units only.) All panels include a 15-pin RS-232/422/485 port. Full featured panels include a 3-wire RS-485 connection and an RJ12 RS-232 connection.

1.) If the touch panel and PLC are connected serially and the communications have seemed to stop working, then first check the **TxD** and **RxD** status indicators on the rear of the panel at the connected port for activity.



If there is no activity on one or both the **TxD** and **RxD** status indicators, then it should be suspected that either:

- · serial comm port settings are incorrect
- the cable is bad and needs to be replaced
- the serial port on the panel is defective
- the PLC serial port is bad
- No TxD also can indicated no tags being polled on device



The status indicators will show activity whether the serial communications is wired for RS-232 or RS-422/485.

Electrical noise, pulse generating wiring and/or improper grounding can also cause problems with communications. Refer to the **Electrical Noise Problems** section later in this chapter for additional help.



No Communications between Panel and PLC (cont'd)

The serial ports on the *C-more* touch panel can be tested using the panel's system setup screens. Access the *Main Menu* of the panel's system setup screens, press the **Test Menu** button, then press the **Test Comm. Port** button and select the appropriate port tab. You will need to fabricate a **Loop Back Connector** for the type of serial connection that is being used in your application, either RS-232 or RS-422/485, per the wiring diagrams shown below. Plug the loop back connector into the panel's 15-pin PLC serial communications port and then press the **Loop Back Test** button to run the test. See **Chapter 5: System Setup Screens** for additional information.

Loop back connector wiring diagrams:



System setup screens Test Comm. Port dialog boxes:

Test Co	mm. Port		Test Co	omm. Port	
Test Co Serial 1 Serial 2 Loop Back Test Use Loop Back Connector RS232 RS422/485	mm. Port Serial 3 Ethemet PLC Enquiry Test Select PLC: [Dovor AutomationDirect Do-more #1,38400bps/None/8,1	COM3 Port TXD/RXD Test RTS/CTS Test	Test Co Serial : Lo Butes Sont 8 Pass	onn. Port Door Back Test Receive Counts 8	Error Counts 8
	Cancel				Cancel

The **PLC Enquiry Test** can also be performed to determine if the **Ethernet** communication is working correctly between the panel and designated PLC.

Test Co	mm. Port	Test Comm. Port
Serial Sarial Sarial 2	Serial 3 Ethomet PLC Enquiry Test Select PLC Select PLC Cancel	Ethernet : Loop Back Test Data1:Test Pass. Data2:Test Pass. Data3:Test Pass. Data4:Test Pass. Cancel



No Communications between Panel and PLC (cont'd)

2.) If using an Ethernet connection between the touch panel and the PLC, and there is a problem with the communications, the first area to check is the Ethernet status indicators located next to the 10/100 Base-T Ethernet Port (shown below) on the rear of the panel.



There are two basic ways to make the connection. You can connect directly from the touch panel to the PLC or connect from the touch panel to a switch that is also connected to the PLC.



Check the status indicators that may be included with the **Ethernet** communications module or device that is part of the PLC. Refer to the PLC's Ethernet user manual for further troubleshooting information.





No Communications between Panel and PLC (cont'd)

The Ethernet port on the *C-more* touch panel can be tested by using the panel's system setup screens. Access the **Main Menu** of the panel's system setup screens, press the **Test Menu** button and then press the **Test Comm. Port** button. Select the **Ethernet** tab in the **Test Comm. Port** dialog box, make sure the Ethernet port is connected to an Ethernet switch or other Ethernet communications device select a PLC from the drop down selection box, and then press the **PLC Enquiry** button to run the test. See **Chapter 5: System Setup Screens** for additional information.

Test Comm. Port		Test Comm. Port	
Serial 1 Serial 2 Link : Offine Address: DHCP 0.000	Seriel 3 Ethernet PLC Enquiry Test Select PLC.	Test Lown. Port Ethernet : PLC Enquiry Test Selected PLC : H0-ECOM Ping Test Data:Reply from PLC:bytes=32 time=2ms TTL=128 Data3:Reply from PLC:bytes=32 time=1ms TTL=128 Data3:Reply from PLC:bytes=32 time=0ms TTL=128 Protocol Test Data1:Test Pass. Data3:Test Pass. Data3:Test Pass. Data3:Test Pass.	
-	Cancel	Cancel	

If a PC running the *C-more* programming software is connected to the **Ethernet** network that is also connected to both the touch panel and PLC, then certain functions in the software, such as the **Main Menu's Setup** drop down selection for **Panel Manager** or **Touch Panel Network** and the **Main Menu's Panel** drop down selection for **Panel Information**, can be used to help troubleshoot problems with the touch panel's communications and operation. See the *C-more* programming software's on-line help for additional information.

IP Address in System Setup Screens displays 0.0.0.0

NOTE: If entering an **IP** Address for the **C-more** touch panel using the **System Setup Screens**, and the IP Address keeps displaying 0.0.0.0, even after entering an IP address, the panel is not functionally connected to an active network. Either the cable, hub, or switch is bad. The entered **IP** Address is stored in the panel's memory, but won't show up until a good connection is established. Keep in mind that if in the **C-more** programming software's **Touch Panel Network** dialog box, under the **Ethernet Port** tab, you have checked the **Save settings to Project** check box and have entered an **IP** Address of 0.0.0.0, then anytime the project is transferred to the panel, the panel's **IP** Address will be overwritten with the entered address.

8-21

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P

Difficulty Connecting to the Panel over the Internet (Web server and Remote Access features)

- Refer to the software help file topics Touch Panel Network and Remote Access Setup for information on configuring the Remote Access accounts, the Web Server Function and the panel IP Attributes.
- 2) In the Ethernet Port tab if DHCP is selected for assigning the IP address, verify the currect address of the panel. The IP address assigned by DHCP may change over time.
- 3) Note that the Web Server Function must be enabled on the Web Server tab before the Remote Access Server Function can be accessed on the panel.
- 4) Verify that the correct TCP ports have been opened and forwarded on the router controlling access to the network where the C-more panel resides.
- 5) If two C-more panels are on a network behind a firewall and they have the same **Remote** Access port number, the router will use the first entry in the Port Forwarding setup that it encounters. The same *C-more* panel will always come up even if the two panels have two different Web Server Port numbers.
- 6) When entering the URL in Internet Explorer to connect the *C-more* web server using a port number other than the default (80), be sure to use the full URL text including the prefix "http://". The URL should be http://xxx.xxx.xxx.aaaaa where xxx.xxx.xxx is the IP address of the panel and aaaaa is the port number configured in the Web Server tab of the Touch Panel Network setting.

PLC Protocol Error Codes

The *C-more* touch panel includes built-in PLC communication protocol diagnostics that monitor the exchange of data between the panel and the PLC. The diagnostics look for the proper exchange of data, correct handshaking signals, addressing errors, incorrect data bytes, wrong packet format, etc. The diagnostics also monitor and report any of the errors that the designated PLC would normally generate if there is a problem with the PLC's communications. Each brand of PLC has its own unique set of diagnostic errors that are typically communicated over the PLC's communications port. The PLC generated errors are interpreted by the *C-more* software. See the PLC manufacturer's user manuals for additional details on the designated PLC's errors.

If a *C-more* communications error does occur, the error message will be displayed in the upper left of the *C-more* screen and the **Error Code** is recorded in the panel's error log. If a PLC error occurs, the PLC error code number will appear across the top of the screen, the PLC error message may not be included in some cases. The error log can be viewed using the system setup screens. See **Chapter 5: System Setup Screens** under the **Information** window to bring up the Error tab which includes a description of the logged data.

A detailed list and description of the various PLC protocol errors can be found in **Appendix** A: PLC Protocol Error Codes.

Error Codes for <i>Direct</i> LOGIC – K-Sequence				
Error Code	Error Message	Description		
PLC-001	PLC Communication Timeout (for single PLC) %Device% PLC Communication Timeout (for multiple PLCs, such as RS-422/485)	A timeout occurred after sending a request to the PLC %Device%. %Device% indicates the device name, such as DEV001. Example error message for multiple PLCs: DEV001 PLC Communication Timeout		
PLC-002	NAK received from PLC	A negative acknowledgement (NAK) control code has been generated during a read/write request.		
PLC-004	STX is not found	A Start of Text (STX) control code was not found in the data packet received from the PLC.		

PLC Protocol Error Codes example:

8-23

Touch Panel Runtime Errors

The *C-more* touch panel includes built-in diagnostics that check for proper operation of the panel when it is running a project that has been transferred to its memory. Faults detected while the panel is running will produce a "Runtime" error. These errors are displayed in the upper left of the panel's display and are also recorded in the panel's error log. The error log can be viewed using the system setup screens. See **Chapter 5: System Setup Screens** under the **Information** window to bring up the **Error** tab which includes a description of the logged data.

A detailed list and description of the various touch panel runtime errors can be found in **Appendix B: Touch Panel Runtime Errors**.

No.	Error Log Code	Error Message Located at upper left of screen	Error Message Tag	Tag Error Code Value	System Screen Info > Error	Cause
Log Error						
1	RTE-001	Log Failed. Not enough Memory Space in %Device%	SYS ERR ERRORCODE	2001	MM/DD/YY HH/MM/SS Error Code RTE-001	The size of the destination memory is not large enough to store the data.
2	RTE-002	Log Failed. %Device% cannot be found	SYS ERR ERRORCODE	2002	MM/DD/YY HH/MM/SS Error Code RTE-002	No device available or the device is defective.

Touch Panel Runtime Errors example:





Panel Constantly Displays "Initializing" when Powering up

If the touch panel constantly displays a message reading "Initializing" while powering up, then check the following possible causes.

- 1.) *C-more* supports USB 1.1 and 2.0 memory devices. Ensure that the USB device is 1.1 or 2.0 or backward compatible to support version 2.0
- 2.) The project that is loaded into the panel's internal SDRAM memory is corrupted. Either use the *C-more* programming software to clear the panel's memory and re-transfer the project to the touch panel, or press the upper left corner of the touch panel screen while powering up to bypass the project and go directly to the **System Setup Screen** menu. Select the **Memory** menu, and use either the **Clear Memory** or **Set to Factory Default** utility to clear the panel's memory and re-transfer the project to the touch panel. (see Chapter 5 System Setup Screens)
- 3.) An SD memory card has been plugged into an SD card slot and the SD card either has no project stored on it or the project is corrupted. Remove the SD memory card from the SD card slot and either load the project to the panel's internal Flash memory, or re-format the SD card using the SD formatter available from SDcard.org, or try a different SD memory card.



NOTE: In the Error Log you may find the error RTE-500 - Check Sum Error, which is defined as "Memory in the panel has been corrupted by power loss, etc." If this is the case, try cycling power to the panel, re-transfer the project to the panel, and re-transfer the firmware, etc. in sequential steps to try to correct the problem.

Data not Logging Problems

If the data log is missing entries, or a Runtime Error for the Log Errors as shown in **Appendix B: Touch Panel Runtime Errors** is seen, then check the following possible causes.

- Check that the memory devices, that were selected for Data Storage under the *C-more* programming software's Main Menu Setup drop down Panel Manager dialog box, are plugged into their proper location. Alarms, messages and screen captures can be independently selected to be saved to either a USB pen drive plugged into the USB Port Type A, or an SD card plugged into SD Card Slot1 or SD Card Slot2 (12-inch and 15-inch panels only).
- 2.) Ensure that the SD card has been formatted with the SD formatter provided by SDcard. org.
- 3.) The memory device could be bad. If possible, check it by plugging it into a PC that has the ability to access the memory device. Also, not all USB devices are compatible with the *C-more* touch panels. Try using the *AutomationDirect* USB Pen Drive, p/n USB-FLASH. Check **System Screen, Memory** for the presence of the USB device inserted.

Electrical Noise Problems

Noise is one of the most difficult problems to diagnose. Electrical noise can enter a system in many different ways which fall into one of two categories, conducted or radiated. It may be difficult to determine how the noise is entering the system but the corrective actions for either of the types of noise problems are similar.

- Conducted noise is when the electrical interference is introduced into the system by way of an attached wire, panel connection, etc. It may enter through a power supply connection, the communication ground connection, or the chassis ground connection.
- Radiated noise is when the electrical interference is introduced into the system without a direct electrical connection, much in the same manner as radio waves.

While electrical noise cannot be eliminated, it can be reduced to a level that will not affect the system.

- Most noise problems result from improper grounding of the system. A good earth ground can be the single most effective way to correct noise problems. If a ground is not available, install a ground rod as close to the system as possible. Ensure all ground wires are single point grounds and are not daisy chained from one device to another. Ground metal enclosures around the system. A loose wire can act as a large antenna, introducing noise into the system. Therefore, tighten all connections in your system. Loose ground wires are more susceptible to noise than the other wires in your system. Review **Chapter 4: Installation & Wiring** if you have questions regarding how to ground the touch panel.
- Electrical noise can enter the system through the power source for the touch panel. Installing a properly wired isolation transformer (neutral grounded) for all AC sources can help the problem, but only if wired correctly. DC sources should be well-grounded good quality supplies.
- Never run communication cables or low-voltage power wiring close to high voltage wiring or pulse generating wiring that controls such devices as solenoids, servos, VFDs, etc.





Replacement Parts

n This Chapter	
Replacement Parts Overview	.9-2
Panel Mounting Clip Replacements – EA9-BRK	.9-3
Logo Label Replacement Insert - EA9-LBL	.9-4
3-wire Communications Terminal Block – EA9-3TB	.9-5
DC Panel Power Connector Replacement – EA-DC-CON	.9-5
AC Power Adapter Connector Replacement– EA-AC-CON	.9-6
Panel Gasket Replacements – EA9-xx-GSK	.9-7
Gasket Replacement Installation Instructions:	.9-7

Replacement Parts Overview

Part Number		Description
EA9-BRK	a a a a a a	Panel mounting brackets, replacement, for <i>C-more</i> EA9 series touch panels. Package of 8 brackets and screws.
EA9-LBL		Blank label insert for front bezel, replacement, for C-more EA9 series touch panels. Package of 10.
EA9-3TB	TOPP	3-pole terminal block, replacement, for 3-wire RS485 communications port on <i>C-more</i> EA9 series panels. Package of 2.
EA-DC-CON	ALL ALL	5-terminal DC power connector, replacement, for C-more EA7 and EA9 series touch panels
EA-AC-CON	and the second sec	3-terminal AC power connector, replacement, for C-more EA7 and EA9 series touch panels
EA9-15-GSK		Panel mounting gasket, replacement, for <i>C-more</i> EA9-T15CL 15-inch touch panel, NEMA 4/4X
EA9-12-GSK		Panel mounting gasket, replacement, for <i>C-more</i> EA9-T12CL 12-inch touch panel, NEMA 4/4X
EA9-10-GSK		Panel mounting gasket, replacement, for <i>C-more</i> EA9-T10CL 10-inch touch panel, NEMA 4/4X
EA9-10W-GSK		Panel mounting gasket, replacement, for <i>C-more</i> EA9-T10WCL 10-inch touch panel, NEMA 4/4X
EA9-8-GSK		Panel mounting gasket, replacement, for <i>C-more</i> EA9-T8CL 8-inch touch panel, NEMA 4/4X
EA9-6-GSK	~	Panel mounting gasket, replacement, for <i>C-more</i> EA9-T6CL(-R) 6-inch and EA9-T7CL(-R) 7-inch touch panels, NEMA 4/4X



Panel Mounting Clip Replacements – EA9-BRK



Spare panel mounting clips for EA9 series *C-more* touch panels. Package of 8 clips with 8 screws.

Mounting Clip Instructions

- 1. Position the touch panel through the cutout in the control cabinet door and hold in place. Position the mounting clips as appropriate for your model. Refer to Chapter 2.
- 2. Tighten the mounting screws in an alternating fashion while observing the front of the touch panel. The goal is to make sure the front bezel is pulled up against the enclosure sheet metal uniformly, and the touch panel gasket is fully compressed all the way around its perimeter. Tighten the screws to a torque rating shown in the table below. Avoid over-tightening the screws to the point that they start to deform or bend the bezel or mounting clip.

Touch	Enclosure	Mounting Clip	Material
Panel Size	Thickness Range	Screw Torque	
6", 7", 8",	0.039 - 0.20 inch	63 - 77 oz-in	Matal
10" & 12"	[1 – 5 mm]	[0.45 - 0.55 Nm]	
10" Wide,	0.039 - 0.20 inch	92 - 106 oz-in	Metal
15"	[1 – 5 mm]]	[0.65 - 0.75 Nm]	



Logo Label Replacement Insert - EA9-LBL

C-more EA9 series panels include one customizable logo label. Additional logo labels can be purchased in packs of 10.



Installation - Insert EA9-LBL into the slot in the side of the panel and lock tab into place.









3-wire Communications Terminal Block – EA9-3TB

C-more EA9 series 3-wire communications terminal block replacement. One (1) terminal block is supplied with each touch panel.



DC Panel Power Connector Replacement – EA-DC-CON

C-more touch panel 5-position DC power connector terminal block replacement. One (1) DC Power Connector is supplied with each touch panel.



9

AC Power Adapter Connector Replacement– EA-AC-CON

C-more AC power adapter 3-position AC power connector terminal block replacement. One (1) AC Power Connector is supplied with each AC/DC Power Adapter, EA-AC.





Panel Gasket Replacements – EA9-xx-GSK



Gasket Replacement Installation Instructions:

Preparation: Disconnect input power and all other connections, then remove the touch panel from the control cabinet. In a clean environment, place the panel face down on a lint-free soft surface to prevent scratching the front of the panel.



Start at one corner and pull the old gasket out of the channel that holds the gasket in place. Pull the gasket up as you work around the entire perimeter of the touch panel. Discard the old gasket.



Lay the new gasket over the channel so that the long and short sides of the gasket match up to the long and short sides of the touch panel. Start at one corner and match the gasket's corner to the channel's corner. Press the gasket into the channel and work all away around the perimeter of the touch panel. Re-install the touch panel.








PANEL AND PLC ERROR CODE TABLES



In This Appendix... DirectLOGIC – Panel Error Code PLC-499 ExplanationA-5 Modbus Protocols Error Code P499 ExplanationA-6 A-6 A-6 AutomationDirect DirectLOGIC - Modbus (Koyo)...... A-6 Modicon Modbus RTU A-6 Entivity Modbus RTU..... A-6 DirectLOGIC ECOM Protocol – PLC Error Codes Productivity Error Code P499......A-7 AutomationDirect Do-More Error Codes...... A-8 Allen-Bradley – Panel Error Code PLC-499 Explanation A-9 Allen-Bradley DF1 & DH485 Protocols – PLC Error Code Tables A-10 Allen-Bradley EtherNet/IP Protocol -Panel Error Code PLC-496, 497 and 498 Explanation A-12 Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, Allen-Bradley – Micro800 Serial and EtherNet/IP Tag Based PLC Error Code Tables A-17 Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables...... A-21 Generic EtherNet IP Protocol – PLC Error Codes A-26 GE 90-30 – Panel Error Code PLC-499 Explanation A-27



PANEL AND PLC ERROR CODE TABLES



GE 90-30 SNPX Protocol – PLC Error Code Tables	A-28
Mitsubishi FX Protocol – PLC Error Codes	A-37
Omron – Panel Error Code PLC-499 Explanation	A-37
Omron Host Link Protocol – PLC Error Code Table	A-38
Omron FINS Protocol – PLC Error Code Table	A-39
Omron – Panel Error Code P495 Explanation	A-42
Omron CS/CJ FINS Ethernet Protocol – PLC Error Code Table	A-43
Siemens – Panel Error Code P499 Explanation	A-44
Siemens PPI Protocol – PLC Error Code Table	A-45
Siemens ISO over TCP Protocol – PLC Error Code Table	A-46



PANEL AND PLC ERROR CODE TABLES



This page intentionally left blank

Introduction

The *C-more* family of touch panels is capable of communicating with a wide variety of Programmable Logic Controllers. *C-more* is capable of communicating over RS232, RS422 and RS485 serial networks as well as Ethernet networks. It communicates with all AutomationDirect PLCs utilizing various protocols. C-more also communicates with other brands of PLCs by their different protocols. For a complete list of PLCs and protocols, see **Step 9 – Connect Touch Panel to PLC** in **Chapter 1: Getting Started**.

As with any network communications, errors will occur. To make it more simple for the user to identify the cause of the possible error, we have provided a error code table for all of the possible errors that *C-more* can detect.

If a *C-more* communications error does occur, the error message will appear across the top of the screen. The *C-more* touch panel also monitors any errors that are generated by the various PLCs that are connected to it. If any of the PLC generated errors are detected, they are displayed across the top of the panel's display embedded as a hexadecimal value in error code P499's message. An explanation of how the specific PLC error is identified in the panel error code P499 is shown proceeding the specific manufacturer's PLC error tables. How the hexadecimal error code value is interrupted is slightly different between manufacturers, so it is important to check the explanation at the beginning of each manufacturer's tables.



NOTE: These PLC error codes are provided by the manufacturer of the related PLC and are subject to change by the PLC manufacturer. Please refer to the manufacturers documentation for a more complete and up-to-date list of error codes.



EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



C-more Touch Panel Error Code Table

The following table includes all of the error codes and error messages that the panel will display if the listed cause is detected. All of these errors involve problems that could result with the panel communicating with the connected PLC. Be aware that not all of the panel errors are used with each type of PLC that can be connected to the panel.

C-more Touch Panel Error Code Table		
Error Code	Error Message	Cause
PI C-001	PLC Communication Timeout (for single PLC)	A timeout occurred after sending a request to the PLC %Device%. %Device% indicates the device name, such as DEV001.
1 20-001	%Device% PLC Communication Timeout (for multiple PLCs, such as RS-422/485)	Example error message for multiple PLCs: DEV001 PLC Communication Timeout.
PLC-002	NAK received from PLC	A negative acknowledgement (NAK) control code has been generated during a read/write request.
PLC-003	EOT received from PLC	An End of Transmission (EOT) control code is sent by the PLC in response to a Read/Write/SetBit request
PLC-004	STX is not found	A Start of Text (STX) control code was not found in the data packet received from the PLC.
PLC-005	ETX or ETB is not found	Neither an End of Text (ETX) nor an End of Transmission Block (ETB) control code was found in the data packet received from the PLC.
PLC-006	LRC does not match	There was an incorrect Longitudinal Redundancy Check (LRC) control code in the communications packet received from the PLC. This is an indication that the data in the packet is corrupted.
PLC-007	CRC does not match	There was an incorrect Cyclic Redundancy Check (CRC) control code in the communications packet received from the PLC. This is an indication that the data in the packet is corrupted.
PLC-008	Address does not match	The address value returned in the data packet from the PLC is incorrect.
PLC-009	Different function code received from PLC	The function code returned in the data packet from the PLC is incorrect.
PLC-010	Data size does not match	There are an incorrect number of bytes found in the data packet returned from the PLC.
PLC-011	Invalid value in function code	There is an invalid value in the function code.
PLC-012	Invalid command sent to PLC	There was an invalid command sent to the PLC that wasn't recognized by the PLC.
PLC-013	ENQ received from PLC	If the data packet does not include a negative acknowledgement (NAK - 0x15 value) in the defined packet field, then an enquiry (ENQ) control code error will be displayed.
PLC-014	Transaction ID does not match	This error will be displayed if after checking the Transaction ID Bytes in the data packet, there is no match to what was requested.
PLC-015	%Device% No device found	A PLC device designated as %Device% could not be found.
PLC-016	Data byte communication error	0 byte of data is recieved
PLC-017	Out of address range	The touch panel requested a file number larger than 255.
PLC-018	Panel communication timeout	The server panel did not respond when using the Panel Pass Through.
PLC-019	Found in parity error by hardware	An error detected in the PLC memory.
PLC-020	Can't open serial port	Cannot open the Serial Port. If this error shows on the panel, it indicates a hardware problem.
PLC-021	PLC number does not match	The PLC number does not match the PLC number configured.
PLC-022	Can't reset DCB	Unable to reset the data communication bit.
PLC-023	Cable not connected properly	Communication cable incorrectly installed.

C-more Touch Panel Error Code Table continued on the next page.

-more

C-more Touch Panel Error Code Table (cont'd)

<i>C-more</i> Touch Panel Error Code Table (cont'd)		
Error Code	Error Message	Cause
PLC-024	Cannot detect other devices on network	The panel is not communicating with other devices on the network.
PLC-025	Panel not in polling list	
PLC-026	PLC connection timeout	A timeout occured after sending a request to the PLC.
PLC-027	Memory type incorrect	
PLC-028	PLC failed to respond	The PLC failed to respond after sending a request to the PLC.
PLC-029	MemVer ERR HMI x PLCy	When connected to a Do-more PLC the PLC memory version must match the C-more project PLC memory version. Make sure that the PLC project does not write into the memory version address.
PLC-495	Omron Ethernet Error	An error code specific to Omron Ethernet with a Value of XXXX has been returned from the PLC. See the explanation for error code PLC-495 proceeding the Omron CS/CJ FINS Ethernet error code tables.
PLC-496	Error code Oxaaaaaaaa returned from PLC	Allen-Bradley EtherNET/IP specific. Encapsulation Error. See the explanation for error code PLC-496 proceeding the Allen- Bradley EtherNet/IP error code tables.
PLC-497	Error code Oxaaaaaaaa returned from PLC	Allen-Bradley EtherNET/IP specific. CIP Error. See the explanation for error code PLC-497 proceeding the Allen- Bradley EtherNet/IP error code tables.
PLC-498	Error code Oxaaaaaaaa returned from PLC	Allen-Bradley EtherNET/IP specific. Service Packet Error. See the explanation for error code PLC-498 proceeding the Allen- Bradley EtherNet/IP error code tables.
PLC-499	Error code XXXX returned from PLC	An error code with a value of XXXX has been returned from the PLC. See the explanation for error code PLC-499 below for <i>Direct</i> LOGIC and proceeding each set of PLC error code tables that use this error code.
PLC-500	Cannot write to Serial Port	Data cannot write to the Serial port. Data was sent to the PLC via the Serial Port. If this error shows on the Panel, it indicates a Hardware Problem.
PLC-700	Not enough buffer memory	There was an error while allocating memory for the read buffer. When this error is displayed, a memory leak may have occurred.
PLC-701	Access to inaccessible PLC memory	Request to inaccessible memory from the HMI layer to the PLC protocol layer. This error is an indication that there is a problem in the HMI layer.
PLC-702	Cannot access by different function code	A Read/Write/SetBit request has been sent to an invalid memory area. This error is an indication that there is a problem in the HMI layer.
PLC-703	Write request to PLC Read Only Memory	A PLC Write request was made to the PLC's Read-Only memory area. This error is an indication that there is a problem in the HMI layer or the PLC protocol layer.
PLC-704	Bad device-access	No device (PLC) exists in the server panel or the device name does not match between the server and client when using the Panel Pass Through.
PLC-705	Protocol does not match	The protocol for the device does Not match between the server and client when using the panel pass through.



DirectLOGIC – Panel Error Code PLC-499 Explanation

The PLC-499 error code is used to show any errors that are generated by the connected PLC. The PLC-499 error message includes a four digit hexadecimal value embedded in the message. This value can be looked up in the specific PLC's error tables to determine the cause of the error. The possible PLC generated error codes for the *Direct*LOGIC communication protocol are represented by a hexadecimal value as shown in the following message example.

Direct LOGIC Error Code PLC-499 Message Example:



DirectLOGIC K-Sequence Protocol – PLC Error Code Table

The following table lists the errors that can be generated by the *Direct*LOGIC PLC when using the K-Sequence protocol.

PLC Error Codes for <i>Direct</i> LOGIC – K-Sequence	
Panel Error Code PLC-499 Hex Value	Description
01F8	Error setting value.
020D	Error in key mode - Set switch on PLC CPU to "Term"
021C	Password protected.



NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** touch panel, and displayed on the touch panel's screen as a hexadecimal value in panel error code PLC-499 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

DirectLOGIC DirectNET Protocol – PLC Error Codes

Only errors as listed in the Touch Panel Error Code Table shown on page A-3 can occur when using the *Direct*LOGIC *Direct*NET protocol, there are no PLC generated errors.

*Direct*LOGIC error code tables continued on the next page.



Modbus Protocols Error Code P499 Explanation

The following table lists the errors that can be generated by the Modbus protocols:

AutomationDirect CLICK

AutomationDirect DirectLOGIC - Modbus (Koyo)

Modicon Modbus RTU

Entivity Modbus RTU



NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** touch panel, and displayed on the touch panel's screen as a hexadecimal value in panel error code PLC-499 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

PLC Error Codes Modbus Protocols		
Panel Error Code P499 Hex Value	Name	Meaning
0x0001	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server (or slave). This may be because the function code is only applicable to newer devices and was not implemented in the unit selected. It could also indicate that the server (or slave) is in the wrong state to process a request of this type, for example because it is unconfigured and is being asked to return registered values.
0x0002	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the server (or slave). More specifically, the combination of reference number and transfer length is invalid. For a controller with 100 registers, the PDU addresses the first register as 0, and the last one as 99. If a request is submitted with a starting register address of 96 and a quantity of registers of 4, then the request will successfully operate (address-wise at least) on registers 96, 97, 98, 99. If a request is submitted with a starting register of 96 and a quantity of registers of 5, then the request will fail with Exception code 0x02 "lllegal Data Address" since it attempts to operate on registers 96, 97, 98, 99 and 100, and there is no register with address 100.
0x0003	illegal data Value	A value contained in the query data field is not an allowable value for server (or slave). This indicates a fault in the structure of the remainder of a complex request, such as that the implied length is incorrect. It specifically does NOT mean that a data item submitted for storage in a register has a value outside the expectation of the application program, since the Modbus protocol is unaware of the significance of any particular value of any particular register.
0x0004	SLAVE DEVICE FAILURE	An unrecoverable error occurred while the server (or slave) was attempting to perform the requested action.

DirectLOGIC ECOM Protocol – PLC Error Codes

Only errors as listed in the Touch Panel Error Code Table shown previously in this Appendix can occur when using the *Direct*LOGIC ECOM protocol, there are no PLC generated errors.



Productivity Error Code P499

NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** touch panel, and displayed on the touch panel's screen as a hexadecimal value in panel error code PLC-499 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

PLC Error Codes for Productivity	
Panel Error Code P499 Hex Value	Meaning
0x0001	The function code received in the query is not an allowable action for the server (or slave). This may be because the function code is only applicable to newer devices and was not implemented in the unit selected. It could also indicate that the server (or slave) is in the wrong state to process a request of this type, for example because it is unconfigured and is being asked to return registered values.
0x0002	Address out of range. Check to make sure that the C-more tag and System ID match the Productivity Programming Software Tag Name and System ID. The project file in the Productivity system and the imported CSV into C-more must be in sync with each other.
0x0003	A value contained in the query data field is not an allowable value for the server (or slave). This indicates a fault in the structure of the remainder of a complex request, such as that the implied length is incorrect. It specifically does NOT mean that a data item submitted for storage in a register has a value outside the expectation of the application program, since the Modbus protocol is unaware of the significance of any particular value of any particular register.
0x0004	An unrecoverable error occurred while the server (or slave) was attempting to perform the requested action.

A-7

AutomationDirect Do-More Error Codes

PLC Errors for Do-more		
Error Code	Description	Resolution
0x01	Unknown Command	Should only occur if message has been corrupted or protocol version is mismatched. Check versions and update appropriately. If versions are correct, check cabling, routing and switches for bad packets.
0x02	Out of Sessions	Too many devices connected to the CPU. Reduce number of devices connected.
0x03	Illegal Operation	Occurs when permission level is not sufficient for the operation performed by the panel. Increase the permission level to correct the problem.
0x04	Invalid Session	Session number does match for sending device. Re-establish connection by power cycling or sending updated project.
0x05	Out of Range	Invalid address exists. Ensure that address range is expanded and load configuration to the CPU.
0x06	Invalid Argument	Occurs when message cannot be parsed correctly. Could occur from noise or faulty wiring.
0x07	Program Update Active	Wait until program update is complete.
0x08	No Token	Occurs when client attempts to update the project without first acquiring the program update token.
0x09	Program Update Inhibited	Occurs when client attempts to update the project while ST21 is true. This allows the customer to programmatically prevent the project from being updated.
0x0A	System Configuration Update Active	Wait until System Configuration update is complete to continue communications.
0x0B	Invalid Mode	Ensure that the switch on the CPU is in Term mode.
0x0C	Mode Change Active	Occurs when a PLC mode change is attempted while a mode change is in progress. In some cases it takes several scans for a mode change.
0x0D	Mode Locked	Occurs when mode change is attempted and keyswitch is not in Term.
0x0E	Invalid Password	Enter Do-more password in Password field of C-more Panel Manager for this device.
0x0F	Resource Locked	Occurs when trying to update a tag that is forced. Force must be removed in order to update the tag.
0x010	Doc Update Active	Occurs when someone attempts to access the documentation file while it is being written back to ROM.
0x011	Invalid Driver	Occurs when attempting to read driver data from a driver that doesn't exist.
0x012	Invalid Driver Data	Occurs when attempting to read a driver data type that isn't valid.
0x013	Shared RAM write failed	Occurs when attempting to read or write to a module's shared RAM and it fails. Usually occurs when the module has gone bad.



Allen-Bradley – Panel Error Code PLC-499 Explanation

The PLC-499 error code is used to show any errors that are generated by the connected PLC. The PLC-499 error message includes a four digit hexadecimal value embedded in the message. This value can be looked up in the specific PLC's error tables to determine the cause of the error. The possible PLC generated error codes for the Allen-Bradley DF1 and DH485 communication protocols are represented by a hexadecimal value as shown in the following diagram. Please note that the error code is broken down into three sections. It is possible for more than one type of PLC error to be displayed in this value.





Allen-Bradley DF1 & DH485 Protocols – PLC Error Code Tables

A

The following PLC error code tables cover possible errors that are detected by the panel from Allen-Bradley PLCs using the DF1 and DH485 protocols. DF1 includes full and half duplex communications for the MicroLogix 1000, 1100. 1200, 1400, 1500, SLC 5/03, /04, /05, ControlLogix, CompactLogix and FlexLogix, and full duplex communications for the PLC5. DH485 includes all MicroLogix and SLC500 PLC's and any communication connection using an Allen-Bradley AIC device using the DH485 protocol.



A-10

NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** touch panel, and displayed on the touch panel's screen as a hexadecimal value in panel error code PLC-499 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

PLC Errors for Allen-Bradley DF1 and DH485 Protocols, Local STS Errors (0-3 bits)		
Panel Error Code PLC-499 Hex Value	Description	
0x0	Success; no error.	
0x1	DST node is out of buffer space.	
0x2	Cannot guarantee delivery; link layer. (The remote node specified does not ACK command.)	
0x3	Duplicate token holder detected.	
0x4	Local port is disconnected.	
0x5	Application layer timed out waiting for response.	
0x6	Duplicate node detected.	
0x7	Station is offline.	
0x8	Hardware fault.	

PLC Errors for Allen-Bradley DF1 and DH485 Protocols, Remote STS Errors (4-7 bits)		
Panel Error Code PLC-499 Hex Value	Description	
0x0	Success; no error.	
0x10	Illegal command or format.	
0x20	Host has a problem and will not communicate.	
0x30	Remote node host is missing, disconnected, or shut down.	
0x40	Host could not complete function due to hardware fault.	
0x50	Addressing problem or memory protect rungs.	
0x60	Function not allowed due to command protection selection.	
0x70	Processor is in Program Mode.	
0x80	Compatibility mode file missing or communication zone problem.	
0x90	Remote node cannot buffer command.	
0xA0	Wait ACK (1775 KA buffer full).	
0xB0	Remote node problem due to download.	
0xC0	Wait ACK (1775 KA buffer full).	
0xD0	not used	
0xE0	not used	
0xF0	Error code in the EXT STS byte. See the error code table on the next page.	

(PLC generated error codes for the Allen-Bradley DF1 protocol continued on the next page.)

MOLE EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Allen-Bradley DF1 & DH485 Protocols – PLC Error Code Tables (cont'd)

PLC Errors for Allen-Bradley DF1 and DH485 Protocols, EXT STS Command Code for FU Command		
Panel Error Code PLC-499 Hex Value	Description	
0x0	not used	
0x1	A field has an illegal value.	
0x2	Fewer levels specified in address than minimum for any address.	
0x3	More levels specified in address than system supports.	
0x4	Symbol not found.	
0x5	Symbol is of improper format.	
0x6	Address does not point to something usable.	
0x7	File is wrong size.	
0x8	Cannot complete request; situation has changed since start of the command.	
0x9	Data or file size is too large.	
0xA	Transaction size plus word address is too large.	
0xB	Access denied; improper privilege.	
0xC	Condition cannot be generated; resource is not available.	
0xD	Condition already exists; resource is readily available.	
0xE	Command cannot be executed.	
0xF	Histogram overflow.	
0x10	No access.	
0x11	Illegal data type.	
0x12	Invalid parameter or invalid data.	
0x13	Address reference exists to deleted area.	
0x14	Command execution failure for unknown reason; possible PLC 3 histogram overflow.	
0x15	Data conversion error.	
0x16	Scanner not able to communicate with 1771 rack adapter.	
0x17	Type mismatch.	
0x18	1771 module response was not valid.	
0x19	Duplicated label.	
0x22	Remote rack fault.	
0x23	Timeout.	
0x24	Unknown error.	
0x1A	File is open; another node owns it.	
0x1B	Another node is the program owner.	
0x1C	Disk File is write protectid or otherwise unavailable	
0x1D	Disk File is being used by another application. Update not performed (offline only).	
0x1E	Data table element protection violation.	
0x1F	Temporary internal problem.	

Allen-Bradley EtherNet/IP Protocol – Panel Error Code PLC-496, 497 and 498 Explanation

The PLC-496, PLC-497, and PLC-498 error codes are used to show any errors that are generated by the connected PLC. These error messages include an eight digit hexadecimal value displayed embedded in the message. This value can be looked up in the specific PLC's error tables to determine the cause of the error. The possible PLC generated error codes for the Allen-Bradley EtherNet/IP communication protocol is represented by a hexadecimal value as shown in the following message example.

Allen-Bradley Error Code PLC-496, 497, 498 Message Example:







Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, CompactLogix, & FlexLogix

The following PLC error code tables cover possible errors that are detected by the panel from Allen-Bradley PLCs using the EtherNet/IP protocol. This includes all ControlLogix, CompactLogix and FlexLogix PLCs.



NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** touch panel, and displayed on the touch panel's screen as a hexadecimal value in panel error code PLC-496 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

PLC Errors for Allen-Bradley EtherNet/IP Protocol –Encapsulation Errors (Error code Oxaaaaaaaa returned from the PLC.)		
Panel Error Code PLC-496 Hex Value	Description	
0x0000001	The sender issued an invalid or unsupported encapsulation command.	
0x0000002	Insufficient memory resources in the receiver to handle the command. You can get this error if the 1761-NET-ENI cannot connect to the PLC serially.	
0x0000003	Poorly formed or incorrect data in the data portion of the encapsulation message.	
0x00000004 - 0x00000063	Reserved for legacy (Rockwell Automation).	
0x0000064	An orginator used an invalid session handle when sending an encapsulation message to the target.	
0x0000065	The target received a message of invalid length.	
0x00000066 - 0x00000068	Reserved for legacy (Rockwell Automation).	
0x0000069	Unsupported encapsulation protocol revision.	
0x0000006a - 0x0000ffff	Reserved for future expansion.	

PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code Oxaaaaaaaa returned from the PLC.)

Panel Error Code PLC-497 Hex Value	Description
0x010100	Connection Manager: Connection in Use or Duplicate Forward Open.
0x010103	Connection Manager: Transport Class and Trigger combination not supported.
0x010106	Connection Manager: Ownership Conflict.
0x010107	Connection Manager: Connection not found at target application.
0x010108	Connection Manager: Invalid connection type (problem with type or priority).
0x010109	Connection Manager: Invalid connection size.
0x010110	Connection Manager: Device not configured.
0x010111	Connection Manager: RPI not supported. Could also be problem with inactivity timeout.
0x010113	Connection Manager: Connection Manager cannot support any more connections.
0x010114	Connection Manager: Either the vendor ID or the Product Code in the key segment did not match the device.
0x010115	Connection Manager: Product Type in the key segment did not match the device.
0x010116	Connection Manager: Major or minor revision information in the key segment did not match the device.

(PLC generated error codes for the Allen-Bradley EtherNet/IP protocol continued on the next page.)

C-more.

Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, CompactLogix, & FlexLogix (cont'd)

PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code 0xaaaaaaaa returned from the PLC.)	
Panel Error Code PLC-497 Hex Value	Description
0x010117	Connection Manager: Invalid connection point.
0x010118	Connection Manager: Invalid configuration format.
0x010119	Connection Manager: Connection request fails since there is no controlling connection currently open.
0x01011a	Connection Manager: Target application cannot support any more connections.
0x01011b	Connection Manager: RPI is smaller than the Production Inhibit Time.
0x010203	Connection Manager: Connection cannot be closed since the connection has timed out.
0x010204	Connection Manager: Unconnected Send timed out waiting for a response.
0x010205	Connection Manager: Parameter error in Unconnected send service.
0x010206	Connection Manager: Message too large for Unconnected message service.
0x010207	Connection Manager: Unconnected acknowledge without reply.
0x010301	Connection Manager: No buffer memory available.
0x010302	Connection Manager: Network Bandwidth not available for data.
0x010303	Connection Manager: No Tag filters available.
0x010304	Connection Manager: Not configured to send real-time data.
0x010311	Connection Manager: Port specified in Port segment not available.
0x010312	Connection Manager: Link address specified in port segment not available.
0x010315	Connection Manager: invalid segment type or segment value in path.
0x010316	Connection Manager: Path and Connection not equal in close.
0x010317	Connection Manager: Ether Segment not present or Encoded Value in Network Segment is invalid.
0x010318	Connection Manager: Link address to self invalid.
0x010319	Connection Manager: Resources on Secondary unavailable.
0x01031a	Connection Manager: Connection already established.
0x01031b	Connection Manager: Direct connection already established.
0x01031c	Connection Manager: Miscellaneous.
0x01031d	Connection Manager: Redundant connection mismatch.
0x01031e	Connection Manager: No more consumer resources available in the producing module.
0x01031f	Connection Manager: No connection resources exist for target path.
0x010320 - 0x0107ff	Connection Manager: Vendor specific.
0x020000	Resource unavailable: Connection Manager resources are unavailable to handle service request.
0x030000	Invalid parameter value.
0x040000	Path segment error: The path segment identifier or the segment syntax was not understood by the processing node.
0x050000	Path destination unknown: The path is referencing an object class, instance or structure element that is not known or is not contained in the processing node.
0x060000	Partial transfer: Only part of the expected data was transferred.
0x070000	Connection lost: The messaging connection was lost.

(PLC generated error codes for the Allen-Bradley EtherNet/IP protocol for continued on the next page.)

A-14 Cincle EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, CompactLogix, & FlexLogix (cont'd)

	PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code 0xaaaaaaaa returned from the PLC.)
Panel Error Code PLC-497 Hex Value	Description
0x080000	Service not supported: The requested service was not implemented or was not defined for this Object Class/Instance.
0x090000	Invalid attribute value: Invalid attribute data detected.
0x0a0000	Attribute list error: An attribute in the Get_Attribute_List or Set_Attribute_List response has a non-zero status.
0x0b0000	Already in requested mode/state: The object is already in the mode/state being requested by the service.
0x0c0000	Object state conflict: The object cannot perform the requested service in its current mode/state.
0x0d0000	Object already exists: The requested instance of object to be created already exists.
0x0e0000	Attribute not settable: A request to modify non-modifiable attribute was received.
0x0f0000	Privilege violation: A permission/privilege check failed.
0x100000	Device state conflict: The device's current mode/state prohibits the execution of the requested service.
0x110000	Reply data too large: The data to be transmitted in the response buffer is larger than the allocated response buffer.
0x120000	Fragmentation of a primitive value: The service specified an operation that is going to fragment a primitive data value. For example, trying to send a 2 byte value to a REAL data type (4 byte).
0x130000	Not enough data: The service did not supply enough data to perform the specified operation.
0x140000	Attribute not supported: The attribute specified in the request is not supported.
0x150000	Too much data: The service supplied more data than was expected.
0x160000	Object does not exist: The object specified does not exist in the device.
0x170000	Service fragmentation sequence not in progress: The fragmentation sequence for this service is not currently active for this data.
0x180000	No stored attribute data: The attribute data of this object was no saved prior to the requested service.
0x190000	Store operation failure: The attribute data of this object was not saved due to a failure during the attempt.
0x1a0000	Routing failure, request packet too large: The service request packet was too large for transmission on a network in the path to the destination.
0x1b0000	Routing failure, response packet too large: The service reponse packet was too large for transmission on a network in the path from the destination.
0x1c0000	Missing attribute list entry data: The service did not supply an attribute in a list of attributes that was needed by the service to perform the requested behavior.
0x1d0000	Invalid attribute value list: The service is returning the list of attributes supplied with status information for those attributes that were invalid.
0x1e0000	Embedded service error: See Service Packet error list (PLC-498 Error codes) below:
0x1f0000	Vendor specific error: A vendor specific error has been encountered. This occurs when none of the specified errors relate to the error in the device.
0x200000	Invalid parameter: A parameter associated with the request was invalid. This code is used when a parameter does meet the requirements defined in an Application Object specification.
0x210000	Write-once value or medium already written: An attempt was made to write to a write-once-medium that has already been written or to modify a value that cannot be change once established.
0x220000	Invalid Reply Received: An invalid reply is received (example: service code sent doesn't match service code received.).

(PLC generated error codes for the Allen-Bradley EtherNet/IP protocol for continued on the next page.)

A-15

Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, CompactLogix, & FlexLogix (cont'd)

PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code 0xaaaaaaaa returned from the PLC.)	
Panel Error Code PLC-497 Hex Value	Description
0x230000	Reserved by CIP for future extensions.
0x240000	Reserved by CIP for future extensions.
0x250000	Key failure in path: The key segment was included as the first segment in the path does not match the destination module. The object specific status shall indicate which part of the key check failed.
0x260000	Path Size Invalid: The size of the path which was sent with the Service Request is either not large enough to allow the Request to be routed to an object or too much routing data was included.
0x270000	Unexpected attribute in list: An attempt was made to set an attribute that is not able to be set at this time.
0x280000	Invalid Member ID: The Member ID specified in the request does not exist in the specified Class/Instance/ Attribute.
0x290000	Member not settable: A request to modify a non-modifiable member was received.
0x2a0000	Group 2 only server general failure: This error code may only be reported by DeviceNet group 2 only servers with 4K or less code space and only in place of Service not supported, Attribute not supported and Attribute not settable.
0x2b0000 - 0xcf0000	Reserved by CIP for future extensions.
0xd00000 - 0xff0000	Reserved for Object Class and service errors: This range of error codes is to be used to indicate Object Class specific errors. Use of this range should only be used when errors in this table don't accurately reflect the error encountered.

PLC Errors for Allen-Bradley EtherNet/IP Protocol – Service Packet Errors (Error code Oxaaaaaaaa returned from the PLC.)	
Panel Error Code PLC-498 Hex Value	Description
0x040000	This general status codes that the tag name could not be deciphered. This could mean that the tag name was entered incorrectly or does not exist in the PLC.
0x050000	The particular item referenced (usually instance) could not be found.
0x060000	The amount of data requested would not fit into the response buffer. Partial data transfer has occurred.
0x0a0000	An error has occurred trying to process one of the attributes.
0x130000	Not enough command data/parameters were supplied in the command to execute the service requested.
0x1c0000	An insufficient number of attributes were provided compared to the attribute count.
0x260000	The tag name length specified did not match what was in the message.
0xff0521	You have tried to access beyond the end of the data object.
0xff0721	The abbreviated type does not match the data type of the data object.
0xff0421	The beginning offset was beyond the end of the template.



Allen-Bradley – Micro800 Serial and EtherNet/IP Tag Based PLC Error Code Tables

The following PLC error code tables cover possible errors that are detected by the panel from Allen-Bradley Micro800 PLCs using the tag based serial or EtherNet/IP protocols.



NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** HMI, and are displayed on the attached screen as a hexadecimal value in panel error code PLC-496 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

PLC Errors for Allen-Bradley EtherNet/IP Protocol –Encapsulation Errors (Error code Oxaaaaaaaa returned from the PLC)	
Panel Error Code PLC-496 Hex Value	Description
0x0000001	The sender issued an invalid or unsupported encapsulation command.
0x0000002	Insufficient memory resources in the receiver to handle the command. You can get this error if the 1761-NET-ENI cannot connect to the PLC serially.
0x0000003	Poorly formed or incorrect data in the data portion of the encapsulation message.
0x00000004 - 0x00000063	Reserved for legacy (Rockwell Automation).
0x0000064	An orginator used an invalid session handle when sending an encapsulation message to the target.
0x0000065	The target received a message of invalid length.
0x0000066 - 0x0000068	Reserved for legacy (Rockwell Automation).
0x0000069	Unsupported encapsulation protocol revision.
0x0000006a - 0x0000ffff	Reserved for future expansion.

PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code 0xaaaaaaaa returned from the PLC)	
Panel Error Code PLC-497 Hex Value	Description
0x010100	Connection Manager: Connection in Use or Duplicate Forward Open.
0x010103	Connection Manager: Transport Class and Trigger combination not supported.
0x010106	Connection Manager: Ownership Conflict.
0x010107	Connection Manager: Connection not found at target application.
0x010108	Connection Manager: Invalid connection type (problem with type or priority).
0x010109	Connection Manager: Invalid connection size.
0x010110	Connection Manager: Device not configured.
0x010111	Connection Manager: RPI not supported. Could also be problem with inactivity timeout.
0x010113	Connection Manager: Connection Manager cannot support any more connections.
0x010114	Connection Manager: Either the vendor ID or the Product Code in the key segment did not match the device.
0x010115	Connection Manager: Product Type in the key segment did not match the device.
0x010116	Connection Manager: Major or minor revision information in the key segment did not match the device.

(PLC generated error codes for the Allen-Bradley Micro800 Serial and EtherNet/IP Tag Based PLC continued on the next page)



Allen-Bradley – Micro800 Serial and EtherNet/IP Tag Based PLC Error Code Tables (cont'd)

PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code Oxaaaaaaaa returned from the PLC)	
Panel Error Code PLC-497 Hex Value	Description
0x010117	Connection Manager: Invalid connection point.
0x010118	Connection Manager: Invalid configuration format.
0x010119	Connection Manager: Connection request fails since there is no controlling connection currently open.
0x01011a	Connection Manager: Target application cannot support any more connections.
0x01011b	Connection Manager: RPI is smaller than the Production Inhibit Time.
0x010203	Connection Manager: Connection cannot be closed since the connection has timed out.
0x010204	Connection Manager: Unconnected Send timed out waiting for a response.
0x010205	Connection Manager: Parameter error in Unconnected Send service.
0x010206	Connection Manager: Message too large for Unconnected message service.
0x010207	Connection Manager: Unconnected acknowledge without reply.
0x010301	Connection Manager: No buffer memory available.
0x010302	Connection Manager: Network Bandwidth not available for data.
0x010303	Connection Manager: No Tag filters available.
0x010304	Connection Manager: Not configured to send real-time data.
0x010311	Connection Manager: Port specified in Port segment not available.
0x010312	Connection Manager: Link address specified in port segment not available.
0x010315	Connection Manager: Invalid segment type or segment value in path.
0x010316	Connection Manager: Path and Connection not equal in close.
0x010317	Connection Manager: Ether Segment not present or Encoded Value in Network Segment is invalid.
0x010318	Connection Manager: Link address to self invalid.
0x010319	Connection Manager: Resources on Secondary unavailable.
0x01031a	Connection Manager: Connection already established.
0x01031b	Connection Manager: Direct connection already established.
0x01031c	Connection Manager: Miscellaneous.
0x01031d	Connection Manager: Redundant connection mismatch.
0x01031e	Connection Manager: No more consumer resources available in the producing module.
0x01031f	Connection Manager: No connection resources exist for target path.
0x010320 - 0x0107ff	Connection Manager: Vendor specific.
0x020000	Resource unavailable: Connection Manager resources are unavailable to handle service request.
0x030000	Invalid parameter value.
0x040000	Path segment error: The path segment identifier or the segment syntax was not understood by the processing node.
0x050000	Path destination unknown: The path is referencing an object class, instance or structure element that is not known or is not contained in the processing node.
0x060000	Partial transfer: Only part of the expected data was transferred.
0x070000	Connection lost: The messaging connection was lost

(PLC generated error codes for the Allen-Bradley Micro800 Serial and EtherNet/IP Tag Based PLC continued on the next page)

A-18 Cimore: EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



Allen-Bradley – Micro800 Serial and EtherNet/IP Tag Based PLC Error Code Tables (cont'd)

	PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code 0xaaaaaaaa returned from the PLC)
Panel Error Code PLC-497 Hex Value	Description
0x080000	Service not supported: The requested service was not implemented or was not defined for this Object Class/Instance.
0x090000	Invalid attribute value: Invalid attribute data detected.
0x0a0000	Attribute list error: An attribute in the Get_Attribute_List or Set_Attribute_List response has a non-zero status.
0x0b0000	Already in requested mode/state: The object is already in the mode/state being requested by the service.
0x0c0000	Object state conflict: The object cannot perform the requested service in its current mode/state.
0x0d0000	Object already exists: The requested instance of object to be created already exists.
0x0e0000	Attribute not settable: A request to modify non-modifiable attribute was received.
0x0f0000	Privilege violation: A permission/privilege check failed.
0x100000	Device state conflict: The device's current mode/state prohibits the execution of the requested service.
0x110000	Reply data too large: The data to be transmitted in the response buffer is larger than the allocated response buffer.
0x120000	Fragmentation of a primitive value: The service specified an operation that is going to fragment a primitive data value - for example, trying to send a 2 byte value to a REAL data type (4 byte).
0x130000	Not enough data: The service did not supply enough data to perform the specified operation.
0x140000	Attribute not supported: The attribute specified in the request is not supported.
0x150000	Too much data: The service supplied more data than was expected.
0x160000	Object does not exist: The object specified does not exist in the device.
0x170000	Service fragmentation sequence not in progress: The fragmentation sequence for this service is not currently active for this data.
0x180000	No stored attribute data: The attribute data of this object was no saved prior to the requested service.
0x190000	Store operation failure: The attribute data of this object was not saved due to a failure during the attempt.
0x1a0000	Routing failure, request packet too large: The service request packet was too large for transmission on a network in the path to the destination.
0x1b0000	Routing failure, response packet too large: The service reponse packet was too large for transmission on a network in the path from the destination.
0x1c0000	Missing attribute list entry data: The service did not supply an attribute in a list of attributes that was needed by the service to perform the requested behavior.
0x1d0000	Invalid attribute value list: The service is returning the list of attributes supplied with status information for those attributes that were invalid.
0x1e0000	Embedded service error: See Service Packet error list (PLC-498 Error codes) later in this appendix
0x1f0000	Vendor specific error: A vendor specific error has been encountered. This occurs when none of the specified errors relate to the error in the device.
0x200000	Invalid parameter: A parameter associated with the request was invalid. This code is used when a parameter does meet the requirements defined in an Application Object specification.
0x210000	Write-once value or medium already written: An attempt was made to write to a write-once-medium that has already been written or to modify a value that cannot be change once established.
0x220000	Invalid Reply Received: An invalid reply is received (example: service code sent doesn't match service code received).

(PLC generated error codes for the Allen-Bradley Micro800 Serial and EtherNet/IP Tag Based PLC continued on the next page)

A-19

Α

Allen-Bradley – Micro800 Serial and EtherNet/IP Tag Based PLC Error Code Tables (cont'd)

PLC Errors for Allen-Bradley EinerNet/IP Protocol – CIP Errors (Error code Ovacacacaca returned from the PLC)	
Panel Error Code PLC-497 Hex Value	Description
0x230000	Reserved by CIP for future extensions.
0x240000	Reserved by CIP for future extensions.
0x250000	Key failure in path: The key segment was included as the first segment in the path does not match the destination module. The object specific status shall indicate which part of the key check failed.
0x260000	Path Size Invalid: The size of the path which was sent with the Service Request is either not large enough to allow the Request to be routed to an object or too much routing data was included.
0x270000	Unexpected attribute in list: An attempt was made to set an attribute that is not able to be set at this time.
0x280000	Invalid Member ID: The Member ID specified in the request does not exist in the specified Class/Instance/ Attribute.
0x290000	Member not settable: A request to modify a non-modifiable member was received.
0x2a0000	Group 2 only server general failure: This error code may only be reported by DeviceNet group 2 only servers with 4K or less code space and only in place of Service not supported, Attribute not supported and Attribute not settable.
0x2b0000 - 0xcf0000	Reserved by CIP for future extensions.
0xd00000 - 0xff0000	Reserved for Object Class and service errors: This range of error codes is to be used to indicate Object Class specific errors. Use of this range should only be used when errors in this table don't accurately reflect the error encountered.

PLC Errors for Allen-Bradley EtherNet/IP Protocol – Service Packet Errors (Error code Oxaaaaaaaa returned from the PLC)	
Panel Error Code PLC-498 Hex Value	Description
0x040000	This general status codes that the tag name could not be deciphered. This could mean that the tag name was entered incorrectly or does not exist in the PLC.
0x050000	The particular item referenced (usually instance) could not be found.
0x060000	The amount of data requested would not fit into the response buffer. Partial data transfer has occurred.
0x0a0000	An error has occurred trying to process one of the attributes.
0x130000	Not enough command data/parameters were supplied in the command to execute the service requested.
0x1c0000	An insufficient number of attributes were provided compared to the attribute count.
0x260000	The tag name length specified did not match what was in the message.
0xff0521	You have tried to access beyond the end of the data object.
0xff0721	The abbreviated type does not match the data type of the data object.
0xff0421	The beginning offset was beyond the end of the template.



Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables

The following PLC error code tables cover possible errors that are detected by the panel from Allen-Bradley PLCs using the EtherNet/IP protocol. This includes MicroLogix 1100, 1400 & SLC 5/05, both using their native Ethernet port, and MicroLogix 1000, 1100, 1200, 1400, 1500, SLC 5/03, 5/04 and 5/05 using an Allen-Bradly ENI Adapter.



NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** touch panel, and displayed on the touch panel's screen as a hexadecimal value in panel error code PLC-496 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

PLC Errors for Allen-Bradley EtherNet/IP Protocol –Encapsulation Errors (Error code Oxaaaaaaaa returned from the PLC.)	
Panel Error Code PLC-496 Hex Value	Description
0x0000001	The sender issued an invalid or unsupported encapsulation command.
0x00000002	Insufficient memory resources in the receiver to handle the command. You can get this error if the 1761-NET-ENI cannot connect to the PLC serially.
0x0000003	Poorly formed or incorrect data in the data portion of the encapsulation message.
0x00000004 - 0x00000063	Reserved for legacy (Rockwell Automation).
0x0000064	An orginator used an invalid session handle when sending an encapsulation message to the target.
0x0000065	The target received a message of invalid length.
0x00000066 - 0x00000068	Reserved for legacy (Rockwell Automation).
0x0000069	Unsupported encapsulation protocol revision.
0x0000006a - 0x0000ffff	Reserved for future expansion.

PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code Oxaabbbb returned from the PLC.)

Panel Error Code PLC-497 Hex Value	Description
0x010100	Connection Manager: Connection in Use or Duplicate Forward Open.
0x010103	Connection Manager: Transport Class and Trigger combination not supported.
0x010106	Connection Manager: Ownership Conflict.
0x010107	Connection Manager: Connection not found at target application.
0x010108	Connection Manager: Invalid connection type (problem with type or priority).
0x010109	Connection Manager: Invalid connection size.
0x010110	Connection Manager: Device not configured.
0x010111	Connection Manager: RPI not supported. Could also be problem with inactivity timeout.

(PLC generated error codes for the Allen-Bradley EtherNet/IP protocol continued on the next page.)

A-21

Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables (cont'd)

	PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code Oxaabbbb returned from the PLC.)
Panel Error Code PLC-497 Hex Value	Description
0x010113	Connection Manager: Connection Manager cannot support any more connections.
0x010114	Connection Manager: Either the vendor ID or the Product Code in the key segment did not match the device.
0x010115	Connection Manager: Product Type in the key segment did not match the device.
0x010116	Connection Manager: Major or minor revision information in the key segment did not match the device.
0x010117	Connection Manager: Invalid connection point.
0x010118	Connection Manager: Invalid configuration format.
0x010119	Connection Manager: Connection request fails since there is no controlling connection currently open.
0x01011a	Connection Manager: Target application cannot support any more connections.
0x01011b	Connection Manager: RPI is smaller than the Production Inhibit Time.
0x010203	Connection Manager: Connection cannot be closed since the connection has timed out.
0x010204	Connection Manager: Unconnected Send timed out waiting for a response.
0x010205	Connection Manager: Parameter error in Unconnected send service.
0x010206	Connection Manager: Message too large for Unconnected message service.
0x010207	Connection Manager: Unconnected acknowledge without reply.
0x010301	Connection Manager: No buffer memory available.
0x010302	Connection Manager: Network Bandwidth not available for data.
0x010303	Connection Manager: No Tag filters available.
0x010304	Connection Manager: Not configured to send real-time data.
0x010311	Connection Manager: Port specified in Port segment not available.
0x010312	Connection Manager: Link address specified in port segment not available.
0x010315	Connection Manager: invalid segment type or segment value in path.
0x010316	Connection Manager: Path and Connection not equal in close.
0x010317	Connection Manager: Ether Segment not present or Encoded Value in Network Segment is invalid.
0x010318	Connection Manager: Link address to self invalid.
0x010319	Connection Manager: Resources on Secondary unavailable.
0x01031a	Connection Manager: Connection already established.
0x01031b	Connection Manager: Direct connection already established.
0x01031c	Connection Manager: Miscellaneous.
0x01031d	Connection Manager: Redundant connection mismatch.
0x01031e	Connection Manager: No more consumer resources available in the producing module.
0x01031f	Connection Manager: No connection resources exist for target path.
0x010320 - 0x0107ff	Connection Manager: Vendor specific.

(PLC generated error codes for the Allen-Bradley EtherNet/IP protocol continued on the next page.)



Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables (cont'd)

	PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code Oxaabbbb returned from the PLC.)
Panel Error Code PLC-497 Hex Value	Description
0x020000	Resource unavailable: Connection Manager resources are unavailable to handle service request.
0x030000	Invalid parameter value.
0x040000	Path segment error: The path segment identifier or the segment syntax was not understood by the processing node.
0x050000	Path destination unknown: The path is referencing an object class, instance or structure element that is not known or is not contained in the processing node.
0x060000	Partial transfer: Only part of the expected data was transferred.
0x070000	Connection lost: The messaging connection was lost.
0x080000	Service not supported: The requested service was not implemented or was not defined for this Object Class/Instance.
0x090000	Invalid attribute value: Invalid attribute data detected.
0x0a0000	Attribute list error: An attribute in the Get_Attribute_List or Set_Attribute_List response has a non-zero status.
0x0b0000	Already in requested mode/state: The object is already in the mode/state being requested by the service.
0x0c0000	Object state conflict: The object cannot perform the requested service in its current mode/state.
0x0d0000	Object already exists: The requested instance of object to be created already exists.
0x0e0000	Attribute not settable: A request to modify non-modifiable attribute was received.
0x0f0000	Privilege violation: A permission/privilege check failed.
0x100000	Device state conflict: The device's current mode/state prohibits the execution of the requested service.
0x110000	Reply data too large: The data to be transmitted in the response buffer is larger than the allocated response buffer.
0x120000	Fragmentation of a primitive value: The service specified an operation that is going to fragment a primitive data value. For example, trying to send a 2 byte value to a REAL data type (4 byte).
0x130000	Not enough data: The service did not supply enough data to perform the specified operation.
0x140000	Attribute not supported: The attribute specified in the request is not supported.
0x150000	Too much data: The service supplied more data than was expected.
0x160000	Object does not exist: The object specified does not exist in the device.
0x170000	Service fragmentation sequence not in progress: The fragmentation sequence for this service is not currently active for this data.
0x180000	No stored attribute data: The attribute data of this object was no saved prior to the requested service.
0x190000	Store operation failure: The attribute data of this object was not saved due to a failure during the attempt.
0x1a0000	Routing failure, request packet too large: The service request packet was too large for transmission on a network in the path to the destination.
0x1b0000	Routing failure, response packet too large: The service reponse packet was too large for transmission on a network in the path from the destination.
0x1c0000	Missing attribute list entry data: The service did not supply an attribute in a list of attributes that was needed by the service to perform the requested behavior.

(PLC generated error codes for the Allen-Bradley EtherNet/IP protocol continued on the next page.)

A

EA9-USER-M Hardware User Manual, 1st Ed. Rev. P Cimple A-23

Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables (cont'd)

	PLC Errors for Allen-Bradley EtherNet/IP Protocol – CIP Errors (Error code Oxaabbbb returned from the PLC.)
Panel Error Code PLC-497 Hex Value	Description
0x1d0000	Invalid attribute value list: The service is returning the list of attributes supplied with status information for those attributes that were invalid.
0x1e0000	Embedded service error: See Service Packet error list (PLC-498 Error codes) below:
0x1f0000	Vendor specific error: A vendor specific error has been encountered. This occurs when none of the specified errors relate to the error in the device.
0x200000	Invalid parameter: A parameter associated with the request was invalid. This code is used when a parameter does meet the requirements defined in an Application Object specification.
0x210000	Write-once value or medium already written: An attempt was made to write to a write-once-medium that has already been written or to modify a value that cannot be change once established.
0x220000	Invalid Reply Received: An invalid reply is received (example: service code sent doesn't match service code received.).
0x230000	Reserved by CIP for future extensions.
0x240000	Reserved by CIP for future extensions.
0x250000	Key failure in path: The key segment was included as the first segment in the path does not match the destination module. The object specific status shall indicate which part of the key check failed.
0x260000	Path Size Invalid: The size of the path which was sent with the Service Request is either not large enough to allow the Request to be routed to an object or too much routing data was included.
0x270000	Unexpected attribute in list: An attempt was made to set an attribute that is not able to be set at this time.
0x280000	Invalid Member ID: The Member ID specified in the request does not exist in the specified Class/Instance/ Attribute.
0x290000	Member not settable: A request to modify a non-modifiable member was received.
0x2a0000	Group 2 only server general failure: This error code may only be reported by DeviceNet group 2 only servers with 4K or less code space and only in place of Service not supported, Attribute not supported and Attribute not settable.
0x2b0000 - 0xcf0000	Reserved by CIP for future extensions.
0xd00000 - 0xff0000	Reserved for Object Class and service errors: This range of error codes is to be used to indicate Object Class specific errors. Use of this range should only be used when errors in this table don't accurately reflect the error encountered.

(PLC generated error codes for the Allen-Bradley EtherNet/IP protocol continued on the next page.)



Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables (cont'd)

PLC Errors for Allen-Bradley EtherNet/IP Protocol – Service Packet Errors (Error code Oxaabbbb returned from the PLC.)	
Panel Error Code PLC-498 Hex Value	Description
0x010000	DST Node is out of buffer space.
0x020000	Cannot guarantee delivery; link layer (The remote node specified does not ACK command).
0x030000	Duplicate token holder detected.
0x040000	Local port is disconnected.
0x050000	Application layer timed out waiting for response.
0x060000	Duplicate node detected.
0x070000	Station is offline.
0x080000	Hardware fault.
0x100000	Illegal command or format. Typical error received from PLC when addressed requested to the PLC does not exist. Usually occurs if memory map has not been expanded in PLC to the range requested from panel.
0x200000	Host has a problem and will not communicate.
0x300000	Remote node host is missing, disconnected, or shut down.
0x400000	Host could not complete function due to hardware fault.
0x500000	Addressing problem or memory protected rungs.
0x600000	Function not allowed due to command protection selection.
0x700000	Processor is in Program Mode.
0x800000	Compatibility mode file missing or communication zone problem.
0x900000	Remote node cannot buffer command.
0xA00000	Wait ACK (1775 KA buffer full).
0xB00000	Not used.
0xC00000	Not used.
0xD00000	Error code in the EXT STS byte. See the error code table below.
0xE00000	Fewer levels specified in address than minimum for any address.
0xF00300	More levels specified in address than system supports.
0xF00400	Symbol not found.
0xF00500	Symbol is of improper format.
0xF00600	Address does not point to something usable.
0xF00700	File is wrong size.
0xF00800	Cannot complete request, situation has changed since start of the command.
0xF00900	Data or file size is too large.
0xF00900	Transaction size plus word address is too large.
0xF00B00	Access denied; improper privilege. This will occur if data file is set to constant or protected.
0xF00C00	Condition cannot be generated; resource is not available.
0xF00D00	Condition already exists; resource is readily available.

(PLC generated error codes for the Allen-Bradley EtherNet/IP protocol continued on the next page.)

Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables (cont'd)

PLC Errors for Allen-Bradley EtherNet/IP Protocol – Service Packet Errors (Error code Oxaabbbb returned from the PLC.)

Panel Error Code PLC-498 Hex Value	Description
0xF00E00	Command cannot be executed.
0xF00F00	Histogram overflow.
0xF01000	No access.
0xF01100	Illegal data type.
0xF01200	Invalid parameter or invalid data.
0xF01300	Address reference exists to deleted area.
0xF01400	Command execution failure for unknown reason; possible histogram overflow.
0xF01500	Data conversion error.
0xF01600	Scanner not able to communicate with 1771 rack adapter.
0xF01700	Type mismatch.
0xF01800	1771 module response was not valid.
0xF01900	Duplicated label.
0xF02200	Remote rack fault.
0xF02300	Timeout.
0xF02400	Unknown error.
0xF01A00	File is open; another node owns it.
0xF01B00	Another node is the program owner.
0xF01C00	Reserved.
0xF01D00	Reserved.
0xF01E00	Data table element protection violation.
0xF01F00	Temporary internal problem.

Generic EtherNet IP Protocol – PLC Error Codes

Only errors as listed in the Touch Panel Error Code Table shown previously in this Appendix can occur when using the Generic Ethernet IP protocol, there are no PLC generated errors.



GE 90-30 – Panel Error Code PLC-499 Explanation

The PLC-499 error code is used to show any errors that are generated by the connected PLC. The PLC-499 error message includes a four digit hexadecimal value embedded in the message. This value can be looked up in the specific PLC's error tables to determine the cause of the error. The possible PLC generated error codes for the GE 90-30 communication protocol are represented by a hexadecimal value as shown in the following message example.

GE 90-30 Error Code PLC-499 Message Example:







The following table lists the errors that can be generated by the GE 90-30 PLC when using the SNPX protocol.



NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** touch panel, and displayed on the touch panel's screen as a hexadecimal value in panel error code PLC-499 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

PLC Errors for GE 90-30 SNPX Protocol (Major)	
Panel Error Code PLC-499 Hex Value	Description
No error	Successful completion. (This is the expected completion value in the COMMREQ Status Word.)
0x0002	Insufficient Privilege. For Series 90-70 PLC, the minor error code contains the privilege level required for the service request.
0x0004	Protocol Sequence Error. The CPU has received a message that is out of order.
0x0005	Service Request Error, the minor error code contains the specific error code.
0x0006	Illegal Mailbox Type. Service request mailbox type is either undefined or unexpected.
0x0007	The PLC CPU's Service Request Queue is full. The master should retry later. It is recommended that the master wait a minimum of 10 msec before sending another service request.
0x000A	SNP DOS Driver Error. The minor error code contains the specific error code.
0x000B	Illegal Service Request. The requested service is either not defined or not supported. (This value is returned in lieu of the actual 01h value passed in the SNP error message, to avoid confusion with the normal successful COMMREQ completion.)
0x000C	Local SNP/SNP-X Error. An error occurred within the SNP task in the CMM module in this PLC. This error may occur in either an SNP master or an SNP slave. The minor error code contains the specific error code.
0x000D	Remote SNP Error. An error occurred within the SNP slave task in the CMM module in the remote PLC. The minor error code contains the specific error code.
0x000E	Autodial Error. An error occurred while attempting to send a command string to an attached external modem. The minor error code contains the specific error code.
0x000F	SNP-X slave error. An error occurred within the SNPX task in the remote slave device. The minor error code contains the specific error code.
0x0013	Port configurator error.
0x0050	Problem with sending mail to the slave Service Request task. (Series 90-70 PLC CPUs only)
0x0051	Problem with getting mail from the slave Service Request task. (Series 90-70 PLC CPUs only)
0x0055	Slave SNP task timed out before receiving an SRP response. (Series 90-70 PLC CPUs only)
0x0056	Slave SNP task could not find the requested datagram connection. (Series 90-70 PLC CPUs only)
0x0057	Slave SNP task encountered an error in trying to write the datagram. (Series 90-70 PLC CPUs only)
0x0058	Slave SNP task encountered an error in trying to update the datagram. (Series 90-70 PLC CPUs only)

(PLC generated error codes for the GE 90-30 SNPX protocol continued on the next page.)



	PLC Errors for GE 90-30 SNPX Protocol (Minor-Major) (cont'd)
Panel Error Code PLC-499 Hex Value	Description
PLC Error 0x010C	WAIT-type COMMREQ is not permitted; must use NOW AIT-type.
PLC Error 0x010E	Not used
PLC Error 0x010F	The service request code in an X-Request message is unsupported or invalid at this time. This error may occur if an SNP-X communication session has not been success fully established at the slave device.
PLC Error 0x020C	COMMREQ command is not supported.
PLC Error 0x020E	The modem command string length exceeds 250 characters.
PLC Error 0x020F	Insufficient privilege level in the slave PLC CPU for the requested SNP-X service. Password protection at PLC CPU may be preventing the requested service.
PLC Error 0x0213	Unsupported COMMREQ. These errors are only generated when there is no protocol currently being run on a port, and the port receives a COMMREQ. (The port may be disabled or an error has occurred in processing a new configuration).
PLC Error 0x030C	SNP communication is not active. Must initiate a new SNP communication by sending an Attach or Long Attach COMMREQ.
PLC Error 0x030E	COMMREQ Data Block Length is too small. Output command string data is missing or incomplete.
PLC Error 0x030F	Invalid slave memory type in X-Request message.
PLC Error 0x0313	Invalid COMMREQ length.
PLC Error 0x040C	SNP slave did not respond to Attach message from master.
PLC Error 0x040E	Serial output timeout. The CMM module was unable to transmit the modem autodial output from the serial port. (May be due to missing CTS signal when the CMM is configured to use hardware flow control.)
PLC Error 0x040F	Invalid slave memory address or range in X-Request message.
PLC Error 0x0413	Invalid COMMREQ status word location.
PLC Error 0x050C	Unable to write SNP Status Word to local PLC memory; may be due to invalid Status Word memory type or address.
PLC Error 0x050E	Response was not received from modem. Check modem and cable.
PLC Error 0x050F	Invalid data length in X-Request message. Data length must be non-zero, and may not exceed decimal 1000 bytes.
PLC Error 0x0513	Invalid COMMREQ data.
PLC Error 0x060C	Master device memory type is not valid in this PLC.
PLC Error 0x060E	Modem responded with BUSY. Modem is unable to complete the requested connection. The remote modem is already in use; retry the connection request at a later time.
PLC Error 0x060F	X-Buffer data length does not match the service request in X-Request message. The X-Buffer message length is obtained from the Next Message Length field in the X-Request message; the length of the data within the buffer message is always the message length.
PLC Error 0x070C	Master device memory address or length is zero.
PLC Error 0x070E	Modem responded with NO CARRIER. Modem is unable to complete the requested connection. Check the local and remote modems and the telephone line.
PLC Error 0x070F	Queue Full indication from Service Request Processor in slave PLC CPU. The slave is temporarily unable to complete the service request. The master should try again later. It is recommended that the master wait at least 10 msec before repeating the X-Request.

(PLC generated error codes for the GE 90-30 SNPX protocol continued on the next page.)

PLC Errors for GE 90-30 SNPX Protocol (Minor-Major) (cont'd)	
Panel Error Code PLC-499 Hex Value	Description
0x080C	Unable to read or write master device memory locations specified in COMMREQ. Usually caused by invalid memory address for this PLC. SNP message exchange may have taken place.
0x080E	Modem responded with NO DIALTONE. Modem is unable to complete the requested connection. Check the modem connections and the telephone line.
0x080F	Service Request Processor response exceeds 1000 bytes; the SNP-X slave device cannot return the data in an X-Response message. (This error applies to CMM module only.)
0x090C	Master device memory data length exceeds maximum data size of CMM module (2048 bytes). Must use a smaller data length. Use multiple COMMREQs if total data length exceeds this maximum value.
0x090E	Modem responded with ERROR. Modem is unable to complete the requested command. Check the modem command string and modem.
0x0A0C	Slave device memory type is missing or not valid.
0x0A0E	Modem responded with RING, indicating that the modem is being called by another modem. Modem is unable to complete the requested command. Retry the modem command at a later time.
0x0B0C	Slave device memory address is missing or zero.
0x0B0E	An unknown response was received from the modem. Modem is unable to complete the requested command. Check the modem command string and modem. The modem response is expected to be either CONNECT or OK.
0x0C0C	COMMREQ Data Block Length is too small. (When expected COMMREQ length is 6 words or less. An improper length may cause other minor error codes 6-11.)
0x0D0C	Invalid Diagnostic Status Word (DSW) starting word or length.
0x0E0C	Invalid maximum SNP message data size. Must be an even value from 42 to 2048.
0x0F0C	Invalid Privilege Level. Must be 0 through 4 or -1.
0x100C	Invalid Fault Table selector. Must be 1 for I/O Fault Table, or 2 for PLC Fault Table.
0x100F	Unexpected Service Request Processor error. (This error applies to CMM module only; the unexpected SRP error code is saved in the Diagnostic Status Words in the CMM module.)
0x110C	Invalid Fault Table starting index. Must be 1-32 for I/O Fault Table, or 1-16 for PLC.
0x120C	Invalid fault count. Must be 1-32 for I/O Fault Table, or 1-16 for PLC Fault Table.
0x130C	Invalid Set PLC Date/Time mode. Must be 1-4.
0x140C	Invalid Set PLC Date/Time date, time, or day-of-week value.
0x150C	Unable to retrieve master device PLC time/date from PLC CPU.
0x150F	Requested service is not permitted in a Broadcast request. The master must direct the X-Request message to a specific SNP-X slave device.
0x160C	Invalid slave PLC type. Must be 0 for Series 90-70, or 1 for Series 90-30 or Series 90-20.
0x170C	Invalid datagram type. Must be 01h for normal datagram, or 81h (129) for permanent datagram.
0x180C	Missing or too many datagram point formats. Must be 1-32.
0x190C	Invalid datagram point format data.

(PLC generated error codes for the GE 90-30 SNPX protocol continued on the next page.)



	PLC Errors for GE 90-30 SNPX Protocol (Minor-Major) (cont'd)
Panel Error Code PLC-499 Hex Value	Description
0x1A0C	Datagram area size is too small to include data for all specified point formats.
0x1B0C	Invalid number of Control Program Names. Must be 1-8.
0x1C0C	SNP-X Request exceeds maximum data size (1000 bytes). Must use a smaller data length. Use multiple COMMREQs if necessary.
0x1D0C	Invalid SNP-X communication session type. Must be 0 for a single slave device, or 1 for multiple slave devices.
0x1E0C	Illegal destination SNP ID specified for SNP-X slave. Must be 0-7 ASCII characters, plus a terminating null character (00h). The Null SNP ID (eight bytes of 00h) may be used to specify any single device. The Broadcast SNP ID (eight bytes of FFh) may be use to specify all slave devices on the serial link.
0x1F0C	Destination SNP ID does not match SNP-X session type. The Broadcast SNP ID is not permitted in a single-slave SNP-X session. The Null SNP ID is not permitted in a multiple-slave SNP-X session.
0x200C	Inactivity timeout (T3'). The SNP slave has not received any new SNP messages within the configured T3' time interval.
0x200F	Invalid Message Type field in a received X-Request message. The message type of an X-Request message must be 58h = 'X'.
0x210C	A Parity error has occurred on an Attach, Attach Response, or Update Real–time Datagram message. Communications have not been established.
0x210F	Invalid Next Message Type or Next Message Length field in a received X Request message. If this request does not use a buffer (0-2 bytes of data), the Next Message Type must be zero. If this request will be followed with a buffer message (more than 2 byte.)), the Next Message Type must be 54h = 'T', and the Next Message Length must specify the length of the X-Buffer message. Valid X-Buffer message lengths are 9-1008 bytes (data length plus 8 bytes).
0x220C	A BCC (Block Check Code) error has occurred on an Attach, Attach Response, or Update Realtime Datagram message. Communications have not been established.
0x220F	Invalid Message Type field in a received X-Buffer message. The message type of an X-Buffer message must be 54h = 'T'.
0x230C	A Framing or Overrun serial error has occurred on an Attach, Attach Response, or Update Realtime Datagram message. Communications have not been established.
0x230F	Invalid Next Message Type field in a received X-Buffer message. Since an X-Buffer message is never followed by another message, the Next Message Type must always be zero.
0x240C	An invalid SNP message type was received when an Attach, Attach Response, or Update Realtime Datagram message was required. Communications have not been established.
0x250C	An invalid next message length value was specified in an Attach, Attach Response, or Update Realtime Datagram message. Communications have not been established.
0x260C	An unexpected SNP message type was received when an Attach, Attach Response, or Update Realtime Datagram was required. Communications have not been established.
0x270C	Another Break was received while SNP slave was waiting for an Attach or Update Realtime Datagram message.
0x280C	An SNP message has been sent and retried the maximum number of times. A maximum of two retries are permitted. A retry is caused by a NAK from from the remote SNP device.
0x290C	A received SNP message has been NAKed the maximum number of two times. The NAKed message may be retransmitted a maximum of two times.

(PLC generated error codes for the GE 90-30 SNPX protocol continued on the next page.)

PLC Errors for GE 90-30 SNPX Protocol (Minor-Major) (cont'd)	
Panel Error Code PLC-499 Hex Value	Description
0x2A0C	An unknown message was received when an acknowledge (ACK or NAK) was required.
0x2B0C	Sequence Error. An unexpected SNP message type was received.
0x2C0C	Received SNP message contains bad next message length value.
0x2D0C	Acknowledge timeout. An acknowledge (ACK or NAK) was not received within the configured T2 time interval. A slave device may generate this error if the master device has aborted after maximum response NAKs and does not NAK the next response retry.
0x2E0C	Response timeout. The SNP Master did not receive an SNP Response message within the configured T5' time interval.
0x2F0C	Buffer message timeout. An expected Text Buffer or Connection Data message was not received within the configured T5" time interval.
0x300C	Serial output timeout. The CMM module was unable to transmit a Break, an SNP message, or SNP acknowledge (ACK or NAK) from the serial port. (May be due to missing CTS signal when the CMM module is configured to use hardware flow control.)
0x310C	SNP slave did not receive a response from the Service Request Processor in the PLC CPU.
0x320C	COMMREQ timeout. The COMMREQ did not complete within the configured time interval.
0x330C	An SNP Request or Response was aborted prior to completion due to reception of a Break.
0x340C	PLC backplane communications error
0x350C	Invalid Piggyback Status data memory type or address. Communications have not been established.
0x360C	Invalid SNP Slave SNP ID. Must be a 0-7 ASCII characters, plus a terminating null character (00h). The Null SNP ID (eight bytes of 00h) may be used to specify any single slave device.
0x370C	The SNP master has received a response message containing an unexpected data length. Usually indicates a problem with the remote SNP slave device. May occur when Series 90-70 commands (Task Memory or Program Block Memory Read/Write) are issued to a Series 90-30 slave device.
0x380C	Response code in received SNP-X response message does not match expected value. (Response code must equal the request code +80h.)
0x390C	SNP-X Response message exceeds maximum data size (decimal 1000 bytes). Data in the Response is ignored.
0x400C	A parity error has occurred on an X-Attach Response message when establishing a new SNP-X communication session. Communications have not been established.
0x400D	The requested service is not supported by the SNP slave.
0x400F	Serial output timeout. The slave was unable to transmit an SNP-X message from the serial port. (May be due to missing CTS signal when the CMM module is configured to use hardware flow control.)

(PLC generated error codes for the GE 90-30 SNPX protocol continued on the next page.)



PLC Errors for GE 90-30 SNPX Protocol (Minor-Major) (cont'd)	
Panel Error Code PLC-499 Hex Value	Description
0x410C	A framing or overrun error has occurred on an X-Attach Response message when establishing a new SNP-X communication session. Communications have not been established.
0x410D	SNP slave on CMM module requires PLC CPU privilege level 2 to operate. The SNP slave has rejected a request to change to a higher or lower privilege level.
0x410F	An SNP-X request was aborted prior to completion due to reception of a Break.
0x420C	A BCC (Block Check Code) error has occurred on an X-Attach Response message when establishing a new SNP-X communication session. Communications have not been established.
0x420D	SNP Request or Response message exceeds maximum data length of the CMM module. (Total data length for Mailbox and all following Buffer messages is 2048 bytes.) The master must use a smaller data length. Use multiple requests if total data length exceeds the maximum value.
0x420F	An X-Buffer message was received containing greater than 1000 bytes of data. The data is ignored.
0x430C	An invalid message type was received when an X-Attach Response was required when establishing a new SNP-X communication session. Communications have not been established.
0x430D	Improper Write Datagram message format. Series 90-70 slave devices use a different format for this message than Series 90-30 or Series 90-20 slave devices. The master must use the proper message format for this SNP slave device. (The SNP master in the CMMmodule sends this message as part of the Establish Datagram COMMREQ command. The datagram has been partially established, but is not usable; the datagram should be cancelled by using the Datagram ID returned by the COMMREQ.)
0x430F	The SNP-X slave did not receive a response from the Service Request Processor in the PLC CPU.
0x440C	An invalid next message type value was detected in an X-Attach Response message when establishing a new SNP-X communication session. Communications have not been established.
0x440D	A datagram error occurred in a Series 90-70 slave device (dual-port error).
0x440F	PLC backplane communications error.
0x450C	An invalid response code was detected in an X-Attach Response message when establishing a new SNP-X communication session. Communications have not been established.
0x460C	An expected X-Attach Response message was not received within the response timeout interval when establishing a new SNP-X communication session. The master has retried the X-Attach message twice without receiving a response. Communications have not been established.
0x500C	A parity error has occurred on an X-Attach Response message when re-establishing an existing SNP-X communication session. Communications have not been established.
0x500F	A parity error has occurred in a received X-Attach message.
0x510C	A framing or overrun error has occurred on an X-Attach Response message when re-establishing an existing SNP-X communication session. Communications have not been established.
0x510F	A framing or overrun error has occurred in a received X-Attach message.
0x520C	A BCC (Block Check Code) error has occurred on an X-Attach Response message when re-establishing an existing SNP-X communication session. Communications have not been established.
0x520F	A BCC (Block Check Code) error has occurred in a received X-Attach message.

(PLC generated error codes for the GE 90-30 SNPX protocol continued on the next page.)

	DIC Exercise for CE 00 20 CNDV Distance (Minor Moior) (sont'd)
	PLC Errors for GE 90-30 SNPX Protocol (Millior-Major) (colit u)
Panel Error Code PLC-499 Hex Value	Description
0x530C	An invalid message type was received when an X-Attach Response was required when re-establishing an existing SNP-X communication session. Communications have not been established.
0x530F	An invalid Message Type was received when an X-Attach message was required. (For an X-Attach message, the message type must be 58h = 'T'.)
0x540C	An invalid Next Message Type value was detected in an X-Attach Response message when re-establishing an existing SNP-X communication session. Communications have not been established.
0x540F	An invalid Next Message Type value was detected in a received X-Attach message. (For an X-Attach message, the Next Message Length must be zero.)
0x550C	An invalid response code was detected in an X-Attach Response message when re-establishing an existing SNP-X communication session. Communications have not been established.
0x550F	An invalid request code was detected in a received X-Attach message.
0x560C	An expected X-Attach Response message was not received within the response timeout interval when re-establishing an existing SNP-X communication session. The master has retried the X-Attach message twice without receiving a response. Communications have not been established.
0x600C	A parity error has occurred on an X-Response message.
0x600F	A parity error has occurred in a received X-Request message.
0x610C	A framing or overrun error has occurred on an X-Response message.
0x610F	A framing or overrun error has occurred in a received X-Request message.
0x620C	A BCC (Block Check Code) error has occurred on an X-Response message.
0x620F	A BCC (Block Check Code) error has occurred in a received X-Request message.
0x630C	An invalid message type was received when an X-Response message was required.
0x640C	An invalid next message type value was detected in an X-Response message.
0x650C	An invalid response code was detected in an X-Response message.
0x660C	An expected X-Response message was not received within the response time.
0x700C	A parity error has occurred on an Intermediate Response message.
0x700F	A parity error has occurred in a received X-Buffer message.
0x710C	A framing or overrun error has occurred on an Intermediate Response message.
0x710F	A framing or overrun error has occurred in a received X-Buffer message.
0x720C	A BCC (Block Check Code) error has occurred on an Intermediate Response message.
0x720F	A BCC(Block Check Code) error has occurred in a received X-Buffer message.
0x730C	An invalid message type was received when an Intermediate Response message was required.
0x730F	An expected X-Buffer message was not received.
0x740C	An invalid next message type value was detected in an Intermediate Response message.
0x750C	An invalid response code was detected in an Intermediate Response message.
0x760C	An expected Intermediate Response message was not received within the response timeout interval.

(PLC generated error codes for the GE 90-30 SNPX protocol continued on the next page.)


GE 90-30 SNPX Protocol – PLC Error Code Tables (cont'd)

	PLC Errors for GE 90-30 SNPX Protocol (Minor-Major) (cont'd)					
Panel Error Code PLC-499 Hex Value	Description					
0x8D0A	Bad DOS Version. Must have DOS 2.0, or later, to support the SNP DOS Driver.					
0x8E0A	PC Serial port configured for SNP Master driver is not open; no communication can take place.					
0x8F0A	Out-of-Sequence SNP message. SNP message type received was not the type expected.					
0x900A	Bad SNP BCC encountered. Transmission was aborted after maximum retries due to a bad Block Check Code.					
0x910A	Bad SNP communication. Transmission was aborted after maximum retries due to serial errors (that is, parity, overrun, or framing errors).					
0x920A	No SNP communication. Either communication has been lost or a communication session has not been established.					
0xC105	Invalid block state transition.					
0xC205	The OEM key is NULL (inactive).					
0xC305	Text length does not match traffic type.					
0xC405	Verify with FA Card or EEPROM failed.					
0xC505	No task-level Rack/Slot configuration to read or delete.					
0xC605	Control Program (CP) tasks exist but requestor not logged into main CP.					
0xC705	Passwords are set to inactive and cannot be enabled or disabled.					
0xC805	Password(s) already enabled and can not be forced inactive.					
0xC905	Login using non-zero buffer size required for block commands.					
0xCA05	Device is write-protected.					
0xCB05	A comm or write verify error occurred during save or restore.					
0xCC05	Data stored on device has been corrupted and is no longer reliable.					
0xCD05	Attempt was made to read a device but no data has been stored on it.					
0xCE05	Specified device has insufficient memory to handle request.					
0xCF05	Specified device is not available in the system (not present).					
0xD005	One or more PLC modules configured have unsupported revision.					
0xD105	Packet size or total program size does not match input.					
0xD205	Invalid write mode parameter.					
0xD305	User Program Module (UPM) read or write exceeded block end.					
0xD405	Mismatch of configuration checksum.					
0xD505	Invalid block name specified in datagram.					
0xD605	Total datagram connection memory exceeded.					
0xD705	Invalid datagram type specified.					
0xD805	Point length not allowed.					
0xD905	Transfer type invalid for this Memory Type selector.					
0xDA05	Null pointer to data in Memory Type selector.					
0xDB05	Invalid Memory Type selector in datagram.					
0xDC05	Unable to find connection address.					
0xDD05	Unable to locate given datagram connection ID.					
0xDE05	Size of datagram connection invalid.					
0xDF05	Invalid datagram connection address.					

(PLC generated error codes for the GE 90-30 SNPX protocol continued on the next page.)

A

GE 90-30 SNPX Protocol – PLC Error Code Tables (cont'd)

PLC Errors for GE 90-30 SNPX Protocol (Minor-Major) (cont'd)			
Panel Error Code PLC-499 Hex Value	Description		
0xE005	Service in process cannot login.		
0xE105	No I/O configuration to read or delete.		
0xE205	IOS could not delete configuration, or bad type.		
0xE305	CPU revision number does not match.		
0xE405	Memory Type for this selector does not exist.		
0xE505	DOS file area not formatted.		
0xE605	CPU model number does not match.		
0xE705	Configuration is not valid.		
0xE805	No user memory is available to allocate.		
0xE905	Memory Type selector not valid in context.		
0xEA05	Not logged in to process service request.		
0xEB05	Task unable to be deleted.		
0xEC05	Task unable to be created.		
0xED05	VME bus error encountered.		
0xEE05	Could not return block sizes.		
0xEF05	Programmer is already attached.		
0xF005	Request only valid in stop mode.		
0xF105	Request only valid from programmer.		
0xF205	Invalid program cannot log in.		
0xF305	I/O configuration mismatch.		
0xF405	Invalid input parameter in request.		
0xF505	Invalid password.		
0xF605	Invalid sweep state to set.		
0xF705	Required to log in to a task for service.		
0xF805	Invalid Task Name referenced.		
0xF905	Task address out of range.		
0xFA05	Cannot replace I/O module.		
0xFB05	Cannot clear I/O configuration.		
0xFC05	I/O configuration is invalid.		
0xFD05	Unable to perform auto configuration.		
0xFE05	No privilege for attempted operation.		
0xFF05	Service Request Error has been aborted.		



Mitsubishi FX Protocol – PLC Error Codes

Only errors as listed in the Touch Panel Error Code Table shown previously in this Appendix can occur when using the Mitsubishi FX protocol, there are no PLC generated errors.

Omron – Panel Error Code PLC-499 Explanation

The PLC-499 error code is used to show any errors that are generated by the connected PLC. The PLC-499 error message includes a four digit hexadecimal value embedded in the message. This value can be looked up in the specific PLC's error tables to determine the cause of the error. The possible PLC generated error codes for the Omron Host Link and FINS communication protocol are represented by a hexadecimal value as shown in the following message example.

Omron Error Code PLC-499 Message Example:





A

Omron Host Link Protocol – PLC Error Code Table

The following table lists the errors that can be generated by the Omron PLC when using the Host Link protocol.



NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** touch panel, and displayed on the touch panel's screen as a hexadecimal value in panel error code PLC-499 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

PLC Error Codes for Omron Host Link			
Panel Error Code PLC-499 Hex Value	Description		
0x0000	Normal Completion.		
0x0001	Not executable in RUN mode.		
0x0002	Not executable in MONITOR mode.		
0x0003	Not executable with PROM mounted.		
0x0004	Address over (data overflow).		
0x000B	Not executable in PROGRAM mode.		
0x000C	Not executable in DEBUG mode.		
0x000D	Not executable in LOCAL mode.		
0x0010	Parity error.		
0x0011	Framing error.		
0x0012	Overrun.		
0x0013	FCS error.		
0x0014	Format error (parameter length error).		
0x0015	Entry number data error (parameter error, data code error, data length error).		
0x0016	Instruction not found.		
0x0018	Frame length error.		
0x0019	Not executable (due to Un-executable error clear, non-registration of I/O table, etc.).		
0x0020	I/O table generation impossible (unrecognized remote I/O unit, channel over, duplication of optical transmitting I/O unit).		
0x00A0	Abort due to parity error in transmit data under process.		
0x00A1	Abort due to framing error in transmit data under process.		
0x00A2	Abort due to overrun in transmit data under process.		
0x00A3	Abort due to FCS error in transmit data under process.		
0x00A4	Abort due to format error in transmit data under process.		
0x00A5	Abort due to frame length error in transmit data under process.		
0x00A8	Abort due to entry number data error in transmit data under process.		
0x00B0	Un-executable due to program area capacity other than 16k bytes		



Omron FINS Protocol – PLC Error Code Table

The following table lists the errors that can be generated by the Omron PLC when using the FINS protocol.



NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** touch panel, and displayed on the touch panel's screen as a hexadecimal value in panel error code PLC-499 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

PLC Error Codes for Umron FINS			
Panel Error Code PLC-499 Hex Value	Description		
0x0000	Normal Completion.		
0x0001	Service Canceled.		
0x0101	Local Error: Local node not in network.		
0x0102	Local Error: Token Timeout.		
0x0103	Local Error: Retries Failed.		
0x0104	Local Error: Too many send frames.		
0x0105	Local Error: Node address range error.		
0x0106	Local Error: Node Address Duplication.		
0x0201	Destination Node Error: Destination Node not in network.		
0x0202	Destination Node Error: Unit Missing.		
0x0203	Destination Node Error: Third Node missing.		
0x0204	Destination Node Error: Destination Node busy.		
0x0205	Destination Node Error: Response Timeout.		
0x0301	Controller Error: Communications Controller Error.		
0x0302	Controller Error: CPU Unit Error.		
0x0303	Controller Error: Controller Error.		
0x0304	Controller Error: Unit number Error.		
0x0401	Service Unsupported: Undefined Command.		
0x0402	Service Unsupported: Not supported by Model/Version.		
0x0501	Routing Table Error: Destination address setting error.		
0x0502	Routing Table Error: No routing tables.		
0x0503	Routing Table Error: Routing table error.		
0x0504	Routing Table Error: Too many delays.		
0x1001	Command Format Error: Command too long.		
0x1002	Command Format Error: Command too short.		
0x1003	Command Format Error: Elements/Data don't match.		
0x1004	Command Format Error: Command format error.		
0x1005	Command Format Error: Header Error.		
0x1101	Parameter Error: Area classification missing.		
0x1102	Parameter Error: Access Size Error.		
0x1103	Parameter Error: Address range error.		

(PLC generated error codes for the Omron FINS protocol continued on the next page.)

Omron FINS Protocol – PLC Error Code Table (cont'd)

PLC Error Codes for Omron FINS			
Panel Error Code PLC-499 Hex Value	Description		
0x1104	Parameter Error: Address range exceeded.		
0x1106	Parameter Error: Program Missing.		
0x1109	Parameter Error: Relational Error.		
0x110A	Parameter Error: Duplicate Data Access.		
0x110B	Parameter Error: Response too long.		
0x110C	Parameter Error: Parameter Error.		
0x2002	Read Not Possible: Protected.		
0x2003	Read Not Possible: Table missing.		
0x2004	Read Not Possible: Data missing.		
0x2005	Read Not Possible: Program missing.		
0x2006	Read Not Possible: File missing.		
0x2007	Read Not Possible: Data mismatch.		
0x2101	Write Not Possible: Read Only.		
0x2102	Write Not Possible: Protected - cannot write data link table.		
0x2103	Write Not Possible: Cannot register.		
0x2105	Write Not Possible: Program missing.		
0x2106	Write Not Possible: File missing.		
0x2107	Write Not Possible: File name already exists.		
0x2108	Write Not Possible: Cannot change.		
0x2201	Not executable in current mode: Not possible during execution.		
0x2202	Not executable in current mode: Not possible while running.		
0x2203	Not executable in current mode: Wrong PLC mode (Program).		
0x2204	Not executable in current mode: Wrong PLC mode (Debug).		
0x2205	Not executable in current mode: Wrong PLC mode (Monitor).		
0x2206	Not executable in current mode: Wrong PLC mode (Run).		
0x2207	Not executable in current mode: Specified node not polling node.		
0x2208	Not executable in current mode: Step cannot be executed.		
0x2301	No such device: File device missing.		
0x2302	No such device: Missing memory.		
0x2303	No such device: Clock missing.		
0x2401	Cannot Start/Stop: Table missing.		
0x2502	Unit Error: Memory Error.		
0x2503	Unit Error: I/O setting Error.		
0x2504	Unit Error: Too many I/O points.		
0x2505	Unit Error: CPU bus error.		
0x2506	Unit Error: I/O Duplication.		

(PLC generated error codes for the Omron FINS protocol continued on the next page.)



Omron FINS Protocol – PLC Error Code Table (cont'd)

PLC Error Codes for Omron FINS			
Panel Error Code PLC-499 Hex Value	Description		
0x2507	Unit Error: I/O bus error.		
0x2509	Unit Error: SYSMAC BUS/2 error.		
0x250A	Unit Error: CPU Bus Unit Error.		
0x250D	Unit Error: SYSMAC BUS No. duplication.		
0x250F	Unit Error: Memory Error.		
0x2510	Unit Error: SYSMAC BUS terminator missing.		
0x2601	Command Error: No protection.		
0x2602	Command Error: Incorrect password.		
0x2604	Command Error: Protected.		
0x2605	Command Error: Service already executing.		
0x2606	Command Error: Service stopped.		
0x2607	Command Error: No execution right.		
0x2608	Command Error: Settings not complete.		
0x2609	Command Error: Necessary items not set.		
0x260A	Command Error: Number already defined.		
0x260B	Command Error: Error will not clear.		
0x3001	Access Right Error: No access right.		
0x4001	Abort: Service aborted.		

A

-

Omron – Panel Error Code P495 Explanation

The PLC-495 error code is used to show any errors that are generated by the connected PLC. The PLC-495 error message includes a four digit hexadecimal value embedded in the message. This value can be looked up in the specific PLC's error tables to determine the cause of the error. The possible PLC generated error codes for the Omron CS/CJ FINS Ethernet communication protocol are represented by a hexadecimal value as shown in the following message example.

Omron Error Code PLC-495 Message Example:







Omron CS/CJ FINS Ethernet Protocol – PLC Error Code Table

The following table lists the errors that can be generated by the Omron PLC when using the CS/CJ FINS Ethernet protocol.



NOTE: The following errors can be generated from the designated PLC, are monitored by the **C-more** touch panel, and displayed on the touch panel's screen as a hexadecimal value in panel error code PLC-495 message, if active. Please refer to the PLC manufacturer's documentation for additional information.

PLC Error Codes for Omron CS/CJ FINS Ethernet						
Panel Error Code PLC-495 Hex Value	Description					
0103	Local Error: Send Error from lack of buffer space. Try reducing Ethernet load to the module.					
0201	Destination Node Error: IP address of remote node not set correctly.					
0202	Destination Node Error: No node with the specified unit address found.					
0205	Destination Node Error: Packet corrupted or Response timeout. Try increasing timeout.					
0301	Controller Error: Communications controller error.					
0302	Controller Error: CPU Unit error. Check error LEDs on PLC. Refer to documentation for that CPU.					
0304	Controller Error: Unit number error. Make sure Unit number is not used twice.					
0401	Service unsupported: Undefined command.					
0501	Routing table error: Destination address setting error. Routing table incorrect.					
0502	Routing table error: No routing tables.					
0503	Routing table error: Routing table error.					
0504	Routing table error: Too many relays.					
1001	Command format error: Command too long. Bad packet: check for electrical noise and grounding.					
1002	Command format error: Command too short. Bad packet: check for electrical noise and grounding.					
1003	Command format error: Elements/data don't match. Bad packet: check for electrical noise and grounding.					
1005	Command format error: Header error. This is the error received when station # set in the command does not match the station # of the Ethernet module.					
1100	Parameter error: UDP socket number bad.					
1101	Parameter error: Address requested does not exist in PLC.					
1103	Parameter error: Address area requested in not accessible.					
220F	Status error: Duplicate Socket error.					
2210	Status error: Specified socket not open.					
2305	Environment Error: IP address conversion failed. Only encountered when using routing tables.					
2307	Environment Error: IP address conversion set for automatic.					
2503	Unit error: I/O setting error.					
2505	Unit error: CPU bus error.					
250A	Unit error: CPU Bus Unit error.					

A-43

VICPAS mens – Panel Error Code P499 Explanation

The PLC-499 error code is used to show any errors that are generated by the connected PLC. The PLC-499 error message includes a four digit hexadecimal value displayed at the end of the message. This value can be looked up in the specific PLC's error tables to determine the cause of the error. The possible PLC generated error codes for the Siemens PPI communication protocols breakdown into a four digit hexadecimal value as shown in the following message example.

Siemens Error Code PLC-499 Message Example:





Siemens PPI Protocol – PLC Error Code Table

PLC PDU Header Errors for S7-200 PPI			
Panel Error Code PLC-499 Hex Value	Description		
0x0001	Hardware Fault.		
0x0003	Object access not allowed: Occurs when access to Timer and Counter data type is set to Signed Integer and not BCD.		
0x0004	Context not supported.		
0x0005	Address out of range: Occurs when requesting an address within a Data Block that does not exist or is out of range.		
0x0006	Address out of range.		
0x0007	Write Data size mismatch.		
0x000A	Object does not exist: Occurs when trying to request a Data Block that does not exist.		
0x8000	Function being used.		
0x8001	Action is not allowed in current mode.		
0x8101	Hardware fault.		
0x8103	Access not allowed.		
0x8104	Function not supported.		
0x8105	Address invalid.		
0x8106	Data Type not supported.		
0x8107	Data Type is not consistent with size.		
0x810A	Object does not exist.		
0x8500	PDU Size is incorrect.		
0x8702	Address is invalid.		
0xD201	Block name syntax error.		
0xD202	Error with function parameter.		
0xD203	Error with block type.		
0xD204	No linked block.		
0xD205	Object already exists.		
0xD206	Object already exists.		
0xD207	Block already used in EPROM.		
0xD209	Block does not exist.		
0xD20E	No Block does not exist.		
0xD210	Block number incorrect.		

Α

Siemens ISO over TCP Protocol – PLC Error Code Table

PLC PDU Header Errors for S7-300 CPU; S7-200, S7-400, S7-1200, S7-1500 Ethernet						
Panel Error Code PLC-499 Hex Value	Description					
0x0001	Hardware Fault.					
0x0003	Object access not allowed: Occurs when access to Timer and Counter data type is set to Signed Integer and not BCD.					
0x0004	Context not supported.					
0x0005	Address out of range: Occurs when requesting an address within a Data Block that does not exist or is out of range.					
0x0006	Address out of range.					
0x0007	Write Data size mismatch.					
0x000A	Object does not exist: Occurs when trying to request a Data Block that does not exist.					
0x8000	Function being used.					
0x8001	Action is not allowed in current mode.					
0x8101	Hardware fault.					
0x8103	Access not allowed.					
0x8104	Function not supported.					
0x8105	Address invalid.					
0x8106	Data Type not supported.					
0x8107	Data Type is not consistent with size.					
0x810A	Object does not exist.					
0x8500	PDU Size is incorrect.					
0x8702	Address is invalid.					
0xD201	Block name syntax error.					
0xD202	Error with function parameter.					
0xD203	Error with block type.					
0xD204	No linked block.					
0xD205	Object already exists.					
0xD206	Object already exists.					
0xD207	Block already used in EPROM.					
0xD209	Block does not exist.					
0xD20E	No Block does not exist.					
0xD210	Block number incorrect.					

A-46 C-more EA9-USER-M Hardware User Manual, 1st Ed. Rev. P



TOUCH PANEL RUNTIME ERRORS



In This Appendix	
Introduction	В-2
Runtime Errors	В-З
Log File Naming	В-4

Introduction

The *C-more* touch panels have diagnostics built-in to the operating system that monitor various runtime functions that will display an error message on the panel's display indicating that a particular error has occurred and what the error represents. The Error Message(s) is displayed in the upper left area of the display screen. The Runtime Errors are also logged into the panel's Error log under the Information tab in the panel's System Setup Screens. The Error tab and in the error log. See Chapter 5: System Setup Screens for additional details. The tables that follow show the possible Runtime Errors.

The user can include in their touch panel project the use of this diagnostic information by using the system tag name SYS ERR ERRORCODE to control displayed screens, operator messages, etc., and also communicate error information to the PLC or controlling device. If a runtime error occurs, the SYS ERR ERRORCODE system tag will contain the numeric value shown under the Tag Code Error Value. For example, For example, if the panel project is configured to log to USB and no USB flash drive is installed in the panel, the panel will display "RTE-004 Log buffer memory is full" and the SYS ERR ERRORCODE system tag will contain the value 2004. The value of the last runtime error detected will remain in the SYS ERR ERRORCODE.

If you have difficulty determining the cause of the error, refer to **Chapter 8: Troubleshooting** for additional help or contact our technical support group at 770-844-4200





Runtime Errors

If there is more than one **Runtime Error**, then the **Error Message** displayed at the top of the panel's screen will display for 3 seconds, then be off for 2 seconds. The next **Error Message** will display for the same time increments, continue through any other active runtime error messages, and then start over. When only one **Runtime Error** is active, then that message will continuously be displayed until it is no longer active.

No.	Error Log Code	Error Message Located at upper left of screen	Error Message Tag	Tag Error Code Value	System Screen Info > Error	Cause
Log Erro	r					
1	RTE-001	Log Failed. Not enough Memory Space in %Device%	SYS ERR ERRORCODE	2001	MM/DD/YY HH/MM/SS Error Code RTE-001	The size of the destination memory is not large enough to store the data. See Log File Naming below.
2	RTE-002	Log Failed. %Device% cannot be found	SYS ERR ERRORCODE	2002	MM/DD/YY HH/MM/SS Error Code RTE-002	No device available or the device is defective. See Log File Naming below.
3	RTE-003	Log Failed. Can not write file - %file%	SYS ERR ERRORCODE	2003	MM/DD/YY HH/MM/SS Error Code RTE-003	Logging the data has failed due to a problem such as the memory write protect is enabled. See Log File Naming below.
4	RTE-004	Log cache memory is full	SYS ERR ERRORCODE	2004	MM/DD/YY HH/MM/SS Error Code RTE-004	The data log buffer in the SRAM memory is full. See Log File Naming below.
Screen (Capture					
1	RTE-011	Capture Failed. Not enough Memory Space in %Device%	SYS ERR ERRORCODE	2011	MM/DD/YY HH/MM/SS Error Code RTE-011	The size of the destination memory is not large enough to store the data.
2	RTE-012	Capture Failed. %Device% cannot be found	SYS ERR ERRORCODE	2012	MM/DD/YY HH/MM/SS Error Code RTE-012	No device available or the device is defective.
3	RTE-013	Capture Failed. Can not write file - %file%	SYS ERR ERRORCODE	2013	MM/DD/YY HH/MM/SS Error Code RTE-013	Logging the data has failed due to a problem such as the memory write protect is enabled.
Table continued						

Log File Naming

When using the Line Trend Graph to Log, the log file name is formed automatically in the panel. The visible file name has the following format:

Screen Name + "_" + Object name + "_" + Date Stamp YYMMDD + ".txt"

Internal to the panel, the file references are stored as the first four characters of the file name + " $_{-}$ " + a serial number between 000 and 999 + ".txt" So, any "group" of filenames is limited to 999 members.

For example: The following filenames form the same group. All filenames start with "SCRE":

Screen1_Trend1_yymmdd.txt Screen2_Trend2_yymmdd.txt Screen3_Trend3_yymmdd.txt

When the 999 filename limit is reached, the oldest files will automatically be deleted and logging will continue.

Visible File Name	<u>Internal File Name</u>
Screen1_Trend1_120101.txt	SCRE ~001.TXT
Screen2_Trend2_120101.txt	SCRE ~002.TXT
Screen3_Trend3_120101.txt	SCRE ~003.TXT
Screen1_Trend1_120102.txt	SCRE ~004.TXT
Screen2_Trend2_120102.txt	SCRE ~005.TXT
Screen3_Trend3_120102.txt	SCRE ~006.TXT
Screen1_Trend1_121129.txt	SCRE ~997.TXT
Screen2_Trend2_121129.txt	SCRE -998.TXT
Screen3_Trend3_121129.txt	SCRE ~999.TXT
Screen1_Trend3_121130.txt	Runtime Error RTE-001

Workaround: To minimize membership in any one group, change the Screen name and the Object name so the first four characters of the visible file name are unique

For example,

Screen Names: S1, S2

Object Names: AAA, BAA

Visible File Name	Internal File Name
S1_A AA_150101.txt	S1_A ~001.TXT
S1_B AA_150101.txt	S1_B ~001.TXT
\$2_A AA_150101.txt	S2_A ~001.TXT
S2_B AA_150101.txt	S2_B ~001.TXT
S1_A AA_150102.txt	S1_A ~002.TXT
S1_B AA_150102.txt	S1_B ~002.TXT
\$2_A AA_150102.txt	S2_A ~002.TXT
S2_B AA_150102.txt	S2_B ~002.TXT
\$1_A AA_151231.txt	S1_A ~365.TXT
\$1_B AA_151231.txt	S1_B ~365.TXT
\$2_A AA_151231.txt	S2_A ~365.TXT
S2_B AA_151231.txt	S2_B ~365.TXT

Note that there is no conflict between file names and since no log group will exceed 365 (days) the 999 member limit is never exceeded.



Runtime Errors (cont'd)

No.	Error Log Code	Error Message Located at upper left of screen	Error Message Tag	Tag Error Code Value	System Screen Info > Error	Cause
Handsh	ake					
1	RTE-021	Handshake Timeout Error	SYS ERR ERRORCODE	2021	MM/DD/YY HH/MM/SS Error Code RTE-021	A communications timeout occurred when either a Recipe or Numeric Entry Object, in which Notification and Handshake signals are used, failed to complete the responses.
e-mail						
1	RTE-041	E-mail Connection Error %Address%	SYS ERR ERRORCODE	2041	MM/DD/YY HH/MM/SS Error Code RTE-041	An incorrect SMTP address has been entered into the Touch Panel Network dialog screen.
2	RTE-042	Send E-mail Error %Address%	SYS ERR ERRORCODE	2042	MM/DD/YY HH/MM/SS Error Code RTE-042	An incorrect email address has been entered into the Address Book.
3	RTE-043	Email Failed: The file cannot be attached	SYS ERR ERRORCODE	2043	MM/DD/YY HH/MM/SS Error Code RTE-043	
Send FT	P		·			
1	RTE-051	FTP Connection Error %Address%&%ID%	SYS ERR ERRORCODE	2051	MM/DD/YY HH/MM/SS Error Code RTE-051	An incorrect FTP Service has been assigned into the Touch Panel Network dialog screen.
2	RTE-052	Send FTP Error %Address%&%ID%	SYS ERR ERRORCODE	2052	MM/DD/YY HH/MM/SS Error Code RTE-052	Permission to write to the FTP folder has not been authorized. The FTP site may require a user ID and password.
3	RTE-053	FTP Failed: The file cannot be copied	SYS ERR ERRORCODE	2053	MM/DD/YY HH/MM/SS Error Code RTE-053	
Recieve FTP						
1	RTE-061	Receive FTP Error	SYS ERR ERRORCODE	2061	MM/DD/YY HH/MM/SS Error Code RTE-061	
Receive HTTP						
1	RTE-071	Receive HTTP Error	SYS ERR ERRORCODE	2071	MM/DD/YY HH/MM/SS Error Code RTE-071	



B

Runtime Errors (cont'd)

B

No.	Error Log Code	Error Message Located at upper left of screen	Error Message Tag	Tag Error Code Value	System Screen Info > Error	Cause
Sound						
1	RTE-081	Sound Failed. Not enough Memory	SYS ERR ERRORCODE	2081	MM/DD/YY HH/MM/SS Error Code RTE-081	The sound file failed to play due to insufficient memory.
Confiict						
1	RTE-091	IP Address Conflict - Correct IP Address and Power Cycle	SYS ERR ERRORCODE	2091	MM/DD/YY HH/MM/SS Error Code RTE-091	Conflict of IP Address
Multiple	Recipe					
1	RTE-101	Record doesn't exist	SYS ERR ERRORCODE	2101	MM/DD/YY HH/MM/SS Error Code RTE-101	The recipe file or data doesn't exist.
2	RTE-102	File cannot open	SYS ERR ERRORCODE	2102	MM/DD/YY HH/MM/SS Error Code RTE-102	The recipe file cannot be opened.
3	RTE-103	E-mail Connection Error %Address%	SYS ERR ERRORCODE	2103	MM/DD/YY HH/MM/SS Error Code RTE-103	Abnormality is found in the numberic character data of the recipe file.
4	RTE-104	Send E-mail Error %Address%	SYS ERR ERRORCODE	2104	MM/DD/YY HH/MM/SS Error Code RTE-104	Abnormality is found in the Tag data of the recipe file.
5	RTE-105	Recipe - Index (%Row%) error	SYS ERR ERRORCODE	2105	MM/DD/YY HH/MM/SS Error Code RTE-105	Recipe was operated by the record number outside the range.
6	RTE-106	Not enough buffer memory	SYS ERR ERRORCODE	2106	MM/DD/YY HH/MM/SS Error Code RTE-106	Memory allocation error
7	RTE-107	File cannot write	SYS ERR ERRORCODE	2107	MM/DD/YY HH/MM/SS Error Code RTE-107	There was an error trying to write the recipe file.
8	RTE-108	Wrong file format	SYS ERR ERRORCODE	2108	MM/DD/YY HH/MM/SS Error Code RTE-108	The recipe file format is incorrect.
9	RTE-109	Not enough Memory Space in %Device%	SYS ERR ERRORCODE	2109	MM/DD/YY HH/MM/SS Error Code RTE-109	Insufficient storage space on media.





Runtime Errors (cont'd)

No.	Error Log Code	Error Message Located at upper left of screen	Error Message Tag	Tag Error Code Value	System Screen Info > Error	Cause
Action						
1	RTE-121	Action Overflows	SYS ERR Errorcode	2121	MM/DD/YY HH/MM/SS Error Code RTE-121	The number of actions executed in the event exceeded the maximum number.
SRAM Error						
1	RTE-500	SRAM Check Sum Error	SYS ERR ERRORCODE	2500	MM/DD/YY HH/MM/SS Error Code RTE-500	Memory in Panel has been Corrupted by Power Loss, etc. Try cycling power to the panel and re-transfer the project to the panel, in sequential steps to attempt to resolve the error.





SECURITY CONSIDERATIONS FOR CONTROL SYSTEMS NETWORKS

In This Appendix...

Securit	y Considerations fo	r Control Systems	Networks	C-2	2
Securit	y Considerations to	r Control Systems	Networks C	<u> </u>	-

APPENDIX

Security Considerations for Control Systems Networks

Manufacturers are realizing that to stay competitive, their Automation and Control Systems need to be more integrated within their plant. The systems often need to be integrated with upstream Enterprise Data Systems, and even further integrated to allow information to be accessible across multiple plants, or even through the Internet. This convergence of the IT world with the Automation World creates challenges in maintaining secure systems and protecting your investments in processes, personnel, data and intellectual property.

While Automation Networks and Systems have built-in password protection schemes, this is only one very small step in securing your systems. Automation Control System Networks need to incorporate data protection and security measures that are at least as robust as a typical business computer system. We recommend that users of PLCs, HMI products and SCADA systems perform your own network security analysis to determine the proper level of security required for you application. However, the Department of Homeland Security's National Cybersecurity and Communications Integration Center (NCCIC) and Industrial Control Systems Cyber Emergency Response Team (ICS-CERT) has provided direction related to network security and safety under an approach described as "Defense in Depth", which is published at https://ics-cert.us-cert.gov/sites/default/files/recommended_practices/NCCIC_ICS-CERT_Defense in Depth 2016_S508C.pdf.

This comprehensive security strategy involves physical protection methods, as well as process and policy methods. This approach creates multiple layers and levels of security for industrial automation systems. Such safeguards include the location of control system networks behind firewalls, their isolation from business networks, the use of intrusion detection systems, and the use of secure methods for remote access such as Virtual Private Networks (VPNs). Further, users should minimize network exposure for all control system devices and such control systems and these systems should not directly face the internet. Following these procedures should significantly reduce your risks both from external sources as well as internal sources, and provide a more secure system.

It is the user's responsibility to protect such systems, just as you would protect your computer and business systems. AutomationDirect recommends using one or more of these resources in putting together a secure system:

- ICS-CERT's Control Systems recommended practices at the following web address: https://ics-cert.us-cert.gov/Recommended-Practices
- Special Publication 800-82 of the National Institute of Standards and Technology Guide to Industrial Control Systems (ICS) Security: <u>https://csrc.nist.gov/publications/detail/sp/800-82/rev-2/final</u>
- ISA99, Industrial Automation and Control Systems Security <u>https://www.isa.org/MSTemplate.cfm?MicrositeID=988&CommitteeID=6821</u> (please note this is a summary and these standards have to be purchased from ISA)

The above set of resources provides a comprehensive approach to securing a control system network and reducing risk and exposure from security breaches. Given the nature of any system that accesses the internet, it is incumbent upon each user to assess the needs and requirements of their application and take steps to mitigate the particular security risks inherent in their control system



