

OM1500 Operator Terminal

The OM1500 Operator Terminal is a low cost/high performance man/machine interface with a broad range of operator input and display capabilities. The terminal includes a 2 line by 20 character LCD display, a full numeric keypad, five function keys and three LED light bar indicator lights

OptiMate configuration software allows you to predefine up to 160 messages. These messages can be later selected for display by your PLC or com-

puter program to display status, variable data and allow numeric data input. For computer applications, other messages can be sent directly over the serial communication port

Indicator lights and function keys can be custom labeled by the user with plastic inserts. The inserts can be custom legended with text and/or graphics, and slipped into a protective pocket behind the faceplate

The OM1500 Operator Terminal is part of Optimization's OptiMate® series. Each OptiMate module is designed to connect to a microprocessor or most PLC's with a single cable connection. OptiMate modules can be used individually, or together with any combination of other OptiMate modules.

When used with a microprocessor system, simple communications over either an RS232 or RS422 communications cable allows the microprocessor to directly control the lights and LCD display as well as read numeric data entry and function key status.

When used with a PLC, operation is transparent to the user. Terminal functions tie directly into your PLC ladder logic program. The OM1500 takes care of the rest

Applications

- Machine control
- Process control
- Security systems
- HVAC
- Plant monitoring/control
- PLC applications
- Microprocessor applications

Features

- 2 line x 20 character LCD
- Numeric keypad
- 5 User-defined function keys
- 3 LED light bars
- PLC compatible
- RS232/RS422 communications
- Stand alone operation capable
- Multimodule operation capable

Contents


Configuration Options
Stand Alone
PLC Multi-Master
Multidrop
Use with a PLC
Microprocessor-Based
Systems
OptiMate Hex Protocol

SetUp and Interconnect
Legending the Lamps
Connection to the System
Configuration
Configuration Selections
Addressing
Message Definition Template
Label Templates

Specifications

OptiMate is a registered trademark of
Optimization, Inc.
copyright ©1995, Optimization, Inc.

Configuration Options




PLC Stand Alone

OptiMate modules plug directly into most PLCs. A simple cable connection allows you to interface and control the OptiMate module via PLC data registers and ladder logic.

The OM1500 operator terminal uses a bank of PLC registers. Complete Operator interface is performed with 8 PLC registers for display message selection, data entry, function key interface and indicator light control. The OM1500 continuously accesses these PLC registers and performs operations under ladder logic control on a real-time basis.

PLCs are slave devices on their standard communications ports. This means that a panel attached to the standard port must control the transfer of information by reading and writing the PLC registers. OptiMate modules will perform this communications for most major PLC protocols. Configuration for particular PLC protocols and interconnect cabling is covered in the following pages.




PLC Multi Modules

Larger systems involving operator panels can be successfully addressed using OptiMate modules. These applications utilize the OM9001 Communications Master to transfer data between the PLC and the individual OptiMate modules. OptiMate modules can be located together to form custom panels or they can be distributed anywhere within 4000 feet.

The OM9001 Communications Master provides a transparent interface between the PLC and a group of OptiMate modules. The communication interface between modules requires only four wires.

System configuration is simple via an interactive configuration program that runs on any IBM PC compatible computer.

This modular approach to custom applications provides a nearly limitless number of possibilities.



Microprocessor Based Systems

OptiMate modules can interface directly to most computers or microcontrollers. The modules communicate over either RS422 or RS232 serial communications. All that is required to interface OptiMate modules is a serial port. The OptiMate Hex protocol, detailed in this document, allows the user to directly control panel operation and retrieve operator inputs.

Since each module has its own unique address, up to 31 modules can be interfaced on one communications cable.

In a microprocessor-based system, the host microprocessor is the system master. The OptiMate modules are slave devices that respond to commands from the host. In the case of the OM1500, these commands are messages for display and lamp control as well as function button status and data entry retrieval.

Communications over RS422 allows placement of modules anywhere within a 4000 foot cable distance. Modules can be grouped together to form a panel. Modules can be grouped in several clusters all on the same communications cable.

Operational Overview

Displaying Messages on the LCD Display

Through the OptiMate Configuration Editor, up to 160 predefined messages can be entered and stored in the OM1500. These messages are 20 characters long and can include a field for the display and/or entry of numeric data.

Any predefined message can be displayed on either the top or bottom line. The messages entered via the configuration editor are numbered 1 through 160. To display a particular predefined message on the display, simply place that message's number in the message selection register.

For example, let's assume that we have defined message #16 as "Mary had a little .." and message #22 as "white fleeced lamb". If we wanted to put these two lines on the top and bottom lines of the display respectively, we would simply need to put the number 16 in register X and 22 in register X+1.

If any number other than 1 to 160 is placed in a message selection register, the associated line will not change.

Placing Numeric Data in the Display

Certain predefined messages may incorporate a numeric data field. One numeric field per line is allowed. This field may be either a display data field or a data entry field. Messages that contain data are entered through the configuration editor with a caret symbol "^" as a place holder for each numeric digit.

An example of the use of numeric data is the message "#widgets sold:^^^^". Assume that this is message #36 entered through the configuration editor. Also assume that a total of 465 widgets have been sold today. To display the current number of widgets sold on the bottom line of the display, you would place '36' in register X+1 and '465' in register X+4. The bottom line of the display would then read "# widgets sold: 465".

Displaying Data with a Decimal Point

The OM1500 terminal allows you to deal with two types of decimal point numerical displays. These two types are referred to as 1) pseudo-decimal, and 2) variable point decimal.

Pseudo-decimal numbers are numeric values that have a known decimal point placement and are simply handled as inte-

ger values within the PLC program. The only time you use an actual decimal point is for display to the operator. An example of a pseudo-decimal number is a program that uses temperature as a control variable. Within the program, all temperatures are scaled in tenths of a degree. The values are integer. A temperature of 73.5 degrees would be 735 in a data register. For the convenience of the operator, you would want the display to include the decimal.

Variable point numbers include an integer value and a second integer that defines decimal point placement. These numbers are a little more complicated to handle within a PLC program, but may be necessary for certain applications. The OM1500 handles this type of number as an integer value in one register and a second register containing a value, limited from 0 to 5, indicating the number of digits to the right of the decimal point.

Displaying Pseudo-Decimal Numbers

Pseudo-decimal numbers are handled by simply placing a decimal point or period in the message field during configuration. In other words, the message "Temperature : ^^^.^" would be entered during configuration (say message 47). If 47 were placed in register X and the value 735 in register X+2, the display would read "Temperature : 73.5" on the top line.

Displaying Variable Point Numbers

The OptiMate Configuration Editor allows a message to be marked to display a variable point number. When this is done, the OM1500 will use the value in register X+3 (top line) or X+5 (bottom line) for decimal point placement.

Note: A decimal point should not be placed in the configured numeric string for a variable point number.

A typical variable point application might be the display of "Flow factor : ^^^^^" as message 12 selected for variable point display. If '12' is placed in register X+1, 4567 in register X+4 and 3 in register X+5, the bottom line will read "Flow factor : 4.567".

Numeric Data Entry

Numeric data can be entered through either the numeric keypad or the adjustment arrow keys. To do so the message must be marked for data entry in the configuration editor. Additionally, arrow ad-

justment is allowed only if selected in the configuration editor.

Note : Only one data entry message may be active at a time. If data entry is selected simultaneously for both lines, unexpected operation may occur.

All of the numeric features described for data display apply to numeric data entry. This includes the definition of the caret symbol "^" place holder within the message as well as decimal number types.

Data Entry from the Numeric Keypad

A message can be set up for data entry through the Configuration Editor. To do so, simply define the message with the numeric keypad field. For keypad numeric entry, select data entry. If the number is to be variable point, select the variable point option.

When a data entry screen is required in the program, place the number of the preconfigured message in the message selection register. The digits marked by carets in the message definition will initially display as blanks. As numbers are entered by the operator, they will appear in the right-most caret position. Each new digit will be placed in the right-most position and all other digits will be shifted over for each new digit entered. When the ENTER key is pressed, the number entered will be written to the proper data register in the PLC (X+2 or X+4). If the number is variable point, the decimal placement will be placed in the decimal point register (X+3 or X+5). The "data available" status bit (DA) will be set to inform the PLC program that data has been entered.

The OM1500 will automatically handle limitations on data entry. The following limiting actions will occur.

- The numeric entry will be limited to the maximum value that can be held in a 16 bit register (i.e. 65535, or 9999, if BCD)
- The OM1500 will not accept more digits than defined in the message screen.

Example of Keypad Numeric Data Entry

Suppose that you are designing an automatic banana peeler. With the configuration editor you define message 13 as "# of bananas : ^^^". With the configuration editor, you also select keypad data entry and integer.

When it is time to use this message in the display, your PLC program would put

'13' in register X (for top line display). The operator would enter a number and press ENTER. When the operator presses ENTER, the value will be placed in PLC register X+2 and the data available status bit (DA) will be set. **It will remain set until a new message number is placed in register X, or the DAK bit is set.**

Data Entry/Adjustment with the Arrow Keys

There are certain times when you want to have a number adjusted slightly, rather than entered from scratch. This happens many times with setpoints. It is also common when adjusting speeds and rates. When this is done in operation, it is commonly referred to as a "jog" operation.

A message can be set up for arrow adjustment through the Configuration Editor. To do so, define the message with a numeric field. Select arrow adjustment, also select and enter minimum and maximum values.

Note : Arrow adjustment is not available for variable point numbers.

When the data screen is required in the program, place the number of the preconfigured message in the selection register and its current value in the associated data register. The digits marked by carets will initially display the current value.

As the operator presses the up or down arrow key, the numeric value will increment or decrement respectively. As it is adjusted, the value will be continuously updated in the PLC data register. When adjustment is complete, the operator will press the ENTER button. When this happens the data available (DA) status bit will be set. **The DA bit will remain set until a new message number is placed in the message selection register (X or X+1) or the DAK bit is set.**

Adjustment of data will be limited to within the limits defined through the configuration editor. Data also will be limited to the number of digits defined by carets in the message.

Example of Arrow Adjustment of Numeric Data

Suppose that your automatic banana peeler has a peel rate that can be adjusted between 1 and 50 bananas per second. With the configuration editor you define message 15 as "Set Peel Rate : ^.^.". You would also select arrow adjustment and range limits of 10 to 500 (in tenths).

When this message is used, your PLC program would put 15 in register X (or

X+1) and the current peel rate value in X+2 (or X+4). If the current peel rate was 5.7 bananas per second, the display would read "Set Peel Rate : 5.7". Pressing the arrow keys would adjust the value up or down while continuously writing the value to data register X+2 (or X+4). When the adjustment is complete, the operator would press ENTER. The OM1500 will then set DA. DA will remain set until a new message is selected via X (or X+1) or the DAK bit is set.

Function Buttons

The OM1500 contains five user-definable function buttons. These buttons can be custom labeled and used for any purpose.

The buttons can be individually configured as either alternate-action or momentary pushbuttons. Alternate-action buttons alternate state each time they are pressed. Momentary buttons are active only while they are being pressed.

The status register holds the current state of each of the five buttons. In a typical PLC application, these buttons would be mapped to control contacts for easy ladder logic interface.

Indicator Lights

Three general purpose indicator lights are located above the LCD display. These lights can be custom labeled and used for any purpose.

There are two control bits for each light in the control register. One bit controls whether the light is on or off. The other bit controls whether the light is flashing. The light must be turned on in order to flash.

In a typical PLC application, these bits would be mapped to control coils for easy ladder logic interface.

Configuration

Configuration of the OM1500 Terminal or system of OptiMate modules is performed via an IBM PC compatible computer. Optimization supplies configuration software that will allow you to select module configuration, system configuration and PLC protocol definition.

If the OM1500 is to be operated stand alone with a PLC, the configuration selection must be made to select the proper PLC protocol information. If it is part of a multi-module system, it must be configured for OptiMate Hex protocol.

Note : When configuring, always remember to set the module ad-

dress to address 31 (switches 1-5 on, switch 6 OFF).

Specific configuration of the OM1500 begins with defining the block of PLC register data to be used. Next, each of the function buttons must be configured for either momentary or alternate-action operation. Then each of the messages used by the PLC program must be defined.

Message definition is very straightforward and easily accomplished. All that is necessary is the following sequence.

- Select the message number to enter.
- Type the message. Up to 20 characters are allowed. Any unused characters will be filled with blanks. One numeric field may be defined with caret '^' characters. One decimal point or colon may be placed within the field.
- If the message has a field for numeric keypad data entry, select keypad data entry. Select variable point if the number is variable point (may not be used if a predefined decimal point is placed in the message).
- If the message has a field for numeric arrow (jog) adjustment, select arrow adjustment. Select and enter minimum and maximum values. Arrow adjustments are allowed only for integer and pseudo-decimal numbers.

Examples of Use with a PLC Direct PLC

Register Usage


The OptiMate Configuration Editor allows you to configure a module to use a block of registers at a starting value that you define. For a PLC Direct 205 or 405 PLC the recommended memory to use is the general purpose data words starting at V2000 and V4000. For the 305 family, the recommended memory is the registers beginning at R400. Any block of registers within the data word range can be used.

The first six PLC registers in the block used by the OM1500 panel are used for numeric information. As such they are ideally suited for the general purpose data registers (V2000 and V4000 area for the 205/405 and R400 range for the 305). The last two registers use individual bits for control and status. These registers are better suited for the control relay register range of memory. The solution to this minor conflict is to define the base register address in general purpose data register memory and place a rung in your PLC program to copy the last two registers to/from control relay registers.

The following table lists the control relay register addresses for the various PLC Direct PLCs.

PLC Direct CPU	Control Relay Register address range
DL230	V40600-V40617
DL240	V40600-V40617
DL330	R016-R037
DL330P	R016-R017 and R020-R027
DL340	R016-R037 and R100-R106
DL430	V40600-V40635
DL440	V40600-V40677

The examples on the following pages use an OM1500 connected to a PLC Direct 205/405 series PLC. The OM1500 is configured for a base address of V2000. **The following program rung should be placed in the program to copy the status register to V40600 and copy from V40601 to the control register.**



With rung placed into the PLC program, the status and control bits will be control relays. The register association is shown in the figure below.


	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	bit
Register	MSB															LSB	
V40600	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	Status Register
V40601	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	Control Register

This will result in the following control relay association for the status and control registers.

Status Register			Control Register	
bit	relay		bit	relay
F1	C0		L1	C20
F2	C1		L2	C21
F3	C2		L3	C22
F4	C3		L1F	C23
F5	C4		L2F	C24
DA	C5		L3F	C25
ENT	C11		DAK	C26
Up arrow	C12		BD	C31
Dn arrow	C13			


Lighting a Light

Lighting a light simply requires activating the control relay associated with the light. The following example will light the first light when input X7 is active (Remember to place the register copy rung described previously in the program).




Flashing a Light

Flashing a light requires activating the control relay to turn the light on and the flash control relay. The following example will flash the first light when input X7 is active.




Using a Function Button

The five function buttons below the LCD display will appear as control relay coils in your program (assuming the register copy rung described previously is in your program). The following example lights light L1 when button F1 is active.




Displaying Messages on the LCD Display

Messages of various types can be configured via the OptiMate Configuration Editor and downloaded to the OM1500. The message definitions shown in the figure below will be used in all of the examples that follow.




The following example shows a couple of messages being displayed to the LCD display. The top line uses data display message 4. The data for the data field is coming from V2032. The bottom line is text message 8.



Entering Data from the Keypad

The example shown next illustrates keypad data entry. When control relay C64 is active, the top rung of the program will cause the messages shown to be projected on the display. The message shown on the top line is a keypad data entry message.

When the operator enters data on the keypad and presses "ENTER", the OM1500 sets the DA bit (energizes C5). The second program rung shows that when data is available, it will be transferred to V2060 and the data acknowledge bit set. When the OM1500 sees the data acknowledge bit set (C26), it will clear the data available.





Arrow Adjustment of Setpoint Data

The figure below illustrates arrow adjustment of setpoint data (and a whole lot more). The process is enabled when C74 is energized. The first program rung places the "Enter Setpoint" and "Display Setpoint" messages in the top and bottom lines, initializes the setpoint value from the value in V2114, and enables the second rung.

The second rung continually copies the setpoint value to the display value so long as it is enabled. It latches itself until unlatched by the next rung, also disabling the first rung.

The third rung waits until the data available flag is set (C5), then copies the setpoint back to V2114. It also unlatches the second rung and, by activating C77, enables the next block of logic (whatever that might be) in the program.



Examples of Use with an Allen Bradley PLC

Interfacing to A/B Memory


OptiMate modules interface to Allen Bradley SLC 5/03, SLC 5/04 and Micrologix PLCs via integer file type N. The 5/03 and 5/04 have file type N7 as standard. Other "N" type files can be created. The Micrologix has a fixed file type N7. Please refer to Allen Bradley documentation for information on setting up and using "N" type files.

All of the examples that follow assume that the OM1500 module has been configured, through the OptiMate Configuration Editor, for a file number 7 and base register address 0. With this configuration, the status and control registers will be at N7:6 and N7:7 respectively. The following is a table relating status and control register bits to their N7 locations.

Status Register		Control Register	
bit	location	bit	location
F1	N7:6/0	L1	N7:7/0
F2	N7:6/1	L2	N7:7/1
F3	N7:6/2	L3	N7:7/2
F4	N7:6/3	L1F	N7:7/3
F5	N7:6/4	L2F	N7:7/4
DA	N7:6/5	L3F	N7:7/5
ENT	N7:6/9	DAK	N7:7/6
Up arrow	N7:6/10	BD	N7:7/9
Dn arrow	N7:6/11		


Lighting a Light

Lighting a light simply requires activating the register bit associated with the light. The easiest way to do this is to use the bit as a relay coil in the PLC program. The following example will light the first light when input I:2/12 is active.




Flashing a Light

Flashing a light requires activating the register bit to turn on the light and the flash control register bit. The following example will flash the first light when input I:2/12 is active.





Using a Function Button

The five function buttons below the LCD display will appear as control relay coils in your program. The following example lights light L1 when button F2 is active.



Displaying Messages on the LCD Display

Messages of various types can be configured via the OptiMate Configuration Editor and downloaded to the OM1500. The message definitions shown in the figure below will be used in all of the examples that follow.





Arrow Adjustment of Setpoint Data

The figure below illustrates arrow adjustment of setpoint data (and a whole lot more). The process is enabled when B3/0 is energized. The first program rung places the “Enter Setpoint” and “Display Setpoint” messages in the top and bottom lines, initializes the setpoint value from the value in N7:37, and enables the second rung.

The second rung continually copies the setpoint value to the display value so long as it is enabled. It latches itself until unlatched by the next rung, while disabling the first rung.

The following example shows a couple of messages being displayed to the LCD display. The top line uses data display message 4. The data for the data field is coming from N7:54. The bottom line is text message 8.



The third rung waits until the data available flag is set (N7:6/5), then copies the setpoint back to N7:37. It also unlatches the second rung and, by activating B3/3, enables the next block of logic (whatever that might be) in the program.

Entering Data from the Keypad

The example shown next illustrates keypad data entry. When N7:54/12 is active, the top rung of the program will cause the messages shown to be projected on the display. The message shown on the top line is a keypad data entry message.

When the operator enters data on the keypad and presses “ENTER”, the OM1500 sets the DA bit (energizes N7:6/5). The second program rung shows that when data is available, it will be transferred to N7:60 and the data acknowledge bit set. When the OM1500 sees the data acknowledge bit set (N7:7/6), it will clear the data available.

Use in a Microprocessor-Based System

OptiMate modules can interface a microprocessor-based controller over a serial link. This link can be either RS232 (for point to point) or RS422 (for multidrop or point to point). In either case the microprocessor acts as the master. It can write data to the module or read data from the module.

The OM1500 uses OptiMate Hex protocol for fast and easy communications. The OptiMate Hex protocol is defined in subsequent pages.

Module Address

A six-position DIP switch on the back of each OptiMate module provides a method for setting the address. By use of this DIP switch you can set the module address to any number between 0 and 31. (The sixth switch connects a terminating resistor ON only on the last module of an RS422 cable and should be OFF in all other cases.)

Communications Protocols

To use an OptiMate module as a slave device in a microprocessor-based system, the module must be configured for OptiMate Hex protocol. The other options that must be set are baud rate, parity and number of stop bits (note: if parity is set to even or odd, only one stop bit is allowed). Once selected, it must be downloaded to the module.

The OM1500 protocol for computer based operation is OptiMate Hex protocol.

Computer-Based Operation

All of the basic functionality described for PLC operation is also available to computer or microprocessor-based applications. In addition, computer-based systems can send messages directly for display on the LCD display.

The following is a synopsis of the OM1500 operation as it relates to computer-based applications. In certain cases, more detail is provided under the same topic for PLC operation. The details of messages involved are covered in the protocol documentation which follows.

Displaying Messages on the LCD Display

Under computer-based operation, the OM1500 can be instructed to display either predefined messages or display a message string transmitted over the serial port. Selection of a predefined message simply requires transmitting a command which selects the particular message.

Placing Numeric Data in the Display

Any message containing caret '^' place holders will allow either the display of numeric data or numeric data entry. This applies to both the predefined messages and messages sent directly from the computer host.

Numeric data for the numeric data field can be transmitted by the host computer. If it is a display data field, it may be continuously updated. If it is a data adjustment message (arrow key adjustment), only the first value transmission will be accepted. Keypad numeric data messages do not accept values.

Data Entry from the Numeric Keypad

A predefined message can be set up for numeric data entry through the Configuration Editor. A message can also be sent for data entry directly from the computer host. In either case, the numeric entry process on the OM1500 is the same.

When a number entry field is selected or transmitted for display, the digits marked with caret symbols will initially display as blanks. As numbers are entered by the operator, they will appear in the

right-most caret position. Each new digit will be placed in the right-most position and all other digits will be shifted over for each new digit entry. When ENTER is pressed, the number entered will become available to be read by the host.

The OM1500 will automatically handle limitations on data entry. The following limiting actions will occur.

- The numeric entry will be limited to the maximum value that can be held in a 16 bit integer (i.e. 65535, or 9999, if BCD).
- The OM1500 will not accept more digits than defined in the message screen.

Example of Keypad Numeric Data Entry

Suppose that you are designing an automatic bread buttering machine. With the configuration editor you define message 17 as "# of slices : ^^". With the configuration editor, you also select data entry and integer.

When it is time to use this message in the display, your program transmits a message selection for message 17. The operator would enter a number and press ENTER. When the operator presses ENTER, the data available status bit will be set. When the computer host reads the data, the bit will clear.

Data Entry/Adjustment with the Arrow Keys

There are certain times when you want to have a number adjusted slightly, rather than entered from scratch. This happens many times with setpoints. It is also common when adjusting speeds and rates. When this is done in operation, it is commonly referred to as a "jog" operation.

A message can be set up for arrow adjustment either through the Configuration Editor or directly transmitted by the host.

Note : Arrow adjustment is not available for variable point numbers.

When the data screen is required in the program, either transmit a command for the the preconfigured message and send its current value, or download both the

message text and the current value. The digits marked by carets will initially display the current value.

As the operator presses the up or down arrow key, the numeric value will increment or decrement respectively. As it is adjusted, the value is continuously available to be read by the host computer. When adjustment is complete, the operator will press the ENTER button. When this happens the data available status bit will be set. When the computer host reads the data, the bit will clear.

Adjustment of data will be limited to within the limits defined through the configuration editor. Data also will be limited to the number of digits defined by carets in the message.

Function Buttons

The OM1500 contains five user-definable function buttons. These buttons can be custom labeled and used for any purpose.

The buttons can be individually configured as either alternate-action or momentary pushbuttons. Alternate-action buttons alternate state each time they are pressed. Momentary buttons are active only while they are being pressed.

The status request message will return the current state of each of the five buttons along with other status.

Indicator Lights

Three general purpose indicator lights are located above the LCD display. These lights can be custom labeled and used for any purpose.

There are messages defined that allow the host computer to control the on/of state and flash condition of each light.

OptiMate OM1500 Hex Protocol

General Format

STX Module function ftn_data checksum
address

where Module address = 0 to 30
Function = 0xA0 : General status/control
 = 0xA1 : Select predefined message display
 = 0xA2 : Send message text
 = 0xA3 : Send keyboard data entry message
 = 0xA4 : Send arrow key data adjustment message
 = 0xA5 : Read operator entered data
 = 0xA6 : Send data display message
 = 0xA7 : Send data for data display message
ftn_data = Data specific to the function
checksum = 8 bit sum of all characters after address
 until checksum

Note : Spaces are shown for readability only. There no spaces between message fields

General status/control

STX Module 0xA0 control1 control2 checksum
address

where control1 = lamp control bits
 bits 0, 1, 2 = lamp on off control for lamps 1 - 3 respectively
 bits 3, 4, 5 = lamp flash control for lamps 1 - 3 respectively
control2 = misc control bits
 bit 0 : Buzzer disable
 bit 1 : Data acknowledge

Response

STX term_stat disp_stat checksum if message received and processed OK

where term_stat = terminal status
 bits 0 - 4 = Button status for function buttons 1 - 5 respectively
 1 = button active, 0 = button inactive
 bit 5 = operator entered data available
 1 = data available
 bit 6 = Up arrow
 bit 7 = Down arrow
disp_stat = display status (1 = TRUE)
 bit 0 : Top line display data
 bit 1 : Top line arrow adjust
 bit 2 : Top line KB data entry
 bit 3 : Bottom line display data
 bit 4 : Bottom line arrow adjust
 bit 5 : Bottom line KB data entry
 bit 6 : Enter button

or
NAK if any errors in message

Select Predefined message

STX Module 0xA1 line mesg_no data checksum
address

where line = top (0x00) or bottom (0x01) line
mesg_no = number of the predefined (through configuration editor) message
 0 - 71, hex integer, i.e. 33 = 0x21
data = 16 bit integer value plus DP placement (high byte, low byte, DP)
 Used as display data for numeric data display message.
 Used as initial value for arrow adjustment type message (integer
 portion only). Ignored for all other message types

Response

ACK if message received and processed OK
or
NAK if any errors in message

Send message text

STX Module 0xA2 line text checksum
address

where line = top (0x00) or bottom (0x01) line
text = 20 character ASCII test message
example : STX 0x02 0xA2 0x00 Place Part in Collet 0x??(checksum)
 Will display "Place Part in Collet" on the top line

Response

ACK if message received and processed OK
or
NAK if any errors in message

Send keyboard data entry message

STX Module 0xA3 line text checksum
address

where line = top (0x00) or bottom (0x01) line for variable point data entry
 top (0x02) or bottom (0x03) line for integer or fixed point data entry
text = 20 character ASCII test message including caret characters for
 numeric data entry placeholders
example : STX 0x02 0xA3 0x01 Number of Parts: ^^^ 0x??(checksum)
 Will display "Number of parts: " on the bottom line and allow a three digit
 number to display in the last 3 positions on the line

Response

ACK if message received and processed OK
or
NAK if any errors in message

Send arrow key data adjustment message

STX Module 0xA4 line text minimum maximum curr_val checksum
address

where line = top (0x00) or bottom (0x01) line
text = 20 character ASCII test message including caret characters for numeric data entry placeholders
minimum = minimum value allowed (16 bit integer, high byte, low byte)
maximum = maximum value allowed (16 bit integer, high byte, low byte)
curr_val = current value (16 bit integer, high byte, low byte)
example : STX 0x02 0xA4 0x01 Number of Parts: ^^^ 0x00 0x01 0x03 0x84 0x00 0x7B0x??(checksum)
Will display "Number of parts: 123" on the bottom line and allow a three digit number (between 1 and 900) to display in the last 3 positions on the line

Response

ACK if message received and processed OK
or
NAK if any errors in message

Read Operator Entered Data

STX Module 0xA5 checksum
address

Response

STX status data checksum if message received and processed OK
where status = 0x00 if ENTER key has not been pressed
data = 0x01 if ENTER key has been pressed
data = operator entered data (16 bit integer + decimal placement, high byte, low byte, DP)
Notes : 1) This message can be used to read value of an arrow adjusted value while it is being adjusted.
or
NAK if any errors in message

Send data display message

STX Module 0xA6 line text curr_val checksum
address

where line = top (0x00) or bottom (0x01) line
text = 20 character ASCII test message including caret characters for numeric data entry placeholders
curr_val = current value (16 bit integer + decimal placement, high byte, low byte, DP)
example : STX 0x02 0xA6 0x01 -Shift Total- ^^^ 0x03 0x81 0x00 0x??(checksum)
Will display "-Shift Total- : 897" on the bottom line and allow a three digit number (between 1 and 900) to display in the last 3 positions on the line

Response

ACK if message received and processed OK
or
NAK if any errors in message

Send data for data display message

STX Module 0xA7 line curr_val checksum
address

where line = top (0x00) or bottom (0x01) line
curr_val = current value (16 bit integer, high byte, low byte)
example : STX 0x02 0xA6 0x00 0x03 0xE8 0x01 0x92
Will display "100.0" in the numeric display position of the message
Note : If the message has a fixed decimal place, the transmitted decimal position will be ignored. In other words, if the same command had been sent to a line containing the predefined message "Tank 3 level : ^^^", the display would project "Tank 3 level : 10.00"

Response

ACK if message received and processed OK
or
NAK if any errors in message

Display status request

STX Module 0xA9 checksum
address

Response

STX top_msg bot_msg checksum if message received and processed OK
where top_msg = last predefined message selected for top line
bot_msg = last predefined message selected for bottom line
or
NAK if any errors in message

Broadcast message (sent to all modules)**Synchronize lamp flashing (between all system lamp modules)**

STX Broadcast function checksum
address


where broadcast address = 99
function = 0

Set Up and Interconnect


Legending the Lamps and Function Keys

Legending the OM1500 module is a relatively simple process that basically involves sliding legend transparencies into pockets in the panel overlay. Use the following procedure.

- Remove the bezel from the module. The bezel snaps to the module box along the top and bottom edges. Pull the bezel out and over the snaps to remove.



- Create legend transparencies. There are a number of available options for doing so. Patterns are provided on the next to last sheet of this document.
 - > Use a computer graphics program and a laser printer to create the transparency directly. Alternately print on paper and photocopy to a transparency.
 - > Use press-on letters onto a transparency sheet.
 - > Use a typewriter or lettering machine to letter onto paper, then photocopy



- Cut along outline. Slide into overlay pocket. Lamp legends slide in from the top. Pushbutton legends slide in from the bottom.
- Re-attach bezel. Push bezel onto box until it snaps together.

Connection to the System

OptiMate modules are designed for communications connection to system devices. The module can be connected to a computer, PLC or communication master over the serial port (RS232 or RS422).

Connection to a Computer or PLC

Connection of an OptiMate module to a computer or PLC can be accomplished over either an RS232 or RS422 link. RS232 is limited to one OptiMate module to one computer serial port. RS422 allows up to 31 modules to be connected to one computer port. Since PLCs are slave devices, the RS422 link for a PLC is limited to one OptiMate module.

OptiMate Module RS232		OptiMate Module RS422	
Host Computer/PLC	OptiMate Module DB-15 Male	Host Computer/PLC	OptiMate Module DB-15 Male
TX	3 RS232 RX	TX+	9 RS422 RX+
RX	2 RS232 TX	TX-	10 RS422 RX-
Sig Gnd	5 Sig Gnd	RX+	11 RS422 TX+
		RX-	12 RS422 TX-

Refer to manufacturer's documentation for PLC or computer serial link connector pinouts.

Optimization sells interface cables for connection to several different PLCs as well as to IBM PCAT compatible ports.

Serial Connection to Communications Master

Connection to an Optimization Communications Master over a serial link is via RS422. The Communication master port connections are reversed from the module ports to enable direct pin to pin connection. For distances under 50 feet (in a low electrical noise environment), a ribbon cable connection works quite well. For longer distances or in noisy environments, a two pair shielded RS422 cable is recommended.

Configuration Selections

OptiMate modules can be configured for the specific application by using the OptiMate Configuration Editor. The Configuration Editor runs on any IBM PC compatible computer. It allows the user to select the exact functionality to meet application requirements.

For the OM1500 module, the following are important configuration parameters.

Computer-Based Systems

Decision	Selection
Single/Multi Module	Choose Single module even if the system will contain several modules. The Multi module selection applies only to systems using a communications master. In computer-based systems, each module is configured independently. After configuration, multiple modules can be connected together to form a system.
Configuration starting point	First-time configuration, start with defaults for module. Subsequent configurations can utilize disk files you create.
PLC Type	Select OptiMate Hex
Protocol	Select appropriate baud rate, 8 data bits, #stop bits & parity. Note that if even or odd parity selected, only 1 stop bit is available.
Buttons	Select momentary or alternate action as required for your application
Messages	Define messages as required for your application

Configuration must be downloaded from IBM PC compatible to the module. This is done over the serial link. Module address must be set to 31 prior to application of power for module to accept configuration data. The termination DIP switch should always be OFF during configuration. Communication cable is available from Optimization. After configuring, module address should be changed to any address other than 31 to enable the module to communicate with the PLC.

Single Module PLC-Based Systems

Decision	Selection
Single/Multi Module	Choose single module configuration
Configuration starting point	First-time configuration start with defaults for module. Subsequent configurations can utilize disk files you create
PLC Type	Select appropriate PLC type
Protocol	Select appropriate baud rate, # data bits, # stop bits & parity. Note that if 8 data bits and even or odd parity selected, only 1 stop bit is available
Buttons	Select momentary or alternate action as required for your application
Messages	Define messages as required for your application

Configuration must be downloaded from IBM PC compatible to the module. This is done over the serial link. Module address must be set to 31 prior to application of power for module to accept configuration data. The termination DIP switch should always be OFF during configuration. Communication cable is available from Optimization. After configuring, module address should be changed to any address other than 31 to enable the module to communicate with the PLC.


Multi-Module PLC Applications (Uses Communications Master)

Decision	Selection
Single/Multi Module	Choose Multi module
PLC Type	This applies to the Communications master. Choose appropriate type
Protocol	This applies to the Communications master. Choose appropriate baud rate, # bits, # Stop bits & parity. Note that if 8 data bits and even or odd parity are selected, only 1 stop bit is available.
Module Protocol	Choose Optimate Hex
Buttons	Select momentary or alternate action as required for your application.
Messages	Define messages as required for your application.

Configuration must be downloaded from IBM PC compatible to the module. This is done over the serial link. Module address must be set to 31 prior to application of power for module to accept configuration data. The termination DIP switch should always be OFF during configuration. Communication cable is available from Optimization. After configuring, module address should be changed to any address other than 31 to enable the module to communicate with the PLC.

Addressing

Setting the module address is a matter of turning the module over and pressing the appropriate dip switches. There are 6 DIP switches; 5 of which have a numeric value listed next to the switch. To select an address, push (with a pencil or small screwdriver) the appropriate combination of switches down to the right.




For example to select address 14, the 2, 4 and 8 switches should be pressed down to the right and the 1 and 16 switches down to the left.

Remember that for configuration, address 31 (numeric switches 1-16 on) must be selected first, then apply power to the module.


The termination switch must always remain in the OFF position unless the module is the last, and only the last, module on the cable in an RS422 system.

Power

OptiMate modules can operate on any voltage between 8 and 30 VDC. Power must be connected to the terminal plug located on the back of the module.



Lamp Label Strip Pattern




Pushbutton Label Strip Pattern

Specifications

Physical

- Recessed Mount
Housing 9.5"L x 4.0"H x 1.75"D
- Cutout size for above
3.56"H x 8.46"L
- Panel Fasteners :
Four, 6x32 threaded studs, shown above (on ends, symmetrical about center line)
- Weight : 19 ounces
- Colors : Dark gray housing with black panel. Numeric keys; blue with white letters. Other keypad keys; gray with white letters. Function keys ; White with user-supplied label.
- Lamp Colors : Red, Yellow, Green
- LCD Display : 2 line x 20 character STN with LED backlight
character size : 5.5mm high x 3.2mm wide



Message Types (160 user-defined messages available)

- General Text message
- Data display message (one data value per line)
- Keypad data entry (Integer, fixed point, or variable point)
- Arrow adjustment data message (Integer or fixed point)

Numeric Types & Values

- Integer
- Fixed Point (Pseudo-decimal)
- Variable Point
- BCD (Values between 0 & 9999; with appropriate decimal placement)
- Binary (Values between 0 & 65535 with appropriate decimal placement)

Electrical

- Power (all lamps on) : 8 - 30VDC @ 5.7Watts
420 mA @ 12VDC 240 mA @ 24VDC
- Power connector : Pluggable terminal block, 2 position

Communications

- RS232 and RS422
- 4800 to 19200 baud
- Compatible with most major PLC protocols
- OptiMate Hex Protocol for computer based systems
- 15 pin female 'D' shell connector

Communications Failure Operation

Should the module (when set to any address other than 31) ever fail to communicate successfully for a period of 12 seconds, the LCD display will flash "Host Comm Fail!"

Environmental

- Enclosure - NEMA 4 (when properly installed)
- Temperature- 0 to 50 C
- Humidity - 95% Non-condensing