

HONGER COMBINED DECOILER STRAIGHTENER

1. CL for small inner diameter coil

Model	CL-150	CL-200	CL-300	CL-400
Coil Width (mm)	100	200	300	400
Coil Thickness (mm)	0.4-2.2			
Coil I.D. (mm)	50-530			
Coil O.D. (mm)	1000			
Loading Capacity (kgs)	300	400	450	500
Expansion	Manual			
Straightener Roller	Ø52mm*7pcs			
Straightener Motor (HP)	1	1	2	3
Roller Pressing	4 points			
Roller Adjustment	Spring Adjusting			
Inverter	Without			
Feeding Speed (m/min)	16			
Uncoiler Motor	Non-motorized			

2. GO for material thickness 0.4-2.2mm

Model	GO-200	GO-300	GO-400	GO-500	GO-600
Coil Width (mm)	200	300	400	500	600
Coil Thickness (mm)	0.4-2.2				
Coil I.D. (mm)	450-530				
Coil O.D. (mm)	1200				
Loading Capacity (kgs)	800	1000	1500	2000	2500
Expansion	Manual				
Straightener Roller	Ø52mm*7pcs				
Straightener Motor (HP)	1	2	2	3	3
Roller Pressing	4 points				
Roller Adjustment	Spring Adjusting				
Inverter	Without				
Feeding Speed (m/min)	16				
Uncoiler Motor	Non-motorized				

3. GL high precision for material thickness 0.3-3.5mm

Model	GL-200	GL-300	GL-400	GL-500	GL-600
Coil Width (mm)	200	300	400	500	600
Coil Thickness (mm)	0.3-3.5				
Coil I.D. (mm)	460-520				
Coil O.D. (mm)	1200				
Loading Capacity (kgs)	600	1000	1500	2000	2000
Expansion	Manual				
Straightener Roller	Ø48mm*7pcs				
Straightener Motor (HP)	1	2	2	3	3
Roller Pressing	Pneumatic Rod				
Roller Adjustment	Eccentric turbine worm adjusting				
Inverter	Delta, Taiwan				
Feeding Speed (m/min)	16				
Uncoiler Motor	Non-motorized				

4. GL-H high precision for material thickness 0.5-4.5mm

Model	GL-300H	GL-400H	GL-500H	GL-600H
Coil Width (mm)	300	400	500	600
Coil Thickness (mm)	0.5-4.5			
Coil I.D. (mm)	460-520			
Coil O.D. (mm)	1200			
Loading Capacity (kgs)	2000	2000	2000	5000
Expansion	Manual			
Straightener Roller	Ø68mm*7pcs			
Straightener Motor	2.2kW	2.2kW	4.4kW	4.4kW
Roller Pressing	Pneumatic Rod			
Roller Adjustment	Eccentric turbine worm adjusting			
Inverter	Delta, Taiwan			
Feeding Speed (m/min)	16			
Uncoiler Motor	1.5kW	1.5kW	1.5kW	2.2kW

Please contact with our sales team to find a suitable configuration for your material:

Email: export@he-machine.com

Tel: +86 755 28372363

Add: F1601-02, A4 Bldg Zhujiang Plaza, Longgang, Shenzhen, 518172, China

www.hongerjixie.com