


H4S 中英文爆炸图 (H4S Spare Parts List)



S/N	Ref. No.	品名	Description
1	89125	把手套 (2)	handle grips (2)
2	89119	弹簧	latch spring
3	89123	卡爪销	latch pin
4	89115	卡爪	jaw
5	89122	刀轮销定位卡簧 (4)	ring (4)
6	03027	弹性圆柱销 8*55 (2)	guide pin 8*55 (2)
7	89116	卡管爪 (2)	guide (2)
8	89124	固定滚轮刀架销	lower yoke pin
9	89112	固定滚轮刀架	lower yoke
10	01879	锁紧螺母 M8	locknut M8
11	01230	六角纹制孔用螺栓 M8*45	hinge bolt M8*45
12	89126	4"割刀片 (4)	cutter wheel (4)
13	89121	刀轮销 (4)	wheel pin (4)
14	89113	移动滚轮刀架	crosshead
15	89120	垫	thrust washer
16	89118	扭簧	guide spring
17	89117	螺母	crosshead locknut
18	01610	开槽锥端紧定螺钉 M8*8 (2)	set screws M8*8 (2)
19	89111	割刀架	upper yoke
20	89114	手柄焊接件	screw handle