


H14S 中英文爆炸图 (H14S Spare Parts List)



S/N	Ref. No.	品名	Description
1	09420	弹性垫圈 (3)	washer ( 3 )
2	09361	六角螺母 (3)	Hex nut ( 3 )
3	89413	滚轮 (8)	Roller ( 8 )
4	89419	割刀片 (4)	cutter wheel ( 4 )
5	09020	六角头螺栓 (3)	bolt ( 3 )
6	89423	定位爪 (2)	guide ( 2 )
7	89417	右旋活节螺栓 (2)	right-hand bolt ( 2 )
8	89411	扭簧 (2)	guide spring ( 2 )
9	03032	重型直槽弹性圆柱销 8*95 (2)	heavy-duty guide pin ( 2 )
10	89421	进刀螺母 (2)	feeding nut ( 2 )
11	89415	左旋活节螺栓 (2)	left-hand bolt ( 2 )
12	89425	割刀架 (2)	yoke ( 2 )
13	89490	割刀轴总成 (4)	wheel pin complete ( 4 )
14	89491	定位杆总成	yoke pin
15	89492	扳手总成	handle complete