

KEYENCE **Touch Panel Display** VT Series **Extension Unit** VT3-VD4/VD1/R1/E3 (for VT3 Series) VT2-E1/P1/E2/P2 (for VT3/VT2 Series)

Instruction Manual



Preface

This document describes how to install and set up the Touch Panel Display VT3/VT2 Series hardware.

Before you start to use the Touch Panel Display VT3 Series, be sure to thoroughly read this document in order to fully understand the functions of the Touch Panel Display VT3/ VT2 Series and VT STUDIO/VT2 BUILDER.

Store this document in a safe place so that you can retrieve it whenever necessary.

Symbols

This manual uses the following symbols to alert you to important information.



WARNING Failure to follow these instructions may lead to injury.

CAUTION Failure to follow these instructions may lead to physical

damage (product malfunction, etc.).

Important: Provides additional information on precautions and restrictions that must be followed in operation.

Note: Provides additional information on proper operation.

[Tip]

Indicates useful information or information that aids understanding of text descriptions.

Request

- (1) No part of this instruction may be reprinted or reproduced without the prior written permission of KEYENCE CORPORATION.
- (2) The contents of this manual are subject to change without notice.
- (3) Every effort has been made in preparing this document. If, however, you find any unclear points, errors, omissions or other inconsistencies, please feel free to contact us.
- (4) Note that KEYENCE CORPORATION shall not be liable for any influence resulting from operation of the VT series regardless of item (3) above.
- (5) We shall replace any missing or incorrectly collated pages.

Trademarks

- · Windows is a registered trademark of Microsoft Corporation of the United States.
- Pentium is a registered trademark of Intel Corporation.
- Other company names, product names, and model names used in this manual are trademarks or registered trademarks of their respective companies.
- UNLHA32 and DLL are public domain software made by Micco.

Safety Precautions

General Precautions

- At startup and during operation, be sure to monitor the functions and performance of the VT3 series
- We recommend that you take substantial safety measures to avoid any damage in the event that a problem occurs.
- Do not modify the VT3 series or use it in any way other than described in the specifications. The functions and performance of products used or modified in this way cannot be assured.
- When the VT3 series is used in combination with other instruments, functions and performance
 may be degraded, depending on operating conditions and the surrounding environment.
- Do not subject instruments including peripheral devices to sudden changes in temperature. Doing so might cause condensation which may cause the instrument or device to malfunction.
- Mount the VT3 as far away as possible from power lines or high-voltage lines. Noise from power lines and high-voltage lines may cause the VT3 to malfunction.

WARNING

The VT STUDIO VT-H5G/VT-H5J system disc is a DVD. Do not play this disc in an audio player. Otherwise, your hearing and/or the speakers may be damaged by sudden high volume sound.

- Do not use the touch panel (touch switches), cross-key pads or push-button switches on the switch unit to make switches that may affect human life or lead to product damage. Also, design a system that is adaptable to touch panel (touch switches), cross-key pad or push-button switches on the switch unit malfunction.
- Do not touch the touch panel or touch switches with a sharp-pointed object such as a pen or screwdriver. Doing so might scratch the touch panel or touch switches or cause them to malfunction.
- Do not subject the touch panel (touch switches), cross-key pad or push-button switches on the switch unit to shock or impact, or touch them with more than necessary force. Doing so might damage them.
- Never wipe the display with paint thinner or organic solvents. Doing so might damage the display. When wiping the display, use a soft cloth moistened with watered down neutral detergent.
- Do not copy copyrighted fonts and image data onto this unit for use as this infringes on the copyright.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Request

When using the VT3 series under conditions and environment indicated below, use with sufficient margin with respect to ratings and functions, adopt safety countermeasures such as fail-safe measures, and consult your sales representative.

- · Use under conditions and environment not described in this manual
- Use for nuclear power control, railroad facilities, aircraft facilities, vehicles, combustion units, medical equipment, amusement machines, and safety devices
- Use in applications where a major influence on human life or property is anticipated, and where safety in particular is required

About CE Marking and UL Approval

For details on precautions for CE marking and for UL Approval, refer to the VT3 Series Hardware Manual "3-1 Operating Environment", and the VT2 Series Hardware Manual "3-1 Operating Environment".

Operating Environment

Installation location

Do not install the VT3 in the following places.



* When the ambient temperature is higher than 40°C, please use it at a maximum absolute humidity of 85% RH at 40°C.

Install the VT3 as far away as possible from locations where radios, etc. are located. Radio waves emitted by the VT3 may cause noise to occur on the radio.

List of Supported Devices

						٧٦	r3 S	Seri	es				VT2 Series									
Op	lion	X15(D)	S12(D)	S10	V10(D)	8A	V7	V6H(G)	Q5H(G)	Q5T(W)/Q5T(W)A	Q5S(W)	Q5M(W)/Q5M(W)A	W4	12F	10F	107	10S	8T	7S	5T	5S	M5
	VT3-VD1	0	0	0	0	0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	Ι
Video Unit	VT3-VD4	0	0	0	0	0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	VT3-R1*	0	0	0	0	0	-	-	-	-	-	-	-	١	-	-	-	١	-	-	-	-
	VT2-E1/P1	0	0	0	0	0	0	-	-	0	0	-	-	0	0	0	0	0	0	0	0	-
Ethernet Printer Unit	VT2-E2/P2	0	0	0	0	0	0	-	-	0	0	-	-	0	0	0	0	0	0	0	0	-
Finiter Onit	VT3-E3	0	0	0	0	0	0	-	-	0	0	-	-	١	-	-	-	١	-	-	-	-

* VT3-R1 can only be used with the VT3 system of version 2.23 or higher.

Video Unit (VT3-X15(D)/S12(D)/S10/V10(D)/V8)

The Video Unit can be used to display images from external CCD camera, VTR, PC or other devices on VT3 screen, or to project screens currently displayed on the VT3 on the RGB monitor.



1ch Video Input Unit VT3-VD1



Name	Function
Video input connector	Used for connecting to devices having an NTSC composite video signal output
RGB input connector	Used for connecting to devices having an analog RGB output
Console output connector	Used for connecting to the CV Series made by Keyence Corporation
Video capture trigger	Used for saving image data that is input to video input connector or RGB input connector to Memory Card. When the video capture output destination is set to the printer, output is from a PictBridge-compatible printer.

RGB Output Unit VT3-R1



 Name
 Function

 RGB output connector
 Used for connecting to devices having an analog RGB input.

Specifications

• 4-channel/1-channel Video Input Unit VT3-VD4/VD1 Specifications General Specifications

Item	VT	3-VD4		VT3-VD1	
Rated voltage					
Current consumption	1080	mA max.	470 mA max.		
Noise resistance	1500 Vp-p p	oulse width 1µse	ec (by commo	on mode noise simulator)	
Withstand voltage	1500 VA0	C for 1 minute (a	across power	terminal and housing)	
Insulating resistance	5 MΩ or more b	by 500 VDC me	gger (across	power terminal and housing)	
Vibrating resistance	Intermittent Vi	bration		Compliant with JIS B3502	
	Frequency	Acceleration	Amplitude	IEC61131-2	
	5 to 9 Hz	-	3.5 mm		
	9 to 150 Hz	9.8 m/s ²	-	Number of sweeps: 10	
	Continuous Vil	oration	times each on X-, Y-		
	Frequency	Acceleration	Amplitude	and Z-axes	
	5 to 9 Hz	-	1.75 mm	(for 100 mins.)	
	9 to 150 Hz	4.9 m/s ²	—		
Operating atmosphere	Mus	st be free from s	evere dust a	nd corrosive gas	
Operating surrounding air temperature*1			0 to +50°C		
Operating surrounding air humidity	35 to 85%RH (condensation not allowed)				
Storage ambient tempera- ture	-10 to +60°C (icing not allowed)				
Storage ambient humidity	35 to 85%RH (condensation not allowed)				
Weight	Appro	Approx. 230 g Approx. 160 g			

*1 Prevent the operating ambient temperature of the VT3 from being exceeded.

Performance Specifications

Video input

Item	VT3-VD4	VT3-VD1		
Display colors	Color: 260000 colors, Black-and-white: 256 tones			
Signal method	NTSC composite video signal			
Display size 640 x 480, 480 x 360, 320 x 240, 160 x 120				
(W x H dots)	600 x 480, 500 x 400, 400 x 320, 300 x 240			
Number of input channels	4	1		

RGB input

Item	VT3-VD4					
Display colors	Color: 260000 colors					
Signal method	Analog RGB					
Horizontal synchronizing frequency	VGA: 31.4 to 43.3 kHz SVGA: 35.1 to 46.9 kHz XGA: 48.4 kHz					
Vertical synchronizing frequency	VGA: 59.0 to 85.1 Hz SVGA: 56.0 to 75.0 Hz XGA: 60.0 Hz					
Display size (W x H dots)	VGA: 640 x 480, 480 x 360, 320 x 240, 160 x 120 SVGA: 800 x 600, 600 x 450, 400 x 300, 200 x 150 XGA: 1024 x 768, 768 x 576, 512 x 384, 256 x 192					
Number of input channels	1					

Pin No.	Signal name	Pin No.	Signal name	Pin No.	Signal name
1	R	6	R_GND	11	NC
2	G	7	G_GND	12	NC
3	В	8	B_GND	13	H_SYNC
4	NC	9	NC	14	V_SYNC
5	GND	10	GND	15	NC



D-sub 15-pin connector * External view from VT3-VD4

• Video capture trigger

Pin assignments (RGB input)



- Set TRIG input to ON for at least 10 msec. The VT3 captures the displayed video image in up to 500 msec after the trigger input.
- It takes about 20 seconds for each channel to write the captured video image to the Memory Card.
- When triggers are input sequentially, the second trigger is stored in the buffer area and suspended until the first captured image is written to the Memory Card. Once the data is written, the suspended trigger input becomes valid.
 While a trigger is stored in the buffer area, the subsequent triggers are invalid.
- If the location to which the captured video image is sent is set to "Printer", the time it takes for printing depends on the printer.

Note: Even when the next trigger is input while a captured video image is being processed, the video image that will be displayed is the one that was being processed when the trigger was input.

Item	Specifications
Wire gage	AWG28-16
Wire strip length	5.5 mm
Wire type	Stranded wire
Rated temperature of wire	60°C
Tightening torque	0.3 Nm {3.1kgf•cm}
Wire material	Copper

Terminal block specification

• RGB Output Unit VT3-R1 Specifications General Specifications

Item		VT3-R1					
Rated voltage	5 VDC±5%						
Current consumption		8	30mA max.				
Noise resistance	1500 Vp-p	oulse width 1µse	ec (by commor	n mode noise simulator)			
Withstand voltage	1500 VA	C for 1 minute (a	across power t	erminal and housing)			
Insulating resistance	5 MΩ or more b	by 500 VDC me	gger (across p	ower terminal and housing)			
Vibrating resistance	Intermittent V	ibration		Compliant with JIS B3502			
	Frequency	Acceleration	Amplitude	IEC61131-2			
	5 to 9 Hz	—	3.5 mm				
	9 to 150 Hz	9.8 m/s ²	—	Number of sweeps: 10			
	Continuous Vi	bration		times each on X-, Y-			
	Frequency	Acceleration	Amplitude	and Z-axes			
	5 to 9 Hz	-	1.75 mm	(for 100 mins.)			
	9 to 150 Hz	4.9 m/s ²	—				
Operating atmosphere	Mu	st be free from s	severe dust an	d corrosive gas			
Operating surrounding air temperature*1		I	0 to +50°C				
Operating surrounding air humidity	35 to 85%RH (condensation not allowed)						
Storage ambient tempera- ture	-10 to +60°C (icing not allowed)						
Storage ambient humidity	35 to 85%RH (condensation not allowed)						
Weight		A	pprox. 150 g				

*1 Prevent the operating ambient temperature of the VT3 from being exceeded.

Performance Specifications

Item	VT3-R1					
Signal method	Analog RGB					
Horizontal synchronizing frequency	VGA: 31.5 kHz XGA: 48 kHz	SVGA: 37.9 kHz				
Vertical synchronizing frequency	VGA: 59.9 Hz XGA: 59.9 Hz	SVGA: 60.3 Hz				
Display size (W x H dots)	VGA: 640 x 480 XGA: 1024 x 768	SVGA: 800 x 600				
Number of output channels		1				

Pin assignments

Pin No.	Signal name	Pin No.	Signal name	Pin No.	Signal name
1	R	6	R_GND	11	NC
2	G	7	G_GND	12	NC
3	В	8	B_GND	13	H_SYNC
4	NC	9	NC	14	V_SYNC
5	GND	10	GND	15	NC



* External view from VT3-R1

Ethernet Unit/Printer Unit

Various VT3/VT2 data can be printed using the Ethernet Unit or Printer Unit. Alternately, VT3/VT2 can be used via Ethernet by the Ethernet Unit.



*1 VT2-E1/E2, VT3-E3 only *2 VT2-E1/P1 only *3 VT2-E2/P2 only

- *4 This indicator is not available on VT3-E3 units that have a serial number ending in A or a later letter (A, B, C, etc.).
 - Note: When the Ethernet Unit is connected and turned ON for the first time, the message "Invalid IP setup. Please touch the display." is displayed. Touch the screen, and make the Ethernet Setup in "Option Setup" in the System mode.

After making the Ethernet settings, move to the Data Transmission mode. VT3 Series Hardware Manual "Data Transmission" page 5-33

- Do not use the printer I/F (USB) at sites subject to strong vibration or impact. The USB connector does not have a lock function, and so the cable may fall off or a communications error may occur.
- Do not connect the personal computer to the VT2-E2/P2 by the USB cable.
- VT3-E3 with "A" or a following letter as the last letter of the serial number requires that the VT3 system program be Ver. 4.51 or later.
- VT3-E3 with "A" or a following letter as the last letter of the serial number supports MDI/MDI-X automatic switching function.

Specifications

• Ethernet Unit VT2-E1/E2, VT3-E3 / Printer Unit VT2-P1/P2 Specifications General Specifications

Item	VT2-E1	VT2-P1	VT2-E2	VT2-P2	VT3-E3		
Rated voltage		5 VDC±5%					
Current consumption	200m/	200mA max. 400mA n			200mA max.		
Noise resistance	1500 Vp-p	pulse width 1	usec (by comm	on mode noise	simulator)		
Withstand voltage	1500 V	AC for 1 minute	(across power	terminal and h	nousing)		
Insulating resistance	5 MΩ or mo	ore by 500 VDC r	negger (across p	ower terminal a	nd housing)		
Vibrating resistance	Intermittent	Vibration			with JIS B3502		
	Frequency	Acceleration	Half amplitu	de IEC61131-	2		
	5 to 9 Hz	—	3.5 mm				
	9 to 150 Hz	9.8 m/s ²	—	Number of	Number of sweeps: 10		
	Continuous V	/ibration		times each on X-, Y-			
	Frequency	Acceleration	Half amplitu				
	5 to 9 Hz	—	1.75 mm	(for 100 m	ins.)		
	9 to 150 Hz	4.9 m/s ²	—				
Operating atmosphere	M	lust be free fron	n severe dust a	nd corrosive g	as		
Operating surrounding air temperature*			0 to +50°C				
Operating surrounding air humidity	35 to 85%RH (condensation not allowed)						
Storage ambient temperature	-10 to +60°C (icing not allowed)						
Storage ambient humidity		35 to 85%RH (condensation not allowed)					
Weight	Approx. 135 g	Approx. 125 g	Approx. 150 g	Approx. 140 g	Approx. 130 g		

 Prevent the operating surrounding air temperature of the VT3/VT2 from being exceeded.

Performance Specifications

Printer output (VT2-E1/P1)

Item	Printer type	VT2-E1/P1
Color printer	ESC/P raster 2	Made by EPSON SALES JAPAN CORPORATION
		PM-930C/940C/870C PM-3700C/4000PX
	ESC/P raster	Made by EPSON SALES JAPAN CORPORATION
		PM-950C/890C/840C/830C/740C/730C PM-3500C/2200C
	LIPS IV raster	Made by CANON Inc.
		LIPS IV-compatible Color/black-and-white laser printer
Thermal printer	Thermal printer	Made by CITIZEN SYSTEMS Corporation CBM-293, CT-P293

Pin assignment (printer output)

Pin No.	Signal name	Pin No.	Signal name	Pin No.	Signal name
1	nStrobe	10	NC	19	GND
2	Data1	11	Busy	20	GND
3	Data2	12	NC	21	GND
4	Data3	13	NC	22	GND
5	Data4	14	NC	23	GND
6	Data5	15	NC	24	GND
7	Data6	16	NC	25	GND
8	Data7	17	NC		
9	Data8	18	GND		-



D-sub 25-pin connector * External view from VT2-E1/P1

Printer output (VT2-E2/P2)

Item	Printer type	VT2-E2/P2
PictBridge-	PictBridge	Made by EPSON SALES JAPAN CORPORATION
compatible		PM-A650/A700/A750/A850/A870/A890/A900/A950/
printer		PM-D600/D750/D770/D800/D1000
		Made by CANON Inc.
		PIXUS 80i/455i/560i/860i/960i/990i/iP90/iP3100/iP8600

Ethernet

Item	VT2-E1/E2, VT3-E3				
	10BASE-T	100BASE-TX			
Compliant standard	IEEE802.3				
Baud rate	10 Mbit/s	100 Mbit/s			
Transmission medium*1	STP or UTP of Category 3 or higher	STP or UTP of Category 5 or higher			
Max. cable length	10	0 m			
Max. number of	4	2			
hub connections					
Max. number of	PC application*2: 3				
connections	FTP: 4				

- *1 STP: Shielded Twisted Pair cable, UTP: Unshielded Twisted Pair cable
- *2 "PC application" refers to VT STUDIO or DATA BUILDER.

Pin assignment (Ethernet)

Pin No.	MDI signal name	Function
1	TD+	Send data (+)
2	TD-	Send data (-)
3	RD+	Receive data (+)
4	-	—
5	-	—
6	RD-	Receive data (-)
7	_	_
8	I	—



RJ-45 modular connector * External view from VT2-E1/E2 and VT3-E3

Printer output (VT2-E1/E2, VT3-E3)

Item	Printer type	VT2-E1/E2, VT3-E3 Ethernet connection
Color printer	ESC/P-R	Seiko Epson
	Ethernet	ESC/P-R and ESC/Page compatible
	ESC/Page Ethernet	color/monochrome printers

* Can only be used on the VT3 Series and printer connected to the Ethernet. The VT3 System Program must be in Ver. 4.81 or above.

Attaching the Video Unit/Ethernet unit/Printer Unit

Video Unit (VT3-VD4/VD1/R1)

The following example shows how to attach the VT3-VD1 on the VT3.

Before attaching extension units on the VT3, be sure to turn the VT3 OFF. Also, make sure that screws are firmly secured before using the VT3 again.

1 Remove the seal of extension connector 2 on the rear of the VT3.



2 Align the Video Unit with the VT3 as shown in the figure below, and gently insert the Video Unit vertically into the VT3 while confirming the position of extension connector 2.



3 Secure the Video Unit onto the VT3 using four screws.



Ethernet Unit (VT2-E1/E2, VT3-E3)/Printer Unit (VT2-P1/P2)

The following example shows how to attach the VT2-E1 on the VT3.

CAUTION

Before attaching extension units on the VT3, be sure to turn the VT3 OFF. Also, make sure that screws are firmly secured before using the VT3 again.

1 Remove the seal of extension connector 1 on the rear of the VT3.



2 Align the Ethernet Unit with the VT3 as shown in the figure below, and gently insert the Ethernet Unit vertically into the VT3 while confirming the position of extension connector 1.



3 Secure the Ethernet Unit onto the VT3 using four screws.



Tightening Torque	
0.4 Nm {4 kgf•cm}	

External Dimensions of the Extension Units



VT2-E1/P1



■ VT2-E2/P2, VT3-E3





VT3 body mounting position



Model	X15(D)	S12(D)	S10/V10(D)	V8	V7	Q5T(W)/ Q5T(W)A/ Q5S(W)	Q5M(W)/ Q5M(W)A
Α	10.5	29.0	18.5	9.0	_	_	_
В	182.5	108.5	107.5	67.0	-	-	-
С	52.0	21.5	20.5	17.5	-	-	-
D	22.5	41.0	30.5	21.0	19.0	7.0	-
Е	182.5	108.5	107.5	67.0	67.0	39.0	-
F	143.0	90.5	84.0	18.0	19.0	48.5	—

(Unit: mm)

VT2 body mounting position



Model	12F	10F/10T	10S	8T	7S	5T/5S	5M
Α	41.5	30.5	30.5	21.0	19.0	7.0	—
В	108.5	107.5	107.5	67.0	67.0	39.0	-
С	92.5	83.5	83.5	18.0	19.0	48.5	_

(Unit: mm)

MEMO

WARRANTIES AND DISCLAIMERS

- (1) KEYENCE warrants the Products to be free of defects in materials and workmanship for a period of one (1) year from the date of shipment. If any models or samples were shown to Buyer, such models or samples were used merely to illustrate the general type and quality of the Products and not to represent that the Products would necessarily conform to said models or samples. Any Products found to be defective must be shipped to KEYENCE with all shipping costs paid by Buyer or offered to KEYENCE for inspection and examination. Upon examination by KEYENCE, KEYENCE, at its sole option, will refund the purchase price of, or repair or replace at no charge any Products found to be defective. This warranty does not apply to any defects resulting from any action of Buyer, including but not limited to improper installation, improper interfacing, improper repair, unauthorized modification, misapplication and mishandling, such as exposure to excessive current, heat, coldness, moisture, vibration or outdoors air. Components which wear are not warranted.
- (2) KEYENCE is pleased to offer suggestions on the use of its various Products. They are only suggestions, and it is Buyer's responsibility to ascertain the fitness of the Products for Buyer's intended use. KEYENCE will not be responsible for any damages that may result from the use of the Products.
- (3) The Products and any samples ("Products/Samples") supplied to Buyer are not to be used internally in humans, for human transportation, as safety devices or fail-safe systems, unless their written specifications state otherwise. Should any Products/Samples be used in such a manner or misused in any way, KEYENCE assumes no responsibility, and additionally Buyer will indemnify KEYENCE and hold KEYENCE harmless from any liability or damage whatsoever arising out of any misuse of the Products/Samples.
- (4) OTHER THAN AS STATED HEREIN. THE PRODUCTS/SAMPLES ARE PROVIDED WITH NO OTHER WARRANTIES WHATSOEVER. ALL EXPRESS. IMPLIED. AND STATUTORY WARRANTIES. INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF PROPRIETARY RIGHTS, ARE EXPRESSLY DISCLAIMED, IN NO EVENT SHALL KEYENCE AND ITS AFFILIATED ENTITIES BE LIABLE TO ANY PERSON OR ENTITY FOR ANY DIRECT. INDIRECT. INCIDENTAL. PUNITIVE. SPECIAL OR CONSEQUENTIAL DAMAGES (INCLUDING, WITHOUT LIMITATION. ANY DAMAGES RESULTING FROM LOSS OF USE. BUSINESS INTERRUPTION. LOSS OF INFORMATION. LOSS OR INACCURACY OF DATA. LOSS OF PROFITS. LOSS OF SAVINGS. THE COST OF PROCUREMENT OF SUBSTITUTED GOODS. SERVICES OR TECHNOLOGIES. OR FOR ANY MATTER ARISING OUT OF OR IN CONNECTION WITH THE USE OR INABILITY TO USE THE PRODUCTS. EVEN IF KEYENCE OR ONE OF ITS AFFILIATED ENTITIES WAS ADVISED OF A POSSIBLE THIRD PARTY'S CLAIM FOR DAMAGES OR ANY OTHER CLAIM AGAINST BUYER. In some jurisdictions, some of the foregoing warranty disclaimers or damage limitations may not apply.

BUYER'S TRANSFER OBLIGATIONS:

If the Products/Samples purchased by Buyer are to be resold or delivered to a third party, Buyer must provide such third party with a copy of this document, all specifications, manuals, catalogs, leaflets and written information provided to Buyer pertaining to the Products/Samples.

KEYENCE CORPORATION

1-3-14, Higashi-Nakajima, Higashi-Yodogawa-ku, Osaka, 533-8555, Japan www.keyence.com PHONE: +81-6-6379-2211

AUSTRIA

Ph: +43 22 36-3782 66-0 BELGIUM Ph: +32 1 528 1222

BRAZIL Ph: +55-11-3045-4011

CANADA Ph: +1-905-366-7655

CHINA Ph: +86-21-3357-1001

CZECH REPUBLIC Ph: +420 222 191 483

FRANCE Ph: +33 1 56 37 78 00

GERMANY Ph: +49 6102 36 89-0

HONG KONG Ph: +852-3104-1010

HUNGARY Ph: +36 1 802 73 60

INDIA Ph: +91-44-4963-0900

INDONESIA

Ph: +62-21-2966-0120 ITALY Ph: +39-02-6688220

KOREA Ph: +82-31-789-4300

MALAYSIA Ph: +60-3-7883-2211

MEXICO Ph: +52-55-8850-0100

NETHERLANDS Ph: +31 40 20 66 100

POLAND Ph: +48 71 36861 60

ROMANIA Ph: +40 269-232-808

SINGAPORE Ph: +65-6392-1011

SLOVAKIA Ph: +421 2 5939 6461

SLOVENIA

Ph: +386 1-4701-666

A7WW1-MAN-1115

Copyright (c) 2015 KEYENCE CORPORATION, All rights reserved.

Specifications are subject to change without notice.

13792E 1125-1 96M13792 Printed in Japan

SWITZERLAND

Ph: +41 43-45577 30 TAIWAN Ph: +886-2-2718-8700

THAILAND Ph: +66-2-369-2777

UK & IRELAND Ph: +44-1908-696900

USA

Ph: +1-201-930-0100

VIETNAM Ph: +84-4-3772-5555

