



VICPAS[®]



2025 Brochure

Robot Handle Repair

Table of Contents

1 ABB Teach Pendant

ABB Robot IRC5 Teach Pendant Repair Kit.....	6
ABB Robot SxTPU Teach Pendant Repair Kit.....	7
ABB S4, S4+ Teach Pendant Repair Kit.....	8
ABB TPU1 Teach Pendant Repair Kit	9
ABB DSQC3060 FlexPendant Repair Kit.....	10
ABB SxTPU4 DSQC3120 Teach Pendant Repair Kit.....	11
ABB DSQC3124 Teach Pendant Repair Kit	12

2 Fanuc Teach Pendant

Fanuc Type A Teach Pendant Repair Kit	13
Fanuc Type B Teach Pendant Repair Kit.....	14
Fanuc Type C Teach Pendant Repair Kit	15

Fanuc Type D Teach Pendant Repair Kit	16
---	----

3 KAWASAKI Teach Pendant

KAWASAKI Type A Teach Pendant Repair Kit.....	17
---	----

KAWASAKI Type B Teach Pendant Repair Kit	18
--	----

4 KUKA Teach Pendant

KUKA KRC1 Teach Pendant Repair Kit.....	19
---	----

KUKA KRC2 Teach Pendant Repair Kit.....	20
---	----

KUKA KRC4 Teach Pendant Repair Kit.....	21
---	----

KUKA KRC5 Teach Pendant Repair Kit.....	22
---	----

5 Panasonic Teach Pendant

Panasonic G2 Teach Pendant Repair Kit	23
---	----

Panasonic G3 Teach Pendant Repair Kit	24
---	----

6 Yaskawa Teach Pendant

Yaskawa DX100 Teach Pendant Repair Kit	25
--	----

Yaskawa DX200 Teach Pendant Repair Kit	26
--	----

Yaskawa Motoman XRC Teach Pendant Repair Kit	27
--	----

Yaskawa NX100 Teach Pendant Repair Kit	28
--	----

Yaskawa NX100 Teach Pendant Repair Kit	29
--	----

Yaskawa Yasnac MRC Teach Pendant Repair Kit.....	30
--	----

Yaskawa YRC1000 Teach Pendant Repair Kit.....	31
---	----

7 Other Brands Robotic Teach Pendant

ASIC Robotics Switch Hand Control Repair Kit.....	32
---	----

Indramat BTC06 Manual Control Unit Repair Kit.....	33
--	----

KEBA KeTop 070 Mobile Terminal Repair Kit	34
NACHI OTC CFDTP-10-04M Teach Pendant Repair Kit	35
NIKKI DENSO TP-RC7M-1 Teach Pendant Repair Kit	36

ABB Robot IRC5 Teach Pendant Repair Kit

- | | | | | |
|------------------------------|-----------------------|--------------------|------------------|----------------------|
| 1.LCD Display | 5.Front Case | 10.Screws | 15.Touch Pens | 20.Mainboard Bracket |
| 2.Membrane Keypad | 6.Screen Gasket | 11.Touchpen Cover | 16.E-Stop Button | 21.Display Bracket |
| 3.PET Screen Protector | 7.USB Cover | 12.Connector Cover | 17.Back Cover | 22.Joystick |
| 4.Touch Screen | 8.USB Port | 13.Case Gasket | 18.Enable Switch | 23.10m/15m/30m Cable |
| 24.Joystick Connection Cable | 9.Enable Switch Cover | 14.Hand Strap | 19.Main Board | |



ABB Robot SxTPU Teach Pendant Repair Kit

- | | | | |
|----------------|-------------------|------------------------------|-------------------------|
| 1.LCD Display | 5.Membrane Keypad | 10.Enable Switch Cover | 15.Touchscreen Bracket |
| 2.Touch Screen | 6.Joystick | 11.Cable | 16.PET Screen Protector |
| 3.Screws | 7.Back Cover | 12.E-Stop Button Cover | 17.Main Board |
| 4.Front Case | 8.Hand Strap | 13.E-Stop Button | 18.LCD Display Bracket |
| | 9.Connector Cover | 14.Joystick Connection Cable | 19.E-Stop Contact |



ABB S4, S4+ Teach Pendant Repair Kit

- 1.Front Case
- 2.Protection Panel
- 3.Membrane Keypad

- 4.Metal Part
- 5.Back Cover
- 6.LCD Display

- 7.Hand Strap
- 8.Joystick
- 9.E-Stop Button

- 10.E-Stop Button Label
- 11.Cable



ABB TPU1 Teach Pendant Repair Kit

- 1.Front Cover
- 2.Membrane Keypad
- 3.LED Lights Layer

- 4.Back Cover
- 5.LCD Display
- 6.Joystick

- 7.Cable




ABB DSQC3060 FlexPendant Repair Kit

1.Touch Screen
2.E-Stop Button
3.E-Stop Button Label
4.Front Cover
22.PET Screen Protector

5.Back Cover
6.Fasten Strip
7.Membrane Keypad
8.Screws

9.USB Cover
10.USB Port
11.Joystick Guard
12.Joystick

13.Power Cable Cover
14.Main Board
15.Enabling Device Cover
16.Enabling Controller Switch
17.LCD Display

18.LCD Bracket
19.Silicone Gasket
20.Cable
21.Enable Switch
Accessories




ABB SxTPU4 DSQC3120 Teach Pendant Repair Kit

1.Touch Screen
2.E-Stop Button
3.E-Stop Button Label
4.Front Cover
22.PET Screen Protector

5.Back Cover
6.Fasten Strip
7.Membrane Keypad
8.Screws

9.USB Cover
10.USB Port
11.Joystick Guard
12.Joystick

13.Power Cable Cover
14.Main Board
15.Enabling Device Cover
16.Enabling Controller Switch
17.LCD Display

18.LCD Bracket
19.Silicone Gasket
20.Cable
21.Enable Switch
Accessories




ABB DSQC3124 Teach Pendant Repair Kit


1.Touch Screen
2.E-Stop Button
3.E-Stop Button Label
4.Front Cover
22.PET Screen Protector

5.Back Cover
6.Fasten Strip
7.Membrane Keypad
8.Screws

9.USB Cover
10.USB Port
11.Joystick Guard
12.Joystick

13.Power Cable Cover
14.Main Board
15.Enabling Device Cover
16.Enabling Controller Switch
17.LCD Display

18.LCD Bracket
19.Silicone Gasket
20.Cable
21.Enable Switch
Accessories



Fanuc Type A Teach Pendant Repair Kit

- 1.Touch Screen
- 2.LCD Display
- 3.Hand Strap
- 4.Front Cover
- 5.Case Gasket

- 6.Protective Film
- 7.Screws
- 8.E-Stop Button Label
- 9.USB Cover

- 10.Enabling Derive Cover
- 11.Back Cover
- 12.Enabling Controller Switch
- 13.Cable

- 14.AWE2 Keypad
- 15.GLS1 Keypad
- 16.GNE2 Keypad
- 17.MHE2 Keypad

- 18.SWE2 Keypad
- 19.Key Board
- 20.Main Board
- 21.E-Stop Button
- 22.Mode Select Switch



Fanuc Type B Teach Pendant Repair Kit

- 1.Touch Screen
- 2.LCD Display
- 3.Hand Strap
- 4.Front Cover
- 5.Case Gasket

- 6.Protective Film
- 7.Screws
- 8.E-Stop Button Label
- 9.USB Cover

- 10.Enabling Derive Cover
- 11.Back Cover
- 12.Enabling Controller Switch
- 13.Cable

- 14.AWE2 Keypad
- 15.GLS1 Keypad
- 16.GNE2 Keypad
- 17.MHE2 Keypad

- 18.SLE2 Keypad
- 19.SWE2 Keypad
- 20.Key Board
- 21.Main Board
- 22.E-Stop Button
- 23.Mode Select Switch



Fanuc Type C Teach Pendant Repair Kit


1.Front Cover
2.Anti-Collision Particle
3.Enabling Derive Cover
4.Back Cover
24.PET Screen Protector

5.Case Gasket
6.LCD Display
7.Key Board
8.Hand Strap

9.Enabling Controller Switch
10.E-Stop Button Label
11.Screws
12.E-Stop Button
13.Mode Select Switch

14.Hanger
15.AWE2 Keypad
16.AWE3 Keypad
17.GNE2 Keypad
18.MHE2 Keypad

19.SW1E2 Keypad
20.SW2E2 Keypad
21.Touch Screen
22.Main Board
23.Cable



Fanuc Type D Teach Pendant Repair Kit

1. Protection Panel
2. LCD Display
3. Front Cover
4. LED Function Label
5. E-Stop Button Label

6. Screws
7. Switch Parts
8. Back Cover
9. E-Stop Button
10. Mode Select Switch
11. Anti-Collision Particle

12. Hand Strap
13. Cable
14. AWE1 Keypad
15. AWE2 Keypad

16. GLS1 Keypad
17. GNE2 Keypad
18. MHE1 Keypad
19. PNE1 Keypad
20. SLE2 Keypad

21. MHE2 Keypad
22. SWE2 Keypad
23. SWE3 Keypad
24. Key Board
25. Main Board



KAWASAKI Type A Teach Pendant Repair Kit

1.Hanger

2.Type A Keypad

3.Type B Keypad

4.Front Case

5.Back Cover

6.E-Stop Switch Label

7.Screws

8.Touch Screen

9.Enable Switch Covers

10.LCD Display

11.Key Board

12.Main Board

13.Hand Strap


14.Teach Lock Switch

15.E-Stop Switch

16.Lone Line Enable Switch

17.Short Line Enable Switch

18.PET Screen Protector




KAWASAKI Type B Teach Pendant Repair Kit

- 1.Touch Screen
- 2.Type A Keypad
- 3.Front Case
- 4.Back Cover

- 5.LCD Display
- 6.Enabling Derive Cover
- 7.Anti-Collision Particles
- 8.Screws

- 9.Hanger
- 10.Key Board
- 11.Main Board
- 12.Teach Lock Switch
- 13.E-Stop Switch

- 14.E-Stop Switch Label
- 15.Enable Switch
- 16.Hand Strap
- 17.Type B Keypad
- 18.PET Screen Protector



KUKA KRC1 Teach Pendant Repair Kit

1.Membrane Keypad

2.LCD Display

3.Front Case

4.Back Cover

5.Case Accessories

6.Mode Selector Switch

7.E-Stop Button

8.E-Stop Contact

9.Switch Cover

10.Cable

11.Sticker

12.6D Mouse



KUKA KRC2 Teach Pendant Repair Kit

1.Membrane Keypad

2.LCD Display

3.Front Case

4.Back Cover

5.Case Accessories

6.Mode Selector Switch

7.E-Stop Button

8.E-Stop Contact

9.Switch Cover

10.Cable

11.Sticker

12.6D Mouse



KUKA KRC4 Teach Pendant Repair Kit

- | | | | | |
|---------------------|-------------------------|-------------------------|---------------------------------|-----------------------------|
| 1. Front Case | 5. E-Stop Contact | 9. Disconnecting Button | 13. Touch Screen | 17. Main Board |
| 2. Back Cover | 6. Hand Strap | 10. PTOO Switch Contact | 14. Cable | 18. Conversion Switch Board |
| 3. Protective Cover | 7. 6D Mouse | 11. LCD Display | 15. Touch Pen | 19. PET Screen Protector |
| 4. E-Stop Button | 8. Mode Selector Switch | 12. Membrane Keypad | 16. 2 Enabling Switch Case Kits | 20. Enabling Switch Cover |
| | | | | 21. Start Key Cover |



KUKA KRC5 Teach Pendant Repair Kit

- 1.LCD Display
- 2.Membrane Keypad
- 3.Touch Screen
- 4.E-Stop Button

- 5.E-Stop Contact
- 6.USB Cover
- 7.Disconnecting Button
- 8.PTOO Switch Contact

- 9.Mode Selector Switch
- 10.Front Case
- 11.Back Cover
- 12.Space Mouse

- 13.Hand Strap
- 14.Cable
- 15.Enabling Switch Cover
- 16.Start Key Cover

- 17.PET Screen Protector
- 18.2 Enabling Switch Cases
- 19.Conversion Switch Board
- 20.Main Board




Panasonic G2 Teach Pendant Repair Kit

- 1.Front Case
- 2.Back Cover
- 3.Membrane Keypad

- 4.Mode Select Switch
- 5.E-Stop Switch
- 6.E-Stop Switch Label

- 7.Acrylic Board
- 8.LCD Display
- 9.Encoder

- 10.Dial
- 11.Cable Connector
- 12.Main Board
- 13.Cable



Panasonic G3 Teach Pendant Repair Kit

- 1.Front Case
- 2.Back Cover
- 3.Membrane Keypad

- 4.E-Stop Switch Label
- 5.Mode Select Switch
- 6.Acrylic Board

- 7.LCD Display
- 8.Encoder
- 9.Dial

- 10.E-Stop Switch
- 11.Cable Connector
- 12.Cable
- 13.Main Board



Yaskawa DX100 Teach Pendant Repair Kit

- | | | | | | |
|-------------------------|-------------------|--------------------------|---------------|------------------|-------------------|
| 1.Touch Screen | 6.YKS-005E | 11.Key Buttons | 16.Screws | 21.30 PIN FPC | 26.Enabling |
| 2.LCD Display | 7.YKS-012E | 12.Hanger | 17.Hand Strap | 22.Mode Switch | Controller Switch |
| 3.YKS-000E | 8.Front Case | 13.Case Accessories | 18.Back Cover | 23.Start Button | 27.40 PIN FPC |
| 4.YKS-001E | 9.Silicone Gasket | 14.E-Stop Button Label | 19.USB Cover | 24.Hold Button | 28.Main Board |
| 5.YKS-002E | 10.Screen Gasket | 15.Enabling Device Cover | 20.Key Board | 25.E-Stop Button | 29.Cable |
| 30.PET Screen Protector | | | | | |



Yaskawa DX200 Teach Pendant Repair Kit

1.Touch Screen
2.LCD Display
3.YKS-500E
4.YKS-700E
5.YKS-701E
32.YKS-214E


6.YKS-702E
7.YKS-705E
8.YKS-712E
9.YKS-B
10.Front Case
33.PET Screen Protector

11.Silicone Gasket
12.Screen Gasket
13.Key Buttons
14.Hanger
15.Case Accessories
33.PET Screen Protector

16.E-Stop Button Label
17.Enabling Device Cover
18.Screws
19.Hand Strap
20.Back Cover

21.USB Cover
22.Key Board
23.30 PIN FPC
24.Mode Switch
25.Start Button
26.Hold Button

27.E-Stop Button
28.Enabling Controller Switch
29.40 PIN FPC
30.Main Board
31.Cable



Yaskawa Motoman XRC Teach Pendant Repair Kit

- 1.Front Case
- 2.XKS-000E
- 3.XKS-001E
- 4.XKS-002E

- 5.XKS-005E
- 6.XKS-012E
- 7.XKS-014E
- 8.LCD Display

- 9.E-Stop Button Label
- 10.E-Stop Button
- 11.Screws
- 12.Case Accessory

- 13.Enabling Device Cover
- 14.Hanger
- 15.Hand Strap
- 16.Enabling Controller Switch

- 17.Back Cover
- 18.Key Board
- 19.Main Board
- 20.Cable



Yaskawa NX100 Teach Pendant Repair Kit


- 1.Touch Screen
- 2.LCD Display
- 3.NKS-000E
- 4.NKS-001E
- 5.NKS-002E

- 6.NKS-005E
- 7.NKS-012E
- 8.Front Case
- 9.Hand Strap
- 10.Silicone Gasket

- 11.Screen Gasket
- 12.Key Buttons
- 13.E-Stop Button Label
- 14.Hanger
- 15.Case Accessories


- 16.Enabling Device Cover
- 17.Back Cover
- 18.Main Board
- 19.Key Board
- 20.Enabling Controller Switch
- 27.PET Screen Protector

- 21.Screws
- 22.Mode Switch
- 23.Start Button
- 24.Hold Button
- 25.E-Stop Button
- 26.Cable



Yaskawa NX100 Teach Pendant Repair Kit

- | | | | | |
|-----------------------|-------------------|--------------------------|-------------------------------|-------------------------|
| 1.Front Case | 5.Silicone Gasket | 9.Hanger | 13.Back Cover | 17.Cable |
| 2.Touch Screen | 6.Screen Gasket | 10.Case Accessories | 14.Main Board | 18.Mode Switch |
| 3.Hand Strap | 7.Key Buttons | 11.Enabling Device Cover | 15.Key Board | 19.E-Stop Button |
| 4.E-Stop Button Label | 8.LCD Display | 12.Front Overlay | 16.Enabling Controller Switch | 20.Screws |
| | | | | 21.PET Screen Protector |



Yaskawa Yasnac MRC Teach Pendant Repair Kit

1.LCD Display

2.Membrane Keypad

3.SERVO POWER ON Button

4.E-Stop Button


5.Front Cover

6.Back Case



Yaskawa YRC1000 Teach Pendant Repair Kit

- | | | | | | |
|----------------------|---------------|--------------------------|------------------------|-------------------------------|-----------------------|
| 1.Touch Screen | 5.AKS-002E | 9.Hanger | 13.E-Stop Button Label | 17.Enabling Controller Switch | 21.Start Button |
| 2.Type A LCD Display | 6.AKS-005E | 10.Hand Strap | 14.Back Cover | 18.USB Cover | 22.E-Stop Button |
| 3.AKS-000E | 7.Front Case | 11.Screws | 15.Key Board | 19.SD Cover | 23.Hold Button |
| 4.AKS-001E | 8.Case Gasket | 12.Enabling Device Cover | 16.Main Board | 20.Mode Switch | 24.Cable |
| | | | | 26.PET Screen Protector | 25.Type B LCD Display |



ASIC Robotics Switch Hand Control Repair Kit

1.Acrylic Board



2.Front Cover



3.Back Cover



Indramat BTC06 Manual Control Unit Repair Kit

- 1.Front Cover
- 2.Back Cover
- 3.Membrane Keypad

- 4.Override Switch Label
- 5.Emergency Stop Switch Label
- 6.Case Accessories

- 7.Hanger



KEBA KeTop 070 Mobile Terminal Repair Kit

- | | | | | |
|-----------------|-----------------|----------------------------|--------------------------|-------------------------------|
| 1.Front Case | 5.Type C Keypad | 9.Touch Pen | 13.Hanger | 17.Enabling Controller Switch |
| 2.Back Cover | 6.Type D Keypad | 10.Backside Keypad | 14.USB Cover | 18.E-Stop Button |
| 3.Type A Keypad | 7.Touch Screen | 11.Anti-Collision Particle | 15.Switch Cover | 19.Mode Select Switch |
| 4.Type B Keypad | 8.Bracket | 12.Case Accessories | 16.Enabling Device Cover | 20.Screws |
| | | | | 21.PET Screen Protector |




NACHI OTC CFDTP-10-04M Teach Pendant Repair Kit

- 1.Front Case
- 2.Back Cover
- 3.Cable
- 4.Membrane Keypad

- 5.Front Overlay
- 6.Touch Screen
- 7.E-Stop Button Label
- 8.Silicone Gasket
- 9.LCD Display

- 10.Case Accessories
- 11.JOG Dial
- 12.USB Cover
- 13.Screws
- 14.Enabling Controller Switch

- 15.Enabling Device Cover
- 16.TP Selector Switch
- 17.Emergency Stop Button
- 18.PET Screen Protector
- 19.Main Board



NIKKI DENSO TP-RC7M-1 Teach Pendant Repair Kit

1.Front Cover
2.Back Cover
3.LCD Display

4.Mode Selector Switch Label
5.Emergency Stop Button Label
6.Touch Screen

7.Membrane Keypads
8.Hanger
9.Case Accessory

10.PET Screen Protector



Who is VICPAS

VICPAS is a global supplier of HMI accessories, providing professional one-stop service for automation equipment maintainers and traders.

VICPAS has been engaged in the HMI parts industry for 20 years since 2004, serving more than 5000 industry customers from 130 countries.

VICPAS has more than 80,000 models for customers to choose quickly, 90% of the product model VICPAS has inventory, can meet the maintenance needs of various brands, quickly shipped parts and ensure a reasonable price.

EVERYTHING FOR YOUR HMI RUNNING

Follow VICPAS



@VICPAS Touchscreen



@VICPASTouch



Guangzhou Vicpas Touch Technology Co.,Ltd



<https://www.youtube.com/vicpastouch>

Contact Us


Email: sales@vicpas.com

Call: 0086-13763341328

Whatsapp: 0086-13763341328

Skype: jack90522

VICPAS[®]




VICPAS

HMI Parts Center

www.vicpas.com

HMI&Terminal Parts



Operator Panel Parts



Teach Pendant Parts



Other Accessories



HMI Brands



Touchscreen Brands



Robotic Brands



Why Choose VICPAS

- ⚡ Fast Quote & Quick Service
- 🏠 Over 80000 HMI Parts Stock
- 🛡️ 12 Months VICPAS Warranty
- 💳 Multiple Payment Methods
- ✈️ Urgent Worldwide Shipping
- 📋 Perfect Service Policies

Customize

VICPAS has produced a wide variety of HMI & teach pendant parts to date. Our specialty is to propose the best parts solutions to each customer's needs. And also provide customized services for HMI & teach pendant parts that are hard to find and obsolete products.

Unparalleled Expertise

With over 20 years of HMI & teach pendant parts experience.

Small MOQ

Even if only one piece is needed, it can be customized for production.

Fast Producing

VICPAS has a strong HMI Parts supply chain management system.