

VICPAS®



2025 Brochure

Siemens Replacement

Table of Contents

Siemens C7-613 Repair Kit.....	7
Siemens C7-613 GEA Repair Kit	8
Siemens C7-621 Repair Kit.....	9
Siemens C7-623 Repair Kit.....	10
Siemens C7-626 Repair Kit.....	11
Siemens C7-633 Repair Kit.....	12
Siemens C7-634 Repair Kit.....	13
Siemens C7-635 GEA Repair Kit	14
Siemens C7-635 KEY Repair Kit.....	15
Siemens C7-635 TOUCH Repair Kit	16
Siemens HT2 Repair Kit.....	17
Siemens HT6 Repair Kit.....	18
Siemens HT8 Repair Kit.....	19

Siemens K-TP178 Micro Repair Kit.....	20
Siemens KTP400 Basic color PN Repair Kit	21
Siemens KTP400 Repair Kit.....	22
Siemens KTP400 Basic Mono Repair Kit.....	23
Siemens KTP600 Repair Kit.....	24
Siemens KTP700 Repair Kit.....	25
Siemens KTP900 Repair Kit.....	26
Siemens KTP1000 Repair Kit.....	27
Siemens KTP1200 Repair Kit.....	28
Siemens LOGO! TD Repair Kit	29
Siemens LOGO! TDE Repair Kit	30
Siemens Mobile Panel 170 Repair Kit.....	31
Siemens Mobile Panel 177 Repair Kit.....	32
Siemens Mobile Panel 277-8 IWLAN Repair Kit	33

Siemens Mobile Panel 277-8 IWLAN V2 Repair Kit	34
Siemens MP177-6 Repair Kit	35
Siemens MP270-6 Repair Kit	36
Siemens MP277-8 KEY Repair Kit	37
Siemens MP277-8 TOUCH Repair Kit	38
Siemens MP277-10 Repair Kit	39
Siemens MP277T mono 6 Repair Kit	40
Siemens MP377-12 Repair Kit	41
Siemens MP377-15 Repair Kit	42
Siemens OP3 Repair Kit	43
Siemens OP7 Repair Kit	44
Siemens OP17 Repair Kit	45
Siemens OP73 Repair Kit	46
Siemens OP77 Repair Kit	47

Siemens OP170B Repair Kit.....	48
Siemens OP177 Repair Kit	49
Siemens OP270-6 Repair Kit	50
Siemens OP277-6 Repair Kit	51
Siemens TD17 Repair Kit.....	52
Siemens TD200 Repair Kit.....	53
Siemens TD390 Repair Kit.....	54
Siemens TD400C Repair Kit	55
Siemens TP070 Repair Kit.....	56
Siemens TP170 Repair Kit.....	57
Siemens TP177A/B 6” Repair Kit	58
Siemens TP177B-4 Repair Kit	59
Siemens TP270 6 STN Repair Kit.....	60
Siemens TP277-6 Repair Kit.....	61


Siemens TP700 Repair Kit.....	62
Siemens TP900 Repair Kit.....	63
Siemens TP1200 Repair Kit.....	64
Siemens TP1500 Repair Kit.....	65
Siemens AOP30 Repair Kit.....	66
Siemens Mini Handheld Units Repair Kit.....	67
Siemens 6FC5203-0AD10-0AA0 Repair Kit.....	68
Siemens PLC S7-200 PLC S7-200 SMART Repair Kit.....	69
Siemens PLC S7-300 Repair Kit.....	70
Siemens PLC S7-1200 Repair Kit.....	71
Siemens SINUMERIK Operator Panel Parts.....	72

Siemens C7-613 Repair Kit

1. Front Case
2. LCD Display

3. Power Supply Connector
4. Gasket

5. 7 Mounting Clips
6. Membrane Keypad




Siemens C7-613 GEA Repair Kit

- 1. Front Case
- 2. LCD Display


- 3. Power Supply Connector
- 4. Gasket

- 5. 7 Mounting Clips
- 6. Membrane Keypad



Siemens C7-621 Repair Kit

1. Membrane Keypad



2. Front Case



3. Power Supply Connector



Siemens C7-623 Repair Kit



1. Membrane Keypad
2. Power Supply Connector
3. Gasket
4. Front Case

Siemens C7-626 Repair Kit

1. Membrane Keypad


2. Front Case

3. LCD Display

4. Power Supply Connector

5. Gasket

6. Protection Board



Siemens C7-633 Repair Kit



1. Membrane Keypad

2. Front Case

3. Gasket

4. 4 Mounting Clips

5. Power Supply Connector



Siemens C7-634 Repair Kit


1. Membrane Keypad

2. Front Case

3. Gasket

4. 4 Mounting Clips

5. Power Supply Connector




Siemens C7-635 GEA Repair Kit

- 1. LCD Display
- 2. Protection Board

- 3. 10 Mounting Clips
- 4. Power Supply Connector

- 5. Front Case
- 6. Membrane Keypad
- 7. Gasket





Siemens C7-635 KEY Repair Kit

- 1. LCD Display
- 2. Protection Board

- 3. 10 Mounting Clips
- 4. Power Supply Connector

- 5. Front Case
- 6. Membrane Keypad
- 7. Gasket



Siemens C7-635 TOUCH Repair Kit

- 1. LCD Display
- 2. Touch Screen

- 3. 8 Mounting Clips
- 4. Power Supply Connector

- 5. Front Case
- 6. Membrane Keypad Overlay
- 7. Gasket



Siemens HT2 Repair Kit

- | | | | | |
|--------------------|------------------|----------------------|-------------------|----------------------------|
| 1. Membrane Keypad | 4. Back Cover | 7. Case Accessories | 9. LCD Display | 12. Mode Selector Switch |
| 2. Front Case | 5. EVA Gasket | 8. Standard-Position | 10. Cable | 13. Rotary Override Switch |
| 3. Middle Cover | 6. Rubber Gasket | Halterung Cover | 11. E-Stop Button | 14. Handwheel |
| | | | | 15. Enabling Button |
| | | | | 16. Mainboard |



Siemens HT6 Repair Kit

- 1. Membrane Keypad
- 2. Protection Board
- 3. LCD Display

- 4. Case Accessories
- 5. V.24 Interface Cover
- 6. Agreement Buttons Cover

- 7. Front Case
- 8. Middle Cover
- 9. Back Cover

- 10. Cable



Siemens HT8 Repair Kit

1. Touch Screen
2. LCD Display
3. LCD Bracket
4. Membrane Keypad
5. Front Case

6. Back Cover
7. Case Gasket
8. Rubber Handle
9. Screws
10. Case Accessories

11. Emergency Stop Button Label
12. Handwheel Label
13. Rotary Override Switch Label
14. Touchscreen Gasket
15. Cable

16. Emergency Stop Button
17. Rotary Override Switch
18. Handwheel
19. Enabling Button Covers



Siemens K-TP178 Micro Repair Kit

1. LCD Display
2. Power Supply Connector
3. Membrane Keypad

4. 4 Screws
5. Touch Screen

6. Front Case
7. Back Cover

8. Gasket
9. 4 Mounting Clips
10. Cable




Siemens KTP400 Basic color PN Repair Kit

- 1. LCD Display
- 2. Membrane Keypad
- 3. Touch Screen

- 4. Power Supply Connector
- 5. 4 Screws
- 6. Front Case

- 7. Back Cover
- 8. Gasket
- 9. 5 Mounting Clips




Siemens KTP400 Repair Kit

- 1. LCD Display
- 2. Membrane Keypad
- 3. Touch Screen

- 4. Power Supply Connector
- 5. 4 Screws
- 6. Front Case

- 7. Back Cover
- 8. Gasket
- 9. 4 Mounting Clips




Siemens KTP400 Basic Mono Repair Kit

1. Membrane Keypad
2. LCD Display
3. Touch Screen

4. Power Supply Connector
5. 4 Screws
6. Front Case

7. Back Cover
8. Gasket
9. 5 Mounting Clips




Siemens KTP600 Repair Kit

1. LCD Display
2. Membrane Keypad
3. Touch Screen
4. Power Supply Connector

5. 8 Mounting Clips
6. Front Case
7. Back Cover

8. Case Gasket
9. LCD Gasket
10. Screws




Siemens KTP700 Repair Kit

- 1. LCD Display
- 2. Membrane Keypad
- 3. Touch Screen

- 4. Power Supply Connector
- 5. 7 Screws
- 6. Front Case

- 7. Back Cover
- 8. Gasket
- 9. 7 Mounting Clips

- 10. Cable




Siemens KTP900 Repair Kit

- 1. LCD Display
- 2. Membrane Keypad
- 3. Touch Screen

- 4. Front Case
- 5. Back Cover
- 6. Gasket

- 7. Power Supply Connector
- 8. 10 Mounting Clips




Siemens KTP1000 Repair Kit

1. LCD Display
2. Power Supply Connector
3. Membrane Keypad

4. Protective Film
5. Touch Screen
6. Front Case

7. Back Cover
8. Case Gasket
9. LCD Gasket

10. 12 Mounting Clips
11. Cable



Siemens KTP1200 Repair Kit

- 1. LCD Display
- 2. Protective Film
- 3. Membrane Keypad

- 4. Touch Screen
- 5. 7 Screws
- 6. Front Case

- 7. Back Cover
- 8. Gasket
- 9. Power Supply Connector
- 10. 12 Mounting Clips





Siemens LOGO! TD Repair Kit

- 1. Front Case
- 2. Back Cover

- 3. LCD Display
- 4. Gasket

- 5. Membrane Keypad
- 6. 2 Mounting Clips

- 7. Power Supply Connector
- 8. Cable




Siemens LOGO! TDE Repair Kit

1. LCD Display
2. Main Board
3. Power Supply Connector


4. Membrane Keypad
5. Front Case

6. Back Cover
7. Cable




Siemens Mobile Panel 170 Repair Kit

- | | | | | |
|-----------------------------------|----------------|------------------------|-------------------------|------------------------------------|
| 1. Membrane Keypad | 5. Front Case | 9. Rubber Handle | 13. Cable | 17. Key-Operated Switch Contact |
| 2. Touch Screen | 6. Back Cover | 10. Case Accessories | 14. Stop Button | 18. Key-Operated Switch |
| 3. LCD Display | 7. Label | 11. Screws | 15. Stop Button Contact | 19. Pushbutton With Integrated LED |
| 4. LCD Bracket | 8. Case Gasket | 12. Touchscreen Gasket | 16. Knob | 20. Pushbutton Contact |
| 21. Acknowledgement Button Covers | | | | |



Siemens Mobile Panel 177 Repair Kit

- | | | | | |
|-----------------------------------|----------------|------------------------|-------------------------|------------------------------------|
| 1. Membrane Keypad | 5. Front Case | 9. Rubber Handle | 13. Cable | 17. Key-Operated Switch Contact |
| 2. Touch Screen | 6. Back Cover | 10. Case Accessories | 14. Stop Button | 18. Key-Operated Switch |
| 3. LCD Display | 7. Label | 11. Screws | 15. Stop Button Contact | 19. Pushbutton With Integrated LED |
| 4. LCD Bracket | 8. Case Gasket | 12. Touchscreen Gasket | 16. Knob | 20. Pushbutton Contact |
| 21. Acknowledgement Button Covers | | | | |



Siemens Mobile Panel 277-8 IWLAN Repair Kit

- | | | | |
|--------------------|-----------------------|--|-------------------------------------|
| 1. Touch Screen | 7. Rubber Handle | 12. Covers for the Labeling Strip Guides | 17. Key-Operated Switch |
| 2. LCD Display | 8. Touchscreen Gasket | 13. Optional Cover | 18. Handwheel |
| 3. Membrane Keypad | 9. Screws | 14. Label | 19. Enabling Button Covers |
| 4. Cable | 10. Case Accessories | 15. Emergency Stop Button | 20. Illuminated Pushbutton Contacts |
| 5. Front Case | 11. STOP Button Label | 16. Key-Operated Switch Contact | 21. Illuminated Pushbuttons |
| 6. Back Cover | | | |



Siemens Mobile Panel 277-8 IWLAN V2 Repair Kit

- | | | | |
|--------------------|-----------------------|--|-------------------------------------|
| 1. Touch Screen | 7. Rubber Handle | 12. Covers for the Labeling Strip Guides | 17. Key-Operated Switch |
| 2. LCD Display | 8. Touchscreen Gasket | 13. Optional Cover | 18. Handwheel |
| 3. Membrane Keypad | 9. Screws | 14. Label | 19. Enabling Button Covers |
| 4. Cable | 10. Case Accessories | 15. Emergency Stop Button | 20. Illuminated Pushbutton Contacts |
| 5. Front Case | 11. STOP Button Label | 16. Key-Operated Switch Contact | 21. Illuminated Pushbuttons |
| 6. Back Cover | | | |





Siemens MP177-6 Repair Kit

1. Protective Film
2. Touch Screen
3. LCD Display

4. Power Supply Connector
5. 4 Mounting Clips
6. Front Case

7. Back Cover
8. Case Gasket
9. LCD Gasket

10. 4 Screws
11. Cable




Siemens MP270-6 Repair Kit

- 1. Protective Film
- 2. Touch Screen
- 3. LCD Display

- 4. Power Supply Connector
- 5. 4 Mounting Clips
- 6. Front Case

- 7. Back Cover
- 8. Case Gasket
- 9. LCD Gasket

- 10. 4 Screws
- 11. Cable




Siemens MP277-8 KEY Repair Kit

1. LCD Display
2. Membrane Keypad
3. Protection Board

4. Power Supply Connector
5. Front Case
6. Back Cover

7. Case Gasket
8. 14 Mounting Clips
9. Cable




Siemens MP277-8 TOUCH Repair Kit

- 1. LCD Display
- 2. Protective Film
- 3. Touch Screen

- 4. Front Case
- 5. Back Cover

- 6. Power Supply Connector
- 7. Case Gasket
- 8. LCD Gasket

- 9. 10 Mounting Clips
- 10. Cable



Siemens MP277-10 Repair Kit

- 1. LCD Display
- 2. LCD FPC
- 3. 12 Mounting Clips

- 4. Power Supply Connector
- 5. Touch Screen
- 6. Front Case

- 7. Protective Film
- 8. Case Gasket

- 9. LCD Gasket
- 10. Cable




Siemens MP277T mono 6 Repair Kit

- 1. LCD Display
- 2. Protective Film

- 3. Touch Screen
- 4. Front Case
- 5. 10 Mounting Clips

- 6. Power Supply Connector
- 7. Case Gasket
- 8. Cable





Siemens MP377-12 Repair Kit

1. LCD Display
2. Touch Screen
3. Power Supply Connector

4. 12 Mounting Clips
5. Front Case
6. Protective Film

7. Case Gasket
8. LCD Gasket
9. Cable



Siemens MP377-15 Repair Kit

1. LCD Display
2. Touch Screen
3. Power Supply Connector

4. 14 Mounting Clips
5. Front Case
6. Protective Film

7. Case Gasket
8. Cable





Siemens OP3 Repair Kit

1.3 Screws
2.Gasket

3.Membrane Keypad
4.Front Case

5.Back Cover
6.Cable




Siemens OP7 Repair Kit

- 1. Front Case
- 2. Back Cover

- 3. Membrane Keypad
- 4. Power Supply Connector

- 5. Gasket
- 6. 4 Mounting Clips

- 7. Cable






Siemens OP17 Repair Kit

1. Front Case
2. Back Cover

3. Membrane Keypad
4. Power Supply Connector

5. Gasket
6. 5 Mounting Clips

7. Cable




Siemens OP73 Repair Kit

- 1. Membrane Keypad
- 2. Gasket
- 3. LCD Display

- 4. 4 Screws
- 5. Power Supply Connector
- 6. Front Case

- 7. Back Cover
- 8. 2 Mounting Clips
- 9. Cable




Siemens OP77 Repair Kit

- 1. Front Case
- 2. Back Cover

- 3. Membrane Keypad
- 4. 4 Screws

- 5. Power Supply Connector
- 6. Gasket

- 7. 4 Mounting Clips
- 8. Cable




Siemens OP170B Repair Kit

- 1. LCD Display
- 2. Membrane Keypad
- 3. Power Supply Connector

- 4. Protection Board
- 5. Front Case
- 6. Back Cover

- 7. Gasket
- 8. 6 Mounting Clips
- 9. 4 Screws

- 10. Cable




Siemens OP177 Repair Kit

- 1. LCD Display
- 2. LCD Bracket
- 3. Front Case

- 4. Back Cover
- 5. Touch Screen
- 6. 12 Mounting Clips

- 7. Power Supply Connector
- 8. Type A Keypad
- 9. Type B Keypad
- 10. Type C Keypad

- 11. Case Gasket
- 12. LCD Gasket
- 13. 4 Screws
- 14. Cable




Siemens OP270-6 Repair Kit

1. Protection Board
2. LCD Display
3. Membrane Keypad

4. Power Supply Connector
5. Front Case
6. Back Cover

7. Gasket
8. 9 Mounting Clips
9. 6 Screws
10. Cable




Siemens OP277-6 Repair Kit

1. Membrane Keypad
2. Protection Board
3. LCD Display

4. 12 Mounting Clips
5. Power Supply Connector
6. Front Case

7. Back Cover
8. Case Gasket
9. LCD Gasket

10. 4 Screws
11. Cable




Siemens TD17 Repair Kit

1. Membrane Keypad
2. Gasket

3. Power Supply Connector
4. 4 Mounting Clips

5. Front Case
6. Back Cover

7. Cable



Siemens TD200 Repair Kit

1. 3 Screws

2. Power Supply Connector

3. Type A Keypad

4. Type B Keypad

5. Type C Keypad


6. Front Case

7. Back Cover

8. Type D Keypad

9. Gasket

10. Cable




Siemens TD390 Repair Kit

1.Front Case
2.Back Cover

3.3 Screws
4.Power Supply Connector

5.Membrane Keypad
6.Gasket

7.Cable



Siemens TD400C Repair Kit

1.Membrane Keypad
2.Front Case

3.Back Cover
4.Power Supply Connector

5.5 Screws
6.Gasket

7.Cable






Siemens TP070 Repair Kit

- 1. Touch Screen
- 2. LCD Display
- 3. LCD Bracket

- 4. 4 Mounting Clips
- 5. Front Case
- 6. Back Cover

- 7. Case Gasket
- 8. LCD Gasket
- 9. 4 Screws

- 10. Power Supply Connector
- 11. Cable






Siemens TP170 Repair Kit

- 1. Touch Screen
- 2. LCD Display
- 3. LCD Bracket

- 4. 4 Mounting Clips
- 5. Front Case
- 6. Back Cover

- 7. Case Gasket
- 8. LCD Gasket
- 9. 4 Screws

- 10. Power Supply Connector
- 11. Cable





Siemens TP177A/B 6" Repair Kit

1. Protective Film
2. Touch Screen
3. LCD Display

4. LCD Bracket
5. Front Case
6. Back Cover

7. Case Gasket
8. LCD Gasket
9. 4 Screws

10. Power Supply Connector
11. 4 Mounting Clips
12. Cable




Siemens TP177B-4 Repair Kit

1. Membrane Keypad
2. Touch Screen
3. LCD Display

4. Front Case
5. Back Cover
6. Gasket

7. 4 Mounting Clips
8. Power Supply Connector

9. 4 Screws
10. Cable




Siemens TP270 6 STN Repair Kit

- 1. Protective Film
- 2. Touch Screen
- 3. LCD Display

- 4. Power Supply Connector
- 5. 4 Mounting Clips
- 6. Front Case

- 7. Back Cover
- 8. Case Gasket
- 9. LCD Gasket

- 10. 4 Screws
- 11. Cable





Siemens TP277-6 Repair Kit

1. Protective Film
2. Touch Screen
3. LCD Display

4. Power Supply Connector
5. 4 Mounting Clips
6. Front Case

7. Back Cover
8. Case Gasket
9. LCD Gasket

10. 4 Screws
11. Cable



Siemens TP700 Repair Kit

- 1. Protective Film
- 2. Touch Screen
- 3. 12 Mounting Clips

- 4. LCD Display
- 5. Front Case
- 6. Back Cover

- 7. Memory Card Cover
- 8. Power Supply Connector
- 9. Gasket

- 10. LCD Bracket
- 11. Cable




Siemens TP900 Repair Kit

- 1. LCD Display
- 2. Protective Film
- 3. Touch Screen

- 4. Front Case
- 5. Back Cover
- 6. Memory Card Cover

- 7. Power Supply Connector
- 8. Gasket
- 9. 16 Mounting Clips
- 10. Cable





Siemens TP1200 Repair Kit

- 1. LCD Display
- 2. Protective Film
- 3. Touch Screen

- 4. Front Case
- 5. Back Cover
- 6. Memory Card Cover

- 7. Power Supply Connector
- 8. Gasket
- 9. 16 Mounting Clips

- 10. Cable



Siemens TP1500 Repair Kit

- 1. LCD Display
- 2. Protective Film
- 3. Touch Screen

- 4. Front Case
- 5. Power Supply Connector
- 6. 12 Mounting Clips

- 7. Gasket
- 8. Cable



Siemens AOP30 Repair Kit

- 1. Front Case
- 2. Back Case
- 3. Membrane Keypad

- 4. LCD Display
- 5. Cable
- 6. Gasket

- 7. 4 Mounting Clips
- 8. Power Supply Connector
- 9. 4 Screws



Siemens Mini Handheld Units Repair Kit

1. Membrane Keypad

2. Cable

3. E-Stop Button

4. Enable Switch

5. Front Case

6. Type A Back Cover

7. Type B Back Cover

8. Type C Back Cover

9. Gasket

10. Screws





Siemens 6FC5203-0AD10-0AA0 Repair Kit


- 1. Plastic Case Cover
- 2. Emergency-Stop Button Cover
- 3. Emergency-Stop Button Base

- 4. Key Button Base
- 5. Key Button Cover
- 6. Transparent Key Button Cover


- 7. Emergency-Stop Button Label
- 8. Spindle Control Switch Label
- 9. Feed Control Switch Label




Siemens PLC S7-200 PLC S7-200 SMART Repair Kit



Siemens PLC S7-300 Repair Kit



Siemens PLC S7-1200 Repair Kit



This image displays a variety of electronic parts and assemblies. At the top left are two black rectangular panels with circular cutouts and mounting holes. To their right is a small black L-shaped bracket. Below these is a large black panel with a grid of square openings. Further right is another large black frame with a central rectangular opening. In the bottom left is a complex assembly featuring a keyboard, a numeric keypad, and several function buttons. To its right are four different types of cooling fans. Below the fans are two white plastic components, one cylindrical and one with three prongs. On the far right are several other components, including a black stand-like structure, a multi-pin connector, a small control unit labeled "MICROMASTER Vector" with safety warnings, and a black metal frame.

Who is VICPAS

VICPAS is a global supplier of HMI accessories, providing professional one-stop service for automation equipment maintainers and traders.

VICPAS has been engaged in the HMI parts industry for 20 years since 2004, serving more than 5000 industry customers from 130 countries.

VICPAS has more than 80,000 models for customers to choose quickly, 90% of the product model VICPAS has inventory, can meet the maintenance needs of various brands, quickly shipped parts and ensure a reasonable price.

EVERYTHING FOR YOUR HMI RUNNING

Follow VICPAS



@VICPAS Touchscreen



@VICPASTouch



Guangzhou Vicpas Touch Technology Co.,Ltd

<https://www.youtube.com/vicpastouch>

Contact Us


Email: sales@vicpas.com

Call: 0086-13763341328

Whatsapp: 0086-13763341328

Skype: jack90522

VICPAS®




VICPAS

HMI Parts Center

www.vicpas.com

HMI&Terminal Parts



Operator Panel Parts



Teach Pendant Parts



Other Accessories



HMI Brands



Touchscreen Brands



Robotic Brands



Why Choose VICPAS

- Fast Quote & Quick Service
- Over 80000 HMI Parts Stock
- 12 Months VICPAS Warranty
- Multiple Payment Methods
- Urgent Worldwide Shipping
- Perfect Service Policies

Customize

VICPAS has produced a wide variety of HMI & teach pendant parts to date. Our specialty is to propose the best parts solutions to each customer's needs. And also provide customized services for HMI & teach pendant parts that are hard to find and obsolete products.

Unparalleled Expertise

With over 20 years of HMI & teach pendant parts experience.

Small MOQ

Even if only one piece is needed, it can be customized for production.

Fast Producing

VICPAS has a strong HMI Parts supply chain management system.