




H14S 中英文爆炸图 (H14S spare parts list) 89400



S/N	Ref. No.	品名	Description
1	09420	弹性垫圈 (3)	washer (3)
2	09361	六角螺母 (3)	Hex nut (3)
3	89413	滚轮 (8)	Roller (8)
4	89419	割刀片 (4)	cutter wheel (4)
5	09020	六角头螺栓 (3)	bolt (3)
6	89423	定位爪 (2)	guide (2)
7	89417	右旋活节螺栓 (2)	right-hand bolt (2)
8	89411	扭簧 (2)	guide spring (2)
9	03032	重型直槽弹性圆柱销8*95 (2)	heavy-duty guide pin (2)
10	89421	进刀螺母 (2)	feeding nut (2)
11	89415	左旋活节螺栓 (2)	left-hand bolt (2)
12	89425	割刀架 (2)	yoke (2)
13	89490	割刀轴总成 (4)	wheel pin complete (4)
14	89491	定位杆总成	yoke pin
15	89492	扳手总成	handle complete

