
CYNDAR®

◆ Appearance size chart

CYNDAR®



(Aluminum Alloy)

◆ Appearance size chart




Right angle frame




Right angle fixing frame







QSN Built-in controller

CCT\CAT built-in controller















配件表 Accessory table

shape	Model	describe	Remarks
Built-in Controller	QCA	Installation of electronic control box with CCT, CAT safety light curtain and passive output can directly connect high-power load	Spare parts
Built-in Controller	QET	Installation of electronic control box with CET,CTT safety light curtain and passive output can directly connect high-power load	Spare parts
Built-in Controller	QCA2	Installation of electronic control box with CCT,CAT safety light curtain and passive output can directly connect high-power load	Spare parts
Built-in Controller	QSN	Installation of electronic control box with CST, CVT safety light curtain and passive output can directly connect high-power load	Spare parts
Built-in Controller	Tner-A31	Installation of electronic control box and CCT, CAT, CET, CTT double output safety light curtain matching use of passive output can directly connect high-power load, provide four groups of passive switching signals	Spare parts
Built-in Controller	LCS-SRA/B	Installation of electronic control box and CCT, CAT, CET, CTT double outpu safety light curtain matching use of passive output can directly connect high-power load, provide four groups of passive switching signals	t Spare parts
External Controller	qsws	Install machine side QSW Dual relay passive output	Spare parts
External Controller	QSWS	Install machine side Q5W Dual relay passive output	Spare parts
Controller holder	QCA-06	For CST external controller mounting bracket	Standard

	QSN543 QA543	Five-pin Φ16 aviation joint with 2.5x3.56m shielded cable transmitting and receiving unit	Standard
	QSN545 QA545	Five-pin Φ16 aviation joint with 5m shielded cable	
5-pin 5-core cable	QSN5410 QA5410	Five-pin Φ16 aviation joint with 10m shielded cable	Spare parts
	QSW543	Five-pin Φ16 aviation joint with 10m shielded cable	Standard
	QSW545	Five-pin Φ16 aviation joint with 10m shielded cable	C
5-pin 5-core cable	QSW5410	Five-pin Φ16 aviation joint with 10m shielded cable	Spare parts
	QVW543	seven-hole Φ16 aviation joint with 3m shielded cable	Standard
	QVW545	seven-hole Ф16 aviation joint with 3m shielded cable	1
7-hole 7-core data cable	QVW5410	seven-hole Ф16 aviation joint with 3m shielded cable	Spare parts
	QC543	Five-pin Φ12 aviation joint with 3m shielded cable Receiver	Standard
	QC545	Five-pin Φ12 aviation joint with 5m shielded cable Receiver	Spare
5-pin 5-core cable	QC5410	Five-pin Φ12 aviation joint with 10m shielded cable Receive	parts
	QC433	Four-hole Ф12 aviation joint with 3m shielded cable	Standard
4-hole 4-core cable	QC435	Four-hole Ф12 aviation joint with 5m shielded cable	Spare
	QC4310	Four-hole Ф12 aviation joint with 10m shielded cable	parts
	QT702	seven-pin Ф16 aviation joint with 2m External controller	Standard
	Q17703	seven-pin Ф16 aviation joint with 3m External controller	Spare
7-pin 7-core data cable	Q T705	seven-pin Ф16 aviation joint with 5m External controller	parts
	Q E702	seven-pin Φ16 aviation joint with 2m External controller	Standard
	Q E703	seven-pin Φ16 aviation joint with 3m External controller	Spare
7-pin 7-core data cable	Q E705	seven-pin Φ16 aviation joint with 5m External controller	narts

CYNDAR®

Accessory table



Right angle frame	QCA-04	For CCT、CATside chute installation	Standard
Side right angle frame	QCA-05	For CCT/CAT/CSTside fixing	Standard
Right angle frame	QLMR-06	For CLT、CMT、CR two-head installation	Standard
Right angle frame	QRFT-07	For CRFTtwo-head installation	Standard
High-strength tubular stent	QSA-07	or CST、CATtubular installation	Spare parts
Side right angle bracket	QSA-08	For CST/CAT/CVT/CTT Side mounting method	Spare parts
Frontal right angle bracket	QSA-09	For CST/CAT/CVT/CTT Frontal mounting method	Spare parts
Reflector	QSA-10	For CST/CAT/CVT/CTT Accessories for 2 or 3-sided reflectors	Spare parts

Note: Standard accessories... Free distribution. Optional accessories... Need to be purchased separately. Standard accessories: QCA-02,QCA-03,QCA-04 Optional one, QS type: QCA-01 is the standard accessory.

