DNT®
Auto Tools

Internal/External Gear Puller Set
DN-D1031

- Small of internal puller 15mm-30mm
- Large of internal puller 30-80mm
- Exernal puller 15-80mm
- Locking the nut to open 3-jaws and clip on the bearing.
- Use the slide hammer to pull out the bearing.

Product Information

DNT Tools @dnttoolsricky YouTube DNT Tools

Dongning Tools(Ningbo) Co.,Ltd
No.6 Falan Rd,Hengjie Town,
Ningbo City,China

Tel:+86 57488298696
Fax:+86 57488296233
Mail:info@nbdntools.com
www.nbdntools.com