## USB drives for XGT Panel

Update: 30-June, 2016

Please find USB drives compatible with XGT Panel (XP/eXP/iXP series).

[USB drives List]

Manufacturer	Part Name	Image
SanDisk ( <u>www.sandisk.com</u> )	CRUZER Force USB Flash Drive 16GB	SanDísk
	Ultra USB 3.0 Flash Drive 32GB	
	Cuzer Blade Flash Drive 32GB	SanDisk
	Cuzer Switch Flash Drive 32GB	SanDisk
	CRUZER FIT USB 3.0 Flash Drive 32GB	CCYYNNXXXXL SOC245 128 GB.
Transcend ( <u>www.transcend-</u> <u>info.com</u> )	Jet Flash710 32GB	Stensond (

Page 1 / 4



	Jet Flash520S 32GB	androsea O	
Kingston ( <u>www.kingston.com)</u>	DTSE9 G2 32GB		
	DTSE9 8GB		
Sony ( <u>www.sony.com</u> )	USB Flash Drive 32GB	SONY	
	USMW series USB Flash Drive 32GB	SONY 32 5	
PNY	FD16GATT4-EF 16GB		

Page 2 / 4



We tested the above but the specifications and characteristics of USB drives are subject to change without notice of manufacturers. And we do not guarantee USB compatibility; this is for your information only.

When the USB drive is not recognized, please check the following.

- 1. Deselect "Reset USB Power"
  - (1) Select [Settings  $\rightarrow$  Environment Setting  $\rightarrow$  Touch Setting] menu in XGT Panel.
  - (2) Deselect 'Reset USB Power' combo box. Initial setting is 'Selected'.

Environment Settings	ок 🗙			
Screen General BK Image Printer				
Hide mouse cursor				
Buzzer On/Off	Buzzer test			
Reset USB power after boot up				
Low Memory Mode				
RS-232C 5V power supply				
Clear SRAM memory and data files				

## 2. Inspect USB drive

A USB drive may be damaged during operation (repeated insertion and removal), resulted in dent, crack, etc. Please inspect the USB contact surface and change other USB drive when you find any damage on it.

## 3. Operation environment


USB Drives are supposed to be used in room temperature/humidity. USB drives do not operate properly and may be broken at high temperature conditions. And corrosion may occur when humidity is high.

And when you have difficulties in finding USB drives in the list, please refer to the below.

Page 3 / 4



1. Select the shielded USB drive to protect electric noise, vibration, shock, etc.



- 2. Check the compatible USB version. XGT Panel supports USB 2.0 or higher.
- 3. USB drives with AutoRun program/file are not recommended.
- 4. Check the file system of USB Drive. (NTFS is not supported.)
  - XP: FAT, FAT32
  - iXP/eXP: FAT, FAT32, exFAT
  - Can you check the file system at 'Properties' of the USB Drive.

🥪 Removable Disk (F:) Properties							
General Tools Ha	rdware Sharing	ReadyBoost	Customize				
<i>~</i>							
Type: Removable Disk							
File system: FAT3	File system: FAT32						
Used space:	7,024,132,09	6 bytes 6.	54 GB				
Free space:	8,976,072,70	4 bytes 8.	35 GB				
Capacity: 16,000,20		0 bytes 14	4.9 GB				
	Drive F:						
OK Cancel Apply							

Page 4 / 4

