STEP 7: GATE NETTING

Before placing the last gate post into the spring of the gate plate, hook the bottom corner of the netting onto the plate.

## STEP 8: GATE MECHANICS

The gate closes by clicking the gate post clips to the fence posts with its plastic clips.

STEP 9: FITTING GUY LINES & PEGS

Place the pre-tied loop over the corner post cap. Pull a loop from the tensioner and anchor it down with a peg. Pull up the tensioner to tighten the line until corner posts are straight.

With the remaning pegs, distribute evenly and drive them between all the posts, pinning the thicken border to the ground.


12 Meters chicken fence

Disclaimer: This product only aim to keep chickens within an enclosured area. It does not keep predators or other animals from getting inside the area. If your flock continues trying to fly out, you may need to consider other measures like wing clipping.

THINGS YOU WILL FIND INSIDE THE POULTRY FENCE KIT

NET   POST   GATE-POST   CAP   x6   GUY LINE   x4

GATE PLATE   x1

PEGS   x16

x1   x6

STEP 1: LAY POULTRY FENCE OUT

Lay the netting out around the coop which it will enclose. The poultry fence can make a 3m square sided perimeter but you are free to make an arrangement to suit your backyard. There is only one entrance so make that the reference point.


COOP

3M

STEP 2: WEAVE GATE POST

Starting from one end of the fence, weave the gate post through the fence netting as per the diagram on the left.

COOP

Once the post has been woven through the netting, clip the thicken border into the clips like the diagram blow.

Start with the top clip and tighten together from the corner.

Repeat again for the clip in the beneath.

STEP 3: FITTING FENCE POSTS

Leaving a gate space of approximately 70cm, start to weave a fence post into the netting. Continue by putting a post in every corner of the perimeter and weave them through. Then weave the remaining posts between all the corner posts with equal spacing 3m.

3m

COOP

70CM

STEP 4: FIT POST CAPS

Place caps onto of posts and slide the netting border into the the caps. Once the netting has been inserted, twist the post cap so that the fence line is straight.

STEP 5: SECURE FENCE NETTING

Pull the thickened netting border over the shorter end of the post spike. Repeat this for all the posts, now the posts and nettng strongly secured to each other.

STEP 6: FITTING GATE PLATE

Put the gate plate on the ground of the desired location and ensure the orientation of the plate runs length wise to the fence direction. Use the fence post and thread the spikes through the holes in the plate. Erect the remaining fence post to create the fenced perimeter, leave space at the end of the netting for the gate post.

It is vital that you try to make taut the fence netting before placing the posts into the ground.

*If the ground is hard, you can water the ground before driving the posts into the ground.